



DP18 Series Model DP18-P8 Process Indicator for Potentiometric Transducers

INSTRUCTION
SHEET

M2116/1294




INSTRUMENT FOR USE WITH POTENTIOMETRIC TRANSDUCERS. THE READING CAN BE MODIFIED IN ENGINEERING UNITS, THEREFORE THE DISPLAY WILL SHOWS THE VALUE DESIRED. THE NECCESARY REGULATED VOLTAGE (5 Vdc) FOR THE TRANSDUCER IS SUPPLIED FROM THE INSTRUMENT (FIG. 3). MAY BE USED POTENTIOMETERS WITH A RESISTANCE VALUE BETWEEN 200Ω MINIMUM AND 10.000Ω MAXIMUM.

SPECIFICATIONS

DISPLAYS	3 ½ digits, 7 segment, red LED
HEIGHT	0.56" (14.2 mm.)
SYMBOLS	± 1.8.8.8
DECIMAL POINTS	Selectable by jumpers
OVERRANGE INDICATION	Display flashes 1999
INPUT CONFIGURATION	Bipolar single
ZERO	Automatic
CONVERTER	Dual-slope, average value
POLARITY	Automatic ±
SIGNAL INTEGRATION PERIOD	80 ms.
READ RATE	3.12 / sec.
HOLD	Optional
NOISE REJECTION NMR	50 dB. 50/60 Hz.
ACCURACY	0.15 % ± 1 count
WARMUP TO RATED ACCURACY ...	2 minutes
SPAN TEMP CO	100 ppm.
ZERO TEMP CO	2.5 μV/°C.
OPERATING TEMPERATURE	0 to 50 °C (32 to 122 °F)
STORAGE TEMPERATURE	-40 to 80 °C (-40 to 176 °F)
WEIGHT	310 gr. (0.68 lb)
CASE MATERIAL	ABS, DIN 43700, black color
STANDARD POWER	115 Vac. ± 10 %, 50/60 Hz.
POWER CONSUMPTION	5.5 VA for AC.
ELECTRICAL CONNECTIONS	Push-in cable connectors
BURN-IN	24 h.
RECALIBRATION	12 months.
EXCITATION OUTPUT	5 Vdc.
-OUTPUT CURRENT	50 mA. max.
-RIPPLE AT 50/60 Hz.	0.2 % max.


FIG. 1 FRONT VIEW



SPAN: ADJUST THE MAXIMUM READING.
OFFSET: ZERO BALANCE


SPAN AND OFFSET ADJUSTMENT ARE ACCESSIBLE BEHIND THE LOW DOOR.

FIG. 2 REAR VIEW



TRANSDUCER WIRING - SPAN AND OFFSET SELECTION

FIG. 3



GROSS SPAN ADJUSTMENT

SPAN AND OFFSET ADJUSTS (S3 SELECTOR)

SPAN RANGE		OFFSET RANGE		OFFSET	
DISPLAY	CLOSE JUMPER	COUNTS	CLOSE JUMPER	+	-
0 to 1.000	K	0 to 500	P	O	M
1.000 to 2.000	---	500 to 1.000	--		
2.000 to 4.000	L	1.000 to 1.999	N		

CLOSE THE APPROPRIATE DECIMAL POINT JUMPER (FIG.5), CORRESPONDING TO THE READING DESIRED. FOR READING 14.50, PLACE THE JUMPER ON THE D2 POSITION.



OPTIONS AND POWER SUPPLIES AVAILABLE FOR DP18 Series


CONTROL OUTPUT/COMMUNICATIONS OPTIONS
Select a maximum of one option from each column

POWER SUPPLY OPTIONS

Table with 4 columns: OPTION, DESCRIPTION, OPTION, DESCRIPTION. Lists options like BCD, R1, R2, APH1, 232 and A01, A02, A03, APH2.


Table with 4 columns: OPTION, POWER, OPTION, POWER. Lists power supply options like 230, STD, 24, 48.

SELECTION OF : DECIMAL POINTS AND SPECIAL OPTIONS



JUMPERS SELECTION FOR SPECIAL OPTIONS

AL: OPEN ONLY WHEN ALARM SETPOINT CARD OPTION IS ADDED
J1: OPEN TO ELIMINATE THE LEAST-SIGNIFICANT DIGIT (LSD)
J2: OPEN TO ELIMINATE THE INDICATION ±




INSTALL THE JUMPER IN THE INDICATED PLACE, ACCORDING TO THE RANGE SELECTED.

DECIMAL POINTS SELECTOR

D3 D2 D1
D3 = 1.XXX
D2 = 1X.XX
D1 = 1XX.X

MECHANICAL DIMENSIONS mm (in)

FIG. 6



WARRANTY/DISCLAIMER

OMEGA warrants this unit to be free of defects in materials and workmanship and to give satisfactory service for a period of 13 months from date of purchase.

OMEGA is pleased to offer suggestions on the use of its various products. However OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products.

LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity;



Servicing USA and Canada: Call OMEGA Toll Free USA Canada

One Omega Drive, Box 4047 Stamford, CT 06907-0047 Telephone: (203) 359-1660 FAX: (203) 359-7700

976 Bergar Laval (Quebec) H7L 5A1 Telephone: (514) 856-6928 FAX: (514) 856-6886

Servicing Europe: One OMEGA Drive, River Bend Technology Centre

Northbank, Irlam, Manchester M44 5EX, England Telephone: 44 (161) 777-6611 FAX: 44 (161) 777-6622

RETURN REQUESTS/INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA ENGINEERING Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT.

FOR WARRANTY RETURNS, please have the following information available BEFORE contacting OMEGA:

- 1. P. O. number under which the product was PURCHASED.
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR NON-WARRANTY REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

- 1. P. O. number to cover the COST of the repair,
2. Model and serial number of product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering. OMEGA is a registered trademark of OMEGA ENGINEERING, INC. © Copyright 1998 OMEGA ENGINEERING, INC. All rights reserved.