


CE



User's Guide



omega.comTM

Ω OMEGA[®]

www.omega.com

e-mail: info@omega.com

PX292 Series Low Differential Pressure Transmitter



OMEGAnet® On-Line Service
www.omega.com

Internet e-mail
info@omega.com

Servicing North America:

USA:
ISO 9001 Certified

One Omega Drive, P.O. Box 4047
Stamford CT 06907-0047
TEL: (203) 359-1660 FAX: (203) 359-7700
e-mail: info@omega.com

Canada:

976 Bergar
Laval (Quebec) H7L 5A1
TEL: (514) 856-6928 FAX: (514) 856-6886
e-mail: info@omega.ca

For immediate technical or application assistance:

USA and Canada: Sales Service: 1-800-826-6342 / 1-800-TC-OMEGA®
Customer Service: 1-800-622-2378 / 1-800-622-BEST®
Engineering Service: 1-800-872-9436 / 1-800-USA-WHEN®
TELEX: 996404 EASYLINK: 62968934 CABLE: OMEGA

Mexico:

Tel: (001) 800-826-6342 FAX: (001) 203-359-7807
En Español: (001) 203-359-7803 e-mail: espanol@omega.com
info@omega.com.mx

Servicing Europe:

Benelux:

Postbus 8034, 1180 LA Amstelveen, The Netherlands
TEL: +31 (0)20 6418405 FAX: +31 (0)20 6434643
Toll Free in Benelux: 0800 0993344
e-mail: nl@omega.com

Czech Republic:

Rudé armády 1868, 733 01 Karviná
TEL: +420 (0)69 6311899 FAX: +420 (0)69 6311114
Toll Free in Czech Rep.: 0800-1-66342 e-mail: czech@omega.com

France:

9, rue Denis Papin, 78190 Trappes
TEL: +33 (0)130 621400 FAX: +33 (0)130 699120
Toll Free in France: 0800-4-06342
e-mail: france@omega.com

Germany/Austria:

Daimlerstrasse 26, D-75392 Deckenpfronn, Germany
TEL: +49 (0)7056 3017 FAX: +49 (0)7056 8540
Toll Free in Germany: 0800 TC-OMEGASM
e-mail: germany@omega.com

United Kingdom:

ISO 9002 Certified

One Omega Drive, River Bend Technology Centre
Northbank, Irlam, Manchester
M44 5EX, United Kingdom
TEL: +44 (0)161 777 6611 FAX: +44 (0)161 777 6622
Toll Free in the United Kingdom: 0800 488 488
e-mail: sales@omega.co.uk

It is the policy of OMEGA to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct, but OMEGA Engineering, Inc. accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

WARNING: These products are not designed for use in, and should not be used for, patient-connected applications.

INSTALLATION OF PRESSURE TRANSMITTERS SERIES PX292

NOTE: *Each transmitter is calibrated in the vertical position. For maximum accuracy, re-zero the transmitter if it is mounted in other than the vertical position. It is not necessary to respan the instrument.*

The Series PX292 differential pressure transmitter is suitable for clean air or inert gas applications. If dust is present, a small in-line filter is recommended to insure long trouble-free operation. The normal operating temperature range is from 0°C to 45°C (32°F to 115°F), and the normal humidity range is from 10% to 90% R.H.

Remove the cover to gain access to the two mounting holes. These holes are suitable for #8 (4mm) max. screws.

Air connections are by means of 3/16" (4.75mm) barbed fittings suitable for ¼" (6mm) O.D. polyethylene tubing, 1/8" (3–4mm) I.D. Tygon or polyurethane tubing.

Pluggable terminal strips, rated at 250Vac, accept wire range of 14 to 26 AWG for electrical connection.

Care should be taken not to exceed the maximum overpressure.

Maximum Safe Momentary Overpressure Table			
Range		Overpressure	
English	Metric	English	Metric
0.1" to 1.0" H ₂ O	25 to 250 Pa	8" H ₂ O	2 kPa
2.0" to 10.0" H ₂ O	0.5 to 2.5 kPa	5 PSID	35 kPa
11" H ₂ O to 5 PSID	2.7 to 35 kPa	20 PSID	140 kPa
6 PSID to 15 PSID	40 to 100 kPa	30 PSID	200 kPa
16 PSID to 30 PSID	110 to 200 kPa	60 PSID	420 kPa

Zero and Span Adjustment

The transmitter may be re-zeroed if overpressure occurs and a permanent drift is noted. Vent both pressure ports to atmosphere before re-zeroing the transmitter.

- A. Voltage Output units (PX292-XXXXD5V): Connect a voltmeter across the signal terminals and adjust the zero potentiometer until the voltage is equal to or less than .015 Volts.
- B. Current Output units (PX292-XXXXDI): Connect an ammeter in the loop and adjust the zero potentiometer (R2) until the ammeter reads 4.00mA.

Should re-spanning of the transmitter become necessary in the field, a manometer or gage of satisfactory accuracy must be used.

- A. Voltage Output units (PX292-XXXXD5V): With the voltmeter connected across the signal terminals (see Figure 1) apply full pressure to the instrument and adjust the Span potentiometer (R1), until the output reading is 5.00V.
- B. Current Output units (PX292-XXXXDI): With the ammeter connected in the loop (see Figure 2), apply full pressure to the instrument and adjust the Span potentiometer (R2), until the output reading is 20.00mA.

Check the zero reading again for accuracy, and repeat the above steps if required.

VOLTAGE OUTPUT UNITS (PX292-XXXD5V)

This transmitter is powered by an external power supply between 11 and 32 Vdc, the current drawn is less than 6mA.

The output voltage is limited to about 5.6V when the applied pressure exceeds the range of the transmitter. Short-circuiting the signal terminals will not damage the transmitter.

Figure 1 shows typical transmitter wiring.




Figure 1

CAUTION: REVERSAL OF THE "Vdc SUPPLY" AND "SIGNAL OUT" MAY RESULT IN PERMANENT DAMAGE TO THE TRANSMITTER.

CURRENT OUTPUT UNITS (PX292-XXXDI)

This is a 2-wire 4-20mA pressure transmitter which requires an external power supply of 11 to 32Vdc to power the loop. The supply voltage should not exceed 32Vdc (see Figure 2)




Figure 2

The following graph (see Figure 3) illustrates the maximum wire and receiver resistances as a function of supply voltage. For example, the total loop resistance should not exceed 650 Ohms for a typical supply voltage of 24Vdc.




Figure 3

The standard transmitter is current-limited to about 3.85mA at the low end and approximately 27mA at the high end. An internal diode protects the transmitter against reverse polarity (there is no current flowing through the loop if the leads are reversed).

WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of 13 months from date of purchase. OMEGA's Warranty adds an additional one (1) month grace period to the normal one (1) year product warranty to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components which wear are not warranted, including but not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by it will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESS OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

RETURN REQUESTS / INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR WARRANTY RETURNS, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR NON-WARRANTY REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of the product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 1999 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.

Where Do I Find Everything I Need for Process Measurement and Control? OMEGA...Of Course!

TEMPERATURE

- ☑ Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- ☑ Wire: Thermocouple, RTD & Thermistor
- ☑ Calibrators & Ice Point References
- ☑ Recorders, Controllers & Process Monitors
- ☑ Infrared Pyrometers

PRESSURE, STRAIN AND FORCE

- ☑ Transducers & Strain Gages
- ☑ Load Cells & Pressure Gages
- ☑ Displacement Transducers
- ☑ Instrumentation & Accessories

FLOW/LEVEL

- ☑ Rotameters, Gas Mass Flowmeters & Flow Computers
- ☑ Air Velocity Indicators
- ☑ Turbine/Paddlewheel Systems
- ☑ Totalizers & Batch Controllers

pH/CONDUCTIVITY

- ☑ pH Electrodes, Testers & Accessories
- ☑ Benchtop/Laboratory Meters
- ☑ Controllers, Calibrators, Simulators & Pumps
- ☑ Industrial pH & Conductivity Equipment

DATA ACQUISITION

- ☑ Data Acquisition & Engineering Software
- ☑ Communications-Based Acquisition Systems
- ☑ Plug-in Cards for Apple, IBM & Compatibles
- ☑ Datalogging Systems
- ☑ Recorders, Printers & Plotters

HEATERS

- ☑ Heating Cable
- ☑ Cartridge & Strip Heaters
- ☑ Immersion & Band Heaters
- ☑ Flexible Heaters
- ☑ Laboratory Heaters

ENVIRONMENTAL MONITORING AND CONTROL

- ☑ Metering & Control Instrumentation
- ☑ Refractometers
- ☑ Pumps & Tubing
- ☑ Air, Soil & Water Monitors
- ☑ Industrial Water & Wastewater Treatment
- ☑ pH, Conductivity & Dissolved Oxygen Instruments