

# TABLE OF CONTENTS

<b>Introduction .....</b>	<b>iv</b>
• Terms used in this Manual .....	iv
• Product Symbols .....	iv
<b>Operator Safety Information .....</b>	<b>v</b>
<b>1.0 GENERAL INFORMATION AND FEATURES .....</b>	<b>1</b>
1.1 INTRODUCTION & SYSTEM OPERATION .....	1
1.1.1 LOGGER MAINFRAME .....	2
1.1.2 MULTIPLEXER .....	3
1.2 LOGGER EXTERIOR FEATURES .....	4
<b>2.0 PREPARATION AND SET-UP .....</b>	<b>6</b>
2.1 UNPACKING .....	6
2.2 QUICK HOOK UP .....	8
2.3 ATTACHING A OM-5200 TO THE WALL .....	8
2.4 CONNECTING TRANSDUCER INPUTS TO MULTIPLEXER .....	9
2.4.1 CONNECTING TRANSDUCERS TO THE TV-10/40 MUX .....	11
2.5 CONNECTING IN THE AC POWER ADAPTER .....	12
2.6 CONNECTING OPTIONAL DC POWER CABLE .....	12
2.7 GROUNDING THE ENCLOSURE .....	13
2.8 PAPER INSTALLATION .....	13
2.9 RS-232 FUNCTIONS .....	14
2.9.1 DATA PORT CONNECTION .....	15

<b>3.0 OPERATION .....</b>	<b>16</b>
3.1 FRONT PANEL .....	16
3.1.1 DISPLAY .....	17
3.1.2 PRINTOUTS .....	17
3.1.2.1 POWER UP .....	17
3.1.2.2 LOGGER CONFIGURATION .....	18
• CONFIGURATION UNITS TABLE .....	18
• CONFIGURATION ALARM TABLE .....	18
3.1.2.3 CHANNEL CONFIG .....	19
• LOG INTERVAL .....	19
• PRINT OPTIONS .....	20
• CHANNELS/DWELL .....	20
• VOLTAGE SCALING .....	20
• TADJUST .....	20
• CHANNEL / ALARMS .....	20
3.1.2.4 NORMAL LOGGING .....	21
3.1.2.5 MANUAL PRINT .....	21
3.2 PROGRAMMING .....	22
3.2.1 KEYPAD INTRODUCTION .....	22
3.2.1.1 THE ALPHA KEY .....	23
3.2.1.2 THE ALT KEY .....	23
3.2.1.3 THE CLEAR KEY .....	24
3.2.2 PROGRAMMING MAINFRAME FUNCTIONS .....	25
3.2.2.1 MAINFRAME PROGRAM STORAGE .....	25
3.2.2.2 TIME .....	25
3.2.2.3 DATE .....	25
3.2.2.4 BAUD RATE .....	26
3.2.2.5 LOG INTERVAL .....	26
3.2.2.6 CHANNEL LOGGING KEYS .....	27
• ACTIVE CHANNEL .....	27
• DWELL .....	27
• HOLD .....	27

3.2.3 PROGRAMMING MULTIPLEXER FUNCTIONS .....	28
3.2.3.1 MUX PROGRAM STORAGE .....	28
3.2.3.2 CHANNEL TYPE KEYS (J,K,T,E,B,S,R,Volts, Pt & SKIP) .....	28
3.2.3.3 VOLTAGE SCALING KEYS.....	29
• VOLTAGE INPUT SCALING .....	29
• MATCHING TRANSDUCERS TO THE LOGGER .....	29
• MATCHING A VOLTAGE TRANSDUCER .....	29
• MATCHING A CURRENT TRANSDUCER .....	30
• DATA SCALING (mX + b calculation) .....	30
• EXAMPLE - VOLTAGE TRANSDUCER .....	31
• EXAMPLE - CURRENT TRANSDUCER.....	33
• PROGRAMMING EXAMPLE .....	34
• DECIMAL POINT .....	34
3.2.3.4 TADJUST (TEMPERATURE ADJUSTMENT) .....	35
3.2.3.5 ALARM KEYS .....	36
• ALARM TABLE .....	36
• HIGH and LOW .....	37
3.2.3.6 UNIT KEYS .....	38
• UNITS TABLES.....	38
• UNITS .....	38
• C/F .....	39
3.3 DATA CACHE FUNCTIONS.....	40
3.3.1 CACHE KEYS.....	41
3.3.1.1 CACHE ERASE KEY .....	41
3.3.1.2 CACHE FWD KEY .....	41
3.3.1.3 CACHE REV KEY .....	42
3.3.1.4 CACHE PRINT KEY .....	42
<b>APPENDIX A: CALIBRATION .....</b>	<b>43</b>
• CALIBRATION INTERVAL.....	43
• TV-10 and TV-40 MUX CALIBRATION.....	43
• VOLTS.....	44
• THERMOCOUPLES .....	44
• COLD JUNCTION COMPENSATION CHECK .....	44
<b>APPENDIX B: SPECIFICATIONS .....</b>	<b>45</b>
<b>APPENDIX C: CONNECTING ACCESSORIES .....</b>	<b>49</b>
THE ACCESSORY CARD .....	49
• USING GLOBAL ALARM RELAYS .....	49
• USING THE EXTERNAL PRINT TRIGGER.....	49
CONNECTING THE 20-RELAY ALARM CARD (OPTION) .....	50
CHANGING FIRMWARE EPROMS.....	51

## Introduction

---




This **User's Guide** explains how to use Omega's OM-5000 series Dataloggers.

This manual is written for users of varied experience. If a section covers information you already know, feel free to skip to the next section.

### • Terms used in this Manual

---








In this manual, the following definitions are used for special terms and symbols.

-  **Warns the user that the note identifies conditions or practices that could result in personal injury or damage to property other than the equipment.**
-  **Warns the user that the note identifies conditions or practices that could result in damage to the equipment.**
-  **Warns the user that the note includes important information.**
- **Thermocouple** may be referred to as **T/C**.
- Both the **OM-5100** and **OM-5200** may be referred to as "**Logger**".

### • Product Symbols

---

The following symbols may be present on the Product:

-  Direct Current (DC) Power
-  Alternating Current (AC) Power
-  **CAUTION:** Whenever this internationally recognized symbol is used on the product, additional information concerning that particular feature or function appears in the manual.
-  Frame or Chassis Terminal
-  Battery Charger protected throughout by double or reinforced insulation.
-  Indoor use only. For electric-shock protection, always operate the battery charger in a protected, indoor location.
-  Thermocouple connection

## Operator Safety Information

---

The safety information in this summary is for the benefit of operating personnel. Warnings and Cautions will also be found throughout the manual where they apply.



### **PRODUCT USAGE WARNINGS:**

For fire and electric shock protection, DO NOT connect the input channels to objects at elevated electrical potential. The common terminal of each measurement input channel is not isolated from the common terminal of the input power connector and the RS-232 serial data port while that channel is being measured.



**This interconnected common circuitry is not connected to ground or to the enclosure of the Logger. If the Logger is interconnected to a desktop computer, its internal circuitry very likely could be connected to ground through the serial data port of the computer. The Logger enclosure and the measurement circuitry provide functional isolation of the measurement and data circuitry sufficient to allow for small electrical noise-related potentials to occur. This functional isolation is not intended for electrical safety isolation. Therefore for electric-shock protection and to prevent fire and damage to data interconnect wiring due to high currents, the input channels must not be connected to objects at elevated electrical potential.**

- Do not operate the Logger in flammable or explosive atmospheres. Such usage constitutes a fire or explosion risk.
- For electric-shock protection, only operate the AC power adapter indoor location.
- For continued fire and electric shock protection, use only the specified power adapter.
- For continued fire protection, use only the specified optional DC power cable, which incorporates a two-ampere fuse.



**A two-ampere fuse is incorporated in the cigarette lighter plug which is part of the DC power cable. This fuse provides overcurrent protection should a short or overload circuit occur in the Logger or the DC power cable.**



**For protection of the Logger itself, observe the following:**

- Do not immerse the Logger in liquids.
- Do not subject the Logger to sharp impacts or drops.
- Do not expose the Logger to corrosive environments.
- Extended exposure to temperatures below the specified minimum may damage the battery (optional external rechargeable battery pack only).
- Extended exposure to temperatures above the specified maximum may damage the Logger itself or its optional external rechargeable battery pack.
- Do not excessively stress the power input, the RS-232 serial data, and the accessory port connections.



**The warranty will not cover damage caused by neglect or abuse of this product. To maintain the safety features incorporated in this product, operation must be in strict compliance with the requirements specified herein.**

## 1.0 GENERAL INFORMATION AND FEATURES

---

This section explains the Features for the OM-5100 (Bench Top) and OM-5200 (Wall Mount) Systems.

### 1.1 INTRODUCTION & SYSTEM OPERATION

---

Omega's digital Logger can be furnished with a variety of multiplexers and other circuitry for various logging tasks.

The Logger is completely self-contained and equipped with a built-in 24-column thermal printer, an alphanumeric keyboard, a 16-digit vacuum-fluorescent display, a real-time clock (with rechargeable 30-day battery backup), and an RS-232 serial data port for connection to a computer serial port.

An AC Power Adapter provides 12 V DC for powering the Logger. North American and selected international configurations of this power adapter are available.


The Logger includes a Data Cache memory that provides temporary storage of logged data for reviewing before printing or uploading to a remote computer. RS-232 cable for connecting to a computer, Accessory board with an external print trigger input; Relay contact signal outputs for high and low alarms; and an optically isolated serial interface for use with optional accessories such as the 20-relay alarm card. Also available are: carrying case, and cables for operating from an automotive 12V DC source.

The Logger can be programmed directly from the keyboard or from a remote computer. Programmable functions include:

1. Current date, time, and log interval.
2. The contents and format of the printout.
3. The configuration of each channel to match the kind of sensor to be used, such as thermocouple type, voltage input, and pH probes.
4. The number of channels scanned and which channels are to be skipped. Also the dwell time between channels and a hold command for continuous logging of one selected channel.
5. Scaling the display reading to accommodate various input sensors by multiplying, adding, or subtracting ( $mX+b$ ).
6. High and low alarm points.
7. Engineering units.
8. Default unit of temperature (C or F).
9. Nonvolatile storage of the configuration for your system in an electrically programmed ROM.

### 1.1.1 LOGGER MAINFRAME

The Logger Mainframe, as diagramed in Figure 1-1 consists of a microprocessor with internal EEPROM and external RAM and ROM. The printer, display, and real-time clock subsystems communicate with the CPU over a serial bus. The processor also receives data from a 24-key keyboard and is capable of communication to external computers or devices through the RS-232 port. The serial (SPI) bus is also used to communicate control and input information to the MUX, Accessory, and Alarm cards.




*Figure 1-1: Mainframe Block Diagram*



### 1.1.2 MULTIPLEXER


Multiplexers perform the signal conditioning functions for the Logger. The multiplexer shown in the block diagram below is designed for use with thermocouple and voltage inputs. Relays select which input (voltage or thermocouple) is to be read. The input signals are amplified and digitized by the A/D converter. Provision is also made for measuring the temperature at the thermocouple attachment point and the system zero-voltage input. Using these parameters, thermocouple readings are compensated for junction temperature, and offset zero drifts are canceled. The CPU controlled range switch is set according to the type of input that is selected. Information as to the channel type, display units, and alarm points is stored in EEPROM in the multiplexer, allowing you to change multiplexers without losing channel configuration information. The plug-in accessory board and optional Alarm Cards can be plugged into the multiplexer.




**Figure 1-2: Typical Multiplexer Block Diagram**

## 1.2 LOGGER EXTERIOR FEATURES

### OM-5100 Features:




**Figure 1-3**




**Figure 1-4**

## **OM-5200 Features:**



**Figure 1-5**



**Figure 1-6**

## 2.0 PREPARATION AND SET-UP

This section provides the necessary information to set the Logger up for proper operation.

### 2.1 UNPACKING

Unpack the unit carefully. Check for options and accessories that may have been packed separately. Retain the shipping carton for reshipment (for recalibration or any other purpose).

#### OM-5100 System:




Figure 2-1: OM-5100 System

## OM-5200 System:





Figure 2-2: OM-5200 System

## 2.2 QUICK HOOK UP

If you have an OM-5200 System or do not want to attach your Logger to the wall, go directly to the section *2.4 CONNECTING TRANSDUCER INPUTS TO MULTIPLEXER*.

## 2.3 ATTACHING A OM-5200 TO THE WALL

This procedure is for the OM-5200 **ONLY**.



**Figure 2-3: Mounting Holes**


Locate the Wall Mount template. Observe the indicated setbacks from obstructions when placing the template. Mark four mounting hardware locations on the wall. Drill holes for the hardware and insert the anchors into the drilled holes. Tighten the screws into the anchors until only about 1/4 inch is exposed. Slide the key-hole-shaped mounting holes in the bottom of the Logger over the screws. It is important that there be space around the Logger for the printout paper.

The Knock-out tabs in the base may be used for conduit entry if more permanent installation is desired.

## 2.4 CONNECTING TRANSDUCER INPUTS TO MULTIPLEXER


---

1. **If you have an OM-5100**, place it on a bench in the normal operating position and loosen the two MUX attachment thumbscrews on the rear panel. Carefully slide the Mainframe forward exposing the green quick-disconnect terminal strips. Now proceed to step #3.




*Figure 2 4: Quick-Disconnect Terminals*

2. **If you have a OM-5200**, first loosen the thumbscrew on the front of the mainframe and carefully lifting the Mainframe up, exposing the green quick-disconnect terminals.



**Figure 2- 5: Quick-Disconnect Terminals**

3. Strip 1/4" of insulation from wire ends.
4. Connect each transducer input by pressing down the corresponding small orange terminal tab on the green terminal strip, inserting the wire into the hole (approx. 1/2") and releasing the tab. Make sure the wire is pushed far enough into the hole to engage the locking device. This can be tested by lightly pulling on the wire after insertion. A problem will occur if the wire is not stripped back far enough (1/4"), and insulation interferes with the connection.




**Figure 2-6: Connecting a Terminal**



## 2.4.1 CONNECTING TRANSDUCERS TO THE TV-10/40 MUX

The TV-10 and TV-40 multiplexers are designed to accept any of type J,K,B,S,R, or T thermocouples. Channels are numbered from top to bottom and labeled on the Thermal bar. For best accuracy the thermocouple leads should be placed as close as possible to the thermal bar and covered to eliminate any drafts or thermal gradients. Channel type (either J,K,B,S,R, o or V) must be programmed from the front panel (refer to section 3.2.3.2 *CHANNEL TYPE KEYS (J,K,T,E,B,S,R, Volts, Pt & SKIP)*).




**Figure 2-7: TV-40 Multiplexer Quick-Disconnect Terminals and Thermal Bar**

## 2.5 CONNECTING IN THE AC POWER ADAPTER

1. Turn the power switch on the rear panel of the Logger to the “OFF” position.
2. Plug the small DC connector of the power supply into the 12V power connector on the rear panel.
3. Plug the AC Power Adapter into the wall outlet.



**For continued fire and electric-shock protection, use only the specified AC Power Adapter.**



*Figure 2-8: OM-5100 Rear Panel*

## 2.6 CONNECTING OPTIONAL DC POWER CABLE

1. Turn the power switch on the rear panel to the “OFF” position.
2. Plug the small DC connector of the 12V DC Cable into the DC connector on the rear panel.
3. Plug the large DC cable connector into a 12V DC cigarette lighter power outlet, whether in the optional rechargeable battery pack or in a motor vehicle.



**For continued fire protection, use only the specified DC power cable which contains a two-ampere fuse.**

## 2.7 GROUNDING THE ENCLOSURE

The rear panel incorporates a threaded chassis-connection point, identified with the "chassis connection" symbol, which may be used for grounding the enclosure should the user desire to do so. This terminal is not required to be used for "protective grounding" because the unit is only powered by the low-voltage Power Adapter or optional rechargeable battery pack. Also, the measurement circuits must not be connected to hazardous circuits. The enclosure is functionally isolated from the internal circuits.

## 2.8 PAPER INSTALLATION

1. Unwind several inches of paper from the paper roll.
2. Fold the end of the thermal paper over creating a straight flat edge. This creates a strong paper edge and allows the paper properly center in the printer when inserting it into the rear paper slot on the printer. As shown in Figure 2-9 the thermally sensitive side (printing side) of the paper is down.




Figure 2-9

3. Insert the paper into the rear printer slot as shown in Figure 2-9. Turn the Logger "ON", then press and hold the **FEED** key to feed the paper through the printer.




**Paper orientation is important because only one side is coated for thermal printing.**

4. After the paper appears in the front window, pull several inches through.
5. Test the operation of the printer & paper-feed mechanism by turning the unit "OFF" and back "ON". When finished examine the printed messages for clarity.


## 2.9 RS-232 FUNCTIONS

The Logger is equipped with an RS-232 communication interface. The RS-232 port is configured 8 bits, 1 stop, 1 start and no parity. Baud rate is selected from the front panel. (Refer to section 3.2.2.4 *BAUD RATE*).



**Figure 2-10: R2-232 Cable Wiring**

Interface operation can be tested by connecting the terminal, then turning on the Logger. A sign-on message similar to the following should appear:




**Figure 2-11: Sign on Message**

### 2.9.1 DATA PORT CONNECTION

---

When the Logger is logging, data is saved in the internal cache RAM. The OM-550/5000 Windows software supplied with the Logger is used to transfer this data through the RS-232 Serial Port to a PC for analysis and storage. Prior to transferring data, the Logger must be connected to a PC with the supplied RS-232 cable assembly.

The cable is fitted with a 9-pin connector for the Data Port on Logger and a 25-pin connector for the PC COM port.



*Figure 2-12*



**To minimize danger to personnel, and to avoid ground loops which could affect measurement accuracy, never connect the Logger to a PC and to the signal inputs simultaneously!**

## 3.0 OPERATION

The following section covers the functionality and programming of the Logger for proper operation.

### 3.1 FRONT PANEL

The front panel includes a Display, Keypad, and Quick Start Instructions.





Figure 3-1

### 3.1.1 DISPLAY

---

The Logger display is used for displaying current channel data and prompting programming. When logging, the display indicates the current time of day, channel number sign, channel data value, and engineering units of the data. During programming the operator is prompted by the display for information about the function being programmed.



*Figure 3-2*

### 3.1.2 PRINTOUTS


---

The Logger incorporates a built-in 24 column printer that is an integral part of the operation. The printer records data, prints out Logger program configuration and alarm messages.

#### 3.1.2.1 POWER UP

---

When the Logger is initially turned on, the power up message is printed.



*Figure 3-3: Power Up Printout*

### 3.1.2.2 LOGGER CONFIGURATION

Pressing the **LOGGER CONFIG** key causes the Logger configuration to be printed out on the printer. An example of a configuration printout is shown in Figure 3-4.

```
01/01/00 12:00
*****
* 5000 SERIES LOGGERS *
*****

LOGGER CONFIGURATION
FIRMWARE VERSION X.XX
POD TYPE: TV-10
A/D=60HZ
CACHE? N
ACCESSORY? Y
DEFAULT UNIT OF TEMP= C

      UNITS TABLES
      00 C          08 pH
      01 F          09 mS
      02 V          10 uS
      03 MV         11 LBS
      04 A          12 KG
      05 MA         13 G
      06 P          14 US1
      07 PSI        15 US2

      ALARM TABLE
      00+ NONE      08+35798
      01+25550      09-00300
      02+10000      10+00100
      03+00000      11+00000
      04+00000      12+00000
      05+00000      13+00000
      06+00000      14+00000
      07+00000      15+00000
```

*Figure 3-4: Configuration Printout*

#### • CONFIGURATION UNITS TABLE

16 unit labels are listed in a table and may be assigned to any of the Logger channels. For example, if unit label 04 is assigned to a channel, an "A" will be displayed and printed following the data on the channel. Unit labels 14 and 15 are user programmable, and up to a three-character label may be programmed into these table positions (refer to section· CONFIGURATION UNITS ).


#### • CONFIGURATION ALARM TABLE

In a manner similar to the system used for Units Tables shown in Figure 3-4 the Alarms are assigned to channels by selection from a table of possible numbers. All alarm values except 00 (NONE) are user programmable, and may be either positive or negative. Alarm values are numbers only and assume the format or decimal printing position of the channel to which they are assigned. After alarm values are assigned to channels a complete list of channels and alarms can be printed out by pressing the **ALARM TABLE** key.



### 3.1.2.3 CHANNEL CONFIG

Pressing the **CHANNEL CONFIG** key causes the Logger Channel configuration to be printed out on the printer. An example of a Channel configuration printout is shown in Figure 3-5.



**Figure 3-5: Channel Configuration Printout**

- (1) Date & Time
- (2) Log Interval is 10 minutes
- (3) All channels will print
- (4) 10 channels are configured for scanning
- (5) Dwell is 3 seconds
- (6) Voltage scaling
- (7) DP is number of places to right of decimal point
- (8) Channels 1 & 7 are Type J Thermocouple
- (9) Low alarm for channel 2 & 9 is 10.0
- (10) High alarm for channel 2 & 9 are 1000.0
- (11) Channel 4 is a voltage channel with units = MV
- (12) Channel 4 has no alarms

\*Channels 3, 5, 6, 8, & 10 are skipped

#### • LOG INTERVAL

The Log Interval listed in Figure 3-5 is the time between printouts of all currently enabled channels.

## • PRINT OPTIONS

---

The Print Options shown in Figure 3-5 determines the amount of data that is sent to the printer. If the Print Options are set to ALL, all data and alarm information goes to the printer. If the Print Options are set to ALARMS, only out-of-range alarms are printed. If the Print Options are set to NONE, no data is printed. In all cases data is sent to the cache memory. If the **MANUAL PRINT** key is pressed or an external print trigger is initiated through the accessory port, the Print Options setting is ignored and normal channel data will be printed.

## • CHANNELS/DWELL

---

The Channel Configuration information shown in Figure 3-5 documents the maximum channel number that will be logged. The Dwell is the time in seconds that the Logger sits on a channel before testing alarm points or saving or printing data.

## • VOLTAGE SCALING

---

The **m**, **b** and DP parameters shown on the Channel Configuration printout indicate the current scaling and format constants used for channels configured as Voltage. The voltage reading from the MUX is multiplied by the **m** constant and then the **b** constant is added before displaying. The DP determines how many places will appear to the right of the decimal point when printing voltage alarms.

## • TADJUST

---

The Tadjust portion of the Channel Configuration printout shows the number of degrees that thermocouples are adjusted before printing or displaying.

## • CHANNEL / ALARMS

---

The Channel Alarm portion of the Channel Configuration printout shows the number, sensor type, units and alarm points programmed for all active channels.

### 3.1.2.4 NORMAL LOGGING

When operating the Logger in a normal logging mode the printout appears similar to the one shown in Figure 3-6.

```
01/01/00 12:00
01+T/C OPEN.
02-0038.4 F
04+0100.2 MV
07+0075.3 F
01/01/00 12:01
01+T/C OPEN.
02-0038.4 F
04+0100.2 MV
07+0075.3 F
```

**Figure 3-6: Normal Logging Printout**

- (1) Date & Time
- (2) Channel 1 has an open Thermocouple
- (3) Channel 4 reads 100.2MV

### 3.1.2.5 MANUAL PRINT

Pressing the **MANUAL PRINT** key on the front panel initiates a printout similar to the normal logging printout except that the time line is marked with a "%" character.

```
01/01/00 12:00
01+T/C OPEN.
02-0038.4 F
04+0100.2 MV
07+0075.3 F
01/01/00 12:01
01+T/C OPEN.
02-0038.4 F
04+0100.2 MV
07+0075.3 F
%01/01/00 12:02
01+T/C OPEN.
02-0038.4 F
04+0100.2 MV
07+0075.3 F
```

**Figure 3-7: "MANUAL PRINT" Printout**

- (1) Date & Time
- (2) Channel 1 has an open Thermocouple
- (3) Channel 4 reads 100.2MV
- (4) Printing was initiated by the Manual Print key or external print trigger.

## 3.2 PROGRAMMING

### 3.2.1 KEYPAD INTRODUCTION

When programming data into the Logger, be certain that a **beep** is heard when pressing a key to insure that the CPU has responded to the keystroke. Most keys perform one primary, one alpha, and one alternate function. Program data entry is done by displaying an example of how the data is to be entered and flashing the position at which the data is to be entered. If data out of range for the function being programmed is entered, the Logger will not accept the data.



In the following instructions and examples, MSD means most significant digit and LSD means least significant digit.




Figure 3-8: Keypad

### 3.2.1.1 THE ALPHA KEY

Alpha characters are entered by pressing the **ALPHA** key, which shifts the key functions to the letters at the top left of each key. The keyboard remains in the Alpha mode until the Alpha key is pressed again.




Figure 3-9: Alpha Keys

### 3.2.1.2 THE ALT KEY

The alternate legends for keys are activated by pressing the **ALT** key to shift the key functions to the upper keyboard legend. The Alternate key functions are engaged for one keystroke only.




Figure 3-10: Alternate Key Legend

### 3.2.1.3 THE CLEAR KEY

---

The **CLEAR** key may be pressed at any time to return to the normal operating mode. The Keypad then returns to its primary function and all keystrokes for the current operation are canceled. All program entries are automatically stored in memory after the last digit or character is entered for that operation.

## 3.2.2 PROGRAMMING MAINFRAME FUNCTIONS

### 3.2.2.1 MAINFRAME PROGRAM STORAGE

---

Mainframe program variables are stored in either the real-time clock, or the CPU electrically alterable RAM. The variables stay with the mainframe even if Multiplexers are changed.

### 3.2.2.2 TIME

---

The Logger keeps time in the 24-hour format HH:MM:SS. To enter the time, press the **ALT** key followed by the **LOGGER CONFIG** key. The time currently programmed will appear for 3 seconds, then Time (HH:MM:SS) appears with the digit ready for entry flashing. If the time is correct, pressing the **CLEAR** key will preserve it. To set the time to 14:20:00 enter as follows:

<u>FUNCTION</u>	<u>KEY PRESSED</u>	<u>DISPLAY</u>
Shift to ALT keyboard	ALT	SELECT ALTERNATE
Select time	LOGGER CONFIG	TIME (HH:MM:SS)
Enter MSD hour (tens)	1	TIME (1H:MM:SS)
Enter LSD hour (units)	4	TIME (14:MM:SS)
Enter MSD minutes (tens)	2	TIME (14:2M:SS)
Enter LSD minutes (units)	0	TIME (14:20:SS)
Enter MSD seconds (tens)	0	TIME (14:20:0S)
Enter LSD seconds (units)	0	TIME (14:20:00)

### 3.2.2.3 DATE

---

When the **DATE** key is pressed, the date currently entered in memory will appear for 3 seconds after which a new date may be entered. If the displayed date is correct, pressing the **CLEAR** key will preserve it. Dates are incremented when the time passes from 23:59:59 to 00:00:00. Leap years are accommodated. The new date is entered in the form MM:DD:YY.

Follow the procedure and example below to enter a new date of 01/01/97:

<u>FUNCTION</u>	<u>KEY PRESSED</u>	<u>DISPLAY</u>
Shift to alt. keyboard	ALT	SELECT ALTERNATE
Select DATE	CHANNEL CONFIG	DATE (MM-DD-YY)
Enter MSD month	0	DATE (0M-DD-YY)
Enter LSD month	1	DATE (01-DD-YY)
Enter MSD day	0	DATE (01-0D-YY)
Enter LSD day	1	DATE (01-01-YY)
Enter MSD year	9	DATE (01-01-9Y)
Enter LSD year	7	DATE (01-01-97)

### 3.2.2.4 BAUD RATE

---

The RS-232 port baud rate is selectable as either 9600, 1200, or 600 and is selected by pressing the **YES** or **NO** key in response to the baud rates as they appear.

**Follow the procedure below to set the baud rate to 600 baud:**

<b><u>FUNCTION</u></b>	<b><u>KEY PRESSED</u></b>	<b><u>DISPLAY</u></b>
Shift to alt. keyboard	ALT	SELECT ALTERNATE
Select BAUD	PRINT OPTIONS	BAUD=9600Y/N ?
	NO	BAUD=1200Y/N ?
	NO	BAUD= 600Y/N ?
	YES	

### 3.2.2.5 LOG INTERVAL

---

The Log Interval is a 6-digit entry in the form HH:MM:SS. Logging intervals can range from 1 second to 23 hours, 59 minutes and 59 seconds, however the log interval should be chosen to log all active channels before the next log interval starts.

If the log interval is set shorter than the total scan time, the log interval will be “overrun”. The effect of overrunning the log interval is twofold. First is that your data will not be recorded at the desired time. Second is that only data is stored in the cache, not time. The Logger calculates the event time using the time of the last data taken and the log interval. Therefore the time stamp on the printout and cache printout will not agree.

Set log intervals as follows (the example is for 1 hour, 30 minutes, and 15 seconds):

<b><u>FUNCTION</u></b>	<b><u>KEY PRESSED</u></b>	<b><u>DISPLAY</u></b>
Shift to alt. keyboard	ALT	SELECT ALTERNATE
Select log interval	LOG INTERVAL	INTRVL (HH:MM:SS)
Enter MSD hour	0	INTRVL (0H:MM:SS)
Enter LSD hour	1	INTRVL (01:MM:SS)
Enter MSD minute	3	INTRVL (01:3M:SS)
Enter LSD minute	0	INTRVL (01:30:SS)
Enter MSD second	1	INTRVL (01:30:1S)
Enter LSD second	5	INTRVL (01:30:15)



### 3.2.2.6 CHANNEL LOGGING KEYS

---

#### • ACTIVE CHANNEL

---


The Logger allows setting the maximum number of channels to be scanned from 1 to the capability of the multiplexer (up to 40 in a 40-channel MUX). Enter the desired maximum channels to be scanned with the following procedure and example (8 channels):

<u>FUNCTION</u>	<u>KEY PRESSED</u>	<u>DISPLAY</u>
Shift to alt. keyboard	ALT	SELECT ALTERNATE
Select Maximum channels	9	MAX CHANNELS CC
Enter MSD channel	0	MAX CHANNELS 0C
Enter LSD channel	8	MAX CHANNELS 08

#### • DWELL

---

Dwell time is a 2-digit entry, which can range from 1 to 9 seconds. Enter the desired time using the following procedure and example (05 seconds dwell):



**Dwell time is used to allow the Logger needed time to settle on a channel. The total time needed is dependent on the input type and is best determined by experience. Dwell is part of the total scan time and must be taken into consideration along with Active Channels and Log Interval to get a scan time that will not be longer than the Log Interval.**

<u>FUNCTION</u>	<u>KEY PRESSED</u>	<u>DISPLAY</u>
Shift to alt. keyboard	ALT	SELECT ALTERNATE
Select dwell time	6	DWELL SEC NN
Enter MSD second	0	DWELL SEC 0N
Enter LSD second	5	DWELL SEC 05

#### • HOLD

---

The Hold function allows the user to continuously scan on any individual channel. The channel hold continues until the **CLEAR** key is pressed.

**In the following example:** Channel 10 is designated to be put on Hold:

<u>FUNCTION</u>	<u>KEY PRESSED</u>	<u>DISPLAY</u>
Shift to alt. keyboard	ALT	SELECT ALTERNATE
Select hold function	3	HOLD CHANNEL CC
Enter MSD of channel	1	HOLD CHANNEL 1C
Enter LSD of channel	0	HOLD CHANNEL 10

## 3.2.3 PROGRAMMING MULTIPLEXER FUNCTIONS

### 3.2.3.1 MUX PROGRAM STORAGE

---

Mainframe program variables are stored in electrically alterable RAM located on the MUX. These variables are retained even if power is disconnected.

### 3.2.3.2 CHANNEL TYPE KEYS (J,K,T,E,B,S,R,Volts, Pt & SKIP)

---

Each channel in the Logger can be individually programmed for measuring voltage ( $\pm 2.000$  volts), or thermocouples. The availability of thermocouples depends on the type of multiplexer you have. When programming channels as a thermocouple the default unit of temperature will be assigned to it. Channels may also be skipped when no logging is desired. Different thermocouple types are selected from the front panel as J,K,B,S,R or T:

#### In the following example:

Channel 1 is for a type T thermocouple (**Note:** Thermocouple-10/40 Mux only)

Channel 4 is for a type K thermocouple (**Note:** Thermocouple-10/40 Mux only)

Channel 10 is set to read voltage (V) ( $\pm 2.000$  volts max.)

Channel 12 is to be skipped.

<u>FUNCTION</u>	<u>KEY PRESSED</u>	<u>DISPLAY</u>
Shift to alt. keyboard	ALT	SELECT ALTERNATE
Select T/C type T	CACHE FWD	CHANNEL T CC
Enter MSD channel	0	CHANNEL T 0C
Enter LSD channel	1	CHANNEL T 01
Shift to alt. keyboard	ALT	SELECT ALTERNATE
Select T/C type K	X	CHANNEL K CC
Enter MSD channel	0	CHANNEL K 0C
Enter LSD channel	4	CHANNEL K 04
Shift to alt. keyboard	ALT	SELECT ALTERNATE
Select voltage	YES	CHANNEL V CC
Enter MSD channel	1	CHANNEL V 1C
Enter LSD channel	0	CHANNEL V 10
Shift to alt. keyboard	ALT	SELECT ALTERNATE
Select skip	-	CHAN SKIP CC
Enter MSD channel	1	CHAN SKIP 1C
Enter LSD channel	2	CHAN SKIP 12
Shift to alt. keyboard	ALT	SELECT ALTERNATE

### 3.2.3.3 VOLTAGE SCALING KEYS



**mX + b effects all voltage channels**

#### • VOLTAGE INPUT SCALING

Any of the Logger input channels may be programmed as Voltage channels. Voltage channels include **m** and **b** constants for "scaling" all voltage data to your application. The following sections include examples for common transducers.


#### • MATCHING TRANSDUCERS TO THE LOGGER

Some transducers provide a "voltage" output others provide a "current" output. This section explains how to use resistors to "Match" either output to the Logger input.

Currents must be converted to a voltage and voltages must be attenuated (reduced) if they can exceed the Logger maximum input ( $\pm 2.0000$  VDC). This process is called Matching, which means converting or attenuating the transducer's output to an acceptable level without overloading it.

#### • MATCHING A VOLTAGE TRANSDUCER

Use two resistors to attenuate a voltage without overloading the transducer. The method shown here will draw approximately half of the transducer's maximum current at full-scale.




**Figure 3-11**

<b>V</b>	=	transducer maximum output voltage
<b>I</b>	=	1/2 transducer's maximum output current
<b>R1</b>	=	$2 / I$
<b>R2</b>	=	$(V-2) / I$

## • MATCHING A CURRENT TRANSDUCER

Use one resistor to develop the necessary voltage at the Logger input:



**Figure 3-12**

$$\begin{aligned} V &= \text{Logger maximum input voltage} \\ &= 2.0000 \text{ VDC} \\ &= R1 * I \end{aligned}$$

$$I = 1/2 \text{ transducer's maximum output current}$$

$$R1 = 2 / I$$

## • DATA SCALING (mX + b calculation)

The Logger can read the output voltage of a properly matched transducer but the data will be in "volts" and you might prefer data in units that reflect your application. Programming the Logger to produce data in terms of the actual parameter being measured is called Scaling.

The linear slope-intercept formula ( $Y = mX + b$ ) shows how to do this. Given input "X", careful choice of **m** and **b** can scale the output "Y" to any value, with some restrictions:

- The **m** and **b** values you choose must be within the allowable ranges:

$$-9.99999 \leq m \leq +9.99999 \quad -999999 \leq b \leq +999999$$

The following equations show how to scale your data to the actual value of the parameter you are measuring. They assume that an increasing transducer output indicates an increasing parameter. If your system is inversely proportional, just change the sign of the **m** value. Remember that **m** and **b** can be positive or negative.

$$\begin{aligned} X1 &= \text{minimum voltage expected at the Logger input} \\ X2 &= \text{maximum voltage expected at the Logger input} \end{aligned}$$

$$\begin{aligned} Y1 &= \text{minimum parameter value for your application} \\ Y2 &= \text{maximum parameter value for your application} \end{aligned}$$

$$m = (Y1 - Y2) / (X1 - X2) \quad b = Y2 - (m * X2)$$

## • EXAMPLE - VOLTAGE TRANSDUCER

---

### **EXAMPLE:**

Given a 20 - 90 % RH (Relative Humidity) transducer with a 0 - 10 VDC output and a maximum current of 3 mA.

Program the Logger to indicate 20.00 %RH to 90.00 %RH (that is, to indicate %RH with 0.01% resolution).

1. First, find the Matching resistors:

$$\begin{aligned} I &= 1/2 \text{ maximum current} \\ &= 0.003 / 2 \\ &= 0.0015 \text{ Amps} \end{aligned}$$

$$\begin{aligned} R1 &= 2 / I \quad R2 &= (V - 2) / I \\ &= 2 / 0.0015 &= (10 - 2) / 0.0015 \\ &= 1333 \, \Omega &= 5333 \, \Omega \end{aligned}$$

2. Check:

$$\begin{aligned} V &= (R1 + R2) * I & V &= R2 * I \\ &= (1333+5333)*1.5 \text{ mA} & &= 1333*1.5 \text{ mA} \\ &= 9.999 & &= 1.9995 \\ &= 10 & &= 2 \end{aligned}$$



**When the transducer output is 10 VDC, the Logger will see 2 VDC.**

3. Next, find m & b:

$$\begin{aligned} X1 &= 0 \text{ VDC} \\ &= 0 \text{ A/D counts} \end{aligned}$$

← minimum expected Logger input

$$\begin{aligned} X2 &= 2.0000 \text{ VDC} \\ &= 20000 \text{ A/D counts} \end{aligned}$$

← Logger maximum allowable input

$$\begin{aligned} Y1 &= 20.00 \%RH \\ &= 2000 \text{ A/D counts} \end{aligned}$$

← choose decimal point = 2

$$\begin{aligned} Y2 &= 90.00 \%RH \\ &= 9000 \text{ A/D counts} \end{aligned}$$

← keep decimal point = 2

$$\begin{aligned} m &= (Y1 - Y2) / (X1 - X2) \\ &= (2000 - 9000) / (0 - 20,000) \\ &= 0.35000 \end{aligned}$$

$$\begin{aligned} b &= Y2 - (m * X2) \\ &= 9000 - (0.350 * 20,000) \\ &= 002000 \end{aligned}$$



**Notice the decision to indicate with 0.01% resolution determined a decimal position of 2.**

## • EXAMPLE - CURRENT TRANSDUCER

### EXAMPLE:

Given a 0 - 150 PSI transducer with a 4-20 mA output.

Program the Logger to indicate 0 - 150 PSI with 0.01 PSI resolution.

1. First, find the Matching resistor:

$$\begin{aligned} R1 &= 2 / I \\ &= 2 / 20 \text{ mA} \\ &= 2 / 0.02 \\ &= 100 \Omega \end{aligned}$$

When the transducer output is 4 mA, the Logger will see 0.4 VDC and when the transducer output is 20 mA, the Logger will see 2 VDC.

2. Next, find m & b:

$$\begin{aligned} X1 &= 0.4000 \text{ VDC} && \leftarrow \text{minimum expected Logger input} \\ &= 4000 \text{ A/D counts} \end{aligned}$$

$$\begin{aligned} X2 &= 2.0000 \text{ VDC} && \leftarrow \text{Logger maximum allowable input} \\ &= 20000 \text{ A/D counts} \end{aligned}$$

$$\begin{aligned} Y1 &= 0 \text{ VDC} && \leftarrow \text{minimum transducer output} \\ &= 0.00 \text{ PSI} && \leftarrow \text{choose decimal point} = 2 \end{aligned}$$

$$\begin{aligned} Y2 &= 150.00 \text{ PSI} && \leftarrow \text{maximum transducer output} \\ &= 15000 \text{ A/D counts} && \leftarrow \text{keep decimal point} = 2 \end{aligned}$$

$$\begin{aligned} m &= (Y1 - Y2) / (X1 - X2) \\ &= (0 - 15000) / (4000 - 20000) \\ &= 0.93750 \end{aligned}$$

$$\begin{aligned} b &= Y2 - (m * X2) \\ &= 15000 - (0.93750 * 20000) \\ &= -003750 \end{aligned}$$



**Notice the decision to indicate with 0.01 PSI resolution determined a decimal position of 2**

## • PROGRAMMING EXAMPLE



### mX + b effects all voltage channels

**In the following example:** The  $mX+b$  equation is set so that  $m = +.6666$  and  $b = -.00010$ . (Range of allowable values for  $b$  are  $-32767$  to  $+32767$  and allowable values for  $m$  are  $-9.9999$  to  $9.9999$ )

<u>FUNCTION</u>	<u>KEY PRESSED</u>	<u>DISPLAY</u>
Shift to alt. keyboard	ALT	SELECT ALTERNATE
Select m coefficient	NO	M COEF +N.NNNN
Select the positive sign	+	M COEF +N.NNNN
Enter the MSD	0	M COEF +0.NNNN
Enter the NSD	6	M COEF +0.6NNN
Enter the NSD	6	M COEF +0.66NN
Enter the NSD	6	M COEF +0.666N
Enter the LSD	6	M COEF +0.6666
Shift to alt. keyboard	ALT	SELECT ALTERNATE
Select b coefficient	DOWN ARROW	B COEF +NNNNN
Select the negative sign	-	B COEF -NNNNN
Enter the MSD	0	B COEF -0NNNN
Enter the NSD	0	B COEF -00NNN
Enter the NSD	0	B COEF -000NN
Enter the NSD	1	B COEF -0001N
Enter the LSD	0	B COEF -00010

## • DECIMAL POINT

The decimal point may be set at any position. In the following example, any number from 0 to 5 may be entered when the display shows DECIMAL POS=N with the N flashing. The number entered determines the number of places from the right that the point will appear.

**In the following example:** The decimal point is set to the hundredths position (000.00), that is 2 places from the right. The range of possible locations are .nnnnn to nnnnn.

<u>FUNCTION</u>	<u>KEY PRESSED</u>	<u>DISPLAY</u>
Shift to alt. keyboard	ALT	SELECT ALTERNATE
Select decimal point (flashing)	UP ARROW	DECIMAL POS=N
Enter position 2	2	DECIMAL POS=2



### 3.2.3.4 TADJUST (TEMPERATURE ADJUSTMENT)

The Logger permits adjustment of the temperature readings to accommodate various thermocouple sensors. This correction is accomplished by adding the value of Tadjust to actual sensor readings. The value of Tadjust is cumulative and the number entered adds (or subtracts if negative) to the Tadjust value already stored in the MUX EEPROM. The accumulated value of Tadjust is shown on the "Channel Configuration" printout (refer to Figure 3-5: Channel Configuration Printout)

**In the following example:** Tadjust is increased by 22.5 degrees. The Range of allowable values for Tadjust is -99.9 to +99.9.



**Tadjust effects all channels the same.**

<b><u>FUNCTION</u></b>	<b><u>KEY PRESSED</u></b>	<b><u>DISPLAY</u></b>
Shift to alt. keyboard	ALT	SELECT ALTERNATE
Select Tadjust	TADJUST	TADJUST +00XX.X
Select the positive sign	+	TADJUST +00XX.X
Enter the MSD	2	TADJUST +002X.X
Enter the NSD	2	TADJUST +0022.X
Enter the LSD	5	TADJUST +0022.5



**If a channel's type is such that the temperature readings are only accurate to one degree resolution (e.g. B,S or R thermocouple), only the integer portion of Tadjust ahead of the decimal point is added.**

### 3.2.3.5 ALARM KEYS

#### • ALARM TABLE

The Logger permits assignment of up to 15 alarm values. These alarm values are put in a table, and may be assigned to any channel as a high or low alarm (refer to section • HIGH and LOW). Alarm values are of fixed format (only whole numbers) and may be either positive or negative. Alarm values may be printed by pressing the **LOGGER CONFIG** key.

**In the following example:** We will assign a value of +100 to alarm number 01, and a value of -100 to number 02:

<b><u>FUNCTION</u></b>	<b><u>KEY PRESSED</u></b>	<b><u>DISPLAY</u></b>
Shift to alt. keyboard	ALT	SELECT ALTERNATE
Select alarm value	7	ALARM NN+XXXXXX
Enter the channel MSD	0	ALARM 0N+XXXXXX
Enter the channel LSD	1	ALARM 01+XXXXXX
Select the positive sign	+	ALARM 01+XXXXXX
Enter the MSD	0	ALARM 01+0XXXXX
Enter the NSD	0	ALARM 01+00XXX
Enter the NSD	1	ALARM 01+001XX
Enter the NSD	0	ALARM 01+0010X
Enter the LSD	0	ALARM 01+00100
Shift to alt. keyboard	ALT	SELECT ALTERNATE
Select alarm value	7	ALARM NN+XXXXXX
Enter the channel MSD	0	ALARM 0N+XXXXXX
Enter the channel LSD	2	ALARM 02+XXXXXX
Select the negative sign	-	ALARM 02-XXXXXX
Enter the MSD	0	ALARM 02-0XXXXX
Enter the NSD	0	ALARM 02-00XXX
Enter the NSD	1	ALARM 02-001XX
Enter the NSD	0	ALARM 02-0010X
Enter the LSD	0	ALARM 02-00100

## • HIGH and LOW

---

The Logger offers 16 alarm values that can be assigned to any channel as either a high or low alarm. The channels are assigned first, then the alarm value (HH or LL). If no alarm is desired on a channel, it may be assigned alarm value 00. The default tag for high and low alarm values is NONE.

**In the following example:** Channel 01 is assigned a high alarm value of +100, which was assigned to Alarm Value 01 in the Alarm Value section.

Channel 05 is assigned a low alarm value of -100 as assigned to Alarm Value number 02 in Section Alarm Value section.

<b><u>FUNCTION</u></b>	<b><u>KEY PRESSED</u></b>	<b><u>DISPLAY</u></b>
Shift to alt. keyboard	ALT	SELECT ALTERNATE
Select HIGH for high alarm	4	HI ALM CH CC HH
Enter MSD of channel	0	HI ALM CH 0C HH
Enter LSD of channel	1	HI ALM CH 01 HH
Enter MSD of alarm value no.	0	HI ALM CH 01 0H
Enter LSD of alarm value no.	1	HI ALM CH 01 01
Shift to alt. keyboard	ALT	Select Alternate
Select LOW for low alarm	1	LO ALM CH CC LL
Enter MSD of channel	0	LO ALM CH 0C LL
Enter LSD of channel	5	LO ALM CH 05 LL
Enter MSD of alarm value no.	0	LO ALM CH 05 0L
Enter LSD of alarm value no.	2	LO ALM CH 05 02

### 3.2.3.6 UNIT KEYS

#### • UNITS TABLES

The Logger has a total of 16 unit labels. The last two, 14 and 15, are programmable with up to 3 characters each. Once the label number is entered numbers may be entered or by using the **ALPHA** key the Keypad shifts to the alpha mode, in which the keys select the alpha characters denoted in red at the top left of each affected key.



**Only labels 14 and 15 can be customized.**

**In the following example:**

Unit label 14 is programmed to read RPM

Unit label 15 is programmed to read MG

<b><u>FUNCTION</u></b>	<b><u>KEY PRESSED</u></b>	<b><u>DISPLAY</u></b>
Shift to alt. keyboard	ALT	SELECT ALTERNATE
Select unit label	8	UNIT LABEL NN CCC
Enter MSD unit label no.	1	UNIT LABEL 1N CCC
Enter LSD unit label no.	4	UNIT LABEL 14 CCC
Enter unit label char	R	UNIT LABEL 14 RCC
Enter unit label char	P	UNIT LABEL 14 RPC
Enter unit label char	M	UNIT LABEL 14 RPM
Shift to alt. keyboard	ALT	SELECT ALTERNATE
Select unit label	8	UNIT LABEL NN CCC
Enter MSD unit label no.	1	UNIT LABEL 1N CCC
Enter LSD unit label no.	5	UNIT LABEL 15 CCC
Enter unit label char	SPACE	UNIT LABEL 15 CC
Enter unit label char	M	UNIT LABEL 15 MC
Enter unit label char	G	Unit LABEL 15 MG

#### • UNITS

The Logger offers 16 unit labels that can be assigned to any channel. The list of units available can be printed out by pressing the **LOGGER CONFIG** key.

**In the following example:** We will assign unit label 03 (MV) to channel 01:

<b><u>FUNCTION</u></b>	<b><u>KEY PRESSED</u></b>	<b><u>DISPLAY</u></b>
Shift to alt. keyboard	ALT	SELECT ALTERNATE
Select UNIT	5	UNIT CH CC UU
Select channel number MSD	0	UNIT CH 0C UU
Select channel number LSD	1	UNIT CH 01 UU
Select unit number MSD	0	UNIT CH 01 0U
Select unit number LSD	3	UNIT CH 01 03

- **C/F**

The **C/F** key is used to set the default unit of temperature, Celsius or Fahrenheit. This default unit of temperature is automatically assigned to any new channel that is programmed as a thermocouple.



**Changing the default unit of temperature does not change any temperature units already set. To change a channel's temperature unit you must reprogram the channel as a thermocouple or actually change the channel's units.**

The default unit of temperature is programmed by pressing the **YES** or **NO** key in response to the options as they appear.

**Use the following procedure to set the default to Fahrenheit:**

<b><u>FUNCTION</u></b>	<b><u>KEY PRESSED</u></b>	<b><u>DISPLAY</u></b>	
Shift to alt. keyboard	ALT	SELECT ALTERNATE	
Select C/F	2	TEMP UNIT C Y/N?	
	NO	TEMP UNIT C Y/N?	YES
	TEMP UNIT F Y/N?		

### 3.3 DATA CACHE FUNCTIONS

---

The Logger contains a 14.5 K Byte data cache that retains logged data even when the unit is "OFF". The cache is a circular buffer; when full, each new data point overwrites the oldest data.

Each data point occupies two bytes of cache memory, so the total capacity of the cache depends upon the quantity of active (unskipped) channels. To calculate the capacity, divide 7250 by the number of active channels, as below:

<u>ACTIVE CHANNELS</u>	<u>CACHE CAPACITY</u>
1	7250 scans of all active channels
2	3625 scans of all active channels
3	2416 scans of all active channels
4	1812 scans of all active channels
5	1450 scans of all active channels

To calculate the time required to "Fill" the cache, multiply the capacity (above) by the current Log Interval.

Although the Logger continuously scans all channels, data is written to the cache only once during each log interval, at the completion of the first scan. The Logger then merely scans the channels and displays the readings until the next log interval has passed.

The data cache will be erased when the Logger is reprogrammed or the **CACHE ERASE** key pressed. If the cached data is valuable, **DO NOT** reprogram the Logger until the data has been transferred to a PC!

The cache can be erased in several ways: From the Keypad, by performing a Power-Up Reset or by reprogramming the channel definitions or Log Interval.


During a Power-Up Reset, the Logger can fill the cache with "phony" data. The artificial data is a functional test of the unit and can also be used to ensure that the RS-232 Port connection to a PC is functioning properly.



**The actual data values will vary with the pod's programming.**

### 3.3.1 CACHE KEYS

Four keys give access to the cached data. One erases it and three let you review or (optionally) print it.



**Figure 3-13: Cache keys**

The **CACHE FWD** and **CACHE REV** keys position a pointer into the cache. Data at the pointer is displayed, with the time it was acquired. The **CACHE PRINT** key prints the displayed data.

#### 3.3.1.1 CACHE ERASE KEY

The **CACHE ERASE** key clears the cache and resets the Review pointer to the earliest data (none, in this case). This key prompts the operator for yes or no confirmation to avoid accidental erasure. Refer to section 3.3 *DATA CACHE FUNCTIONS* for other ways to erase the cache.

#### 3.3.1.2 CACHE FWD KEY

The **CACHE FWD** key displays the cached data in the order it was acquired, from earlier to later. Hold the key down to increase the rate at which the data scrolls through the display. Press any non-cache-related key to end this Forward review and resume logging.

### 3.3.1.3 CACHE REV KEY


---

The **CACHE REV** key displays the cached data in reverse-acquisition order, from later too earlier. Hold the key down to increase the rate at which the data scrolls through the display. Press any non cache-related key to end this Reverse review and resume logging.

### 3.3.1.4 CACHE PRINT KEY

---

The **CACHE PRINT** key prints the cached data from the review pointer to the end of the cache in forward-sequence.



```
* FORWARD DUMP *
%12:00:00
01+0.8501 V
02-0038.4 F
04+0100.2 MV
07+0075.3 F
%12:10:00
01+0.8501 V
02-0038.4 F
04+0100.2 MV
07+0075.3 F
* END OF CDUMP *
```

*Figure 3-14: Cache Printout*




## APPENDIX A: CALIBRATION

### • CALIBRATION INTERVAL

Six months is the recommended calibration interval.

### • TV-10 and TV-40 MUX CALIBRATION



*Figure A-1: TV-40 MUX*

#### **SETUP**

1. Turn the Logger "OFF".
2. Press and Hold the **CLEAR** key down and turn Logger back "ON".
3. Answer "Yes" to the Clear CPU and Clear POD prompts.
4. Press the **CHANNEL CONFIG** key on the to verify that M=1.0000, B=+00000 and that channel #1 is configured as type V and channel #2 is configured as type J thermocouple with F units. Also verify that T<sub>adjust</sub> =0.00 and verify that operating line frequency (50/60 Hz) is set to your particular application.



**Consult factory for 50/60 Hz conversion.**

## • VOLTS

---

1. Hold the Logger on channel #1 Hold, by pressing the **ALT** then **HOLD** keys and selecting 01.
2. Apply a 2.00000 volt  $\pm 10$  microvolts standard voltage to channel 1.
3. Adjust R32 until the mainframe display reads exactly 2.0000.

## • THERMOCOUPLES

---



**This calibration should be made only after Voltage is calibrated.**

1. Set SW1-1 to the "ON" position (this removes the CJC compensation from temperature readings)
2. Connect a precision millivolt voltage standard to the channel #2 input and set the standard to 35.999 millivolts  $\pm 2$   $\mu$ V.
3. Adjust R9 on the MUX until the mainframe display reads 1200.0 F.
4. Set SW1-1 to the "OFF" position and disconnect the voltage standard. Cold junction compensation is now in effect.

## • COLD JUNCTION COMPENSATION CHECK

---

1. Short the Channel #2 input with a copper wire, the display should read room temperature.
2. Measure the temperature of the Isothermal Bar near Q3
3. Temperatures measured in 1 and 2 should agree, within 5 degrees C

## APPENDIX B: SPECIFICATIONS

---

### VOLTAGE MEASUREMENT INPUT:

RANGE:  $\pm 2$  VOLTS  
INPUT IMPEDANCE: 1 MEG-OHM  
CMRR: >105 db at 50/60Hz  
NMRR: >75 db at 50/60Hz  
INPUT BIAS CURRENT: 7 nA  
MAXIMUM OVERVOLTAGE PROTECTION: 120 VOLTS AC  
ACCURACY:  $\pm 400 \mu\text{V}$   
RESOLUTION: 100  $\mu\text{V}$

### THERMOCOUPLE MEASUREMENT INPUT:

TYPES: J,K,T,E,B,S,R  
INPUT IMPEDANCE: 100 MEG-OHM  
LEAD RESISTANCE EFFECT: Less Than 20  $\mu\text{V}/400 \text{ OHM}$   
OPEN THERMOCOUPLE INDICATION: "T/C OPEN"  
COLD JUNCTION COMPENSATION: 0-50°C  
COMMON MODE REJECTION RATIO (CMRR) at 50/60Hz: >140 db  
NORMAL MODE REJECTION RATIO (NMRR) at 50/60Hz: >75 db  
COLD JUNCTION ERROR: 0.5°C Max over range 10°C to 40°C  
RESOLUTION: (SEE TABLE BY TYPE)  
TEMPERATURE RANGE: (SEE TABLE BY TYPE)  
LINEARIZATION CONFORMITY ERROR: (SEE TABLE)

	°F	°C	Resolution	Conformity
<u>TYPE</u>	<u>Range</u>	<u>Range</u>	<u>°F</u>	<u>Error (°C)</u>
J	-265 1400	-165 760	0.1	0.08
K	-150 2282	-101 1250	0.1	0.10
T	-158 752	-105 400	0.1	0.10
E	-220 1225	-140 660	0.1	0.09
B	600 3272	315 1800	1.0	1.00
S	-58 3029	-50 1665	1.0	0.9
R	-58 3029	-50 1665	1.0	0.9

**DIGITAL INTERFACE (RS-232 SERIAL DATA PORT):**

BAUD RATE: 9600/1200/600 (Programmable)

OUTPUT VOLTAGE:  $\pm 9V$

MINIMUM LOAD (OHMS):  $3K\Omega$

CONNECTOR: 9 Pin "D" shell

**A/D CONVERSION:**

MAX SPEED (Conversions/sec) : 10

RESOLUTION (Counts) :  $\pm 20,000$

TECHNIQUE: Dual Slope

**CAPACITY:**

MAXIMUM INPUT CHANNELS : 40

**DISPLAY TYPE:**

16 DIGIT ALPHANUMERIC VACUUM FLUORESCENT

### **ENVIRONMENTAL:**

OPERATING AND STORAGE ENVIRONMENT: Indoor use only

OPERATING TEMPERATURE RANGE: 0 to 50 °C (32° F to 122°F)

STORAGE TEMPERATURE RANGE: -25°C to 75°C (-13°F to 167°F)

OPERATING RELATIVE HUMIDITY RANGE: Maximum 80% R.H. for temperatures up to 31°C decreasing linearly to maximum 50% R.H. at 40°C, remaining constant from 40°C to 50°C.

STORAGE RELATIVE HUMIDITY RANGE: Maximum 95% R.H., non-condensing.

MAINS VOLTAGE FLUCTUATION RANGE: Maximum +10% of the nominal rated input voltage for the specified AC Power Adapter.

POLLUTION DEGREE: Classed as Pollution Degree 2, per IEC Publication 664.



**This means that normally only non-conductive pollution (in the form of dust) occurs. Occasionally, however, a temporary conductivity caused by condensation must be expected.**

INSTALLATION CATEGORY (OVERVOLTAGE CATEGORY): Classed as Installation Category II, which applies to products used on electric supply branch circuits.



**This is an IEC Publication 664 classification of parts of installation systems or circuits with standardized limits for transient overvoltages, dependent on the nominal line voltage to earth.**

### **POWER/CURRENT RATINGS:**

AC POWER ADAPTER:

INPUT: 120 VAC or 230 VAC, model-specific

OUTPUT: 12 VDC, 1 A, 12 W

LOGGER

NON-PRINTING: 12 VDC, 300mA

PRINTING: 12 VDC, 700 mA

### **PHYSICAL:**

DIMENSIONS

Bench top: OM-5100 10.5"D x 10.0"W x 3.5"H

Wall mount: OM-5200 10.5"W x 10.0"H x 4"D

WEIGHT: 9 Lbs.

CALIBRATION : NIST (USA) Traceability

RECALIBRATION CYCLE FREQUENCY (MONTHS): 6

WARRANTY PERIOD: 1 year

**CONNECTORS:**

MUX INPUTS: Spring-loaded, press to release, 16AWG max.

DC POWER: 0.08" Pin x 0.218" Jack

RS-232 Serial Data Port: 9 Pin "D" Shell

ACCESSORY: 8 X 2 X 0.1" 0.025" Header

**PAPER LIFE:**

PAPER TYPE: Thermal

ROLL CAPACITY: 82 ± 1.6 Feet

LINE HEIGHT: 0.150 inches per printed line


LINES PER ROLL: 6,560±128

**EXAMPLE:** If 8 channels are being printed once every 10 minutes, the paper will last 136 hours or 5 days.

## APPENDIX C: CONNECTING ACCESSORIES

### THE ACCESSORY CARD

The Logger comes with the Accessory Card installed, Accessory I/O options and typical applications circuits are shown below:



*Diagram of Accessory Board I/O Options*

#### • USING GLOBAL ALARM RELAYS

The Global Alarm high and low relays are available for switching external devices. The relay contacts close whenever any channel is in an alarm condition.

#### • USING THE EXTERNAL PRINT TRIGGER


The External Print Trigger input is used to initiate a channel data printing sequence. Printing occurs even if the Logger Print Options are set to "NONE". If an external power supply is used, the input is isolated from the Logger circuitry. You may optionally tap a small amount of power off the Accessory Connector as shown in the above diagram.

## CONNECTING THE 20-RELAY ALARM CARD (OPTION)

**In order to use a 20-Relay Alarm Card, you must have an Accessory card installed.**

1. Turn the Logger and the 20-Relay Alarm Card power "OFF".
2. Locate the 16-conductor cable supplied with the Alarm Card and connect the Accessory output connector on the MUX rear apron to the connector labeled "IN" or "Accessory" on the Alarm Card.
3. To test operation, turn the Logger and Alarm Card power "ON", and cause a High or Low alarm to occur on one of the first 10 channels. The appropriate LED on the alarm card should light and the relay should close.

**Up to 3 additional alarm cards may be "daisy chained" for access to High and Low alarms on all 40 channels. No programming is necessary.**




*20-Relay Alarm Card*




## CHANGING FIRMWARE EPROMS

1. Turn the power "OFF", remove the Logger from the wall and loosen the thumbscrew to open the Logger.
2. Lift up the protective cover over the CPU board by grasping it at the front, and lifting up and out.
3. Locate U3 in the following diagram. This IC is mounted in a special low Insertion Force socket. In order to release the socket, push in the bar at the top (OPEN). Note pin #1 location and install the new EPROM.
4. To re-lock the socket, press in at the bottom (ACT).




*Low Insertion Force EPROM Socket*



*CPU Board Parts Layout*

# OM-5000DOS SOFTWARE



## TABLE OF CONTENTS

INTRODUCTION.....	iii
• HARDWARE REQUIREMENTS .....	iii
INSTALLATION.....	iv
• HARD DISK INSTALLATION.....	iv
1.0 STARTING THE PROGRAM .....	1
2.0 READING DATA FROM THE LOGGER .....	2
3.0 LOADING EXISTING DATA FILES.....	3
4.0 MODIFYING THE SOFTWARE CONFIGURATION .....	4
5.0 LIST DATA ON MONITOR .....	6
6.0 PRINTING DATA ON PRINTER.....	7
7.0 SAVING TEXT FILES .....	7
8.0 EDITING PLOT LABELS.....	8

<b>9.0 HOT PLOT.....</b>	<b>10</b>
9.1 FILE NAME, PLOT TITLE, and TIME STAMP.....	11
9.2 DATA PLOTS AND AXES .....	12
9.3 X-DATA CURSORS.....	13
9.4 X-CURSOR DATA TABLE.....	14
9.5 CHANNEL SELECT AND LINK BUTTONS.....	15
9.6 HELP MENU .....	17
9.7 FUNCTION KEY INTERFACE.....	18
9.7.1 X-CURSOR SELECT KEYS (F1 thru F3).....	18
9.7.2 CHANNEL SELECT KEYS (NUMBERS 1 thru 5).....	19
9.7.3 CHANNEL LINK KEYS (ALT-1 thru ALT-5) .....	19
9.7.4 SCALE PLOT KEYS (F5 and F6) .....	20
9.7.5 PRINT SCREEN KEY (F7) .....	21
9.8 MOUSE INTERFACE .....	22
9.8.1 MOUSE AND MOUSE POINTER .....	23
9.8.2 X-Y READOUT .....	24
9.8.3 CHANNEL SELECT AND LINK BUTTONS .....	25
9.8.4 MAGNIFY TOOL.....	27
<b>10.0 QUITTING.....</b>	<b>28</b>
<b>11.0 DISK FILE TYPES .....</b>	<b>29</b>
<b>12.0 READINGS AND DATAPOINTS .....</b>	<b>29</b>

## INTRODUCTION

---

The OM-5000 DOS Software requires an IBM™ PC or compatible, with 640K of ram and 1 or 2 serial ports. Most monitors will work.

The software is supplied on a 3-1/2" disk, and requires a hard drive. It is not copy protected and we recommend that you make at least one backup copy to hold in reserve. Refer to your computer's manual for copying instructions.

OM-5000 data can be saved to disk as experiment files. The files are automatically named with the word LOG, followed by three numbers, like LOG007. The numbers will increment as new experiments are saved or you can choose the number.

In addition to the OM-5000 data, an experiment file can (optionally) contain information describing the parameters of the experiment and the data.

The HOT PLOT display can be operated either from the keyboard or with an optional mouse pointing device.

## • HARDWARE REQUIREMENTS

---

COMPUTER:	IBM* PC, XT, AT, OR PS-2, Compaq*, or compatible, with 640K RAM
DISK DRIVE:	At least one floppy drive (3.5" or 5.25", 720K or 1.44M) and a Hard Drive.
GRAPHICS CARD:	CGA, EGA, VGA or Hercules
MONITORS:	CGA, EGA, VGA or Hercules compatible
PRINTERS:	9-pin Epson compatibles Star Rainbow Color HP* PaintJet Color HP Laserjet
SERIAL PORT:	One, configured as either COM1: or COM2:
MOUSE:	Microsoft or equivalent, with appropriate driver (mouse.com, ect.)

\*IBM is a registered trademark of International Business Machines Corporation.  
COMPAQ is a registered trademark Compaq corporation.  
HP is a registered trademark of Hewlett Packard.

## **INSTALLATION**

---

The OM-5000 DOS Software will operate only from your hard disk. If you are using a mouse, you must install the appropriate mouse driver software (mouse.com or mouse.sys) supplied with your mouse. See your mouse manual for instructions.

### **• HARD DISK INSTALLATION**

---

The OM-5000 DOS Software diskette contains an Install program. This program creates a directory named M5000 on the root directory of your hard disk and copies the necessary files to it. To run the Install program, place the source diskette in drive A:, make it the currently logged directory (refer to your DOS manual if necessary), and type "A:INSTALIT" or "B:INSTALIT".

## 1.0 STARTING THE PROGRAM

---

To start the program, boot your computer from your hard drive. From the DOS prompt, change to the directory where you have installed the OM-5000 DOS Software. (e.g. CD C:\M5000).

TYPE: **M5000C** If you have a computer with CGA video card.  
**M5000E** If you have a computer with EGA video card.  
**M5000V** If you have a computer with VGA video card.  
**M5000H** If you have a computer with Hercules video card.

To exit the program, type **Q** at the MASTER MENU.

When the program begins it will display the MASTER MENU.

```
OM-5000 Graphic Analysis Software V1.10
Copyright Omega Engineering, ECD 1988,89,95

OM-5000 GRAPHIC ANALYSIS MASTER MENU

1-Read Data From OM-5000
2=Load Existing LOG File
3=Modify Software Configuration
4=List Data on Monitor
5=Print Data on Printer
6=Save Text File (LOGNNN.PRN)
7=Edit Plot Labels
8=HOT PLOT
L=List Existing Log Files On Printer
Q=Quit

Current File Loaded =LOG001.bin
```

### *Master Menu Screen*

The MASTER MENU lists the options available to you: reading data from the Logger, reading an existing experiment file, or modifying the software configuration parameters (your custom labels and computer configuration).

The MASTER MENU options change to match what you are doing. For example, if you have read new data from the Logger but have not saved it to disk, the program will prompt you to save the data when you exit.

Experiment file LOG001 is always automatically loaded when the program starts. This is the file used in all examples in this manual.

## 2.0 READING DATA FROM THE LOGGER

---

This selection presents instructions for transferring data from the Logger to the PC.

Be sure the communication cable is properly installed and the Logger is "ON" and set to 9600 baud before starting the read process. If you use the same computer port for both the mouse and the Logger, be sure to reconnect the mouse after the data has been read.

Error messages will warn you if the program detects any errors during the transfer.

TO TRANSFER DATA:

1. Make sure the RS-232 cable is connected.
2. Make sure the OM-5000 is ON (Press ON/OFF KEY if not).
3. Press any key to start data transfer.

-

### *Data Transfer Screen*

Your screen will show the number of bytes moved during the transfer and you can save the data to disk when the transfer is completed.

The new data can be viewed and graphed even if not saved to disk as an experiment file.



### 3.0 LOADING EXISTING DATA FILES

---

Logger data is saved to disk in EXPERIMENT files. You can recall an earlier experiment file from disk at any time:

1. Start the OM-5000 DOS Software program or, if it is already running, press ESC to return to the MASTER MENU.
2. Select the LOAD EXISTING LOG FILE option to see a list of the experiment files on your diskette. The list includes the LOG INTERVAL used to acquire the data, the DATE & TIME when the last datapoint in the file was taken, the NUMBER of datapoints in the file and the (optional) TITLE you assigned to the plot.

```
EXPERIMENT FILES ON DISK
File   Interval   Last Data Taken  Points   Plot Title
LOG001 12:34:56  07/17/89 12:34:56  00100   Sample Experiment
```

```
TYPE IN EXPERIMENT FILE NAME (e.g. LOG003) OR Esc IF NONE
LOG
```

#### *Log Files on Disk Screen*

3. The prompt at the bottom of the screen asks you to type the number of the experiment you wish to review. Incorrect entries will produce warning messages and you can press any key to continue.

## 4.0 MODIFYING THE SOFTWARE CONFIGURATION

---

This MASTER MENU option lets you configure your system by selecting the serial port, printer, next file number and label to identify your data in reports. It describes the printers included in the STD, CLR-1, CLR-2 and LASER groups. To choose print orientation, select Portrait or Landscape.

The choices you make here will be saved to disk in a file named (\*.con) when you press ESC to return to the MASTER MENU.

Current Value: 1

SOFTWARE CONFIGURATION

/LOG001

PC COM: Channel (1=COM1:,2=COM2:) 1

PRINTER (1=STD,2=CLR-1,3=CLR-2,4=LASER)1

PRINTER (1=PORTRAIT,2=LANDSCAPE) 1

COMPANY Your Company Name

NEXT AVAILABLE FILE NUMBER 02

USE ↑ AND ↓ TO MOVE CURSOR

HIT RETURN TO CHANGE

Esc=MENU

### *Modify Software Configuration Screen*

Select the PC COM: # (serial interface port #) that you will use to transfer data from the Logger to your computer. The connectors are named COM1: and COM2:.

To choose a PRINTER, see the README file on OM-5000 DOS Software diskette. It describes the printers included in the STD, COLOR-1, and COLOR-2 groups.

To choose Print orientation select Portrait or Landscape

The COMPANY NAME is a text string that will be included when you LIST or PRINT the data or save it as a TEXT file.

Experiment filenames are automatically incremented when you save your data do disk.

The NEXT AVAILABLE FILE NUMBER determines the name of the next experiment file you save. See the DISK FILE FORMATS section for more information.

To make new entries or change existing ones, use the up and down cursor keys to highlight the area you wish to change, then make the entry.

If you make an error, use the BACKSPACE key to remove it, then retype. When you are satisfied with the configuration, press ESCAPE. The modified setup is saved to disk in the file named (\*.con) and the screen displays the MASTER MENU.

## 5.0 LIST DATA ON MONITOR

Use this MASTER MENU option to view your data on the monitor, in columnar format.

```
OM-5000 Data Transfer
Your Company Name
Log Interval = 12:34:56
Time Stamp = 12:34:56 07/17/89
Pod Type = TV-40
Dwell      = 10
Tadj       = +01.0
RefFreq    = 50
Plot Title = Sample Experiment
Note: Your Experiment Notes Can Be Kept Here
      Ch02      Ch03      Ch04      Ch09      Ch10
TYPE      V      J      K      T      E
UNITS      V      C      C      C      C
M          +1.0000
E          +00000
Press any key to continue
```

### *Listing Data on Monitor Screen*

Press the spacebar (or any key) to stop or restart the listing.

Press ESC to abort the listing.

```
78  -0.1915  0.2382  12.5  4.8930  4.5230
79  -0.1917  0.2373  12.5  4.8895  4.5190
80  -0.1912  0.2367  12.3  4.8868  4.5160
81  -0.1912  0.2359  12.2  4.8828  4.5125
      Ch02      Ch03      Ch04      Ch09      Ch10
82  -0.1910  0.2351  12.1  4.8800  4.5095
83  -0.1910  0.2344  12.0  4.8755  4.5052
84  -0.1908  0.2337  12.2  4.8730  4.5025
85  -0.1908  0.2330  12.1  4.8690  4.4980
86  -0.1910  0.2322  13.5  4.8660  4.4948
87  -0.1902  0.2315  13.6  4.8637  4.4922
88  -0.1902  0.2308  13.5  4.8615  4.4897
89  -0.1900  0.2301  13.2  4.8595  4.4873
90  -0.1898  0.2294  13.3  4.8570  4.4767
91  -0.1898  0.2287  13.1  4.8527  4.4808
92  -0.1895  0.2279  12.9  4.8500  4.4650
93  -0.1895  0.2272  12.9  4.8463  4.4738
94  -0.1890  0.2266  13.2  4.8448  4.4590
95  -0.1887  0.2259  13.2  4.8415  4.4685
96  -0.1887  0.2252  12.9  4.8383  4.4513
97  -0.1887  0.2245  12.5  4.8355  4.4625
98  -0.1887  0.2238  12.7  4.8323  4.4465
99  -0.1880  0.2232  12.5  4.8298  4.4560
100 -0.1883  0.2224  12.2  4.8273  4.4535
Press any key when ready...
```

### *Aborting the Data Listing*

## **6.0 PRINTING DATA ON PRINTER**

---

Use this MASTER MENU option to print you data on the printer, in columnar format. Printing will continue until all data points have been printed.

## **7.0 SAVING TEXT FILES**

---

This MASTER MENU option saves the currently loaded data as a text file suitable for direct Import into Lotus™ or similar spreadsheets. Use the Lotus™ /FIN (File-Import-Number option) or similar spreadsheet command.

Text files are named LOG###.PRN and occupy much more disk space than the binary experiment files, so you may want to erase them to save disk space.

See the DISK FILE FORMATS section of this manual for more information.

## 8.0 EDITING PLOT LABELS

---

This MASTER MENU option lets you choose PLOT LABELS for any channel.

PLOT LABELS are text on the HOT PLOT graph to identify the data from each individual channel. The graph TITLE or other notes about your data, can also be changed

For example, you might label channel 1 as “Boiler Room Temperature”. The label would be displayed near the channel 1 description on the HOT PLOT screen.

Current Value: Sample Experiment

LABEL PLOT AND CHANNELS

/LOG001

PLOT TITLE

Sample Experiment

NOTE:

Your Experiment Notes Can Be Kept Here

USE ↑ AND ↓ TO MOVE CURSOR

HIT RETURN TO CHANGE

Esc=MENU

*Editing Plot Labels Screen*

The PLOT TITLE appears at the top of the HOT PLOT screen.

The PLOT LABELS appears at the bottom of the HOT PLOT screen, next to the appropriate channel number, voltage channels display their m & b values if you enter no PLOT LABEL.

PLOT LABELS are saved in the EXPERIMENT files, for later use. When you read new data from a Logger, the software asks if you wish to reuse the existing PLOT LABELS. Answer YES to use the labels or NO to erase any labels you have previously established.

Use the cursor keys to highlight the label you wish to change then type your text and press RETURN to move to the next label. Press ESC to display the next screen of labels, then return to the MASTER MENU.

Current Value:

	LABEL PLOT AND CHANNELS	/LOG001
CHANNEL 1:		
CHANNEL 2:		
CHANNEL 3:		
CHANNEL 4:	Temp of Heatsink	
CHANNEL 5:	Air Stack Output	
CHANNEL 6:	To Mesh inside	
CHANNEL 7:	Bottom Mesh ins	
CHANNEL 8:	Post Heater	
CHANNEL 9:	Case	
CHANNEL 10:	Shield	
CHANNEL 11:		
CHANNEL 12:		
CHANNEL 13:		
CHANNEL 14:		
CHANNEL 15:		
CHANNEL 16:		
CHANNEL 17:		
CHANNEL 18:		
CHANNEL 19:		
CHANNEL 20:		

USE ↑ AND ↓ TO MOVE CURSOR    HIT RETURN TO CHANGE    Esc=MENU

*Second Screen of Plot Labels*

## 9.0 HOT PLOT


---

This MASTER MENU option graphs your data and provides you with analysis tools.

HOT PLOT was designed for use with either a Mouse or Keyboard interface and this manual has separate sections for each. Refer to the FUNCTION KEY INTERFACE or the MOUSE INTERFACE section of this manual, depending upon your equipment.

Press ESC to exit HOT PLOT and return to the MASTER MENU.

The following sections describe the various elements of the HOT PLOT screen.



### *Areas of the HOT PLOT graphic screen*

The PLOT area displays a graph of your data, in XY format.


The CHANNEL DATA area shows the channel numbers, descriptions, plot labels, sample times (or point numbers), data values and several status indicators. You can consider this the HOT PLOT control center.

When you expand a portion of the graph to fill the entire PLOT area, the small PLOT MAP reminds you which portion you are viewing.



## 9.1 FILE NAME, PLOT TITLE, and TIME STAMP

The top of the HOT PLOT screen shows the FILE NAME, PLOT TITLE TIME STAMP.



**HOT PLOT Screen**


The FILE NAME is the name of the currently loaded experiment file. If you have not saved the data to a file, you will see "?????" in this location.

Use the EDIT PLOT LABELS option in the MASTER MENU to create or change the PLOT TITLE.

If you are using a mouse, place the pointer outside the PLOT area to see the TIME STAMP. If the pointer is within the PLOT area, the TIME STAMP is replaced by X-Y CURSOR DATA (a display showing the data value and time at the pointer position.)

## 9.2 DATA PLOTS AND AXES

You can choose which channels to display on the HOT PLOT graph but the software always begins by plotting the first five active channels. If you use a color monitor, each channel will be plotted in a different color.



### Data Plots & Axis

The **X** (horizontal) axis represents time (or point #) and the **Y** (vertical) Axis shows the values of the data points. The values are also shown in the CHANNEL DATA, below the PLOT area.


The **Y-AXIS LABELS** (to the left of the graph) include the channel number, range of values and units. If no channels are linked together, then the **Y-AXIS LABELS** shows the information for the channel that you've selected.

For example, if you select the channel 2 button, the **Y-AXIS LABELS** will show channel 2 information. To display the **Y-AXIS LABELS** for channel 3, select channel it, instead.

See the CHANNEL SELECT & LINK BUTTONS section for more information.

## 9.3 X-DATA CURSORS

Three vertical cursors terminate in boxes along the X-AXIS. You can position each cursor anywhere on the graph.



*X-DATA Cursors and X-DATA Table*

To move a cursor with a Mouse, click on the box at the base of the cursor and drag it to a new position.

To move a cursor from the keyboard, first select it with a function key (F1 thru F3), and then use the left or right cursor keys to reposition it. Notice that the selected cursor's box will be red.

Cursor position determines the values in the X-CURSOR DATA TABLE below the graph.

## 9.4 X-CURSOR DATA TABLE

---

The CHANNEL DATA area at the bottom of the HOT PLOT screen includes three columns of data, one for each cursor. Each column shows the time (or point #) where a cursor is positioned and the data value on each active channel at that point. Move a cursor and notice that the time (or point #) and data values change accordingly.

If you are using a Keyboard with a large experiment file, the cursor may seem sluggish, although the data in the cursor data table will change. This is because the display screen has more data points than pixels. The cursor will accelerate if you hold the key down and you can release the key momentarily to fine-tune the cursor placement. Don't worry about crossing another cursor; it will move out of your way.

Press F9 to toggle the CHANNEL DATA display from TIME to SAMPLE POINT # and back.


## 9.5 CHANNEL SELECT AND LINK BUTTONS

The CHANNEL DATA AREA includes three columns of boxes that control and indicate the settings for the current HOT PLOT graph. The left-hand column of boxes show which channel is used for the Y-AXIS LABELS. Only one box may be selected at a time. The center column determines which channels are linked together on common Y-AXIS. The right-hand column indicates which channels are currently selected (displayed on the HOT PLOT screen). The boxes toggle between selected & deselected (filled & hollow).

If you have a Mouse you can select which channels to graph or link together by pointing & clicking on the boxes (a filled box is selected). To access the data for additional channels, click on the bright line at the bottom of the cursor data area.

If you are using a Keyboard, press the number keys (1 thru 5) to select channels to graph. Use ALT and the number keys (ALT-1 thru ALT-5) to link the selected channels together. Use CTL and the function keys (CTL-F1 thru CTL-F5) to select an Y-AXIS LABEL. Press F10 to access the data for additional channels.

In the following illustration, channels 2,3,4,9 and 10 are plotted and channels 3 and 4 are linked on a common Y-SCALE, with CH3 as the Y-AXIS LABEL.



*Channel Control Buttons*

The software initially expands each plot line (vertically) to fill the entire screen. You can see all of the data but each channel is shown with a different Y-scale. To compare the plot lines from several channels on a common Y-scale, you must LINK the lines together.


When you LINK plot lines together, you force them to the same Y-scale. This is very useful if you have several temperature channels you want to plot to the same scale. The Y-AXIS LABELS will still show the last channel you selected, but the range will change to include the other linked channels.

A side effect of linking channels with large differences in magnitude is that some may plot along the top or bottom of the graph and be difficult to see.

## 9.6 HELP MENU

Press F8 to see the HELP MENU pop down from the top of the screen.

The HELP MENU lists all available Keyboard functions. Most functions require only a single keystroke but some are ALT-key or CTL-key combinations. An "ALT-key combination" means pressing and holding the ALT key, then pressing the desired number-key, then releasing both keys. A CTL-key combination has a similar meaning.



*HOT PLOT Help Menu*

Press ESC to hide the Help Menu.

## **9.7 FUNCTION KEY INTERFACE**

---

The FUNCTION KEY INTERFACE lets you control the HOT PLOT screen from a keyboard.

Use the function keys if you have no mouse. All but two of the software features are available from either the Keyboard or Mouse interfaces. The PRINTING and POINT/TIME functions are available only from the Keyboard.

Graphic displays can occasionally require a moment to redraw the screen. This is a hardware limitation but the software package includes a keyboard buffer to minimize these delays. You can press several keys in rapid succession and the package will respond as soon as the PC hardware catches up to the software.

### **9.7.1 X-CURSOR SELECT KEYS (F1 thru F3)**

---


Use function keys F1 thru F3 to select one of the X-CURSORS. The selected cursor will terminate in a solid box at the X-AXIS and will move with the left and right arrow keys.

When a cursor is selected, you can use the left and right-arrow keys to position it anywhere along the X-AXIS of the graph.



### 9.7.2 CHANNEL SELECT KEYS (NUMBERS 1 thru 5)

Use F10 to choose which five channels are shown in the CHANNEL DATA AREA on your screen. Then use the number keys (1 thru 5) along the top of your keyboard to choose which of those channels to display on the HOT PLOT screen. Each key toggles the associated channel "ON" or "OFF"



*Channel Selection Window*

The HOT PLOT screen is redrawn whenever the channel selections are changed. You can minimize the delay by pressing several keys quickly.

### 9.7.3 CHANNEL LINK KEYS (ALT-1 thru ALT-5)

Use the ALT key in combination with the number keys (1 thru 5) to LINK groups of channels to a common Y-AXIS range. Each ALT-key combination toggles the associated channel on or off.

The HOT PLOT screen is redrawn whenever the channel selections are changed. You can minimize the delay by pressing several keys quickly.


## 9.7.4 SCALE PLOT KEYS (F5 and F6)

Function keys F5 and F6 select X (horizontal) or Y (vertical) re-scaling or zooming. Either key will produce a HELP MENU and a flashing bar along one axis of the graph.

Use the keyboard arrow keys to position the flashing bar at the portion of the graph you wish to expand, then press RETURN. The graph will be re-plotted, enlarging your area, and small plot map will appear in the lower left corner of the HOT PLOT screen.

The small plot map shows your selected portion within the entire graph. On color monitors the selected area will be red.

The illustration below shows an X-AXIS ZOOM, from the keyboard, in progress. The flashing bar is highlighted the left portion of the X-axis and the menu at the top gives directions.



### *X-AXIS Zoom From Keyboard*

You can re-scale (zoom) either axis 10 times, or until too few data points would be displayed on the HOT PLOT screen. When a warning message advises that you've reached this limit, press ESC to clear the warning.

To return to the original, entire plot, press END instead of RETURN.

### **9.7.5 PRINT SCREEN KEY (F7)**

---

Press F7 to print the current HOT PLOT screen image on your printer.

The image includes a header containing the labels you have chosen from the MASTER MENU and information like the Log interval to specify the conditions in which the data was acquired.

Use the MASTER MENU's SOFTWARE CONFIGURATION option to change your printer selection and edit the channel data labels.


Use the MASTER MENU's EDIT PLOT LABELS option to change the remaining labels on your plots.

The software supports most nine-pin black and white dot matrix printers and some color printers that use ribbons or ink-jets. See the README file on your distribution diskette for other options and late developments.

## 9.8 MOUSE INTERFACE

The MOUSE INTERFACE lets you control the HOT PLOT screen directly, to get the most from your software package. If you have no mouse, use the function keys instead. All software features are available with either the Mouse or Keyboard interfaces except PRINTING and POINT/TIME toggling, which must be done from the keyboard.

Graphic displays can occasionally require a moment to redraw the screen. This is a hardware limitation but the software package is designed to minimize these delays. Most operations are quicker with the mouse than the keyboard and the RESALE or MAGNIFY function has more range.



*Mouse Interface*

## 9.8.1 MOUSE AND MOUSE POINTER

---

This is a list of common terms you will find in the Mouse realm and in this Manual:

**MOUSE:** A computer “mouse” is a small box that is moved about on a flat surface by hand. It sends signals to the computer telling how far and in which direction it has been moved. A mouse usually includes one or more push buttons called “mouse buttons”.

**POINTER:** When the mouse is moved, a visible marker on the computer’s screen moves a corresponding distance and direction. This marker is called the “mouse pointer” and is used to point to something on the screen. The pointer is usually shaped like an arrow.

**CLICKING:** The mouse buttons are clicked to select or activate something. Press and release either mouse button quickly to “click” it.

**PRESSING:** The mouse button can be pressed to cause a continuous action. Press the mouse button and hold as long as you want the action to continue.

**DRAGGING:** To “drag” something, first point at it, then press and hold the mouse button while you move the mouse. Use this function to select a menu option or to move an object on the screen. Release the button when you are at the desired location or selection.

### 9.8.2 X-Y READOUT

---

When the mouse pointer is within the borders of the PLOT AREA, the TIME STAMP information at the top, right corner of your screen is replaced by the X and Y READOUT.

This is a fast way to get information from your HOT PLOT graph because you can use the Mouse to read TIMES and VALUES anywhere on the plot.

The X and Y READOUT shows the DAY, TIME and Y-AXIS VALUE at the place where the pointer is currently positioned. The DAY and TIME are shown in DD-HH-MM-SS format.

For example, **1-12:33:22** means day1, 12 hours, 33 minutes, 22 seconds.

If you have several channels of data on the graph, the Y-AXIS VALUE belongs to the channel identified by the Y-AXIS LABELS, along the left side of the graph. It will be the last channel you selected. On color displays, the PLOT and the LABELS will be the same color.

**NOTE: Screen resolution may limit the accuracy of those x-y readout values to less than that of the actual data displayed in the x-cursor data table near the bottom of your screen.**

The X-Y READOUT can also give DELTA information: When using the MAGNIFY TOOL (see below), the absolute Y-Y values described above are replaced with DELTA-X and DELTA-Y values which are the lengths of the sides of the magnification rectangle.

### **9.8.3 CHANNEL SELECT AND LINK BUTTONS**

---

The CHANNEL DATA area includes two columns of square boxes or BUTTONS to the left of the channel descriptions.


The CHANNEL SELECT BUTTONS, in the right-hand column, determine which channels are displayed on the HOT PLOT screen. Each button toggles the associated channel "ON" or "OFF"

To select a channel, point and click on the appropriate button. A selected button will be filled-in. On color displays, the button will be red. Any number of channels may be selected or deselected before releasing the button and replotting all channels.


The CHANNEL LINK BUTTONS, in the left-hand column, determine which channels are displayed on common Y-AXIS. Selected channels will be scaled together. The multi-channel select/deselect feature described above also works when linking channels and saves replotting time.

See the FUNCTION KEY INTERFACE section for more information.

The following two screens showing channels 9 and 10 before and after linking them together:



*Channels 9 and 10 Before Linking*




*Channels 9 and 10 After Linking*



## 9.8.4 MAGNIFY TOOL

Select the MAGNIFY TOOL by pointing and clicking on the MAGNIFIER symbol in the upper left corner of the HOT PLOT screen. The pointer will become a "+" and a small message box will appear advising you to "Click and Drag to Select Area". This means to move the pointer to the upper left corner of the area you want to magnify, press and hold the mouse button, then move the mouse to "drag out" a rectangle enclosing the area you want to magnify. Release the mouse button to inflate replotting. If you have selected an area too small to magnify, a warning message will appear. To proceed, click the CANCEL box or press ESC.


While you are drawing the rectangle, the X-Y READOUT displays the its size. You can use the READOUT to select a particular span of time or Y-axis values to display.



*Magnify Tool after Click and Drag, Before Release*

When you release the button, the rectangle you selected will be re-plotted to fill the entire graph. A small plot map will also appear at the lower left of the screen. The small map shows your selected portion within the entire graph. On monitors the selected area will be red.

You can re-scale (zoom) either axis 10 times, or until too few data points would be displayed on the HOT PLOT screen. When a warning message advises that you've reached this limit, press ESC to clear the warning.



### *Magnify Tool after Click and Drag, After Release*

You may de-magnify one or more levels at any time by clicking in the small PLOT MAP at the level that you want to return to. Clicking on the PLOT MAP always causes you to de-magnify at least one level.

## 10.0 QUITTING

Press "Q" to quit the program from the MASTER MENU.

To quit from the HOT PLOT screen, press ESC to return to the MASTER MENU, then press "Q".

If you have not saved your data, the software will prompt you to save it when you QUIT the program.

## **11.0 DISK FILE TYPES**

---

Data transferred from the Logger to a PC can be stored to disk in two formats:

EXPERIMENT FILES (LOG###.BIN) are stored in binary format to conserve disk space. Experiment files contain the Logger data and the labels you assign from the MASTER MENU. Experiment files are the primary storage medium for the software package and can be recalled from disk at any time.

You may also save the data in TEXT FILES (LOG###.PRN) for export to other software packages, like spreadsheets. Although the software can write both types of files, it can only read the BINary files.

The software always loads LOG001.BIN when it starts. You may then load other, existing experiment files or read data from the Logger and create new files as necessary.

Experiment files are automatically numbered when saved to disk. You can control the numbers from the MASTER MENU by selecting the option to MODIFY SOFTWARE CONFIGURATION.

If you graph your data before saving it to disk, it has no filename. The “name” is displayed on the graph as LOG??? to remind you to save the data before exiting to DOS.

In general, the software is designed to help you avoid losing your data.

## **12.0 READINGS AND DATAPPOINTS**

---

A READING is a set of data points taken on all active Logger channels. For example, if the Logger is logging every five minutes, with three active channels, then a new reading, containing three data points, is stored every five minutes.