



User's Guide


Shop online at

omega.com™

Ω OMEGA™

www.omega.com

e-mail: info@omega.com



FSW-30A Industrial Flow Switch



OMEGAnet® Online Service
www.omega.com

Internet e-mail
info@omega.com

Servicing North America:

USA:
ISO 9001 Certified One Omega Drive, Box 4047
Stamford CT 06907-0047
Tel: (203) 359-1660 FAX: (203) 359-7700
e-mail: info@omega.com

Canada:
976 Bergar
Laval (Quebec) H7L 5A1
Tel: (514) 856-6928 FAX: (514) 856-6886
e-mail: info@omega.ca

For immediate technical or application assistance:

USA and Canada: Sales Service: 1-800-826-6342 / 1-800-TC-OMEGA®
Customer Service: 1-800-622-2378 / 1-800-622-BEST®
Engineering Service: 1-800-872-9436 / 1-800-USA-WHEN®
TELEX: 996404 EASYLINK: 62968934 CABLE: OMEGA

Mexico: En Español: (001) 203-359-7803 e-mail: espanol@omega.com
FAX: (001) 203-359-7807 info@omega.com.mx

Servicing Europe:

Benelux: Postbus 8034, 1180 LA Amstelveen, The Netherlands
Tel: +31 (0)20 3472121 FAX: +31 (0)20 6434643
Toll Free in Benelux: 0800 0993344
e-mail: nl@omega.com

Czech Republic: Rudé armády 1868, 733 01 Karviná 8
Tel: +420 (0)69 6311899 FAX: +420 (0)69 6311114
Toll Free: 0800-1-66342 e-mail: czech@omega.com

France: 9, rue Denis Papin, 78190 Trappes
Tel: +33 (0)130 621 400 FAX: +33 (0)130 699 120
Toll Free in France: 0800-4-06342
e-mail: france@omega.com

Germany/Austria: Daimlerstrasse 26, D-75392 Deckenpfronn, Germany
Tel: +49 (0)7059 9398-0 FAX: +49 (0)7056 9398-29
Toll Free in Germany: 0800 639 7678
e-mail: sales@omega.com

United Kingdom: One Omega Drive, River Bend Technology Centre
ISO 9002 Certified Northbank, Irlam, Manchester
M44 5EX United Kingdom
Tel: +44 (0)161 777 6611 FAX: +44 (0)161 777 6622
Toll Free in United Kingdom: 0800-488-488
e-mail: sales@omega.co.uk

It is the policy of OMEGA to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct, but OMEGA Engineering, Inc. accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.


WARNING: These products are not designed for use in, and should not be used for, patient-connected applications.

Features


- Supplied With 6 Orifices to Provide 6 Overlapping Flow Ranges From 0.12 to 8.0 GPM for Water
- Responds to Flow Independent of a Broad Range of Environmental Conditions
- Switch Point Adjustable Without Removing Unit From Line
- Mount in Any Position
- 15A SPDT Switch Directly Controls Pump
- Maintains Calibration Limits When Subjected to Reasonable Line Hydraulic Hammer or Surge Pulses
- Easy Screw Terminal Wiring – No Soldering
- Line Pressure to 400 PSIG
- Temperature to 180°F Continuous
- NPT Threaded to Pipe Directly In-Line
- Rugged Industrial Design
- Working Fluids: Pure Water, Tap Water, Filtered Sewage Water, Alcohols, Oils, Glycols, Soap Solutions (check chemical capacity of all wetted materials)

WARNING

These units are not compatible with gasoline; nor are they intended for use with flammable liquids without the proper safety precautions, such as the use of intrinsic safety relays.



FSW-30



Specifications

Flow Range (Water Calibrated @ 70°F):

Orifice #	Orifice I.D. (Inches)	GPM
1	0.073 (DRILL No. 49)	0.12 to 0.25
2	0.0935 (DRILL No. 42)	0.25 to 0.50
3	0.1495 (DRILL No. 25)	0.50 to 1.0
4	0.196 (DRILL No. 9)	1.0 to 2.0
5	0.277 (DRILL LETTER J)	2.0 to 4.0
6	0.375 (DRILL SIZE 3/8)	4.0 to 8.0

Sensitivity (% Flow Change

To Activate Switch): 5% at upper end of flow range;
25% at lower end of flow range

Differential Pressure Drop Across Unit:

(Under Normal Operating Conditions)
1.0 PSI at lower end of flow range;
5.0 PSI at upper end of flow range

Working Line Pressure:

400 PSIG max. @ 180°F max.
(proof tested to 1200 PSIG @ 180°F)

Maximum Continuous Temperature:

180°F

Relay Switch:

SPDT 15A @ 125 or 250 Vac, 10,000,000
operations median; switch may be
overloaded to 20 amps @ 125 or 250
Vac for a minimum of 20,000 operations

Option "D":

Dual SPDT relays; nominal difference
flow between the two relay actuation
points is 5%

Electrical Cable Fitting:

Water resistant for cable diameter
.250" ± .025"

Materials:

Wetted Parts: red brass, 302-304 SS,
phosphor bronze, Buna-N, EPDM,
Noryl (pitot tube), PVC (orifice). Other
materials of construction: brass body,
Noryl cover, stainless steel and
plastic hardware.

Weight:

3.5 lb.

Installation and Operating Instructions

WARNING


THE GASKET SEAL LOCATED BETWEEN THE MAIN BODY CASTING AND THE LID CASTING IS A CORK-RUBBER COMPOSITION WHICH IS SUBJECT TO A SLIGHT CREEP FOR A SHORT PERIOD AFTER APPLICATION OF INITIAL CLAMPING LOAD. ALL GASKETS ARE PROPERLY CLAMPED BEFORE SHIPMENT, HOWEVER, DURING SHIPPING AND STORAGE, THE GASKET MAY COMPRESS ALLOWING THE BODY-LID CLAMP BOLTS TO BECOME SLIGHTLY LOOSE. TIGHTEN THESE BOLTS BEFORE ASSEMBLING THE FLOW SWITCH IN THE SYSTEM. NO FURTHER CREEP OF GASKET WILL OCCUR AFTER SECOND TIGHTENING.

The FSW-30 Fluid Flow Switch is supplied with tapped holes for standard 1/2" pipe. Insert the FSW-30 in line with the arrow on the side of the casting pointed in the direction of flow. (Refer to FLOW TURBULENCE EFFECTS for additional installation considerations.)

NOTE

Care should be exercised to prevent pipe thread sealant (putty, Teflon tape, etc.) from entering the flow switch and restricting flow through the calibrated orifice.

INSTALLATION DIMENSIONS



Terminal Strip Wiring

1. Loosen the round gland nut located on the strain relief cable connector.
2. Insert the cable through the grommet in the strain relief cable connector and tighten the gland nut sufficiently to seal the cable in place.
3. Strip the conductor ends approximately 3/16".
4. Loosen the appropriate terminal strip screw and remove the empty terminal. Insert the bare wire into the terminal barrel and crimp. Place the terminal on the strip in the SAME orientation as received. This is important since terminals and wires may interfere with the cover if the orientation is changed.

Electrical Wiring Schematics

Figure 1: Wiring Schematic for power applied to load when the flow is GREATER than the set point (power to load is interrupted when flow is LESS than the set point).





Figure 2: Wiring Schematic for power applied to load when the flow is LESS than the set point (power to load interrupted when flow is GREATER than the set point).



Switch Point Adjustment

1. Remove the cover.
2. Adjust the fluid flow in the system to the desired rate without regard to the FSW-30 switch point setting.
3. The switch point adjusting mechanism consists of an adjusting screw, a "U" shaped leadscrew nut, and a helical spring.

CLOCKWISE rotation of the adjusting screw changes the microswitch actuation point toward HIGHER flow rates (COUNTERCLOCKWISE rotation towards LOWER flow rates).

NOTE

All the FSW-30 Switches are factory set at the lower end of the flow range, i.e., the adjusting screw is set at the low flow counterclockwise position.

The leadscrew nut locks the adjusting screw in position, maintaining the flow switch set point under all environmental conditions.

4. Turn the adjusting screw in a clockwise direction until the microswitch is actuated while maintaining the desired fluid flow rate in the system. Turn the adjusting screw TWO additional turns in the clockwise direction and then slowly back off in a counterclockwise direction until the microswitch is again actuated. The FSW-30 Switch is now set for maximum sensitivity for detecting small flow changes.
5. The microswitch actuation point may be monitored during the adjustment procedure detailed in Step 4 above by an audible click or with an Ohm meter before connecting line power to the terminal strip or by monitoring the voltage supplied to the load through the microswitch.
6. If the system flow rate is changed, the FSW-30 can be adjusted to monitor the new flow rate by turning the adjustment screw in a counterclockwise direction to the minimum flow position and then proceeding as in Step 4 above.
7. In the event that the system flow is at the desired rate and the adjustment mechanism runs out of travel, i.e. the leadscrew nut is at either end of the support bracket and the microswitch still has not been actuated, then the orifice must be changed to shift the flow switch flow range so that it straddles the system flow rate.

EXAMPLE:

If the FSW-30 is fitted with a No. 3 orifice (range 0.50 to 1.0 GPM), the procedure in Step 4 is followed, the adjusting screw is turned clockwise until the leadscrew nut is at the upper limit of the support bracket and the microswitch still has not been actuated, then the flow is greater than 1.0 GPM and No. 4 orifice will have to be substituted for No. 3 orifice and the procedure in Step 4 is repeated.

General Rules for Selecting a New Orifice

If the system flow is at the proper rate and the procedure in Step 4 has been followed, the leadscrew nut is at the UPPER EXTREME of the support bracket, and the microswitch has not actuated, remove the present orifice, insert the next LARGER size and repeat the procedure in Step 4.

If the system flow is at the proper rate and the procedure in Step 4 has been followed, the leadscrew nut is at the LOWER EXTREME of the support bracket, and the microswitch has not actuated, remove the present orifice, insert the next SMALLER size and repeat the procedure in Step 4.

Changing The Orifice

NOTE

It is not necessary to remove the main body of the switch from the line to change the orifice.

Refer to FSW-30 Parts List Diagram.

1. Remove the cover.
2. Remove the lid casting from the main body casting.
3. Remove the 1/8" diameter orifice retaining pin.
4. Insert a small screw driver blade in the groove located in the exposed end of the orifice and pry the orifice toward the body cavity.
5. Drop the new orifice into the body cavity with the "O" ring toward the upstream hole and press in place.
6. Insert the 1/8" orifice retaining pin. Ensure that the pin is properly located in the groove provided in the orifice.

Flow Turbulence Effects

The FSW-30 Flow Switches are sensitive and fast acting. They respond to pipe system steady flow and also to local time variable turbulent flow caused by valves, pumps, elbows, orifices, etc. For instance, the average steady state flow in a 4" line immediately downstream of a gate valve may be 100 GPM, however, the gate valve may produce turbulence which rapidly changes the downstream flow in a random fashion in the range 90 to 110 GPM. A flow switch set at 100 GPM steady state will chatter in the 90 to 110 GPM turbulent environment. Several different procedures can be employed to correct the chatter condition.


1. Locate the flow switch at least 5 (and preferably 10) pipe diameters downstream of the source of turbulence.
2. Place a turbulence reducing section between the turbulent source and the flow switch, e.g., fill the main pipe with a bundle of small diameter thin wall tubes for 1 or 2 pipe diameters, or fill the pipe for 1 or 2 diameters with a metal or plastic gauze similar to a scouring pad.

Both techniques reduce turbulence effects by breaking large intense flow swirls into a multitude of small less intense flow swirls. A suitable screen will have to be employed to retain the tubes or gauze. Consideration will have to be given to pressure loss effects.

3. Another approach is to "de-tune" the flow switch, i.e., to set it to operate below the lower turbulence induced flow rate. In the 4" example cited above, the adjusting spring could be relaxed so that the switch is activated at 90 GPM or slightly lower. In any given field situation, this is simply accomplished by relaxing the adjusting spring until the chattering ceases.

NOTE

To retain the proper sensitivity, some spring tension is required, i.e., approximately 25% extension minimum (approximately 1/4"). If this 25% spring extension condition is reached and chattering still occurs, then the next smaller size orifice will have to be used.





Notes



WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **13 months** from date of purchase. OMEGA's Warranty adds an additional one (1) month grace period to the normal **one (1) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components which wear are not warranted, including but not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by it will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESS OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

RETURN REQUESTS/INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT IN ORDER TO AVOID PROCESSING DELAYS. The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of the product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 2000 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.

Where Do I Find Everything I Need for Process Measurement and Control? **OMEGA...Of Course!**

Shop online at www.omega.com

TEMPERATURE

- Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- Wire: Thermocouple, RTD & Thermistor
- Calibrators & Ice Point References
- Recorders, Controllers & Process Monitors
- Infrared Pyrometers

PRESSURE, STRAIN AND FORCE

- Transducers & Strain Gages
- Load Cells & Pressure Gages
- Displacement Transducers
- Instrumentation & Accessories

FLOW/LEVEL

- Rotameters, Gas Mass Flowmeters & Flow Computers
- Air Velocity Indicators
- Turbine/Paddlewheel Systems
- Totalizers & Batch Controllers

pH/CONDUCTIVITY

- pH Electrodes, Testers & Accessories
- Benchtop/Laboratory Meters
- Controllers, Calibrators, Simulators & Pumps
- Industrial pH & Conductivity Equipment

DATA ACQUISITION

- Data Acquisition & Engineering Software
- Communications-Based Acquisition Systems
- Plug-in Cards for Apple, IBM & Compatibles
- Datalogging Systems
- Recorders, Printers & Plotters

HEATERS

- Heating Cable
- Cartridge & Strip Heaters
- Immersion & Band Heaters
- Flexible Heaters
- Laboratory Heaters

ENVIRONMENTAL MONITORING AND CONTROL

- Metering & Control Instrumentation
- Refractometers
- Pumps & Tubing
- Air, Soil & Water Monitors
- Industrial Water & Wastewater Treatment
- pH, Conductivity & Dissolved Oxygen Instruments