

**YEAR  
2000  
COMPLIANT**



# User's Guide



**omega.com<sup>®</sup>**  
CEOMEGA<sup>®</sup>

*http://www.omega.com*  
*e-mail: info@omega.com*

## **CN3410 SERIES 1/8 DIN Panel Mount Universal Temperature & Process Controller**



<b>OMEGAnet® On-Line Service</b> <a href="http://www.omega.com">http://www.omega.com</a>	<b>Internet e-mail</b> <a href="mailto:info@omega.com">info@omega.com</a>
---	--

### Servicing North America:

**USA:**  
ISO 9001 Certified

One Omega Drive, Box 4047  
Stamford, CT 06907-0047  
Tel: (203) 359-1660 FAX: (203) 359-7700  
e-mail: [info@omega.com](mailto:info@omega.com)

**Canada:**

976 Bergar  
Laval (Quebec) H7L 5A1  
Tel: (514) 856-6928 FAX: (514) 856-6886  
e-mail: [info@omega.ca](mailto:info@omega.ca)

### For immediate technical or application assistance:

**USA and Canada:** Sales Service: 1-800-826-6342 / 1-800-TC-OMEGA<sup>SM</sup>  
Customer Service: 1-800-622-2378 / 1-800-622-BEST<sup>SM</sup>  
Engineering Service: 1-800-872-9436 / 1-800-USA-WHEN<sup>SM</sup>  
TELEX: 996404 EASYLINK: 62968934 CABLE: OMEGA

**Mexico and Latin America:**

Tel: (95) 800-826-6342 FAX: (95) 203-359-7807  
En Español: (95) 203-359-7803 e-mail: [espanol@omega.com](mailto:espanol@omega.com)

### Servicing Europe:

**Benelux:**

Postbus 8034, 1180 LA Amstelveen, The Netherlands  
Tel: (31) 20 6418405 FAX: (31) 20 6434643  
Toll Free in Benelux: 0800 0993344  
e-mail: [nl@omega.com](mailto:nl@omega.com)

**Czech Republic:**

ul. Rude armady 1868, 733 01 Karvina-Hranice  
Tel: 420 (69) 6311899 FAX: 420 (69) 6311114  
Toll Free: 0800-1-66342 e-mail: [czech@omega.com](mailto:czech@omega.com)

**France:**

9, rue Denis Papin, 78190 Trappes  
Tel: (33) 130-621-400 FAX: (33) 130-699-120  
Toll Free in France: 0800-4-06342  
e-mail: [france@omega.com](mailto:france@omega.com)

**Germany/Austria:**

Daimlerstrasse 26, D-75392 Deckenpfromm, Germany  
Tel: 49 (07056) 3017 FAX: 49 (07056) 8540  
Toll Free in Germany: 0130 11 21 66  
e-mail: [info@omega.de](mailto:info@omega.de)

**United Kingdom:**

ISO 9002 Certified

One Omega Drive, River Bend Technology Centre  
Northbank, Irlam, Manchester  
M44 5EX, United Kingdom  
Tel: 44 (161) 777-6611 FAX: 44 (161) 777-6622  
Toll Free in the United Kingdom: 0800-488-488  
e-mail: [info@omega.co.uk](mailto:info@omega.co.uk)

It is the policy of OMEGA to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct, but OMEGA Engineering, Inc. accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

**WARNING:** These products are not designed for use in, and should not be used for, patient-connected applications.

---

# GETTING STARTED

---

This manual is divided into 5 sections which contain all the information needed to install, configure, set up and operate the instrument. Each section is identified clearly by a symbol as shown below.



## Displays and Function Keys

- Displays and function keys
- LED Indication
- Error Messages



## Operator Mode (Level 1)

- Operator menus for:
  - *Standard controller*
  - *Heat/Cool controller*
  - *Remote Set Point controller*
  - *Profile controller*
  - *Multiple Fixed Set Points controller*
- Auto tuning



## Set Up Mode (Levels 2, 3 and 4)

- Level 2 – Tuning
- Level 3 – Set Points
- Level 4 – Profile



## Configuration Mode (Levels 5 and 6)

- Level 5 – Basic hardware and control functions
- Level 6 – Ranges and passwords



## Installation

- Siting
- Mounting
- Electrical connections

## Symbol Identification and Section Contents

---

# CONTENTS


---

<b>1</b>	<b>DISPLAYS AND FUNCTION KEYS .....</b>	<b>3</b>
1.1	Introduction .....	3
1.2	Use of Function Keys .....	4
1.3	LED Alarms and Indicators .....	5
1.4	Error Messages .....	6
<b>2</b>	<b>OPERATOR MODE .....</b>	<b>7</b>
2.1	Introduction .....	7
2.2	Standard Controller .....	8
2.3	Heat/Cool Controller .....	9
2.4	Remote Set Point Controller .....	10
2.5	Profile Controller .....	12
2.6	Multiple Fixed Set Points Controller .....	14
2.7	Auto-tune .....	16
<b>3</b>	<b>SET UP MODE .....</b>	<b>18</b>
3.1	Introduction .....	18
3.2	Tuning (Level 2) .....	18
3.3	Set Points (Level 3) .....	22
3.4	Profile (Level 4) .....	25
<b>4</b>	<b>CONFIGURATION MODE .....</b>	<b>28</b>
4.1	Introduction .....	
4.2	Accessing the Configuration Mode .....	28
4.3	Basic Hardware and Configuration (Level 5) .....	30
4.4	Ranges and Passwords (Level 6) .....	40
<b>5</b>	<b>INSTALLATION .....</b>	<b>43</b>
5.1	Siting .....	43
5.2	Mounting .....	45
5.3	Electrical Connections .....	47
5.4	Relays, Arc Suppression and Outputs .....	47



## Information.


The fold-out page inside on the back cover of this manual shows all the frames in the programming levels. Space is provided on the page for writing the programmed setting or selection for each frame.



# 1 DISPLAYS AND FUNCTION KEYS

## 1.1 Introduction – Fig. 1.1

The instrument front panel displays, function keys and LED indicators are shown in Fig. 1.1.



**Fig. 1.1 Front Panel Displays, Function Keys and Indicators**

1.2 Use of Function Keys





Fig. 1.2 Use of Function Keys

## 1.3 LED Alarms and Indicators












### LED Status

- All** • All LED's flashing – controller is in the Configuration Mode.
- A1** • Flashes when Alarm 1 is active (off when inactive).
- A2** • Flashes when Alarm 2 is active (off when inactive).
- R** • On when the controller is operating on the remote set point value.  
 • Off when the controller is operating using the local set point value or one of the four fixed set points (in multiple set point mode).  
 • Flashes when a Ramp/Soak profile is running.
- M** • On when the controller is operating in Manual control mode.  
 • Off when the controller is operating in Auto control mode.  
 • Flashes when the controller is performing an auto-tune.
- OP1** • Indicates output 1 (heat) value is displayed in the lower display.
- OP2** • Indicates output 2 (cool) value is displayed in the lower display.

**Fig. 1.3 LED Alarms and Indicators**

1.4 Error Messages

Display	Error/Action	To Clear Display
	<b>Calibration error</b> Turn power off and on again (if the error persists contact the Supplier).	Press the  key
	<b>Configuration error</b> The configuration and/or setup data for the instrument is corrupted. Turn power off and on again (if the error persists, check configuration/setup settings).	Press the  key
	<b>A to D Converter Fault</b> The analog to digital converter is not communicating correctly.	Turn power off and on again, if the problem persists contact the Supplier
	<b>Process Variable Over/Under Range</b>	Restore valid input
	<b>Remote Set Point Over/Under Range</b> The remote set point value is over or under range. Flashing stops automatically when the remote set point input comes back into range.	Select the local set point ( <i>rSP.n</i> ) in the Operating Page or the Set Points Level
	<b>Option error</b> Communications to the option board have failed.	Contact the Supplier
	<b>Auto-tune error</b> The number displayed indicates the type of error present – see Table 2.1 in Section 2.7.	Press any key





---

## 2 OPERATOR MODE

---

### 2.1 Introduction

Operator Mode (Level 1) is the normal day-to-day mode of the instrument.

Frames displayed in level 1 are determined by the control strategy which is selected during configuration of the instrument – see Section 4.




**Note.** Only the operating frames relevant to the configured strategy are displayed in Operator Mode.

The five control strategies are:

- **Standard controller** – page 8
- **Heat/Cool controller** – page 9
- **Remote Set Point controller** – page 10
- **Profile controller** – page 12
- **Multiple Fixed Set Points controller** – page 14




### 2.2 Standard Controller



- 1 Not displayed if the ramping set point facility is turned off – refer to Section 3.3.




### 2.3 Heat/Cool Controller



•1 Not displayed if the ramping set point facility is turned off – refer to Section 3.3.



### 2.4 Remote Set Point Controller




#### Note.

If the remote set point input fails while selected, the controller automatically selects the local set point value. The upper display changes to *rSPF* and the lower display flashes. When the fault condition is removed, the remote set point is re-selected automatically. To clear the error condition while the remote set point input is still outside its allowed range, select the local set point by pressing the key (*rSPn* is displayed).



...2.4 Remote Set Point Controller



**Ramping Set Point Value (Read only)**

The actual set point value is displayed, i.e. the instantaneous value the controller is working to.

**Security Code**

[0 to 9999]

Select the appropriate security code to access:  
 Auto-tune enable frame (Level 1),  
 Set Up mode (Levels 2, 3, 4).

**Auto-tune Enable**

ON – Auto-tune on  
 OFF – Auto-tune off

Refer to page 16 for the Auto-tune procedure.


**Level 1 (Operator mode)**

See Section 3 for levels 2, 3 and 4.

- 1 Not displayed if the ramping set point facility is turned off – refer to Section 3.3.




### 2.5 Profile Controller





...2.5 Profile Controller



**Ramping Set Point Value (Read only)**

The actual set point value is displayed, i.e. the instantaneous value the controller is working to.

**Security Code**

[0 to 9999]

Select the appropriate security code to access:  
 Auto-tune enable frame (Level 1),  
 Set Up mode (Levels 2, 3, 4).

**Auto-tune Enable**

- ON - Auto-tune on
- OFF - Auto-tune off

Refer to page 16 for the Auto-tune procedure.

**Level 1 (Operator mode)**


See Section 3 for levels 2, 3 and 4.

- 1 Not displayed if the ramping set point facility is turned off – refer to Section 3.3.



### 2.6 Multiple Fixed Set Points Controller

If the Multiple Fixed Set Points Controller type is selected during configuration, four fixed control set points can be set – see Section 4.4.




•1 Not displayed if the ramping set point facility is turned off – refer to Section 3.3.





...2.6 Multiple Fixed Set Points Controller






### 2.7 Auto-tune

#### **i** Information.


- Auto-tune optimizes process control by monitoring process performance and automatically updates the control parameters.
- Before starting auto-tune, the process variable must be stable ( $\pm 2\%$  of engineering range).

#### 1 – 'At start up' auto-tune (from manual mode)




1a – Stable process before auto-tune


#### 2 – 'At set point' auto-tune (from manual or automatic mode)



2a – Stable process before auto-tune




1b – Process response during auto-tune



2b – Process response during auto-tune

**\* Note.** The time taken to complete auto-tune depends upon the system response time.




Process response after auto-tune

Fig 2.1 Typical Auto-tune Cycles




### ...2.7 Auto-tune



From **Security Code** frame (any Operating page).  
The correct password must be entered to access the auto-tune frame.

#### Auto-tune Enable

- ON – Auto-tune on
- OFF – Auto-tune off

Auto-tune can be stopped at any time by pressing the  key.

#### Settings for P + I control only

To tune for P + I control only, set the derivative term to 'OFF' in the Tuning Level – see Section 3.2.

#### Notes.

- On completion, the controller enters auto control mode and begins to control the process using the new PID values. For fine tuning – see Section 3.
- For heat/cool control the cool proportional band is set to the same value as the heat proportional band (this value may need modification).
- If an error occurs during auto-tune, the controller reverts to manual mode with the control output set to the configured output value. An error message is displayed – see Table 2.1.

Error	Description	Error	Description
1	PV failed during auto-tune	7	A resultant P, I or D value was calculated out of range
2	Auto-tune has timed out during an auto-tune step	8	PV limit exceeded (At start up auto-tune)
3	Process too noisy to auto-tune	9	Controller put into configuration mode
4	Process too fast to auto-tune	10	Auto-tune terminated by user
5	Process too slow to auto-tune	11	PV is changing in the wrong direction during step test
6	PV deviated from set point by >25% eng. span during frequency response test		


**Table 2.1 Auto-tune Error Codes**




## 3 SET UP MODE

### 3.1 Introduction


To access the Set Up Mode (Levels 2, 3 and 4) the correct password must be entered in the security code frame (the default password code is 0). Refer to the fold-out sheet at the back of this manual for the contents of these levels.




Refer to the fold-out sheet for the contents of each level



### 3.2 Tuning (Level 2) – Fig. 3.2



#### Level 2 – Tuning Level

 **Note.** To select this frame from anywhere in this page, press the  key for a few seconds.

#### Cycle Time

#### Heat Time Proportioning Output

[1.0 to 300.0 seconds (<1.0 = 'On/Off' control)]

#### Cool Time Proportioning Output


[1.0 to 300.0 seconds (<1.0 = 'On/Off' control)]

Continued on next page.

- \*1 Only displayed if Output 1 is assigned to a relay or logic output.
- \*2 Only displayed if heat/cool hardware configuration is selected.




...3.2 Tuning (Level 2) – Fig. 3.2



- 1 Only displayed if On/Off control is selected for either output.
- 2 Only displayed if heat/cool hardware configuration is selected.



### ...3.2 Tuning (Level 2)



- 1 Only displayed if a heat/cool hardware configuration is selected.




Fig. 3.1 Proportional Band & Deadband/Overlap – Heat/Cool Control Only



### 3.3 Set Points (Level 3)

LEU3  
SELP



LSPt  
125.8



\*1  
rSP.n  
145.8



R hP  
800.0



R hY  
270.0

#### Level 3 – Set Points Level



**Note.** To select this frame from anywhere in this page, press the key for a few seconds.

#### Local Set Point Value

[Within set point high and low limits, in engineering units]

#### Remote Set Point Selection

Set Point Type:

*rSP.Y* – remote set point

*rSP.n* – local set point

Remote set point value.

#### Alarm 1 Trip Point

Alarm type:

*R hP* = High process alarm

*R lP* = Low process alarm

*R h d* = High deviation alarm

*R l d* = Low deviation alarm

*R l b* = Loop break alarm

Trip Point:

Process & deviation alarms [in engineering units]

Loop break alarm [1 to 9999 seconds]


Continued on next page.

\*1 Only displayed if the remote set point option is selected.






...3.3 Set Points (Level 3)



**Alarm 1 Hysteresis Value**  
[in engineering units]



**Alarm 2 Trip Point**

Alarm type:

*A2.hP* = High process alarm

*A2.LP* = Low process alarm

*A2.hd* = High deviation alarm


*A2.Ld* = Low deviation alarm

*A2.Lb* = Loop break alarm


Trip Point:

Process & deviation alarms [in engineering units]

Loop break alarm [1 to 9999 seconds]



**Alarm 2 Hysteresis Value**  
[in engineering units]




**Remote Set Point Input Ratio and Bias**

The remote set point value =

ratio x remote set point input + bias.

**Ratio**

[0.001 to 9.999]



**Bias**

[in engineering units]




Continued on next page.

- 1 Only displayed if custom alarm hysteresis is selected – see section 4.3.2, not displayed if Loop Break Alarm type selected.
- 2 Only displayed if the remote set point option is selected.



### ...3.3 Set Points Level




#### Ramp Rate (for ramping set point facility)

[1 to 9999 engineering units per hour, or OFF]

The ramping set point facility can be used to prevent a large disturbance to the control output when the set point value is changed. This only applies to the local and multiple fixed set points.

**\*** **Note.** For remote set points the ramp rate is applicable when switching from remote to local, not local to remote



\* e.g. Ramp Rate = 200 Increments/Hour

#### Offset Adjustment


An offset can be applied to the process variable input to enable spot calibration or the removal of system errors.

[±10% of engineering range in engineering units]



### 3.4 Profile (Level 4)

A four-segment ramp/soak profile facility is provided. This level can only be accessed if the profile option is selected in the configuration level. The four segments are fixed as ramps or soaks as follows:



LEU.4  
PrFL



•1

Str.1  
1000




End.1  
2000



rtE.1  
100

#### Level 4 – Profile Level



**Note.** To select to this frame from anywhere in this page, press the  key for a few seconds.

#### Start Value for 1<sup>st</sup> Segment (ramp).

[Within display range (in engineering units)]

Enter the start value required.

#### End Value for 1<sup>st</sup> Segment (ramp).

[Within display range (in engineering units)]

Enter the end value required.

Continued on next page.

- 1 With the self-seeking set point facility enabled, the first ramp starts at the current process variable value instead of the start value for the 1<sup>st</sup> segment.



## ...3 SET UP MODE

### ...3.4 Profile (Level 4)

•1

**r t E.1**  
**40.00**

▲ ▼

**Ramp Rate for 1<sup>st</sup> Segment.**  
[Engineering units\* ]

Enter the ramp rate required.

\* The time option Eng Units/hr or Eng Units/min is set in the configuration level – see section 4.3.2.

**Example.** Required Ramp Rate 40°C/min  
Ramp Rate set to 40, Time Option set to 'Min' – see section 4.3.2

**SPL.2**  
**60.00**

▲ ▼

**Soak Time for 2<sup>nd</sup> Segment.**  
[0 to 999.9 minutes or hours]\*

**End.3**  
**100.0**

▲ ▼

**End Value for 3<sup>rd</sup> Segment (ramp).**  
[Within display range (in engineering units)]

**r t E.3**  
**20.00**

▲ ▼

**Ramp Rate for 3<sup>rd</sup> Segment.**  
[Engineering units/hour or /minute]\*

\* Depending on the time option selected in the configuration level.


**SPL.4**  
**30.00**

Continued on next page.

- 1 The engineering value is shown with an extra decimal place (up to a maximum of 3) for greater accuracy in setting the ramp rate.



### ...3.4 Profile (Level 4)



- 2 The engineering value is shown with an extra decimal place (up to a maximum of 3) for greater accuracy in setting the ramp rate.



## 4 CONFIGURATION MODE

### 4.1 Introduction

The Configuration Mode comprises two levels (5 and 6) as shown in Fig. 4.2.

Level 5 is divided into four frames. For most simple applications, it is only necessary to set up the parameters in the first frame.



#### Note.

When in the configuration level:

- All the LED indicators flash.
- All relays and logic outputs are turned off.
- The analog output reverts to 0% (4mA) output level.

### 4.2 Accessing the Configuration Mode – Fig. 4.1

To access the Configuration Mode, set the security switch to the 'Configure' position (levels 1 to 4 cannot be accessed from this setting). When the configuration parameters are programmed, reset the security switch to the 'Normal' position and the Operating page is displayed automatically .




Fig. 4.1 Accessing the Configuration Mode (Config/Normal Switch)




Fig. 4.2 Configuration Frames (Levels 5 and 6)



### 4.3 Basic Hardware and Configuration (Level 5)

#### 4.3.1 Hardware Assignment and Input Type – Fig. 4.3

LEU5  
CnFG



AbCd  
24.10



AbCd  
24.10



AbCd  
24.10



AbCd  
24.10



EFGH  
----

---

#### Level 5 – Configuration


 **Note.** To select this frame from anywhere in this page, press the  key for a few seconds.

---

#### 'ABCD' Settings

The parameter to be changed is indicated by the letter which is flashing. Parameter options are shown in Fig. 4.3.

- A* = Hardware configuration
- b* = Input type and range
- C* = Temperature units
- d* = Process variable display decimal places

 **Note 1.** The temperature ranges default to their maximum values when the input type is changed.

---

Continued on page 32.





**A – Hardware Configuration**

Freq.		Relay 1	Relay 2*	Relay 3*	Logic O/P	An. O/P	Control Type
50Hz	60Hz						
1	A	Output 1	Alarm 1	Alarm 2	Output 1	PV	Time Prop. or On/Off
2	b	Alarm 1	Alarm 2	None	None	Output 1	Analog Prop.
3	C	Output 1	Output 2	Alarm 1	Output 1	PV	Heat – Time Prop. Cool – Time Prop.
4	d	Output 2	Alarm 1	Alarm 2	Output 2	Output 1	Heat – Analog Cool – TP or On/Off
5	E	Alarm 1	Alarm 2	None	Output 1	PV	Alarm Unit or Logic O/P Time Prop.
U		Custom	Custom	Custom	Custom	Custom	Custom

\* Only available if option board is fitted



**B – Input Type and Range Configuration**

Display		Display	
b	T/C Type B	1	0 to 20 mA
E	T/C Type E	2	4 to 20 mA
J	T/C Type J	3	0 to 5 V
K	T/C Type K	4	1 to 5 V
N	T/C Type N	6	0 to 50 mV
R	T/C Type R	7	4 to 20 mA (square root linearizer)
S	T/C Type S	U	Custom Configuration
T	T/C Type T		
P	PT100 RTD		



**C – Temperature Units**

Display	Temperature Units
C	Degrees C*
F	Degrees F*
0	No temperature units



**D – Process Variable Display  
Decimal Places**

Display	
0	XXXX
1	XXX . X
2	XX . XX
3	X . XXX

\* Temperature inputs only


**Fig. 4.3 Hardware Assignment and Input Type**



### 4.3.2 Alarms and Set Point Types – Fig. 4.4



**Note.** All relays are **de-energized** in the alarm state.





EFGH  
3241

E – Alarm 1 Type\*

Display	
0	None
1	High Process
2	Low Process
3	High Deviation
4	Low Deviation
5	Loop Break

EFGH  
3241

F – Alarm 2 Type\*

Display	
0	None
1	High Process
2	Low Process
3	High Deviation
4	Low Deviation
5	Loop Break

\* Refer to Figs. 4.5 and 4.6 for alarm action

EFGH  
3241

G – Alarm Hysteresis

Display	
0	None
1	0.1%
2	0.2%
3	0.5%
4	1.0%
5	2.0%
6	5.0%
U	Custom

Value in % of engineering range

Value in engineering units \*<sub>1</sub>



**Note 1.** When custom alarm hysteresis is selected, the alarm hysteresis values are set individually in the **set up level** – see section 3.3

EFGH  
3241

H – Set Point Type

Display	
0	Local Set Point Only
1	Local + Remote Set Point (no Remote Set Point Tracking)** * <sub>2</sub>
2	Local + Remote Set Point (with Remote Set Point Tracking)**
3	Multiple Fixed Set Points
4	Ramp/Soak (Time Units in Minutes)
5	Ramp/Soak (Time Units in Hours)

\*\*Only available if option board is fitted. Remote set point input is 4 to 20 mA



**Note 2.** With remote set point tracking enabled, the local set point tracks the remote set point when in the remote set point mode.

Fig. 4.4 Alarms and Set Point Types



## ...4 CONFIGURATION MODE

### ...4.3.2 Alarms and Set Point Types – Fig. 4.4

\* **Note.** All relays are **de-energized** in the alarm state.

#### Loop Break Alarm

The loop break alarm indicates a fault in the control loop (e.g. failure of a heating element in a furnace). If the control output remains at maximum or minimum for a time exceeding the trip value (in seconds) without any response in the process value, the loop break alarm is activated.

#### Process and Deviation Alarms (High/Low) – Figs 4.5 and 4.6






Fig. 4.5 High and Low Process Alarm Action



**High Deviation Alarm**





**Low Deviation Alarm**

**Fig. 4.6 High and Low Deviation Alarm Action**




### 4.3.3 Operator Access and Control Action – Fig. 4.7






**J – Power Recovery Mode**

Display	Mode
0	Last Mode
1	Manual with Last Output
2	Manual with 0.0% Output
3	Manual with 100.0% Output
4	Auto
U	Custom




**K – Operator Selection Enable Control Functions**

Display	Auto/Manual and Auto-tune
0	Enable Both Functions
1	Disable A/M, Enable Auto-tune
2	Enable A/M, Disable Auto-tune
3	Disable Both Functions



**L – Operator Selection Enable – Set Point Functions**

Display	Local Set Point Adjustment and Local/Remote Set Point Selection
0	Enable Both Functions
1	Disable Set Point Adjust, Enable Local/Remote Selection
2	Enable Set Point Adjust, Disable Local Remote Function
3	Disable Both Functions




**N – Control Action**

Display	Heat Action	Cool Action
0	Reverse	Direct
1	Direct	Reverse

**Fig. 4.7 Operator Access and Control Action**




### 4.3.4 Digital Input and Serial Communications – Fig. 4.8



The parameter to be changed is indicated by the letter which is flashing. Parameter options are shown in Fig. 4.8.

- P* = Digital input function
- r* = Analog input digital filter
- S* = Serial communications configuration
- t* = Serial communication parity



**Information.** All digital input functions except Front Panel Lockout are edge-triggered to enable the front panel keys to change the function when the digital input is operational.

Fig. 4.8 Digital Inputs




**P – Digital Input Functions**

Display	Function
0	None
1	Auto/Manual
2	Local/Remote
3	Auto-tune Start
4	Ramp/Soak Run-Hold
5	Ramp/Soak Run-Stop
6	Front Panel Lockout
7	Select Fixed Set Points

**R – Analog Input Digital Filter**

Display	
0	0 seconds
1	1 second
2	2 seconds
5	5 seconds
R	10 seconds
B	20 seconds
C	40 seconds
D	60 seconds

Input filter averages the process variable input values over the time set

**S – Serial Communication Configuration**

Display	Baud Rate, 2/4 Wire
0	Off
1	2400, 2 Wire
2	2400, 4 Wire
3	9600, 2 Wire
4	9600, 4 Wire


**T – Serial Communications Parity**

Display	
0	None
1	Odd
2	Even

**Fig. 4.9 Digital Input and Serial Communications**




### 4.4 Ranges and Passwords (Level 6)



- 1 The engineering range high and low values are automatically set to the maximum allowed value when thermocouple or RTD is selected in the configuration level – see Section 4.3.1. This value can be modified if required.
- 2 Only displayed if the analog output is configured to retransmit the process variable or control set point value.



### ...4.4 Ranges and Passwords (Level 6)




- 1 This limit applies to the local and remote set point values.
- 2 Only displayed if the multiple fixed set point facility is selected.





## ...4 CONFIGURATION MODE

### ...4.4 Ranges and Passwords (Level 6)


•1  **Output 1 (Heat) High Limit**  
[0% to 110%]

---


•1  **Output 2 (Cool) High Limit**  
[0% to 110%]

•2  **Configured Output**  
[-10% (-110% for heat/cool) to 110% or *LAST* (default)]  
This output value is used when:  
– Manual control is selected using a digital input,  
– the process variable input fails,  
– the auto-tune fails.


---

 **Auto-Tune Password**  
[0 to 9999 (default 0)]  
Enables access to the auto-tune facility in the operating level (Level 1).

---

 **Setup Password**  
[0 to 9999 (default 0)]  
This password enables access to the setup levels (levels 2, 3, and 4) and to the auto tune facility.

---

 **MODBUS Address**  
[1 to 99]

This frame allows the MODBUS address to be set.

- 1 This value only applies in automatic mode.  
The low limit is automatically set to 0.0% (-10% for analog outputs).
- 2 Only displayed if a heat/cool hardware configuration is selected.

# 5 INSTALLATION



## 5.1 Siting – Figs. 5.1 and 5.2





Fig. 5.1 General Requirements



## ...5 INSTALLATION


### ...5.1 Siting – Figs. 5.1 and 5.2





**5.2 Mounting – Figs. 5.3 and 5.4**

The instrument is designed for panel mounting (see Fig. 5.4). Overall dimensions are shown in Fig. 5.3.





## ...5 INSTALLATION

### ...5.2 Mounting – Figs. 5.3 and 5.4




Fig. 5.4 Mounting Details





## EC Directive 89/336/EEC

In order to meet the requirements of the EC Directive 89/336/EEC for EMC regulations, this product must not be used in a non-industrial environment.

## 5.3 Electrical Connections – Figs. 5.5 and 5.6 (overleaf)



**Warning.** Before making any connections, ensure that the power supply, any powered control circuits and high common mode voltages are switched off. The instrument must be connected in accordance with local regulations and have an external means of disconnection. External fuse rating must not exceed 5A.



**Note.** If it is not possible to avoid strong electrical and magnetic fields, screened cables within earthed/grounded metal conduit must be used.

## 5.4 Relays, Arc Suppression and Outputs

### 5.4.1 Relay Contact Ratings

Relay contacts are rated at:

115/230V AC at 5A (non-inductive).  
250V DC 25W max.

### 5.4.2 Arc Suppression – Fig. 5.5

Arc suppression components are fitted to relays 2 and 3 only. If relay 1 is required to switch inductive loads, the arc suppression component supplied must be fitted across the contacts used.

### 5.4.3 Logic Output

18V DC at 20mA.


Min load 900Ω.

Isolation from Analog Output (not isolated from Retransmission Output). Dielectric strength – 500V d.c. for 1 minute.

### 5.4.4 Control or Retransmission Analog Outputs


Max. load 15V (750Ω at 20mA).

Isolation from Analog Output (not isolated from Logic Output). Dielectric strength – 500V d.c. for 1 minute.






## ...5 INSTALLATION



**Note 1.** The Analog Output and Logic Output use a common positive terminal that is capable of driving both outputs simultaneously.

**Note 2.** Fit arc suppression components if switching inductive loads.



**Fig. 5.6 Electrical Connections**



# CUSTOMER CONFIGURATION LOG



LEUS  
CnFG

LEUS  
CnFG

AbCd  
-----

EnGH  
1000

EFGH  
-----

EnGL  
00

JPLn  
-----

rLH1  
1000

PrSt  
-----

rLLO  
00

SP-H  
1000

SP-L  
00

SP-1  
100

SP-2  
200

SP-3  
300

SP-4  
400

OP 1H  
100

OP2H  
100

C-OP  
0


RPAS  
0

SPAS  
0

Addr  
1

Default settings are shown in the lower display

# CUSTOMER SETUP LOG



Company Standard settings are shown in the lower display

Instrument Serial Number: \_\_\_\_\_

## WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of 37 months from date of purchase. OMEGA Warranty adds an additional one (1) month grace period to the normal three (3) year product warranty to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product. If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components which wear are not warranted, including but not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by it will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESS OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

## RETURN REQUESTS / INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR WARRANTY RETURNS, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to product.

FOR NON-WARRANTY REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of the products, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 1998 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.

# Where Do I Find Everything I Need for Process Measurement and Control? OMEGA...Of Course!

## TEMPERATURE

- Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- Wire: Thermocouple, RTD & Thermistor
- Calibrators & Ice Point References
- Recorders, Controllers & Process Monitors
- Infrared Pyrometers

## PRESSURE, STRAIN AND FORCE

- Transducers & Strain Gauges
- Load Cells & Pressure Gauges
- Displacement Transducers
- Instrumentation & Accessories

## FLOW/LEVEL

- Rotameters, Gas Mass Flowmeters & Flow Computers
- Air Velocity Indicators
- Turbine/Paddlewheel Systems
- Totalizers & Batch Controllers

## pH/CONDUCTIVITY

- pH Electrodes, Testers & Accessories
- Benchtop/Laboratory Meters
- Controllers, Calibrators, Simulators & Pumps
- Industrial pH & Conductivity Equipment

## DATA ACQUISITION

- Data Acquisition & Engineering Software
- Communications-Based Acquisition Systems
- Plug-in Cards for Apple, IBM & Compatibles
- Datalogging Systems
- Recorders, Printers & Plotters

## HEATERS

- Heating Cable
- Cartridge & Strip Heaters
- Immersion & Band Heaters
- Flexible Heaters
- Laboratory Heaters

## ENVIRONMENTAL

### MONITORING AND CONTROL

- Metering & Control Instrumentation
- Refractometers
- Pumps & Tubing
- Air, Soil & Water Monitors
- Industrial Water & Wastewater Treatment
- pH, Conductivity & Dissolved Oxygen Instruments