


# User's Guide

CE



**Ω OMEGA®**

<http://www.omega.com>  
e-mail: [info@omega.com](mailto:info@omega.com)

PX750  
Pressure Transmitter



OMEGAnet® On-Line Service    Internet e-mail  
<http://www.omega.com>

[info@omega.com](mailto:info@omega.com)

#### Servicing North America:

USA:                                    One Omega Drive, Box 4047  
ISO 9001 Certified                    Stamford, CT 06907-0047  
Tel: (203) 359-1660                    FAX: (203) 359-7700  
e-mail: [info@omega.com](mailto:info@omega.com)  
Canada:                                    976 Bergar  
    Laval (Quebec) H7L 5A1  
Tel: (514) 856-6928                    FAX: (514) 856-6886  
e-mail: [info@omega.ca](mailto:info@omega.ca)

#### For immediate technical or application assistance:

USA and Canada:                    Sales Service: 1-800-826-6342 / 1-800-TC-OMEGASM  
Customer Service: 1-800-622-2378 / 1-800-622-BESTSM  
Engineering Service: 1-800-872-9436 / 1-800-USA-WHENSM  
TELEX: 996404 EASYLINK: 62968934 CABLE: OMEGA  
Mexico and  
Latin America:                    Tel: (95) 800-826-6342                    FAX: (95) 203-359-7807  
    En Español: (95) 203-359-7803                    e-mail: [espanol@omega.com](mailto:espanol@omega.com)

#### Servicing Europe:

Benelux:                                    Postbus 8034, 1180 LA Amstelveen, The Netherlands  
Tel: (31) 20 6418405                    FAX: (31) 20 6434643  
    Toll Free in Benelux: 0800 0993344  
    e-mail: [nl@omega.com](mailto:nl@omega.com)  
Czech Republic:                    ul. Rude armady 1868, 733 01 Karvina-Hranice  
Tel: 420 (69) 6311899                    FAX: 420 (69) 6311114  
    Toll Free: 0800-1-66342                    e-mail: [czech@omega.com](mailto:czech@omega.com)  
France:                                    9, rue Denis Papin, 78190 Trappes  
Tel: (33) 130-621-400                    FAX: (33) 130-699-120  
Toll Free in France: 0800-4-06342  
    e-mail: [france@omega.com](mailto:france@omega.com)  
Germany/Austria:                    Daimlerstrasse 26, D-75392 Deckenpfronn, Germany  
Tel: 49 (07056) 3017                    FAX: 49 (07056) 8540  
Toll Free in Germany: 0130 11 21 66  
    e-mail: [info@omega.de](mailto:info@omega.de)  
United Kingdom:                    One Omega Drive, River Bend Technology Centre  
ISO 9002 Certified                    Northbank, Irlam, Manchester  
    M44 5EX, England  
Tel: 44 (161) 777-6611                    FAX: 44 (161) 777-6622  
Toll Free in the United Kingdom: 0800-488-488  
e-mail: [info@omega.co.uk](mailto:info@omega.co.uk)

It is the policy of OMEGA to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct, but OMEGA Engineering, Inc. accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

**WARNING:** These products are not designed for use in, and should not be used for, patient-connected applications.



# Table of Contents

## SECTION 1 Introduction

Overview .....	1-1
Models Covered .....	1-1
Using this manual .....	1-2

## SECTION 2 Installation

Overview .....	2-1
Wiring Connections .....	2-3
Load Limitations .....	2-6

## SECTION 3 Commissioning the Smart Transmitter

Overview .....	3-1
Fast key sequences .....	3-1
Configure the Analog Output Parameters .....	3-2
Setting Process Variable Units .....	3-2
Reranging .....	3-3
Setting the Output Type .....	3-4
Setting Damping .....	3-4
Calibrate the sensor .....	3-5
Digital Trim .....	3-5
Calibrate the 4–20 mA Output .....	3-6
Digital to Analog Converter Trim .....	3-6



---

## **SECTION 4 Commissioning the Analog Transmitter**

Overview .....	4-1
Calibration .....	4-1
Setting the EZ/SZ Jumper Pin .....	4-1
Adjusting for Zero and Span .....	4-2
Adjusting Damping .....	4-3
Adjusting Linearity .....	4-3

## **SECTION 5 Troubleshooting**

Troubleshooting .....	5-1
-----------------------	-----

## **SECTION 6 Reference Data**

Overview .....	6-1
----------------	-----

## **APPENDIX A HART<sup>®</sup> Communicator**

HART Communicator .....	A-2
-------------------------	-----

# Introduction

## OVERVIEW

This section outlines the models covered and the organization of this manual.

### ⚠ WARNING

The following performance limitations may inhibit efficient or safe operation. Critical applications should have appropriate diagnostic and backup systems in place.

Pressure transmitters contain an internal fill fluid. It is used to transmit the process pressure through the isolating diaphragms to the pressure sensing element. In rare cases, oil leak paths in oil-filled pressure transmitters can be created. Possible causes include: physical damage to the isolator diaphragms, process fluid freezing, isolator corrosion due to an incompatible process fluid, etc.

A transmitter with an oil fill fluid leak can continue to perform normally for a period of time. Sustained oil loss will eventually cause one or more of the operating parameters to exceed published specifications while a small drift in operating point output continues. Symptoms of advanced oil loss and other unrelated problems include:

- Sustained drift rate in true zero and span or operating point output or both
- Sluggish response to increasing or decreasing pressure or both
- Limited output rate or very nonlinear output or both
- Change in output process noise
- Noticeable drift in operating point output
- Abrupt increase in drift rate of true zero or span or both
- Unstable output
- Output saturated high or low

## MODELS COVERED

This manual provides basic installation, commissioning, and troubleshooting information for the following PX750 Pressure Transmitters:

### **Model PX750 - Differential Pressure Transmitter**

measures differential pressure from 2 inH<sub>2</sub>O to 1,000 psi (0.497 to 6895 kPa).

### **Model PX750 - Gage Pressure Transmitter**

measures gage pressure from 2 inH<sub>2</sub>O to 1,000 psi (0.497 to 41369 kPa).



**Model PX750– Alphaline Draft Range Differential Pressure Transmitter**

designed for monitoring low pressure flow rates with positive and/or negative static pressure capabilities and 0–½ to 0–6 inH<sub>2</sub>O rangeability.

**USING THIS MANUAL**

This manual is designed to assist in basic installation and operation of Model PX750 Pressure Transmitters.

**Section 2 Installation**

provides a flowchart outlining installation procedures and installation wiring diagrams.

**Section 3 Commissioning**

provides a description of common commissioning tasks for the Model PX750 Smart Pressure Transmitter.

**Section 4 Commissioning**

provides a description of common commissioning tasks for the Model PX750 Analog Pressure Transmitter.

**Section 5 Troubleshooting**

provides basic troubleshooting techniques for common diagnostic messages associated with the transmitter and the communicator.

**Section 6 Reference Data**

provides range tables, a typical model structure, and bolt torque specifications for Model PX750 Transmitters.

**Appendix**

contains menu tree and fast key sequence for the HART Communicator.

## Installation

### OVERVIEW

This section contains a flowchart in Figure 2-1 and wiring diagrams in Figures 2-2 through 2-5 to guide you to a successful Model PX750 installation. Shielded cable should be used for best results in electrically noisy environments.


#### WARNING

**Failure to follow safe installation guidelines can cause death or serious injury. Please review the following safety messages before installing a Model PX750 Pressure Transmitter.**

- To avoid output shifts in critical applications, do not plug the low side with a solid plug.
- To avoid process leaks, install and tighten all four flange bolts before applying pressure, or process leakage may result. Attempting to remove the flange bolts while the transmitter is in service may cause process fluid leaks.
- To avoid explosions, do not remove the instrument cover or make electrical connections in explosive atmospheres when the circuit is alive. Make sure the instrument is installed in accordance with intrinsically safe or nonincendive field wiring practice.
- To meet explosion proof requirements, make sure that both transmitter covers are fully engaged.



FIGURE 2-1. Installation Flowchart.





## WIRING CONNECTIONS



Figure 2-2 shows wiring connections necessary to power a Model PX750 Transmitter and if smart, enable communications with a hand-held communicator. Shielded cable should be used for best results in electrically noisy environments.

### NOTE

A resistance of at least 250 ohms must exist between the communicator and the power supply for communications.

FIGURE 2-2. Field Wiring Diagram.








FIGURE 2-3. Model PX750 Wiring Diagrams for Output Codes J and F.



1151-1151G05A

FIGURE 2-4. Model PX750 Wiring Diagram for Smart Output Code S.



1151-1151F05A

**NOTE**  
Signal Loop may be grounded at any point or left ungrounded.


**NOTE**  
A HART Interface may be connected at any termination point in the loop. Signal loop must have 250 ohms minimum load for communications.



## Load Limitations

FIGURE 2-6. Model PX750 Power Supply Requirements.

**NOTE**  
 External power supply required.  
 Transmitter operates on 12 to 45 V dc  
 with no load for Output Codes S and E.



Code	$V_{min}$	$V_{max}$	$R_{min}$	$R_{max}$	$R_L$ at Supply Voltage ( $V_S$ )
S <sup>(1)</sup>	12	45 <sup>(2)</sup>	0	1650	$R_L = 43.5 (V_S - 12)$
E, J	12	45	0	1650	$R_L = 50 (V_S - 12)$
G	30	85	0	1100	$R_L = 20 (V_S - 30)$
L	5	12	Low Power Minimum Load Impedance: 100 k $\Omega$		
M	8	14			

(1) A minimum of 250 ohms is required for communication.

(2)  $V_{max}$  for CESI is 42.5 V dc.

## OVERVIEW

This section provides summarized procedures needed to commission the Model PX750 Smart Transmitter.

### WARNING

**Failure to follow safe commissioning guidelines can cause death or serious injury. Please review the following safety messages before commissioning a Model PX750 Pressure Transmitter.**

- To avoid explosions, do not remove the instrument cover or make electrical connections in explosive atmospheres when the circuit is alive. Make sure the instrument is installed in accordance with intrinsically safe or nonincendive field wiring practice.
- To meet explosion proof requirements, make sure that both transmitter covers are fully engaged.

### Configure the Analog Output Parameters

- Setting Process Variable Units - - - - - Page 3-2
- Reranging (Setting Range Points)- - - - - Page 3-2
- Setting Output Type - - - - - Page 3-4
- Setting Damping - - - - - Page 3-4

### Calibrate the Sensor

- Full Trim- - - - - Page 3-5
- Zero Trim - - - - - Page 3-5

### Calibrate the 4–20 mA Output

- 4–20 mA Output Trim - - - - - Page 3-6
- 4–20 mA Output Trim (Other Scale)- - - - - Page 3-6

## FAST KEY SEQUENCES

For your convenience, fast key sequences are listed for common transmitter functions. Complete tables of fast key sequences are located in Appendix A.




If you are unfamiliar with the communicator or how to follow fast key sequences, please refer to Appendix A for communicator operations.

The fast key boxes in this section contain codes for the HART Communicator Model 275. From the Online Menu (HART Communicator), press these key sequences to access the desired transmitter function.

TABLE 3-1. Fast Key Box.

<b>HART Comm.</b>	1, 5, 3, 2

FIGURE 3-1. CommunicatorWiring Connections.



## CONFIGURE THE ANALOG OUTPUT PARAMETERS

### Setting Process Variable Units

<b>HART Comm.</b>	1, 3, 2

The Model PX750 allows any of the following output units: inH<sub>2</sub>O, inHg, ftH<sub>2</sub>O, mmH<sub>2</sub>O, mmHg, psi, bar, mbar, g/cm<sup>2</sup>, kg/cm<sup>2</sup>, Pa, kPa, torr, and atm.



## Reranging

Reranging matches the transmitter range points with the applied process pressures. It can be performed three ways: using the communicator, using the communicator and a reference pressure, or by using the transmitter zero and span buttons.


To decide which method is appropriate, consider the following:

- Reranging with the keypad changes the analog 4 and 20 mA points independently.
- Reranging with a pressure input source and the keypad allows you to maintain the same analog span.
- Reranging with a pressure input source and the zero and span screws allows you to maintain the same analog span.

### Reranging with a Communicator Only

HART Comm.	1, 2, 3, 1, 1


Reranging with the keypad changes the 4 and 20 mA points independently.



### Reranging with a Pressure Input Source and a Communicator

HART Comm.	1, 2, 3, 1, 2

Reranging with a pressure input source maintains the same span.






## Reranging Using Transmitter Buttons

1. Locate the transmitter zero and span buttons on the transmitter faceplate, as shown in Figure 3-2.

FIGURE 3-2. External Zero and Span Buttons.



1151-0908A02A

2. Press both span and zero buttons simultaneously for 10 seconds.
3. Using a pressure source with an accuracy three to ten times the desired calibrated accuracy, apply the 4 mA-point pressure to the high side of the transmitter.
4. Press the zero button for five seconds and verify that the output is 4 mA.
5. Apply a pressure equivalent to the 20 mA-point pressure to the high side of the transmitter.
6. Press the span button for five seconds to set the 20 mA point. Verify that the output is 20 mA.

### NOTE

Both the lower and upper range values must fall within the lower and upper range limits of the sensor module, and meet the minimum and maximum span criteria allowed by the transmitter.

## Setting the Output Type

HART Comm.	1, 3, 5

Setting the output type changes the mathematical relationship between the input pressure and the 4–20 mA output.

The transmitter output type can be set to either linear or square root.

## Setting Damping

HART Comm.	1, 3, 6

The Model PX750 has electronic damping that can increase the response time of the transmitter to smooth the output when there are rapid input variations. It can also decrease response time when a rapid response to the process is required.

## CALIBRATE THE SENSOR



### Digital Trim

Smart transmitters are factory characterized. The information is stored in the sensor module EEPROM during the characterization process. The digital trim function allows you to make adjustments to this factory-stored curve.

#### Full Trim

HART Comm.	1, 2, 3, 3

A full trim is a two-point sensor calibration where two end-point pressures are applied, and the transmitter process variable output is adjusted to agree with the pressure input.

#### NOTE

A full trim requires a pressure source at least three times more accurate than the transmitter. For best accuracy, make sure the applied pressure is equal to or slightly less than the desired 4 mA setpoint, or equal to or slightly greater than the 20 mA setpoint.

#### Zero Trim


HART Comm.	1, 2, 3, 3, 1

A zero trim is a simpler, one-point process variable adjustment. It must be performed with the low trim value. A zero trim may be used when an exact pressure source is not available for the second pressure needed in a full trim.


A zero trim is useful for compensating for mounting position effects or for zero shifts due to static pressure in differential pressure applications.

#### Zero-Based Applications:

Use the communicator "Zero Trim" function to change the 4 mA point to represent "0" pressure.



3-5





**Nonzero-Based Applications:**



Use the zero pushbutton to shift the 4 and 20 mA points together (maintaining span) to represent new pressure values.

**Zeroing Using Transmitter Buttons**

Locate the transmitter zero and span buttons on the transmitter faceplate, as shown in Figure 3-3.

1. Press both span and zero buttons simultaneously for 10 seconds.
2. Apply the 4 mA-point pressure.
3. Press the zero button for five seconds.
4. Verify that the output is 4 mA.

FIGURE 3-3. External Zero and Span Buttons.



1151-0908A02A

**CALIBRATE THE 4–20 MA OUTPUT****Digital to Analog Converter Trim**

It may be necessary to calibrate the 4–20 output. The 4–20 mA output trim function can also be used to make adjustments to allow for calibration differences of a particular readout device in the loop.

**4–20 mA Output Trim**

<b>HART Comm.</b>	1, 2, 3, 2, 1

A 4–20 mA output trim adjusts the transmitter milliamp output to match your plant's standard. This procedure is used if you want to trim the transmitter using a current meter.

**4–20 mA Output Trim Using Other Scale**

<b>HART Comm.</b>	1, 2, 3, 2, 2

This procedure is used if you want to trim the transmitter and your readout device is in something other than milliamps (e.g. volts).

## OVERVIEW

This section summarizes procedures needed to commission the Analog Model PX750 Transmitter.

### ⚠ WARNING

**Failure to follow safe commissioning guidelines can cause death or serious injury. Please review the following safety messages before commissioning a Model PX750 Pressure Transmitter.**

- To avoid explosions, do not remove the instrument cover or make electrical connections in explosive atmospheres when the circuit is alive. Make sure the instrument is installed in accordance with intrinsically safe or nonincendive field wiring practice.
- To meet explosion proof requirements, make sure that both transmitter covers are fully engaged.

The following tasks are described in this section:

- Setting the EZ/SZ Jumper Pin ----- Page 4-1
- Adjusting Zero and Span (6 Steps) ----- Page 4-2
- Adjusting Damping ----- Page 4-3
- Adjusting Linearity ----- Page 4-3

## CALIBRATION

Basic calibration involves these steps:


- 1. Set the user-selectable jumper pins.**
- 2. Adjusting zero and span.**
- 3. Adjusting damping.**

### Setting the EZ/SZ Jumper Pin

When the zero point setting is greater than  $\pm 15$  percent of the transmitter upper range limit (URL), it is necessary to move the user-selectable jumper pin, located on the component side of the amplifier board, as shown in Figure 4-1.




FIGURE 4-1. Analog Transmitter Jumper Positions.



### Adjusting for Zero and Span

Figure 4-2 shows the zero and span adjustment screws, located beneath the nameplate on the electronics housing.

FIGURE 4-2. Zero and Span Adjustment Screws.



**NOTE**  
The transmitter output increases with clockwise rotation of the adjustment screws.

## 6-Step Calibration Procedure



### NOTE

The zero and span adjustments are interactive. For applications requiring large elevated or suppressed values, refer to “Setting the EZ/SZ Jumper Pin” on page 1.


1. Apply 4 mA-point pressure and turn zero screw to output 4 mA.
2. Apply 20 mA-point pressure.
3. Subtract actual output from desired output.
4. Divide difference by 5.
5. Turn span screw above or below desired output by value in Step 4.
6. Repeat Steps 1 through 5 until calibrated.

## Adjusting Damping

To change the damping setting, locate the damping adjustment screw, shown in Figure 4-3, and turn the damping adjustment screw clockwise to increase the damping to the desired value.

The damping value can be set between 0.2 and 1.66 seconds. The factory default damping position is set to the transmitter minimum of 0.2 seconds.

FIGURE 4-3. Damping Adjustment Screw.



## Adjusting Linearity

The transmitter linearity is factory set for optimum performance over the calibrated range of the instrument and is normally not readjusted in the field.



SECTION  
5



## Troubleshooting

### TROUBLESHOOTING

Tables 5-1 and 5-2 provide summarized troubleshooting suggestions for the most common operating problems.

#### WARNING

**Failure to follow safe operating practices can cause death or serious injury. Please review the following safety messages before troubleshooting the Model PX750 Pressure Transmitter.**

- Using improper procedures or parts can affect product performance and the output signal used to control a process. To ensure safe transmitter performance, use only new parts and follow Omega documented procedures. Questions regarding these procedures or parts should be directed to Omega's customer service dept.
- Isolate a failed transmitter from its pressure source as soon as possible. Pressure that may be present could cause death or serious injury to personnel if the transmitter is disassembled or ruptures under pressure.
- To avoid explosions, do not remove the instrument cover or make electrical connections in explosive atmospheres when the circuit is alive. Make sure the instrument is installed in accordance with intrinsically safe or nonincendive field wiring practice.
- To meet explosion proof requirements, make sure that both transmitter covers are fully engaged.
- To avoid process leaks, use only the O-ring designed to seal with the corresponding flange adapter. Omega supplies two unique styles of O-rings for Omega flange adapters: one for Model PX750 flange adapters and another for Model PX751 flange adapters. Each flange adapter is distinguished by its unique groove.



TABLE 5-1. Model PX750 Smart Troubleshooting Chart.

Symptom	Corrective Action
<b>Milliamp Reading is Zero</b>	<ul style="list-style-type: none"> <li>• Check if Power Polarity is Reversed</li> <li>• Check for Bad Diode in Housing by Jumpering Test Terminals</li> <li>• Replace Transmitter Housing</li> </ul>
<b>Transmitter not in Communication</b>	<ul style="list-style-type: none"> <li>• Check Power Supply Voltage at Transmitter (Minimum 10.5 V)</li> <li>• Check load resistance (250 Ohm minimum)</li> <li>• Replace Electronics Board</li> </ul>
<b>Milliamp Reading is Low or High</b>	<ul style="list-style-type: none"> <li>• Check Pressure Variable Reading</li> <li>• Perform 4–20 mA Output Trim</li> <li>• Replace Electronics Board</li> </ul>
<b>No Response to Changes in Applied Pressure</b>	<ul style="list-style-type: none"> <li>• Check Power Supply Voltage at Transmitter</li> <li>• Check Test Equipment</li> <li>• Verify Calibration Settings (4 and 20 mA points)</li> <li>• Replace Electronics Board</li> <li>• Replace Sensor Module</li> </ul>
<b>Low Reading for Pressure Variable</b>	<ul style="list-style-type: none"> <li>• Check Impulse Piping for Blockage</li> <li>• Check Test Equipment</li> <li>• Perform Full Sensor Trim</li> <li>• Replace Sensor Module</li> </ul>
<b>High Reading for Pressure Variable</b>	<ul style="list-style-type: none"> <li>• Check Impulse Piping for Blockage</li> <li>• Check Test Equipment</li> <li>• Perform Full Sensor Trim</li> <li>• Replace Sensor Module</li> </ul>
<b>Erratic Reading for Pressure Variable</b>	<ul style="list-style-type: none"> <li>• Check Impulse Piping for Blockage</li> <li>• Check Damping</li> <li>• Check for EMF Interference</li> <li>• Replace Sensor Module</li> </ul>

TABLE 5-2. Model PX750 Analog Troubleshooting Chart.

Symptom	Corrective Action
<b>Milliamp Reading is Zero</b>	<ul style="list-style-type: none"> <li>• Check if Power Polarity is Reversed</li> <li>• Check for Bad Diode in Housing by Jumpering Test Terminals</li> <li>• Replace Transmitter Housing</li> </ul>
<b>Milliamp Reading is Low</b>	<ul style="list-style-type: none"> <li>• Check Test Equipment</li> <li>• Check Jumper Pin Position</li> <li>• Adjust Zero</li> <li>• Check Calibration</li> <li>• Replace Sensor Module</li> </ul>
<b>Milliamp Reading is High</b>	<ul style="list-style-type: none"> <li>• Check Test Equipment</li> <li>• Check Calibration</li> <li>• Replace Sensor Module</li> </ul>
<b>Transmitter does not Respond to Changes in Pressure</b>	<ul style="list-style-type: none"> <li>• Close Drain/Vent Valves</li> <li>• Check Power Voltage</li> <li>• Check Test Equipment</li> <li>• Replace Electronics Board</li> <li>• Replace Sensor Module</li> </ul>
<b>Spikes in Output</b>	<ul style="list-style-type: none"> <li>• Check Mounting Location (avoid power lines or motors)</li> </ul>

## Reference Data

### OVERVIEW

This section contains the following reference data for the Model PX750 Transmitter:

- Transmitter Range Limits
- Bolt Torque Values
- Model Structure

MODEL PX750 UPPER RANGE LIMITS (URL)								
Range Code	bar	mbar	kg/cm <sup>2</sup>	psi	kPa	inH <sub>2</sub> O @20 °C	mmH <sub>2</sub> O @20 °C	inHg @0 °C
3	0.075	75	0.076	1.082	7.461	30	762	2.203
4	0.373	373	0.380	5.409	37.305	150	3810	11.013
5	1.865	1865	1.901	27.045	186.505	750	19050	55.065
6	6.90	6895	7.031	100	690	2773	70434	204
7	21	20685	21	300	2069	8319	211302	611
8	69	68950	70	1000	6895	27730	704340	2036
9	207	206850	211	3000	20685	83190	2113020	6108


Transmitter Part	Torque Value n/m (in-lb)
Flange Bolts	37 ±3 (325 ±25)
Flange Adapter Bolts	40 ±6 (350 ±50)
Drain/Vent Seat	28 ±6 (250 ±50)
Drain/Vent Stem	7 ±1 (60 ±10)





# HART® Communicator

FIGURE A-1. HART Communicator Menu Tree for the Model PX750 Smart.






## HART COMMUNICATOR

The HART Communicator provides communication capabilities for Model PX750 Smart Pressure Transmitters. The HART Communicator menu tree provides a schematic overview of configuration functions, and the fast key sequences provide direct access to software functions.

### Online Menu

The Online menu appears automatically if the HART Communicator is connected to an active loop with an operating transmitter. From the Online menu, press the appropriate key sequence to access the desired function. Follow the on-screen instructions to complete the function.

FIGURE A-2. HART Communicator Online Menu.



### HART Fast Key Feature

The fast key sequences for the HART Communicator use the following convention for their identification:

**1 through 9**—Refer to the keys located in the alphanumeric keypad located below the dedicated keypad.

---

#### NOTE

HART fast key sequences are operational only from the Online menu.

---

Begin fast key sequences from the Online menu. Press **HOME** (normally function key F3) to return to the Online menu from within a function.

### HART Fast Key Example

The following example shows how to change the **Date**.

Following the menu tree, press 1 to reach **Device Setup**, press 3 for **Basic Setup**, press 4 for **Device Info**, press 1 for **Date**.

The corresponding HART fast key sequence is 1,3,4,1.



TABLE A-1.  
HART Communicator Fast Key Sequences for  
Model PX750 Transmitters.

Function	HART Communicator Fast Keys
Analog Output	3
Analog Output Alarm	1, 4, 3, 3
Burst Mode Control	1, 4, 3, 4, 3
Burst Operation	1, 4, 3, 4, 4
Calibration	1, 2, 3
Characterize	1, 4, 1, 1, 2, 2
Damping	1, 3, 6
Date	1, 3, 4, 1
Descriptor	1, 3, 4, 2
Digital To Analog Trim (4–20 mA Output)	1, 2, 3, 2, 1
Field Device Info	1, 4, 4, 1
Full Trim	1, 2, 3, 3
Keypad Input	1, 2, 3, 1, 1
Loop Test	1, 2, 2
Lower Range Value	4, 1
Lower Sensor Trim	1, 2, 3, 3, 2
Message	1, 3, 4, 3
Meter Type	1, 3, 4, 5
Number Of Requested Preambles	1, 4, 3, 4, 2
Percent Range	1, 1, 2
Poll Address	1, 4, 3, 4, 1
Pressure	2
Range Values	1, 3, 3
Rerange	1, 2, 3, 1
Scaled D/A Trim (4–20 mA Output)	1, 2, 3, 2, 2
Self Test (Transmitter)	1, 2, 1, 1
Sensor Info	1, 4, 4, 2
Sensor Trim Points	1, 2, 3, 3, 4
Status	1, 2, 1, 2
Tag	1, 3, 1
Transfer Function (Setting Output Type)	1, 3, 5
Transmitter Security (Write Protect)	1, 3, 4, 4
Trim Analog Output	1, 2, 3, 2



TABLE A-1.  
HART Communicator Fast Key Sequences for  
Model PX750 Transmitters.

Function	HART Communicator Fast Keys
Units (Process Variable)	1, 3, 2
Upper Range Value	5, 2
Upper Sensor Trim	1, 2, 3, 3, 3
Zero Trim	1, 2, 3, 3, 1

## WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of 13 months from date of purchase. OMEGA Warranty adds an additional one (1) month grace period to the normal one (1) year product warranty to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components which wear are not warranted, including but not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by it will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESS OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY / DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

## RETURN REQUESTS / INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of the product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible.

This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 1999 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.

# Where Do I Find Everything I Need for Process Measurement and Control? OMEGA...Of Course!

## **TEMPERATURE**

- √ Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- √ Wire: Thermocouple, RTD & Thermistor
- √ Calibrators & Ice Point References
- √ Recorders, Controllers & Process Monitors
- √ Infrared Pyrometers

## **PRESSURE, STRAIN AND FORCE**

- √ Transducers & Strain Gauges
- √ Load Cells & Pressure Gauges
- √ Displacement Transducers
- √ Instrumentation & Accessories

## **FLOW/LEVEL**

- √ Rotameters, Gas Mass Flowmeters & Flow Computers
- √ Air Velocity Indicators
- √ Turbine/Paddlewheel Systems
- √ Totalizers & Batch Controllers

## **pH/CONDUCTIVITY**

- √ pH Electrodes, Testers & Accessories
- √ Benchtop/Laboratory Meters
- √ Controllers, Calibrators, Simulators & Pumps
- √ Industrial pH & Conductivity Equipment

## **DATA ACQUISITION**

- √ Data Acquisition & Engineering Software
- √ Communications-Based Acquisition Systems
- √ Plug-in Cards for Apple, IBM & Compatibles
- √ Datalogging Systems
- √ Recorders, Printers & Plotters

## **HEATERS**

- √ Heating Cable
- √ Cartridge & Strip Heaters
- √ Immersion & Band Heaters
- √ Flexible Heaters
- √ Laboratory Heaters

## **ENVIRONMENTAL MONITORING AND CONTROL**

- √ Metering & Control Instrumentation
- √ Refractometers
- √ Pumps & Tubing
- √ Air, Soil & Water Monitors
- √ Industrial Water & Wastewater Treatment
- √ pH, Conductivity & Dissolved Oxygen Instruments