



YEAR  
2000  
COMPLIANT



MADE IN  
USA




# User's Guide



**omega.com™**  
ΩOMEGA®

***www.omega.com***  
***e-mail: info@omega.com***



## **DPC-23 SERIES**

# **1/16 DIN Preset Counters**



**OMEGAnet® On-Line Service**  
**www.omega.com**

**Internet e-mail**  
**info@omega.com**

### **Servicing North America:**

**USA:**  
ISO 9001 Certified

One Omega Drive, Box 4047  
Stamford CT 06907-0047  
Tel: (203) 359-1660  
e-mail: info@omega.com

FAX: (203) 359-7700

**Canada:**

976 Bergar  
Laval (Quebec) H7L 5A1  
Tel: (514) 856-6928  
e-mail: info@omega.ca

FAX: (514) 856-6886

### **For immediate technical or application assistance:**

**USA and Canada:** Sales Service: 1-800-826-6342 / 1-800-TC-OMEGA®  
Customer Service: 1-800-622-2378 / 1-800-622-BEST®  
Engineering Service: 1-800-872-9436 / 1-800-USA-WHEN®  
TELEX: 996404 EASYLINK: 62968934 CABLE: OMEGA

**Mexico:**

Tel: (001) 800-826-6342  
En Español: (001) 203-359-7803

FAX: (001) 203-359-7807  
e-mail: espanol@omega.com  
info@omega.com.mx

### **Servicing Europe:**

**Benelux:**

Postbus 8034, 1180 LA Amstelveen, The Netherlands  
Tel: +31 20 6418405 FAX: +31 20 6434643  
Toll Free in Benelux: 0800 0993344  
e-mail: nl@omega.com

**Czech Republic:**

Rudé armády 1868, 733 01 Karviná 8  
Tel: +420 (69) 6311899 FAX: +420 (69) 6311114  
Toll Free: 0800-1-66342 e-mail: czech@omega.com

**France:**

9, rue Denis Papin, 78190 Trappes  
Tel: +33 130-621-400 FAX: +33 130-699-120  
Toll Free in France: 0800-4-06342  
e-mail: france@omega.com

**Germany/Austria:**

Daimlerstrasse 26, D-75392 Deckenpfronn, Germany  
Tel: +49 (07056) 3017 FAX: +49 (07056) 8540  
Toll Free in Germany: 0800 TC-OMEGA<sup>SM</sup>  
e-mail: germany@omega.com

**United Kingdom:**

ISO 9002 Certified

One Omega Drive, River Bend Technology Centre  
Northbank, Irlam, Manchester  
M44 5EX United Kingdom  
Tel: +44 (0)161 777 6611 FAX: +44 (0)161 777 6622  
Toll Free in United Kingdom: 0800-488-488  
e-mail: sales@omega.co.uk


It is the policy of OMEGA to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct, but OMEGA Engineering, Inc. accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

**WARNING:** These products are not designed for use in, and should not be used for, patient-connected applications.

# OVERVIEW

## CONSTRUCTION



### Compact Design

Uses only 48mm of panel space. 110mm behind-panel depth.

### Dual Four-character Display

Simultaneous display of Count and Preset data. Red LED display. Annunciators show input, display and output status.


### Ergonomic Keypad

Simple key sequences to view and edit Presets. Front Panel Reset key can be disabled.

### Front Panel Seal

NEMA 4/IP65-rated when installed with panel mount gasket supplied.

## Rear Terminal Connections




# INSTALLATION

## WIRING

**IMPORTANT:** In severe electrical noise environments, shielded cable is recommended for inputs and outputs. Connect the shield only to the building earth (ground).


### AC Power Input

Connect AC power to Terminal 7 (Line) via a 1A slow-blow fuse and to Terminal 8 (Neutral) - see below. AC power should be from a separate branch circuit which is noise-free and does not feed heavy loads.




### DC/Low Voltage AC Power Input

Connect DC/low voltage AC power to Terminal 7 (+) via a 0.5A slow-blow fuse and to Terminal 8 (-) - see below. DC power should have low ripple and be noise-free.




### Reset and Program Inputs

Connect Reset pushbutton or current sink device to Reset (Terminal 5) and COM (Terminal 4). Connect Program switch or jumper to PGM (Terminal 6) and COM (Terminal 4).






### Bi-directional Quadrature Inputs

Connect Quadrature Encoder to V+ (Terminal 1), A input (Terminal 2), B input (Terminal 3) and COM (Terminal 4) as shown below. In Configuration Mode, set **InPu** parameter to **QuAd**. For NPN open collector devices with no pullup resistors, set **PuLL** parameter to **YES**.






### Current Sourcing (PNP) Count Inputs

Connect Add count input to Terminal 2 (A) and/or Subtract count input to Terminal 3 (B) - see below. In Configuration Mode, set **PuLL** parameter to **no** and, for Add/Subtract operation, set **InPu** parameter to **A-B**.



### Current Sinking (NPN) Count Inputs


Connect Add count input to Terminal 2 (A) and/or Subtract count input to Terminal 3 (B) - see below. In Configuration Mode, set **PuLL** parameter to **YES** and, for Add/Subtract operation, set **InPu** parameter to **A-B**.



# INSTALLATION



## Relay Output

Connect AC or DC load circuits to Terminals 9, 10 & 11 (Preset 1 output) or 16, 17 & 18 (Preset 2 output) (see below) as required. Do not route load wiring near count input or transistor output signals.




## Open Collector Output

Connect Terminals 12 (Preset 1 open collector) and 4 (COM) or 15 (Preset 2 Open Collector) and 13 (COM) to solid state devices as below (upper circuit). To drive DC relay coils, connect Terminal 12 or 15 and V+ (Terminal 1) as below (lower circuit). Suppress switching transients with a suppression diode, connected as shown.




## PANEL MOUNTING



## Panel Mounting


Make cut-out(s) according to the details in the diagram on the right. The maximum panel thickness is 6 mm.



## CAUTION


Do not remove the panel gasket from the Counter as this may result in inadequate clamping of the Counter in the mounting panel.

Insert the rear of the Counter housing through the cut-out (from the front of the mounting panel) and hold the Counter lightly in position against the panel. Ensure that the panel gasket is not distorted and that the Controller is positioned squarely against the mounting panel. *Apply pressure to the front panel bezel only.* Slide the mounting bracket in place (see right) and push it forward until it is firmly in contact with the rear face of the mounting panel (tongues on the bracket should engage in matching ratchet positions on the Counter housing and the mounting bracket springs should push firmly against the mounting panel rear face).



# OPERATION

## FRONT PANEL



### Down key

**Operator Mode:** Used to change the currently-selected (flashing) digit. Depressing this key will decrement the value (wrap-around from 0 to 9). If the key is held continuously, the value will decrement at the rate of 2/sec.

**Program Mode:** Used to advance from one parameter to the next. Once a parameter value has been selected for editing (through use of the Next key), depressing this key will decrement the value (wrap-around from 0 to 9). If the key is held continuously, the value will decrement at the rate of 2/sec.

**Configuration Mode:** Used to advance from one parameter to the next.



### Next key

**Operator Mode:** Used to select a parameter for editing (left-most digit will start to flash) and to move between the digits. Once the proper digit is selected (flashing) with the Next key, its value can be altered through use of the Down key. Also used with RST key to reset the Batch Count.

**Program Mode:** Used to select a parameter for editing (left-most digit will start to flash) and to move between the digits. Once the proper digit is selected (flashing) with the Next key, its value can be altered through use of the Down key. For Decimal Point Position, this key scrolls through the available choices.

**Configuration Mode:** Used to select a parameter for editing and to scroll through available choices.



### ENT key

**Operator Mode/Program Mode:** Confirms an edited value (display will cease flashing after the ENT key is depressed).

**Configuration Mode:** Confirms setting/value selection (display will cease flashing after the ENT key is depressed).

Operator Mode - see Page 5.

Program Mode - see Page 6.

Configuration Mode - see Page 7.



### RST key

**Operator Mode/Program Mode:** Resets count value to either zero or Preset value (based on the setting of the Count Direction parameter in Configuration Mode). Also releases latched outputs. Also used with Next key to reset the Batch Count in Operator Mode.

**Configuration Mode:** Exits Configuration Mode when held down for 2 seconds.

**NOTE:** The RST key will not be active unless enabled in Configuration Mode.

### NOTE

To abort changes to a parameter value, press Down and Next together instead of ENT.

### IMPORTANT

In Edit Mode, you must press the ENT key within 15 seconds of the last keypress, otherwise the new data will be lost and the old data will be restored.

# PROGRAMMING

## OPERATOR MODE

### NOTE

Use Down key to step through Count/Preset display, Count/Batch Preset display and Count/Batch Count display (Count/Preset display will be shown on power-up).

### TO ABORT AN EDIT

To abort an edit operation (before the new value is confirmed), press the Down and Next keys simultaneously.

### TO RESET THE BATCH COUNT

To reset the Batch Count (to zero or to the Batch Preset value, according to the Count Direction parameter setting in Configuration Mode):

1. Select the Count/Batch Count display (BCH ON, PST OFF).

2. Press the Next and RST keys simultaneously.

NOTE: This is the only way to reset the Batch Count. It cannot be reset via the rear terminals. The RST key is operative for this function even when disabled in Configuration Mode.

### SETTING THE PRESET VALUE IN 8-DIGIT SINGLE PRESET COUNTER (UP\_8) MODE

To set a Preset value of abcdefgh:


1. Select the Count value/Preset value display (BCH OFF, PST ON) and enter efgh in the lower display in the normal manner.

2. Select the Preset value/Preset value display (BCH ON, PST ON) and enter abcd in the lower display in the normal manner.

### WARNING!

Caution should be observed if it is necessary to change the preset value while the process is operating. Do not set values which are already exceeded by the count value without resetting the counter.

The Operator Mode is used for viewing the Count/Batch Count value and viewing/changing the Preset/Batch Preset value.




NORMAL OPERATION	
LED(s) ON PST	Lower Display Preset
BCH & PST	Batch Preset
BCH	Batch Count *

\* "View Only" display - not editable.

8-DIGIT SINGLE PRESET (UP_8) OPERATION		
LED(s) ON PST	Upper Display Count value *	Lower Display Preset value (bottom 4 digits)
BCH & PST	Preset value (bottom 4 digits)	Preset value (top 4 digits)
BCH	Count value (bottom 4 digits) *	Count value (top 4 digits) *

\* "View Only" display - not editable.



Press the Next key to enter Edit Mode. The most significant digit of the Preset Data display will then flash. Press the Next key repeatedly as required to select the desired digit.

Press the Down key to change the value of the selected digit (there is wrap-round from 0 to 9).

When all digits are as required, press the ENT key to confirm the changes; the display will stop flashing.

### IMPORTANT

You must press the ENT key within 15 seconds of the last keypress when entering a new value, otherwise the new value will be discarded and the old value will be retained.

# PROGRAM MODE

## WARNING!



Changing Program Mode parameter values while the process is operating may be hazardous to the operator and/or the controlled equipment. Use extreme caution and stop the process before attempting to change Program Mode parameter values.

## IMPORTANT

You must press the **ENT** key to implement new parameter values.

## NOTE

Possible Decimal Point Position settings are:



To enter Program Mode, set the PGM input active (low) e.g. by tying it to COM. Whilst in Program Mode, the **PGM indicator will be ON**.

Function	Parameter Description (Upper Display)	Meaning
Pre-scaler <i>INPUT COUNTER MULTIPLIER/DIVIDER</i>		Pre-scales counter operation (multiply from 0.001 to 9.999) Value = $\frac{\text{Count units displayed}}{\text{Count pulses input}}$
Preset Output Time		Sets momentary ON time for Preset output (0.01 - 99.99s; 0.00 for latched operation)
Batch Preset Output Time		Sets momentary ON time for Batch Preset output (0.01 - 99.99s; 0.00 for latched operation)
Decimal Point		Defines decimal point position
Operator Mode:		
Preset	None	Shows Preset value
Batch Preset	None	Shows Batch Preset value
Batch Count	None	Shows Batch Count value

## NOTES

- To adjust Pre-scaler, Out Time or either Preset or Batch Preset value (as selected), press Next key to enter Edit Mode (digits will flash), use Next key to select each digit to be adjusted, and adjust digit value using Down key. When adjustment is complete, press **ENT** key to exit Edit Mode (digits will become static).
- To adjust decimal point position, select that parameter, press Next key to enter Edit Mode, then use Next key to position decimal point. Press **ENT** key when finished.


To exit Program Mode, set the PGM input inactive (High).



# SET UP


## CONFIGURATION MODE

To enter Configuration Mode, power-down the Counter and remove it from its housing. Change the position of the link jumper on the CPU PCB (the actual position is irrelevant, as long as the position is changed). Replace the Counter in its housing and power-up. The PGM indicator will flash whilst the Counter is in Configuration Mode.



To edit a parameter, use the Down key to step through the parameters; when the desired parameter description is shown in the upper display, press the Next key to enter Edit Mode and to scroll through the available settings. When the desired setting is shown, press the ENT key. The Configuration Mode parameters, in order of appearance, are:

Down key steps through parameters



Parameter	Parameter Description (Upper Display)	Available Settings
Counter Speed	SPEED	20Hz               200Hz               10kHz
Input Operation	INP	A-B (Add/Subtract)               Quadrature (bi-directional)               8-digit Single Preset Mode
Panel Reset Key	PRK	Enabled               Disabled
Auto Reset	ARS	Enabled               Disabled
Input Pull-Ups	PULL	Yes (current-sinking)               No (current-sourcing)
Count Direction	CDIR	Up-counting               Down-counting
Lock Strategy	LOC	None               Preset Lock               Partial Program Lock               Preset & Program Lock

### NOTE

When Input Operation is set to UP\_8, counter counts up from zero only (top 4 decades in Batch Preset, bottom 4 decades in Preset).

### LOCK STRATEGY:

- None = No security; all parameters available through regular methods of access
- Preset Lock = Preset/Batch Preset become Read Only
- Partial Lock = Output ON times are Read Only
- Both = Operator Mode parameters and Output ON times are Read Only.

To exit Configuration Mode, either momentarily remove power from the Counter or press and hold down the RST key for at least two seconds.

# APPENDIX A

## SPECIFICATIONS

### Input Power

AC:	Terminals 7 (Line) and 8 (Neutral) 90 - 264V 50/60Hz (standard) 20 - 50V AC 50/60Hz (option)
DC:	Terminals 7 and 8; 22 - 65V (option)
Power consumption:	4W approx.

### Output Power

DC:	Terminals 1 (+) and 4 (COM) 9 - 15V DC (unregulated) 0 - 100mA. $\leq 0.5V$ ripple
-----	--

### Main Counter

Decades:	4, Bi-directional (8, uni-directional in UP_8 mode)
Presets:	2 (4 decades each) - Preset & Batch Preset 1 (8 decades) in UP_8 mode
Operation:	Add/Subtract (Input A counts up, Input B counts down) or bi-directional (quadrature; counts up when Signal A leads Signal B).
Direction:	Up (reset-to-zero) or Down (set-to-a-number)
Count Rate	
High:	10kHz max.
Medium:	200Hz max.
Low:	20Hz max.
Resets:	Manual or automatic. Selectable reset-to-zero or reset-to-Preset

### Calibrator

Range:	0.001 to 9.999 Common to Inputs A and B.
--------	---

### Count Inputs

Signal A:	Terminal 2
Signal B:	Terminal 3
Input Voltage	
High:	$\geq 3.0V$ (source) $\geq 3.0V$ or open (sink)
Low:	$\leq 2.0V$ or open (source) $\leq 2.0V$ (sink)
Max.:	30V DC
Input Impedance	
Source:	10k $\Omega$ to COM
Sink:	4.7k $\Omega$ to +V
Input Response:	0.05ms (high speed)
(Source or sink)	2.5ms (medium speed) 25.0ms (low speed)

### Control Inputs

Remote Reset:	Terminal 5 (edge-sensitive)
Program Mode:	Terminal 6 (level-sensitive)
Input Voltage:	High - $\geq 3.0V$ or open Low - $\leq 2.0V$
Input Impedance:	4.7k $\Omega$ to +V
Input Response:	25.0ms
Max.:	30V DC

### Front Panel Keys

Type:	Mechanical switches under sealed membrane overlay.
-------	--

### Display

Type:	LED (red) 4 digit
Height:	Upper - 0.4" (10mm) Lower - 0.3" (7mm)

### Security

Preset data can be protected (selectable in Configuration Mode).  
Program data is accessible only if the PGM input is active.

### Output

Operation:	Output 1 energised when: Count = Preset 1 (Up mode) Count = 0 (Down mode)
	Output 1 released when: Hold time elapses or reset occurs
	Output 2 energised when: Batch Count = Batch Preset
	Output 2 released when: Hold time elapses or reset occurs

### SOLID STATE (OPEN COLLECTOR)

Terminal Nos.:	12 (Preset) and 15 (Batch Preset)
Type:	Open collector, current sink to COM. 30V DC max. 100mA max.

### RELAY

Terminals:	Preset: 9 (N/C), 10 (C), 11 (N/O) Batch Preset: 16 (N/C), 17 (C), 18 (N/O)
Type:	Form C (SPDT)
Rating:	5A resistive @ 110V AC 3A resistive @ 240V AC

### Mechanical

Cut-Out:	45mm x 45mm (1/16-DIN)
Depth:	110mm
Weight:	0.2kg approx.

### Environmental

Operating Temp.:	0 - 55°C (32 - 131°F)
Storage Temp.:	-20 - 80°C (-4 - 176°F)
Relative Humidity:	20 - 95% non-condensing
Front Panel Seal:	NEMA 4/IP65 when installed with panel gasket (supplied)



## WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **13 months** from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal **one (1) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components which wear are not warranted, including but not limited to contact points, fuses, and triacs.

**OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by it will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESS OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.**

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

## RETURN REQUESTS/INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of the product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 1999 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.

# Where Do I Find Everything I Need for Process Measurement and Control? OMEGA...Of Course!

## **TEMPERATURE**

- Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- Wire: Thermocouple, RTD & Thermistor
- Calibrators & Ice Point References
- Recorders, Controllers & Process Monitors
- Infrared Pyrometers

## **PRESSURE, STRAIN AND FORCE**

- Transducers & Strain Gages
- Load Cells & Pressure Gages
- Displacement Transducers
- Instrumentation & Accessories

## **FLOW/LEVEL**

- Rotameters, Gas Mass Flowmeters & Flow Computers
- Air Velocity Indicators
- Turbine/Paddlewheel Systems
- Totalizers & Batch Controllers

## **pH/CONDUCTIVITY**

- pH Electrodes, Testers & Accessories
- Benchtop/Laboratory Meters
- Controllers, Calibrators, Simulators & Pumps
- Industrial pH & Conductivity Equipment

## **DATA ACQUISITION**

- Data Acquisition & Engineering Software
- Communications-Based Acquisition Systems
- Plug-in Cards for Apple, IBM & Compatibles
- Datalogging Systems
- Recorders, Printers & Plotters

## **HEATERS**

- Heating Cable
- Cartridge & Strip Heaters
- Immersion & Band Heaters
- Flexible Heaters
- Laboratory Heaters

## **ENVIRONMENTAL MONITORING AND CONTROL**

- Metering & Control Instrumentation
- Refractometers
- Pumps & Tubing
- Air, Soil & Water Monitors
- Industrial Water & Wastewater Treatment
- pH, Conductivity & Dissolved Oxygen Instruments