




User's Guide



*<http://www.omega.com>
e-mail: info@omega.com*

DRA-RTT-2 Temperature Two-Wire Transmitter Operator's Manual



Servicing North America:

| | | |
|--|--|--|
| USA: <u>ISO 9001 Certified</u> | One Omega Drive, Box 4047 Stamford, CT 06907-0047 Tel: (203) 359-1660 FAX: (203) 359-7700 e-mail: info@omega.com | Canada : 976 Bergar Laval (Quebec) H7L 5A1 Tel: (514) 856-6928 FAX: (514) 856-6886 e-mail: canada@omega.com |
|--|--|--|

For immediate technical or application assistance:

| | |
|--------------------------------------|---|
| USA and Canada: | Sales Service: 1-800-826-6342 / 1-800-TC-OMEGASM Customer Service: 1-800-622-2378 / 1-800-622-BESTSM Engineering Service: 1-800-872-9436 / 1-800-USA-WHENS M |
| Mexico and Latin America: | Tel: (95) 800-TC-OMEGASM FAX: (95) 203-359-7807 En Espanol: (95) 203 359-7803 e-mail: espanol@omega.com |

Servicing Europe:

| | |
|-----------------|---|
| Benelux: | Postbus 8034, 1180 LA Amstelveen, The Netherlands Tel: (31) 20 64184 Fax (31) 20 6434643 Toll Free in Benelux: 06 0993344 e-mail: nl@omega.com |
|-----------------|---|

Czech Republic: Ostravska 767,733 01 Karvina
Tel:42(69)6311899 Fax:42(69) 6311114
e-mail: czech@omega.com

France: 9, rue Denis Papin, 78190 Trappes
Tel: (33) 130-621-40 Fax: (33) 130-699-120
Toll Free in France: 0800-4-06342
e-mail: france@omega.com

Germany/Austria: Daimlerstrasse 26, D-75392 Deckenpfronn, Germany
Tel: 49 (07056) 301 FAX: 49 (07056) 8540
Toll Free in Germany: 0130 11 21 66
e-mail: germany@omega.com

United Kingdom:
ISO 9002 Certified 25 Swannington Road, P.O. Box 7, Omega Drive,
Broughton Astley, Leicestershire, Irlam, Manchester,
LE9 6TU, England M44 5EX, England
Tel: 44 (1455) 285520 Tel: 44 (161) 777-6611
FAX: 44 (1455) 283912 FAX: 44 (161) 777-6622
Toll Free in England: 0800-488-488
e-mail: uk@omega.com

It is the policy of OMEGA to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification. The information contained in this document is believed to be correct but OMEGA Engineering, Inc. accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

WARNING: These products are not designed for use in, and should not be used for, patient connected applications.

DRA-RTT-2

Contents

1. PROCEDURE TO OPEN THE ENCLOSURE
2. CALIBRATION INSTRUCTIONS
 - 2.1 Switch Setting
 - 2.2 Calibration Tables
 - 2.3 Calibration Example
3. CONNECTION DIAGRAM
4. MECHANICAL DIMENSIONS
5. SPECIFICATIONS

1. PROCEDURE TO OPEN THE ENCLOSURE

Carefully insert a proper screwdriver tip into the side slot. By pressing inward and rotate the plastic locker will release. Gently pull out the unit's back cover.

2. CALIBRATION INSTRUCTIONS

2.1 Switch Setting

Six DIP switches are located inside the enclosure for coarse range, and two multi-turn potentiometers are located on the front panel for fine tuning.

* Define the desired range limits:

T_{min} - the temperature at which the output current is 4mA.

T_{max} - the temperature at which the output current is 20mA.

T_{span} - the difference between T_{max} and T_{min} .

According to the following tables, set switches no.1 to 3 for the Zero (T_{min}), and set switches 4 to 6 for the Span (T_{span}).

Note: "1" represents the switch "ON" state.

2.2 Calibration Tables

"Zero" Table

| Tmin °C | SW1 | SW2 | SW3 |
|-----------|-----|-----|-----|
| -55 ~ 25 | 1 | 1 | 1 |
| -25 ~ 7 | 0 | 1 | 1 |
| 7 ~ 40 | 1 | 0 | 1 |
| 40 ~ 73 | 0 | 0 | 1 |
| 73 ~ 105 | 1 | 1 | 0 |
| 105 ~ 138 | 0 | 1 | 0 |
| 138 ~ 170 | 1 | 0 | 0 |
| 170 ~ 202 | 0 | 0 | 0 |

"Span" Table


| Tspan °C | SW4 | SW5 | SW6 |
|-----------|-----|-----|-----|
| 30 ~ 55 | 1 | 1 | 1 |
| 50 ~ 90 | 1 | 0 | 0 |
| 90 ~ 185 | 0 | 1 | 0 |
| 185 ~ 380 | 0 | 0 | 1 |
| 380 ~ 810 | 0 | 0 | 0 |

2.3 Calibration Example:

Needed: $-50 \sim +50^{\circ}\text{C}$


Tmin: -50°C

Tspan: $50 - (-50) = 100^{\circ}\text{C}$





- Set the DIP switches to: 1,1,1,0,1,0 (sw1..sw6)
- Set the calibrator for -50° and calibrate "Z" to 4.000mA.
- Set the calibrator for $+50^{\circ}$ and calibrate "S" to 20.000mA.
- Repeat steps a~c until satisfactory results are obtain.

3. CONNECTION DIAGRAM



4. MECHANICAL DIMENSIONS

Dimensions in mm (inch)



5. SPECIFICATIONS

- INPUT: 3-wire Pt-100 according to BS 1904 and DIN 43760 characteristics, $\alpha = 0.00385$
- INPUT SPAN CHANGE: 30 to 810°C
Span Calibration: Three DIP switches and "Span" potentiometer
- INPUT ZERO CHANGE: -55 to +202°C
Zero Calibration: Three DIP switches and "Zero" potentiometer
- LEADS COMPENSATION ERROR:
< $\pm 0.05^{\circ}\text{C} / 10 \Omega$ leads resistance
- SENSOR LEAD RESISTANCE:
< 50Ω (two ways)
- SENSOR EXCITATION: < 1mA
- OUTPUT: 4 - 20mA, (28mA limited)
- LOOP RESISTANCE:
 $R_{\text{max}}(\Omega) = (V_{\text{supply}} - 10) / .02$

- ACCURACY (linearity, hysteresis and repeatability):
 $< \pm 0.1\%$ of span
- TEST TERMINALS: 40 to 200 mV represent 4-20 mA
- SUPPLY VOLTAGE: 10 - 36 Vdc reverse
polarity protected
- SUPPLY AND LOAD VARIATION EFFECT:
 $< \pm 0.03\%$ of span for full change
- TEMPERATURE STABILITY: $\pm 0.015\%$ of span /1°C
- OPERATING TEMPERATURE: -4 to 158°F (-20 to +70°C)
- STORAGE TEMPERATURE: -22 to 185°F (-40 to +90°C)
- HUMIDITY: 5 - 95% relative humidity, non-condensing
- ENCLOSURE: Plastic polycarbonate
- PROTECTION LEVEL: enclosure: According to IP-40
Terminals: According to IP-20
- MOUNTING: Standard 35 mm DIN rail
- WEIGHT: 2.5 oz (70 grams)

WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of 13 months from date of purchase. OMEGA Warranty adds an additional one (1) month grace period to the normal one (1) year product warranty to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product. If the unit should malfunction, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of being damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components which wear are not warranted, including but not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors

nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by it will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY / DISCLAIMER language, and additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

RETURN REQUESTS / INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence. The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR WARRANTY RETURNS, please have the following information available BEFORE contacting OMEGA:

1. P.O. number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR NON-WARRANTY REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. P.O. number to cover the COST of the repair,
2. Model and serial number of product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible.

This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 1996 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without prior written consent of OMEGA ENGINEERING, INC.

Where Do I Find Everything I Need for Process Measurement and Control? OMEGA...Of Course!

TEMPERATURE

- ☑ Thermocouple, RTD & Thermistor Probes,
- ☑ Connectors, Panels & Assemblies
- ☑ Wire: Thermocouple, RTD & Thermistor
- ☑ Calibrators & Ice Point References
- ☑ Recorders, Controllers & Process Monitors
- ☑ Infrared Pyrometers

PRESSURE, STRAIN AND FORCE

- ☑ Transducers & Strain Gauges
- ☑ Load Cells & Pressure Gauges
- ☑ Displacement Transducers
- ☑ Instrumentation & Accessories

FLOW/LEVEL

- ☑ Rotameters, Gas Mass Flowmeters & Flow Computers
- ☑ Air Velocity Indicators
- ☑ Turbine/Paddlewheel Systems
- ☑ Totalizers & Batch Controllers

PH/CONDUCTIVITY

- ☑ pH Electrodes, Testers & Accessories
- ☑ Benchtop/Laboratory Meters
- ☑ Controllers, Calibrators, Simulators & Pumps
- ☑ Industrial pH & Conductivity Equipment
- ☑ Data Acquisition & Engineering Software
- ☑ Communications-Based Acquisition Systems
- ☑ Plug-in Cards for Apple, IBM & Compatibles
- ☑ Datalogging Systems
- ☑ Recorders, Printers & Plotters

HEATERS

- ☑ Heating Cable
- ☑ Cartridge & Strip Heaters
- ☑ Immersion & Band Heaters
- ☑ Flexible Heaters
- ☑ Laboratory Heaters

ENVIRONMENTAL

MONITORING AND CONTROL

- ☑ Metering & Control Instrumentation
- ☑ Refractometers
- ☑ Pumps & Tubing
- ☑ Air, Soil & Water Monitors
- ☑ Industrial Water & Wastewater Treatment
- ☑ pH, Conductivity & Dissolved Oxygen Instruments