





omega.com e-mail: info@omega.com For latest product manuals: omegamanual.info



# eZ-PostView and eZ-Analyst

**Post Acquisition Analysis Applications** 



<b>OMEGAnet<sup>sm</sup> On-Line Service</b>	
http://www.omega.com	

Internet e-mail

## **Servicing North America:**

USA: ISO 9001 Certified	One Omega Drive, Box 4047 Stamford, CT 06907-0047 Tel: (203) 359-1660 e-mail: <u>info@omega.com</u>	FAX: (203) 359-7700
Canada:	976 Berger Laval (Quebec) H7L 5A1 Tel: (514) 856-6928 e-mail: <u>canada@omega.com</u>	FAX: (514) 856-6886
For immed	liate technical or applicat	ion assistance:
USA and Canada:	Sales Service: 1-800-826-6342 / 1-800-TC Customer Service: 1-800-622-2378 / 1-80 Engineering Service: 1-800-872-9436 / 1- TELEX: 996404 EASYLINK: 62968934	C-OMEGA <sup>SM</sup> 0-622-BEST <sup>SM</sup> 800-USA-WHEN <sup>SM</sup> 4 CABLE: OMEGA
Mexico and		
Latin America:	Tel: (95) 800-TC-OMEGA <sup>SM</sup> En Espanol: (95) 203-359-7803	FAX: (95) 203-359-7807 e-mail: <u>espanol@omega.com</u>
	Servicing Europe:	
Benelux:	Postbus 8034, 1180 LA Amstelveen, The	Netherlands
	Tel: (31) 20 6418405 Toll Free in Benelux: 06 0993344 e-mail: <u>nl@omega.com</u>	FAX: (31) 20 6434643
Czech Republic:	ul. Rude armady 1868 733 01 Karvina-Hranice Tel: 420 (69) 6311899 e-mail:czech@omega.com	FAX: 420 (69) 6311114
France:	9, rue Denis Papin, 78190 Trappes Tel: (33) 130-621-400 Toll Free in France: 0800-4-06342 e-mail: <u>france@omega.com</u>	FAX: (33) 130-699-120
Germany/Austria:	Daimlerstrasse 26, D-75392 Deckenpfron	n, Germany
	Tel: 49 (07056) 3017 Toll Free in Germany: 0130 11 21 66 e-mail: <u>germany@omega.com</u>	FAX: 49 (07056) 8540
United Kingdom: ISO 9002 CertIfled	25 Swannington Road, Broughton Astley, Leicestershire, LE9 6TU, England Tel: 44 (1455) 285520 FAX: 44 (1455) 283912 Toll Free in England: e-mail: <u>uk@om</u>	P.O. Box 7, Omega Drive, Irlam, Manchester, M44 5EX, England Tel: 44 (161) 777-6611 FAX: 44 (161) 777-6622 0800-488-488 mega.com

It is the policy of OMEGA to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct but OMEGA Engineering, Inc. accepts no liability for any errors it contains, and reserves the right to alter specifications without notice. **WARNING:** These products are not designed for use in, and should not be used for, patient-connected applications.

eZ-PostView User's Guide (p/n 1086-0926, rev 2.0)

**Time-Domain Post-Data Acquisition View Application** 

eZ-PostView User's Click Here

# eZ-Analyst Series software Reference (p/n 1086-0922, rev 6.0)

for Users of

eZ-Analyst eZ-TimeView eZ-FrequencyView

Users of these Applications Click Here

## Introduction

## Ch 1 – Getting Started with eZ-PostView

System Requirements ..... 1-1 Software Installation ..... 1-2

## Ch 2 – eZ-PostView Menus and Windows

Features of eZ-PostView ..... 2-1 File Menu ..... 2-3 Edit Menu ..... 2-4 Window Menu ..... 2-11

#### Ch 3 – Interactive Features of eZ-PostView's Plot Display Window

How to Change Plot Display Characteristics ......3-2 How to Change "Focus" ...... 3-2. How to Add and Remove Channels ...... 3-2 Other Features ...... 3-3

Appendix A – Keyboard Controls



eZ-PostView Can Be Used without the Presence of Acquisition Hardware

*eZ-PostView* is a time-domain post-acquisition data viewing application that has been integrated with primary data acquisition software, including *DaqView*, *Personal DaqView*, *ChartView*, *LogView*, and *WaveView*.

The *eZ-PostView* application provides easy-to-use post-acquisition analysis capability, and is included free of charge as a part of product support. From this application you can display up to 8 time-domain function windows and display up to 16 channel traces per window. Data is automatically scaled to optimize its fit in the window.

From *eZ-PostView* you can customize window, channel trace, and cursor colors.



#### A Screen Capture from eZ-PostView

Once installed, *eZ-PostView* can be launched from the data-acquisition program by a simple click of the <View Data> button. As an alternative, the application can be launched independent of the acquisition program and supported data files can be loaded for viewing.

#### eZ-PostView includes the following features:

- File Input Format Support for: *DaqView, WaveView, Personal DaqView, ChartView*, Universal File Format UFF-58B.
- Can show 8 Display Windows simultaneously
- Can show 16 Channel Traces per Display Window
- Includes Automatic Data Scaling
- User-Configurable Data Display is provided for channels and trace colors
- Allows for multiple Tiling, or Cascading, of display windows

*eZ-PostView* makes use of buttons similar to those found on VCRs. As indicated by the following figure, you can select to play the data display forward, backward, or frame by frame in either direction. The playback task bar is located just below the menu bar, which is detailed in chapter 2.



Playback Task Bar

System Requirements ..... 1-1 Software Installation ..... 1-2

## System Requirements

Your computer should meet the following **minimum** requirements.

- Intel<sup>™</sup>, Pentium 90 MHz or equivalent
- 64 MB Memory
- 100 MB Hard Disk space
- Monitor: SVGA, 800 x 600 resolution
- One of the following Microsoft<sup>®</sup> Windows Operating Systems:
  - Windows 98 Windows Me Windows NT Windows 2000
  - Windows XP



If you purchased software, associated authorization codes will accompany your installation CD. If this is the case, keep your codes in a safe place. You will need to enter them once, during an actual run of the purchased software.

Note that no authorization code or password is needed to run eZ-PostView.

## Software Installation



Before installing a version of our data-acquisition software, remove all previous versions of that software.

#### **Reference Notes**:

- Adobe Acrobat PDF versions of documents pertaining to your system hardware and software are automatically installed onto your PC's hard-drive as a part of product support at the time of software installation. The default location is the **Programs** group, which can be accessed via the *Windows Desktop Start Menu*.
- > PDF versions of documents can be read directly from the data acquisition CD.
- After your software is installed you can setup your data acquisition device, e.g., WaveBook, DaqBook, LogBook, and connect it to the host computer. Instructions for hardware setup are included in your device user's manual, which is included on the CD.

When you first install software for your acquisition device, *eZ-PostView* will automatically be selected for installation along with the primary acquisition software application. For example, when a WaveBook is selected, both *WaveView* and *eZ-PostView* will show as pre-selected software options.

To install eZ-PostView ...

- 1. Start Windows.
- 2. Close all running applications.
- 3. Insert the Data Acquisition CD into your CD-ROM drive and wait for the CD to auto-run.

If the CD does not start on its own:

- (a) click the desktop's <Start> button
- (b) choose the Run command
- (c) select the CD-ROM drive, then select the **setup.exe** file
- (d) click <OK>

An Opening Screen will appear.

- 4. Click the **<ENTER SETUP>** button.
- 5. On the hardware selection screen [which follows a licensing agreement], select your hardware from the drop-down list.
- 6. On the resulting software options screen, select the software that is applicable to your system. Note that *eZ-PostView* is already selected by default.
- 7. Click the <Install> button; then follow the screen prompts to complete the installation.



You will be prompted to enter an Authorization Code.

- ➢ If you purchased *eZ-TimeView* or *eZ-FrequencyView* enter the code for the associated application; then click the <Apply Code> button.
- If you are installing eZ-PostView [which requires no code], simply click the <OK> button or, if you prefer, click the <Start 30 Day Trial> button to try out the more powerful eZ-FrequencyView Application.

uthorization		×
Enter Authorization Code:		
Feature	Authorization	
Apply Code Start 30 Day	Trial OK	
	uthorization       Enter Authorization Code:       Feature       Apply Code	uthorization         Enter Authorization Code:         Feature         Authorization         Authorization         Apply Code         Start 30 Day Trial         OK

Authorization Dialog Box

**Note**: Entry of your Authorization Code is only required once. However, you can enter a new code at a future date, for example, if you wanted to upgrade from *eZ-PostView* to *eZ-FrequencyView*.

#### To open the Authorization Dialog Box:

- 1. Open *eZ-PostView*. You can open *eZ-PostView* by clicking the *<***ViewData***>* button in your primary data acquisition program, e.g. *WaveView, DaqView, LogView,* etc.
- 2. From *eZ-PostView's* File Pull-Down menu, select *Authorization* (following figure). The *Authorization* dialog box appears.

File	Edit	Export	Window	н
0	pen D	ata File		
S	ave Da	ata File		
S	ave Plo	ot Setup(i	PSET)	
R	ecall P	lot Setup	(PSET)	
PI	rint			
C	:\Prog	ram Files'	(eZ-View\e	ZA
A	uthoria	zation		
E	xit			

File Menu

#### To enter a code:

- 1. Type-in the code, as it appears on your Authorization Sheet.
- 2. Click the **<Apply Code>** button.



## Contents

Features of eZ-PostView ..... 2-1 File Menu ..... 2-3 Edit Menu ..... 2-4 Configuration Window ..... 2-4 Acquisition Tab..... 2-5 Channels Tab ..... 2-6 Playback Setup Window ..... 2-7 Window Colors Window..... 2-8 Preferences Window ..... 2-9 Window Menu ..... 2-11 Add Function View (FV) ..... 2-11 Delete Window ..... 2-11 Channel Buttons ..... 2-11 Cascade ..... 2-12 Tile Vertically ..... 2-12 Tile Horizontally ..... 2-13 Refresh Windows ..... 2-13

# Features of eZ-PostView

The free eZ-PostView application includes the following features.

- File Input Format Support for: DaqView, WaveView, Personal DaqView, ChartView, UFF-58B.
- 8 Display Windows
- 16 Channel Traces per Display Window
- Automatic Data Scaling
- Configurable Data Display for channels and trace colors
- Multiple Tiling of display windows

Note that *eZ-PostView* was derived from a much more versatile *eZ-Analyst* program. A comparison of *eZ-PostView* features to those of eZ-Analyst and 2 other derived applications appears on page 2-2.

As indicated by the following table, many features do not apply to *eZ-PostView*. In the screen images, both those of the actual application and those presented as figures in this manual, information that does not apply to *eZ-PostView* is either "grayed-out" or "hidden." The same applies to functions of the pull-down menus.



#### **Reference Note:**

The document, *eZ-Analyst Series Software Reference*, p/n 1086-0922 contains information that is applicable to the higher-level "view" programs *eZ-TimeView and eZ-FrequencyView*, and to *eZ-Analyst*. The *eZ-Analyst Series* document includes information regarding the Miscellaneous and the Octave Tabs, which do not apply to *eZ-PostView*.

eZ-Analyst Series Comparison Matrix					
Feature	Post-A	e7-Analyst			
	eZ-PostView	eZ-TimeView	eZ-FrequencyView	•_ /	
File Input Format Support for: DaqView, WaveView, Personal DaqView, ChartView, UFF-58B.	Yes	Yes	Yes	Yes	
File Export to: ME'Scope and SMS Modal, Microsoft Excel, Binary Universal File, and ASCII text files.		Yes	Yes	Yes	
Display Windows, number of	8	8	8	8	
Channel Traces per Display Window	16	16	16	16	
Automatic Data Scaling	Yes	Yes	Yes	Yes	
Simulated Data Playback		Yes	Yes	Yes	
Configurable Data Display for channels and trace colors	Yes	Yes	Yes	Yes	
Multiple Tiling of display windows	Yes	Yes	Yes	Yes	
Cursor Support - for both Single Cursor and Band Cursor		Yes	Yes	Yes	
Data Strip Chart Display		Yes	Yes	Yes	
Peak-to-Peak Calculations		Yes	Yes	Yes	
Peak Searching, minimum and maximum		Yes	Yes	Yes	
Mean Calculations		Yes	Yes	Yes	
RMS Calculations		Yes	Yes	Yes	
Zooming [of the data display]		Yes	Yes	Yes	
Windowed Time Display Function		Yes	Yes	Yes	
Cross Channel Support			FFT, FRF, Cross, Coherence, Transfer Function	FFT, FRF, Cross, Coherence, Transfer Function	
Transfer Function Display Types			Note 1	Note 1	
Complex Function Display Types			Note 2	Note 2	
Scale Types		RMS, Peak, Peak-to-Peak	RMS, Peak, Peak-to-Peak	RMS, Peak, Peak-to-Peak	
Function Display Types		Time, Strip Chart	Note 3	Note 3	
Octave Types			1/3, Full	1/3, Full	
Octave Weighting			Linear, A, B, C	Linear, A, B, C	
Waterfall Plots			Yes	Yes	
Integration/Differentiation (Single/Double)			Yes	Yes	
Response Channel FFT Windows			Note 4	Note 4	
Reference Channel FFT Windows			Rectangular, Cosine Taper	Rectangular, Cosine Taper	
Low-Pass DC Noise Filtering			Yes	Yes	
Spectral Strip Chart Display Synchronization			Yes	Yes	
Octave Strip Chart Display Synchronization			Yes	Yes	
Record and Save Data to Disk				Yes	
"Real Time" Data Display				Yes	

## Comparing eZ-PostView to other eZ-Analyst Series Applications

Notes: 1) *eZ-Analyst* and *eZ-FrequencyView* - each offers the following Transfer Function Display Types: Inertance, Mobility, Compliance, Apparent Mass, Impedance, and Dynamic Stiffness.

2) eZ-Analyst and eZ-FrequencyView - each offers the following Complex Function Display Types: Magnitude, Phase, Real, Imaginary, Nyquist, Magnitude and Phase, and Real and Imaginary.

3) **eZ-Analyst** and **eZ-FrequencyView** - each offers the following **Function Display Types:** Spectrum, Auto-Spectrum, PSD (Power Spectral Function), Strip Chart.

4) eZ-Analyst and eZ-FrequencyView – each offers the following Response Channel FFT Windows: Hanning, Flat Top, Exponential, and Blackman-Harris.

# File Menu

The File Menu provides a means to print plotted data, as well as open and save data files.

#### Open Data File ... (.thd or .dsc)

Used to locate and open saved files. ZonicBook uses files with **.thd** extensions. View applications, i.e., WaveView, DaqView, Personal DaqView, LogView, and ChartView use files with **.dsc** extensions.

#### Save Plot Setup (PSET) ...

These two menu items provide a means of saving [or opening] function files. Time and auto-spectrum data is saved. If there is any reference channel cross-spectrum is saved for all channel pairs. The file extension is **.mds**.

### Recall Plot Setup (PSET) ...

These two menu items provide a means of saving [or recalling] the current plot condition, such as window locations and window content, including: channel numbers, function type, axis-type, and range. These files can be recalled at a later date to process customized plot conditions.

Without user intervention, the plot setup file is automatically saved with .mds, .dsc, and .thd files.



You can have plot setups automatically recalled whenever you recall data files. To select this option, open the Preferences window [accessed through the Edit pull-down menu] and check the box labeled "Recall Plot Setup When Recall Data Files."

#### Print

The standard print window associated with your specific computer will open. Select a printer and the number of copies needed before clicking <OK>.

Note: In regard to printing, black plot backgrounds changed to white.

#### Authorization

Provides a means of enabling additional view features that are available with purchased software, i.e., *eZ-TimeView* and *eZ-FrequencyView*. Aside from a trial period, an authorization code is required to enable the applications available features. *eZ-TimeView*, *eZ-FrequencyView*, and the *eZ-Analyst* program from which they were derived are discussed in the document, *eZ-Analyst Series Software Reference*, p/n 1086-0922.

#### Exit

This menu item closes the *eZ-PostView* application.

# Edit Menu

The Edit Menu provides a means of configuring *eZ-PostView* in regard to both functionality and appearance. The menu contains the following selections, each of which is detailed in the subsequent sections:

Configuration Window..... 2-4 Playback Setup Window..... 2-7 Window Colors Window..... 2-8 Preferences Window..... 2-9

# Edit Menu > Configuration Window

The **Configuration** item provides a means of changing the majority of *eZ-PostView* settings in regard to determining how the data is manipulated. The Configuration selection displays the **Configuration Window** with one of several tab dialogs displayed. Selectable tabs are:

Acquisition Tab..... 2-5 Input Channels Tab ..... 2-6 Octaves Tab (the tab is present, but does not apply to *eZ-PostView*) Miscellaneous Tab (the tab is present, but does not apply to *eZ-PostView*)

· · · · · · · · · · · · · · · · · · ·	hand Oliverate Y	0.1	Y
Acquisition	Input Channels	Uctaves	Miscellaneous
Acquisition Sample Rate: 2560. samples / ser Time Blocksize: 2048 Time Block : 0.00039 seconds Time Block: 0.8000 seconds File Size: 10.00 seconds 13 blocks 0.3945 MB	Trigger Conditions	3	

eZ-PostView's Acquisition Setup Tab

## Edit Menu > Configuration > Acquisition Tab: <u>Acquisition Panel</u>

With respect to eZ-PostView, the Acquisition Panel provides "read-only" text pertaining to the following:

Sample Rate (samples per second)

Time Blocksize (Acceptable blocksizes range from 128 to 16384 data points).

Time Delta X

Time Block

File Size in: seconds blocks disk space in MB

## Edit Menu > Configuration >

The Input Channels tab displays the setup conditions of the input channels as they were when the acquisition was saved-to-disk. Actual hardware setup can not be changed from *eZ-PostView*. The grayed-out columns, in the following figure, can not be changed from *eZ-PostView*.

No.         Active         Label         R Type         FSV         EU Mode         mV/EU         EU offset Mode         dB Ref(EU/V)         Units         Location           1         ON         Channel 1         Response         20:00         Voit         20:00         1:000(V)         mils         1           2         ON         Channel 2         Response         20:00         Voit         20:00         1:000(V)         mils         2           3         ON         Channel 3         Response         20:00         Voit         20:00         0:00302         1:000(V)         mils         2           4         ON         Channel 4         Response         20:00         Voit         10:00         0:00321         1:000(V)         gris         3           4         ON         Channel 5         Response         20:00         Voit         10:00         0:00621         1:000(V)         gris         5           6         ON         Channel 6         Response         20:00         Voit         10:00         0:00621         1:000(V)         Voits         6           7         ON         Channel 7         Response         20:00         Voit         10:00		Acq	uisition	Inpu	t Channels	Ľ	0	ctaves	Ŷ	Miscella	aneous
1         ON         Channel 1         Response         20.00         Vot         200.0         120.0         1.000(V)         mis         1           2         ON         Channel 2         Response         20.00         Vot         200.0         0.00302         1.000(V)         mis         2           3         ON         Channel 3         Response         20.00         Vot         100.0         0.0062         1.000(V)         gis         3           4         ON         Channel 4         Response         20.00         Vot         100.0         0.0062         1.000(V)         gis         3           5         ON         Channel 5         Response         20.00         Vot         100.0         0.0062         1.000(V)         gis         5           6         ON         Channel 6         Response         20.00         Vot         100.0         0.0062         1.000(V)         Vots         6           7         ON         Channel 7         Response         20.00         Vott         1000.0         0.00606         1.000(V)         Votts         8           8         ON         Channel 8         Response         20.00         Vott         1000	No.	Active	Label	R Type	FSV	EU Mode	m∨/EU	EU Offset	dB Ref(EU V)	Units	Location
2         0N         Channel 2         Response         20.00         Volt         200.0         0.00322         1.000(V)         mils         2           3         0N         Channel 3         Response         20.00         Volt         100.0         0.0052         1.000(V)         g/s         3           4         0N         Channel 4         Response         20.00         Volt         100.0         0.0062         1.000(V)         g/s         3           5         0N         Channel 5         Response         20.00         Volt         100.0         0.00679         1.000(V)         g/s         4           6         ON         Channel 6         Response         20.00         Volt         100.0         0.0062         1.000(V)         Volts         6           6         ON         Channel 7         Response         20.00         Volt         1000.0         0.00660         1.000(V)         Volts         6           7         ON         Channel 7         Response         20.00         Volt         1000.0         0.00660         1.000(V)         Volts         8	1	ON	Channel 1	Response	20.00	Volt	200.0	120.0	1.000(V)	mils	1
3         0N         Channel 3         Response         20.00         Volt         100.0         0.00622         1.000(V)         g's         3           4         0N         Channel 4         Response         20.00         Volt         100.0         0.00619         1.000(V)         g's         4           5         0N         Channel 5         Response         20.00         Volt         100.0         0.00611         1.000(V)         g's         5           6         0N         Channel 6         Response         20.00         Volt         1000.         0.00621         1.000(V)         Volts         6           7         0N         Channel 7         Response         20.00         Volt         1000.         0.00661         1.000(V)         Volts         7           8         0N         Channel 8         Response         20.00         Volt         1000.         0.00661         1.000(V)         Volts         8	2	ON	Channel 2	Response	20.00	Volt	200.0	0.00302	1.000(V)	mils	2
4         0N         Channel 4         Response         20.00         Volt         100.0         0.00619         1.000(V)         g/s         4           5         0N         Channel 5         Response         20.00         Volt         100.0         0.00621         1.000(V)         g/s         5           6         0N         Channel 6         Response         20.00         Volt         1000         0.00621         1.000(V)         Volt         6           7         0N         Channel 7         Response         20.00         Volt         1000.         0.00661         1.000(V)         Volts         7           8         0N         Channel 8         Response         20.00         Volt         1000.         0.00661         1.000(V)         Volts         8	3	ON	Channel 3	Response	20.00	Volt	100.0	0.00622	1.000(V)	g's	3
5         0N         Channel 5         Response         20.00         Volt         100.0         0.00621         1.000(V)         g/s         5           6         0N         Channel 6         Response         20.00         Volt         1000.         0.0062         1.000(V)         Volts         5           7         0N         Channel 7         Response         20.00         Volt         1000.         0.0060         1.000(V)         Volts         7           8         0N         Channel 8         Response         20.00         Volt         1000.         0.00600         1.000(V)         Volts         8	4	ON	Channel 4	Response	20.00	Volt	100.0	0.00619	1.000(V)	g's	4
6         0N         Channel 6         Response         20.00         Volt         1000.         0.00062         1.000(V)         Volts         5           7         0N         Channel 7         Response         20.00         Volt         1000.         0.00060         1.000(V)         Volts         7           8         0N         Channel 8         Response         20.00         Volt         1000.         0.00060         1.000(V)         Volts         8	5	ON	Channel 5	Response	20.00	Volt	100.0	0.00621	1.000(V)	g's	5
7         0N         Channel 7         Response         20.00         Voit         1000.         0.00060         1.000(V)         Voits         7           8         0N         Channel 8         Response         20.00         Voit         1000.         0.00060         1.000(V)         Voits         8	6	ON	Channel 6	Response	20.00	Volt	1000.	0.00062	1.000(V)	Volts	6
8 ON Channel 8 Response 20.00 Volt 1000. 0.00060 1.000(V) Volts 8	7	ON	Channel 7	Response	20.00	Volt	1000.	0.00060	1.000(V)	Volts	7
	8	ON	Channel 8	Response	20.00	Volt	1000.	0.00060	1.000(V)	Volts	8
									1	122	

Input Channels Tab Selected

No.:	This column lists all available channels. It can not be edited.
Active:	Shows "ON" for input channels that were active during the acquisition. The column can not be edited in <i>eZ-PostView</i> .
Label:	This should be a meaningful channel name. Highlight a cell before typing a label. When you press the Enter key, the label is accepted.
Response Reference	There are two types of channels, <b>Response</b> and <b>Reference</b> . All channels are initialized as Response channels. The column can not be edited in <i>eZ-PostView</i> .
FSV:	Full-Scale Voltage. The cells in this column are used to set the FSV value in Volts. This column can not be edited in <i>eZ-PostView</i> .
EU Mode:	<b>E</b> (ngineering) <b>U</b> (nits): Select EU or Volt. This column can not be edited in <i>eZ-PostView</i> .
Units:	Enter the measurement units you will be using.
Location:	This is a simple numbering system. The channel number is the default value for location. However, you can highlight a cell and type a different location number. When you press the Enter key, the value is accepted.
Coord:	This is the axial direction of the transducer that was connected to the channel. This column can not be edited in <i>eZ-PostView</i> .
Input Type:	This is the type of instrument that was attached to the channel. Menu selections include: Acceleration, Velocity, Displacement, Force, Pressure, Stress, Strain, General, and Tach (Tachometer). This column can not be edited in <i>eZ-PostView</i> .

## Edit Menu > Playback Setup Window: Source Information Panel

There are no playback functions that can be setup from within the *eZ-PostView* application. However, the window's *Source Information* panel does provide general file related information such as filename, file location, the number of active channels, sample rate, block size, the number of blocks recorded, and recorded time.

The panel includes a Comments box for user remarks.

owner Information			
ource mormation			
Filename:	C:\Program	n –	
Files\eZ-View\eZAnaly	st.thd		
Active Channels:	8		
Sample Rate (Hz):	2560		
Blocksize:	2048		
Blocks Recorded:	12		
Recorded Time (Sec):	9.6		
Example rile for ea		gram	
Playback Mode		gran	
layback Mode Sample Rate (samples/sec): 2560		yrann	
Playback Mode Sample Rate (samples/sec): 2560 Blocksize: 2048		yanı	
Playback Mode Sample Rate (samples/sec): Blocksize: 2048 Play Speed: © No delay	C Real Speed	O Delay(mSec)	0

**Playback Setup Window** 



**Plot Window Colors** 

Plot window defaults are:	The four possible types of cursor are:
Frame Border = Grey	Single cursor
Plot Background = Black	Second cursor of band cursors
Grid Lines = Grey	Peak Search cursor
Cursor = White	Data List

- 1. To change a Plot Window display color, click on the button that applies to the display characteristic, for example, <Plot Background>.
- 2. Click <OK>. The Color Palette will open.

Color	? ×
Basic colors:	
Custom colors:	
Define Custom Colors >>	
OK Cancel	

#### **Color Palette**

- 3. Select a color by clicking on a color square, or by defining a Custom Color.
- 4. Click <OK>.
- 5. Repeat steps 1 through 4 for each Plot Window color that you want to change.
- 6. When finished, click <OK> in Colors [Color Palette] window.

# Edit Menu >

# **Preferences Window**

.abel Colors Background		
Foreground		
Gursor Movement Control Pick/Drag Pick Only C Drag Only	Lower Frequency Cutoff Freq. (Hz)	
Dursor Peak Search Width of Search (+/- Bins) 0 Auto Tracking Cursor-1 Cursor-2	Peak Picking       Minimum Amplitude     0.0000       Width of Peaks (+/- Bins)     3       Sort By:     C Frequency/Time       C Data Value	

The Preferences window provides a mean of setting several acquisition-related processing options.

#### Preferences

Trace Colors:	Defines colors for traces. Click on a channel's color chip to open a color palette. Pick a new color, then click <ok>.</ok>
Labels Colors:	Defines colors for <i>on-plot</i> text labels. Click on a color chip to open a color palette. Pick a new color, then click <ok>.</ok>
Cursor Movement Control:	<ul> <li>Sets the cursor's action. Options are: <i>Pick/Drag</i>, <i>Pick Only</i>, and <i>Drag Only</i>.</li> <li>Pick/Drag: Makes use of both the Pick Mode and the Drag Mode.</li> <li>Pick Only: Clicking the left mouse button allows the cursor to move instantaneously with the band cursor. The chosen cursor moves to the location when the mouse is clicked.</li> <li>Drag Only: Move the mouse pointer to the cursor location. The pointer will change to a "Left and Right Arrow." Click and drag the cursor to the designated location.</li> </ul>
Cursor Peak Search:	n/a
Peak Picking:	n/a

**Recall Plot Setup...** If the box is checked, the custom plot setup will be saved (recalled) and will be applied when the next time the associated data file is opened.



## Window Menu

```
Menu Items
Add Function View (FV) ..... 2-11
Delete Window ..... 2-11
Channel Buttons .....2-11
Cascade ..... 2-12
Tile Vertically .....2-12
Tile Horizontally ..... 2-13
Refresh Windows ..... 2-13
```



**Reference Note:** 

For information regarding the interactive features of Plot Display Windows, refer to chapter 3. The interactive features are not selected from the Window Menu, but are accessed via mouse buttons and/or hotkeys.

## Window Menu > Add Function View (FV)

This menu selection opens an additional plot window.



Example of an Added Function View

## Window Menu > Delete Window

Deletes the window that is currently in focus. When multiple plot windows are open, one is always the "focus window. When a window does not have focus, its title bar is dimmed. To change the "focus window," simply click on top or side border of the window of interest.

## Window Menu > Channel Buttons

Brings up a display showing squares for all channel buttons. The buttons are used in the exact same manner as the 16 channel buttons that are located on *eZ-PostView*'s main window, just below the Date/Time region.

- **To add a channel**: use the mouse to click and drag a channel box from the complete channel button display into the plot area.
- **To remove a channel**: use the mouse to click and drag a channel box (from the right-side of the plot) into the plot area.

## Window Menu > Cascade

When you have multiple plot windows open, this menu selection arranges them on you screen as shown.



Example of using Cascade with three Plot Windows

## Window Menu > Tile Vertically

When you have multiple plot windows open, this menu selection arranges them on your screen as shown.



*Example of using Vertical Tile with two Plots* Each plot is longer in the "vertical" direction.

## *Window Menu* > Tile Horizontally

When you have multiple plot windows open; this menu selection arranges them on your screen as shown.



*Example of using Horizontal Tile with two Plots* Each plot is longer in the "horizontal" direction.

## Window Menu > Refresh Windows

Used to refresh a window; for example, to refresh a Strip Chart. In this case, the refresh function blanks out the present Strip Chart, essentially providing you with a new, clean window.



How to Change Plot Display Characteristics ......3-2 How to Change "Focus" ...... 3-2 How to Add and Remove Channels ...... 3-2 Other Features ...... 3-3

Copy ..... 3-3 Cursor ..... 3-3 Label / List ..... 3-4 Changing the Display Range ..... 3-5 Changing the Plot's Format / Scale / Grid ..... 3-6

# How to Change Plot Display Characteristics

To change a plot's display characteristics; it must be the "focus plot." Then, you can either use the mouse or key commands to make changes. "Focus" is explained in the following section.



**Open Plot Display Characteristics Menu:** Press "**D**" or right click with the cursor hovering over the plotted data.

Use the down arrow key to highlight a menu option, then press "**Enter**". Note that in some cases you can press the first letter of an option to open its sub menu, for example, pressing the "**S**" key opens the Scale Type sub menu.



*Two Plot Windows* In this figure, the upper plot has the "focus."

# How to Change "Focus"

Focus can refer to the window that is in focus, as well as to a plot that is in focus. When multiple plot windows are open, one is always the "**focus window**." In the following figure, the window with the dark title bar (top window) is the window that currently has "focus." When a window does not have focus, its title bar is dimmed. **To change the "focus window," simply click on top or side border of the window of interest.** 

When multiple plot windows are open, a plot *other than the one* in the "focus" window can be the "**focus plot**." You would typically do this when you want to change a plot's characteristics. To change the "focus plot," **click in the plotted area of the window of interest**. Note that the window must be in focus at the time.

# How to Add and Remove Channels

**To add a channel to a plot ...** With your mouse, click and drag a **channel box** from *above the plot* to the plot area.

**To remove a channel from a plot . . .** With your mouse, click and drag a **channel box** from the *right of the plot* into the plot area. To ADD a channel, click-on the desired "channel box" in this area and drag it into the plot region.



# Other Features

## Сору



To Open the **Copy** Menu: Press "**D**" + "**C**," then release the keys. The **Copy** selection will be highlighted. Press "**Enter**." Next, use the down arrow key to select the item you desire to copy: **Data**, **Plot Window**, or **Screen**, then press "**Enter**."

You can paste the copied item into other applications. For example, plotted data can be copied into Notepad, Word, or Excel for use in reports or in the case of Excel further calculations.

The plot window and full screen can be copied and then pasted into any application that accepts graphics, such as MSPaint or Word.

Function Type:Octave 1/3:None (LIN)		
	g's <lin> [RMS]</lin>	
Overal	10.00603	
Freq.	CH:2	
500.0	0.00097	
630.0	0.00171	
800.0	0.00132	
1000.	0.00114	
1250.	0.00117	
1600.	0.00160	
2000.	0.00135	
2500.	0.00182	
3150.	0.00191	
4000.	0.00197	
5000.	0.00177	
6300.	0.00196	
8000.	0.00241	

*Plot Window Data* Copied and Pasted into Word

## Cursor

Cursor	•	✓ Cursor Off
Label/List	•	Single Curso
	-	Band Cursor

To Open the **Cursor** Menu: Press "**D**" + "**C**," then release the keys. Then use the down-arrow key to highlight **Cursor** and press "**Enter**."

Next use the down arrow key to select, **Cursor Off** or **Single Cursor**, then press "**Enter**."

When **Single Cursor** is selected, a cursor appears at the far left of the plot and cursor controls and cursor information are added below the plot. Click on the plot where you want the cursor. To fine-tune the cursor location, use the right and left arrows at the bottom. Use the X and Y information for additional help. If you have multiple channels in the graph, use the up and down arrows to move the cursor from plot to plot. Press "**C**" to toggle the cursor on and off.



Plot Window with Single Cursor

## Label / List



To Open the **Label/List** Menu press "**D**" + "**L**," then release the keys. **Label/List** will be highlighted. Press "**Enter**."

Using the down arrow key, select Data or Text. Then press "Enter."

**Data** places up to 10 cursor values on your plot. After you select data, a temporary cursor is placed on the plot and the x, y data values are shown for that location. As you move your mouse, the temporary cursor will move across the plot with data values continuously updated. When you have the cursor where you want it, click on the mouse to place the label. Another temporary cursor immediately appears. When you are finished labeling values, right-click and select Pointer to return to a normal state.



Adding Data Point Cursors and Text

**Text** places a comments text box on the plot. After you select text, click on the plot and start typing. You are limited to 26 character places. Click on the right corner of the text box to move it anywhere on the plot window.

## **Changing the Display Range**

To change the maximum or minimum range value: Left-click on upper or lower scale value that is to be changed, then enter the new value. An example follows.

3

3

3,000

3.800



In this example, the cursor and PC keyboard were used to change the maximum scale value from 3.000 volts to 3.800 volts.

**To change the X-Axis:** Hold down the **<Ctrl>** key, at the same time, left-click and drag the mouse cursor horizontally on the plot. Two vertical cursor lines will define the new x-axis end points.



**To change the Y-Axis:** Hold down the **<Alt>** key, at the same time, left-click and drag the mouse cursor vertically on the plot. Two horizontal cursor lines will define the new Y-axis end-points.



To simultaneously change the X & Y Axes: Hold down the <Ctrl> and <Alt> keys, at the same time, left-click and drag the mouse cursor diagonally on the plot. A rectangle will define the new area of the plot.



## Changing the Plot's Format / Scale / Grid

Right-Click on the plot's border to open a popup menu (see figure). If you want to change the y-axis, right-click on the plots left border. If you want to change the x-axis, right-click on the plot's bottom border.



Changing the plot Format, Scale, or Grid affects the display only. It does not change the real data.



#### Format

The Format menu allows you to change the axis format of the plotted data.

#### Scale

The Scale menu allows you to change the plot scale to AutoScale, FixedScale, or Manual. Autoscale ensures that all the captured data is visible on the plot.

#### Grid

The Grid menu allows you to place and remove grid lines from the graph of plotted data. You can also turn the grid on and off by pressing the "G" hot key.

#### Note:

Appendix A, taken from the *eZ-Analyst Series Software Reference Manual*, p/n 1086-0922, consists of several hot key tables for the benefit of those who prefer to use keys in place of mouse/cursor interaction with a GUI.

Although *eZ-PostView* was derived from *eZ-Analyst*, certain key functions will not apply, for example, the keys pertaining to Measurement, Scope, and Generator Control.

This appendix consists of several hot key tables for the benefit of those who prefer to use keys in place of mouse/cursor interaction with a GUI. However, for certain functions, such as changing axis scales, a mouse will be needed. Mouse use is pointed out in the tables, when applicable.

Record / Playback Control		
Keys	Function	Comments
р	Play Forward	
<shift> + p</shift>	Play Backward	
0	Step Forward and Record	
<shift> + o</shift>	Step Backward and Record	
Н	Halt Playback	

Measurement, Scope, and Generator Control		
Keys	Function	Comments
Н	Halt the measurement	
R	Start recording	
S	Start Scope Mode (Measurement)	
w	Turn the signal generator On	

Menu and Window Control		
Keys	Function	Comments
Alt + E	Presents the Edit Menu.	
C	Presents the <b>Plot Window <u>Colors</u></b> window.	After pressing <b>Alt + E</b> to access the Edit Menu, press <b>C</b> to get the Colors Window. Use the Tab key to select a characteristic, then hit <enter>.</enter>
м	Presents the <b>Configuration</b> window.	After pressing Alt + E to access the Edit Menu, press M to get the Configuration Window. You will need a mouse to access all panels. Also, see Ctrl + M.
P	Presents the <b>Playback Setup</b> window.	After pressing <b>Alt + E</b> to access the Edit Menu, press <b>P</b> to get the Playback Setup Window. Use the Tab and arrow keys to make selections within this window. Then hit <enter>.</enter>
Alt + F	Presents the File Menu.	
Alt + W	Presents the Window Menu.	You will need a mouse to make selections.
Ctrl + M	Presents the <b>Configuration</b> window.	You will need a mouse to access all panels. An alternative to Ctrl + M is to press M when the Edit Menu is open.
Ctrl + O	Presents the <b>Open File Dialog</b> window.	From within the window, use the Tab and arrow keys. An alternative to Ctrl + O is to press O when the File Menu is open.
Ctrl + P	Presents the <b>Print Dialog</b> window.	An alternative to Ctrl + P is to press P when the File Menu is open.
D	Presents the <b>Display Menu</b> , also referred to as the Plot Display Characteristics Menu.	Refer to the following table for control options related to the Display Menu.

Α

Display Menu Control			
Keys	Function	Comments	
D	Opens the Plot Display Characteristics Menu	Option: "Right-clicking" the mouse, while the cursor is over the plot will also open this menu.	
<b>D + C</b> (3 functions)	Used to open the <b>Complex Type Display Menu.</b> This option is only available when a function with complex data is displayed. Menu choices are: Magnitude, Phase, Real, Imaginary, Magnitude + Phase, Real + Imaginary, and Nyquist	Press D + C; release, then press <enter>. The Complex Type Display Menu will open. Use the arrow keys to highlight the type of display, then press <enter>.</enter></enter>	
	Used to open the <i>Copy Menu</i> . Menu choices are: Data, Plot Window, Screen.	Press D + C; release, then use the arrow key to select Copy. After selecting Copy, press <enter>.</enter>	
	Used to open the <i>Cursor Menu.</i> Menu choices are: Single Cursor, Band Cursor, or Cursor Off.	Press D + C; release, then use the arrow key to select Cursor. After selecting Cursor press <enter>.</enter>	
D+F	Opens the <i>Display Functions Menu</i> . Note that right-clicking on the plot will also open this menu.	Use arrow keys to highlight your selection, then press <enter>. In some cases you can select the first letter of an option to select it.</enter>	
D+I	Opens the Integration/Differentiation Menu.	Use arrow keys to highlight your selection, then press <enter>.</enter>	
D+L	Opens the <i>Label / List Menu</i> .	Use arrow keys to highlight your selection, then press <enter>.</enter>	
D + O	Opens the Octave Menu.	Use arrow keys to highlight your selection, then press <enter>.</enter>	
D + S	Opens the Scale Type Menu. Menu choices are RMS, Peak, Pk-Pk.	Use arrow keys to highlight your selection, then press <enter>.</enter>	
D+T	Opens the Transfer Type Menu.	Use arrow keys to highlight your selection, then press <enter>.</enter>	

Plot Display Controls (Note)			
Keys	Function	Comments	
Mouse-Click Bottom Border	Change the <b>X-axis</b> in regard to format, scale, and grid.	Right-click on the plot's bottom border to access a menu for changing the X-axis in regard to Format, Scale, and Grid.	
Mouse-Click Left Border	Change the <b>Y-axis</b> in regard to format, scale, and grid.	Right-click on the plot's left border to access a menu for changing the Y-axis in regard to Format, Scale, and Grid.	
,	Moves the primary cursor left along the trace.	When in Band Cursor mode, the comma moves the primary cursor to the left.	
•	Moves the primary cursor right along the trace.	When in Band Cursor mode, the period moves the primary cursor to the right.	
<	Moves the secondary cursor left along the trace.	When in Band Cursor mode, the "<" moves the secondary cursor to the left.	
>	Moves the secondary cursor right along the trace.	When in Band Cursor mode, the ">" moves the secondary cursor to the right.	
<shift></shift>	Peak search.	Press the <shift> key while depressing the left mouse button to search for peaks along the trace.</shift>	

**Note**: Also see the Display Menu Control Table.

Continued



**Reference Note:** For more detailed information, which includes graphics, refer to chapter 3, *Interactive Features of the Plot Display Window*.

Plot Display Control (Note)		
Keys	Function	Comments
Α	Turns Auto-scale On.	
Alt	Expands or contracts the <b>Y-Axis</b> .	(a) While holding down the <alt> key, place the cursor at the desired start point of the Y-axis, (b) click the left mouse button, (c) drag the mouse vertically until the cursor is at the new end point of the scale.</alt>
b	Bank up.	
<shift> + b</shift>	Bank down.	
c	Toggles the cursor On or Off; or cycles the cursor options as follows (if Band Cursor is selected): Adds a Cursor, Adds a second Cursor, turns both cursors Off.	When Band Cursor is selected, the "C" key cycles through On (add a cursor), add a second cursor, and Off.
Ctrl	Expands or contracts the <b>X-Axis</b> .	(a) While holding down the <ctrl> key, place the cursor at the desired start point of the X-axis, (b) click the left mouse button, (c) drag the mouse horizontally until the cursor is at the new end point of the scale.</ctrl>
Ctrl + Alt	Simultaneously expands [or contracts] both the <b>X</b> and <b>Y axes</b> .	(a) While holding down both the <ctrl> and <alt> keys, place the cursor at the desired start point on the plot, (b) click the left mouse button, (c) drag the mouse diagonally until the cursor is at the new end point of the scale.</alt></ctrl>
F2 or Z (2 functions)	Zooms in or out.	When you depress one of these keys, while dragging with the right mouse button depressed, you will zoom in or out, according to the cursor-defined region.
	Pan along the X-axis, Y-axis, or both.	By depressing one of these keys, while dragging with the left mouse button depressed, you can pan in the direction of the drag.
F3	Zoom in or out.	Use F3 with the left mouse button to zoom in our out.
G	Turns Plot Grid On or Off.	Toggles the grid to On or Off.
L	Changes the Scale to Linear or to Log.	Toggles the scale to Linear or to Log.
R	Start Recording	
S	Start Scope Mode (Measurement)	
Х	Presents the X-Axis Menu	
Y	Presents the Y-Axis Menu	
Z or F2	Zooming or Panning.	See " <b>F2</b> ."

Note: Also see the Display Menu Control Table.



**Reference Note**: For more detailed information, which includes graphics, refer to chapter 3, *Interactive Features of the Plot Display Window*.






http://www.omega.com e-mail: info@omega.com

# eZ-Analyst Series

## Software Reference

p/n 1086-0922, Rev 7.0



<b>OMEGAnet<sup>sm</sup> On-Line Service</b>	
http://www.omega.com	

Internet e-mail

## **Servicing North America:**

USA: ISO 9001 Certified	One Omega Drive, Box 4047 Stamford, CT 06907-0047 Tel: (203) 359-1660 e-mail: <u>info@omega.com</u>	FAX: (203) 359-7700
Canada:	976 Berger Laval (Quebec) H7L 5A1 Tel: (514) 856-6928 e-mail: <u>canada@omega.com</u>	FAX: (514) 856-6886
For immed	liate technical or applicat	ion assistance:
USA and Canada:	Sales Service: 1-800-826-6342 / 1-800-TC Customer Service: 1-800-622-2378 / 1-80 Engineering Service: 1-800-872-9436 / 1- TELEX: 996404 EASYLINK: 62968934	C-OMEGA <sup>SM</sup> 0-622-BEST <sup>SM</sup> 800-USA-WHEN <sup>SM</sup> 4 CABLE: OMEGA
Mexico and		
Latin America:	Tel: (95) 800-TC-OMEGA <sup>SM</sup> En Espanol: (95) 203-359-7803	FAX: (95) 203-359-7807 e-mail: <u>espanol@omega.com</u>
	Servicing Europe:	
Benelux:	Postbus 8034, 1180 LA Amstelveen, The	Netherlands
	Tel: (31) 20 6418405 Toll Free in Benelux: 06 0993344 e-mail: <u>nl@omega.com</u>	FAX: (31) 20 6434643
Czech Republic:	ul. Rude armady 1868 733 01 Karvina-Hranice Tel: 420 (69) 6311899 e-mail:czech@omega.com	FAX: 420 (69) 6311114
France:	9, rue Denis Papin, 78190 Trappes Tel: (33) 130-621-400 Toll Free in France: 0800-4-06342 e-mail: <u>france@omega.com</u>	FAX: (33) 130-699-120
Germany/Austria:	Daimlerstrasse 26, D-75392 Deckenpfron	n, Germany
	Tel: 49 (07056) 3017 Toll Free in Germany: 0130 11 21 66 e-mail: <u>germany@omega.com</u>	FAX: 49 (07056) 8540
United Kingdom: ISO 9002 CertIfled	25 Swannington Road, Broughton Astley, Leicestershire, LE9 6TU, England Tel: 44 (1455) 285520 FAX: 44 (1455) 283912 Toll Free in England: e-mail: <u>uk@om</u>	P.O. Box 7, Omega Drive, Irlam, Manchester, M44 5EX, England Tel: 44 (161) 777-6611 FAX: 44 (161) 777-6622 0800-488-488 mega.com

It is the policy of OMEGA to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct but OMEGA Engineering, Inc. accepts no liability for any errors it contains, and reserves the right to alter specifications without notice. **WARNING:** These products are not designed for use in, and should not be used for, patient-connected applications.

**Note**: As this document goes to press, *eZ-Analyst* can only be used with WaveBook or ZonicBook type devices. Other devices, such as LogBook, DaqBook, and MultiScan, are, at present, not compatible with *eZ-Analyst*. However, they can make use of the derived "view" applications (*eZ-PostView*, *eZ-TimeView*, or *eZ-FrequencyView*.)

# Manual Layout

This document is a reference manual for *eZ-Analyst* and its related series of "view" applications. It is intended for use with the following:

- eZ-Analyst
- eZ-FrequencyView
- eZ-TimeView

The document is a reference to Menu options, associated Toolbar buttons, and resulting GUI screen images. Where deemed beneficial, examples were placed to supplement the primary material. For example, after describing the entry fields for "Double-Hammers," an example demonstrates a typical setup.

The document discusses *eZ-Analyst* in relation to both ZonicBook and WaveBook applications. It should be noted that certain *eZ-Analyst* functions that apply to ZonicBook, do not apply to WaveBook, and visa versa. These differences are pointed out in the document, when applicable.

The document is arranged as follows:

- *An Introduction to eZ-Analyst Series Software* compares *eZ-PostView*, *eZ-TimeView*, and *eZ-FrequencyView* to the *eZ-Analyst* program and discusses how the manual relates to each.
- *Installing the "View" Applications* provides instructions for installing *eZ-PostView*, *eZ-TimeView*, and *eZ-FrequencyView*.
- Ch 1 *Getting Started with eZ-Analyst* briefly explains what *eZ-Analyst* is and provides instructions for installing *eZ-Analyst* software for ZonicBook and WaveBook applications.
- Ch 2 *Menus and Windows* explains the Menus, software buttons, and windows that are part of *eZ-Analyst's* Graphical User Interface (GUI).
- Ch 3 *Interactive Features of the Plot Display Window* explains how to change plot display characteristics, including display functions, by using the interactive features of the display window.
- **Appendix A** *Keyboard Controls for eZ-Analyst* identifies keys for controlling plot display, menus, windows, and record/playback functions.
- Appendix B Using Banks and Function Files discusses simultaneous measurement of signal groups, automatic and manual incrementing of banks, and skip factor.
- Appendix C Screen Images in "View" Applications provides screen images and text pertaining to the Miscellaneous Tab, Window Colors and Preferences Windows. The material applies to one or more of the derived "view applications," but does not apply to eZ-Analyst.

#### Glossary



Check the **README.TXT** file, if present, for information that may not have been available at the time this manual went to press.

\* Though this document can be used with eZ-PostView, we recommend that eZ-PostView users refer to the PDF document, eZ-PostView User's Guide (p/n 1086-0926). The reason is that most of the material in this document does not apply to eZ-PostView. Refer to the table on page 0-2 in regard to application features that do apply.

## **Table of Contents**

Manual Layout ..... iii

An Introduction to eZ-Analyst Series Software

## Installing the "View" Applications

### Ch 1 – Getting Started with eZ-Analyst

An Introduction to eZ-Analyst ..... 1-1 ZonicBook, eZ-Analyst Install ..... 1-5 WaveBook, eZ-Analyst Install ..... 1-11

### Ch 2 – Menus and Windows

Comparing the "View" Applications to eZ-Analyst ..... 2-2 Task Menu (eZ-Analyst Only) ..... 2-3 File Menu ..... 2-11 Edit Menu ..... 2-13 Configuration Window ..... 2-13 Analyzer Tab..... 2-15 Input/Output Channels Tab..... 2-21 Recording Setup Tab (eZ-Analyst Only)..... 2-25 Block Rejection Tab (eZ-Analyst Only) ..... 2-29 FFT Setup Tab ..... 2-31 Octave Setup Tab ..... 2-37 Display Preferences Window ..... 2-39 Export Menu ..... 2-41

## Window Menu ..... 2-43

Add Function View (FV) ..... 2-43 Add Strip Chart ..... 2-43 Delete Window ..... 2-44 Channel Buttons ..... 2-44 Modal Locations ..... 2-44 Input Channels ..... 2-44 Input Channels ..... 2-45 Measurement Panel ..... 2-46 Tachometer ..... 2-47 Cascade ..... 2-47 Tile Vertically ..... 2-47 Tile Horizontally ..... 2-48 Refresh Windows ..... 2-48

### Ch 3 – Interactive Features of the Plot Display Window

How to Change Plot Display Characteristics ......3-1 How to Change "Focus" ...... 3-1 How to Add or Remove Channels ...... 3-2 How to Change Display Functions ...... 3-3

## Appendix A – Keyboard Controls for eZ-Analyst

Appendix B – Using Banks and Function Files

Appendix C – Screen Images in "View" Applications

### **Glossary**



A Screen Capture from eZ-PostView

*eZ-PostView*, *eZ-TimeView*, and *eZ-FrequencyView* are part of the *eZ-Analyst* "series" software. Each is a **post-acquisition** analysis application that was derived from the more powerful *eZ-Analyst* program. The later is given an overview in chapter 1 and is detailed throughout the rest of the manual.

Features of the view applications vary from one application to another, and are listed in the comparative table on the following page.

The "view" applications are integrated with the primary data acquisition software, including *DaqView*, *Personal DaqView*, *ChartView*, *LogView*, and *WaveView*. The *eZ-PostView* application provides easy-touse post-acquisition analysis capability, and is included free of charge as a part of product support. The other two view programs (*eZ-TimeView* and *eZ-FrequencyView*) have additional features and are available for purchase. These more versatile "view" applications are initially accessed via an authorization-code. Note that the code is only required to "unlock" the application for its first run and is not required for subsequent startups.

The following table compares the "view" applications to the *eZ-Analyst* program, from which they were derived. At present, the *eZ-Analyst* program is only compatible with WaveBook and ZonicBook devices.

eZ-Analyst Series Comparison Matrix						
Feature Post-Acquisition Viewing Package eZ-Analyst						
	eZ-PostView	eZ-TimeView	eZ-FrequencyView			
File Input Format Support for: DaqView, WaveView, Personal DaqView, ChartView, UFF-58B.	Yes	Yes	Yes	Yes		
File Export to: ME'Scope and SMS Modal, Microsoft Excel, Binary Universal File, and ASCII text files.		Yes	Yes	Yes		
Display Windows, number of	8	8	8	8		
Channel Traces per Display Window	16	16	16	16		
Automatic Data Scaling	Yes	Yes	Yes	Yes		
Simulated Data Playback		Yes	Yes	Yes		
Configurable Data Display for channels and trace colors	Yes	Yes	Yes	Yes		
Multiple Tiling of display windows	Yes	Yes	Yes	Yes		
Cursor Support - for both Single Cursor and Band Cursor	Yes	Yes	Yes	Yes		
Data Strip Chart Display		Yes	Yes	Yes		
Peak-to-Peak Calculations		Yes	Yes	Yes		
Peak Searching, minimum and maximum		Yes	Yes	Yes		
Mean Calculations		Yes	Yes	Yes		
RMS Calculations		Yes	Yes	Yes		
Zooming [of the data display]		Yes	Yes	Yes		
Windowed Time Display Function		Yes	Yes	Yes		
Cross Channel Support			FFT, FRF, Cross, Coherence, Transfer Function	FFT, FRF, Cross, Coherence, Transfer Function		
Transfer Function Display Types			Note 1	Note 1		
Complex Function Display Types			Note 2	Note 2		
Scale Types		RMS, Peak, Peak-to-Peak	RMS, Peak, Peak-to-Peak	RMS, Peak, Peak-to-Peak		
Function Display Types		Time, Strip Chart	Note 3	Note 3		
Octave Types			1/3, Full	1/3, Full		
Octave Weighting			Linear, A, B, C	Linear, A, B, C		
Waterfall Plots			Yes	Yes		
Integration/Differentiation (Single/Double)			Yes	Yes		
Response Channel FFT Windows			Note 4	Note 4		
Reference Channel FFT Windows			Rectangular, Cosine Taper	Rectangular, Cosine Taper		
Low-Pass DC Noise Filtering			Yes	Yes		
Spectral Strip Chart Display Synchronization			Yes	Yes		
Octave Strip Chart Display Synchronization			Yes	Yes		
Record and Save Data to Disk				Yes		

# Comparing the "View" Applications to eZ-Analyst

Notes: 1) *eZ-Analyst* and *eZ-FrequencyView* - each offers the following Transfer Function Display Types: Inertance, Mobility, Compliance, Apparent Mass, Impedance, and Dynamic Stiffness.

- 2) eZ-Analyst and eZ-FrequencyView each offers the following Complex Function Display Types: Magnitude, Phase, Real, Imaginary, Nyquist, Magnitude and Phase, and Real and Imaginary.
- 3) *eZ-Analyst* and *eZ-FrequencyView* each offers the following Function Display Types: Spectrum, Auto-Spectrum, PSD (Power Spectral Function), Strip Chart.
- 4) eZ-Analyst and eZ-FrequencyView each offers the following Response Channel FFT Windows: Hanning, Flat Top, Exponential, and Blackman-Harris.

The eZ-Analyst Series "view" programs make use of *eZ-Analyst's* Playback Mode and, therefore, do not require the presence of physical hardware. In fact, when *eZ-Analyst* is in Playback Mode, it is functioning in the exact manner as *eZ-FrequencyView*. In other words, when in PlayBack Mode, *eZ-Analyst* is strictly a post-acquisition display and analysis program.

Raw time-domain data, that has been recorded-to-disk, can be played back for analysis repeatedly. For example, a raw signal could be played back several times, each time using a different filtering algorithm to manipulate the original signal. Once the desired results have been achieved the new data can be exported in a new format and to a different file. The original file can remain unchanged, and kept for future analysis.

The "view" programs make use of a Play Task Bar, as depicted in the following figure.



## How the Rest of this Manual Relates to the "View" Applications

This manual was original written as a reference guide for users of *eZ-Analyst* prior to the development of the "view" applications. However, since the post-acquisition "view" programs were derived directly from *eZ-Analyst*, it is easy to apply the appropriate sections of the manual to your specific "view" application, i.e., to *eZ-PostView*, to *eZ-TimeView*, or to *eZ-FrequencyView*. Of course, if you are making use of the actual *eZ-Analyst* program, simply use the manual in its entirety.

## eZ-FrequencyView

When you are using *eZ-FrequencyView*, you are essentially running *eZ-Analyst* in its Playback Mode. The table on the page 2 indicates the applicable features. You can not record data from *eZ-FrequencyView*.

*eZ-FrequencyView* is supported by the primary data acquisition programs, for example, *DaqView*, *LogView*, and *WaveView*. It can be accessed through the primary application's View Data button, or accessed independently from your program files directory (where you installed your software).

The first time you run *eZ-FrequencyView*, you will need to enter an authorization code. The code is supplied when the package is purchased.

## eZ-TimeView

When you are using *eZ-TimeView*, you are essentially running *eZ-Analyst* in its Playback Mode, minus several analysis features that are available in *eZ-FrequencyView* and *eZ-Analyst*. For example, when using *eZ-TimeView* there are no Transfer Function Display Types, Complex Function Display Types, or FFT Windows available. However, the application does provide calculation options pertaining to peak-to-peak, mean, RMS, and does allow for data zooming. Refer to the table on page 2 for a complete list of the applicable features. Note that you can not record data from *eZ-TimeView*.

*eZ-TimeView* is supported by the primary data acquisition programs, for example, *DaqView*, *LogView*, and *WaveView*. It can be accessed through the primary application's View Data button, or accessed independently from your program files directory (where you installed your software).

The first time you run *eZ-TimeView*, you will need to enter an authorization code. The code is supplied when the package is purchased.

## eZ-PostView

*eZ-PostView* provides simple "time-domain" viewing. From this application you can display up to 8 time-domain function windows and display up to 16 channel traces per window. Data is automatically scaled to optimize its fit in the window. Window, channel trace, and cursor colors can be customized.

*eZ-PostView* is a free "view" program. The application has no Transfer Function Display Types, Complex Function Display Types, or FFT Windows available. Refer to the table on page 2 for a complete list of the applicable features. Note that you can not record data from *eZ-PostView*.

*eZ-PostView* is supported by the primary data acquisition programs, for example, *DaqView*, *LogView*, and *WaveView*. It can be accessed through the primary application's View Data button, or accessed independently from your program files directory (where you installed your software).

You do not need to enter an authorization code to run eZ-PostView.



### **Reference Note:**

Although this document can be used for *eZ-PostView*, a great deal of the material does not apply, as can be seen from the table on page 2. If you are only making use of *eZ-PostView* you may want to refer to the *eZ-PostView User's Guide*, p/n 1086-0926. A PDF version of that document is installed onto your hard-drive as a part of product support.



#### **Reference Notes:**

- If you purchased eZ-Analyst for use with a ZonicBook, skip this section and proceed to chapter 1, Getting Started with eZ-Analyst.
- If you purchased eZ-Analyst for use with a WaveBook device, and will not be using WaveView, skip this section and proceed to chapter 1, Getting Started with eZ-Analyst.
- If you will be using WaveView and desire post-data analysis capability, install one of the three view applications as discussed in this section.

System Requirements ..... 0-5 Software Installation ..... 0-6

## System Requirements

Before setting up the hardware or installing the software, verify that you have the following items.

- Data Acquisition System, for example, WaveBook, DaqBook, Personal Daq, LogBook.
- Power Supply with cord
- Data Acquisition CD
- Authorization Code for *eZ-TimeView* or *eZ-FrequencyView*, if applicable. Both are options that can be purchased.

In addition, verify that your computer meets the following **minimum** requirements.

- Intel<sup>™</sup>, Pentium 90 MHz or equivalent
- 64 MB Memory
- 100 MB Hard Disk space
- Monitor: SVGA, 800 x 600 resolution
- One of the following Microsoft<sup>®</sup> Windows Operating Systems:
  - Windows 98 Windows Me Windows NT Windows 2000 Windows XP

Optional, but recommended: EPP (Enhanced Parallel Port), or ECP (Extended Capabilities Port)



If you purchased software, associated authorization codes will accompany your installation CD. If this is the case, keep your codes in a safe place. You will need to enter them once, during an actual run of the purchased software.

Note that no authorization code is required to run *eZ-PostView*.

## Software Installation



Before installing a version of our data-acquisition software, remove all previous versions of that software.

#### **Reference Notes**:

- Adobe Acrobat PDF versions of documents pertaining to your system hardware and software are automatically installed onto your PC's hard-drive as a part of product support at the time of software installation. The default location is the **Programs** group, which can be accessed via the *Windows Desktop Start Menu*.
- > PDF versions of documents can be read directly from the data acquisition CD.
- After your software is installed you can setup your data acquisition device, e.g., WaveBook, DaqBook, LogBook, and connect it to the host computer. Instructions for hardware setup are included in your device user's manual, which is included on the CD.

When you first install software for your acquisition device, *eZ-PostView* will automatically be selected for installation along with the primary acquisition software application. For example, when a WaveBook is selected, both *WaveView* and *eZ-PostView* will show as pre-selected software options.

To install one of the three view applications ...

- 1. Start Windows.
- 2. Close all running applications.
- 3. Insert the Data Acquisition CD into your CD-ROM drive and wait for the CD to auto-run.

If the CD does not start on its own:

- (a) click the desktop's <Start> button
- (b) choose the Run command
- (c) select the CD-ROM drive, then select the **setup.exe** file.
- (d) click  $\langle OK \rangle$ .

An Opening Screen appears.

- 4. Click the **<ENTER SETUP>** button.
- 5. On the hardware selection screen [which follows a licensing agreement], select your hardware from the resulting drop-down list
- 6. On the resulting software options screen, select the software options that are applicable to your system. If you purchased *eZ-TimeView* or *eZ-FrequencyView*, select that application, then de-select *eZ-PostView*.
- 7. Click the **<Install**> button and follow the screen prompts.



You will be prompted to enter an Authorization Code.

- If you purchased eZ-TimeView or eZ-FrequencyView enter the code for the associated application; then click the <Apply Code> button.
- If you are installing *eZ-PostView* [which requires no code], simply click the <OK> button or, if you prefer, click the <Start 30 Day Trial> button to try out the more powerful *eZ-FrequencyView* Application.

B: A	uthorization	×	
	Enter Authorization Code:		1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1
	Feature	Authorization	
	Apply Code Start 30 Day	Trial OK	

Authorization Dialog Box

**Note**: Entry of your Authorization Code is only required once. However, you can enter a new code at a future date, for example, if you wanted to upgrade from *eZ-PostView* to *eZ-FrequencyView*.

#### To open the Authorization Dialog Box:

- 1. Open *eZ-PostView*. You can open *eZ-PostView* by clicking the *<***ViewData***>* button in your primary data acquisition program, e.g. *WaveView, DaqView, LogView,* etc.
- 2. From *eZ-PostView's* File Pull-Down menu, select *Authorization* (following figure). The *Authorization* dialog box appears.

File	Edit	Export	Window	н				
0	pen D	ata File						
S	ave Da	ata File						
S	ave Plo	ot Setup(I	PSET)					
R	Recall Plot Setup(PSET)							
Pi	rint							
C	:\Prog	ram Files)	,eZ-View\e	ZA				
A	uthoria	zation						
E:	xit							

File Menu

### To enter a code:

- 1. Type-in the code, as it appears on your Authorization Sheet.
- 2. Click the **<Apply Code>** button.



An Introduction to eZ-Analyst ..... 1-1 ZonicBook, eZ-Analyst Install ..... 1-5 WaveBook, eZ-Analyst Install ..... 1-11



At present, *eZ-Analyst* can only be installed as software support for ZonicBook and WaveBook devices. If your system is making use of another type of data acquisition device, e.g., DaqBook, DaqBoard, or LogBook, you can not install *eZ-Analyst*, but can install one of its related "view" programs. To install *eZ-PostView*, *eZ-TimeView*, or *eZ-FrequencyView*, refer to the section, *Installing the "View" Applications*, which begins on page 0-5.



#### Reference Note:

This chapter applies to *eZ-Analyst*. If you are using a "view" application, and not *eZ-Analyst*, be sure to read the two previous sections, *An Introduction to eZ-Analyst Series Software* and *Installing the "View" Applications*. If you are not using *eZ-Analyst*, you should skip this chapter and continue with chapter 2.

## An Introduction to eZ-Analyst



Recording while in Measurement Mode

*eZ-Analyst* is a graphical analysis application that can be used to collect, analyze, record, and play back recorded data. Using ZonicBook or WaveBook hardware systems, *ez-Analyst* can collect and display multiple channels of data in real-time. The graphical displays can consist not only of the raw time-domain data, but also plots of frequency domain data. For example, real time FFT (*Fast Fourier Transform*) plots.

Data that is recorded to disk-file is in the raw *time domain* and can be played back for additional analysis time and time again. For example, a raw signal can be played back over-and-over using different filtering algorithms to manipulate the signal. Once the desired results have been achieved, the new data can be exported to a different file and format, while preserving the original file. In addition, the playback capability does not require the presence of a ZonicBook or WaveBook system.

From the Task Menu, the user selects either the Measurement Mode or the Playback mode. The Task Tool Bar automatically changes to accommodate the selected mode.

### **Measurement Mode**

The Measurement Mode is an active data-collecting mode, which, for that reason, requires the use of data acquisition hardware. The Measurement Mode can only be selected if a ZonicBook or WaveBook is available; otherwise, *eZ-Analyst* will run in the Playback Mode only.

The Measurement Mode can run in one of three sub-modes, *Scope-Continuous, Scope-Single*, or *Record*. The first two sub-modes are simple displays that do not log data and are most useful for signal validation and checkout. The Record mode is the same as the two Scope modes, but has the added feature of logging data-to-disk based on additional start and stop criteria.

In addition to being selected from the Task Menu, the Measurement Mode can be selected from the Task Tool Bar by clicking the **<Change Task Mode>** button while in the Playback Mode. Clicking this button from Measurement Mode will change the task mode tool bar to Playback.



#### Measurement Mode Task Bar

Note that grayed-out buttons indicate that the associated function is not available due to a prerequisite not being met.

Change Task Mode	-	Changes the task from Measurement Mode to Playback Mode. The Task Bar buttons will change accordingly.
Record		Starts recording data-to-disk. Note that a ZonicBook or WaveBook must be used to acquire data.
Scope-Continuous		Starts a continuous-time acquisition in Scope mode. This mode does not record data to disk. Note that a ZonicBook or WaveBook must be used to acquire data.
Scope-Single	æ	Starts a single-time run data acquisition in the scope mode. This mode does not record data to disk. Note that a ZonicBook or WaveBook must be used to acquire data.
Signal Generator		The Signal Generator button toggles between two images and is only active when hardware is present.
Indicates that the Generator is turned <b>ON</b>	<u>0</u>	The sign wave button indicates that the generator is ON. Clicking on it will turn the generator OFF and the button image will change to a circled red line, indicating that the generator is OFF.
Indicates that — the Generator is turned <b>OFF</b>	$\overline{\Theta}$	Clicking the button, while the "Off Status" image is present, will turn the Signal Generator back ON, and will change the button to show the sign wave image.
		<b>Note</b> : For WaveBook applications you must set the applicable output channel (that is to generate the signal) to "Active." See, <i>Output Channel Setup Tab</i> , <i>WaveBook Applications</i> , page 2-24.

Cursor Lock	An active cursor lock button will have the image of an opened or locked padlock.
	When the padlock is locked (closed), cursors in multiple windows will be synchronized and locked, providing that the windows are of the same time domain, frequency domain, or have the same octave band data.
	An opened padlock image indicates that cursors in multiple windows have independent cursor movement, i.e., they are unsynchronized.
Export	 This button exports data, if export conditions are set. For details, see the section, <i>Export Menu&gt; Save Export Function Data</i> , in chapter 2.

## Regions of the Upper Main Window

Averaging Status		ZAnalyst V3.1.0 Mode Edit Task Control Ex 	Becord File:C:\Program Files\eZ-Analyst Sound-Vibration Software\crcr.dsc         port. Window       Help         Image: Solution Software (4.400 / 10.00 Sec)       Image: Solution Software (4.400 / 10.00 Sec)         Image: Solution Software (4.400 / 10.00 Sec)       Image: Solution Software (4.400 / 10.00 Sec)         Image: Solution Software (4.400 / 10.00 Sec)       Image: Solution Software (4.400 / 10.00 Sec)         Image: Solution Software (4.400 / 10.00 Sec)       Image: Solution Software (4.400 / 10.00 Sec)         Image: Solution Software (4.400 / 10.00 Sec)       Image: Solution Software (4.400 / 10.00 Sec)         Image: Solution Software (4.400 / 10.00 Sec)       Image: Solution Software (4.400 / 10.00 Sec)         Image: Solution Software (4.400 / 10.00 Sec)       Image: Solution Software (4.400 / 10.00 Sec)         Image: Solution Software (4.400 / 10.00 Sec)       Image: Solution Software (4.400 / 10.00 Sec)         Image: Solution Software (4.400 / 10.00 Sec)       Image: Solution Software (4.400 / 10.00 Sec)         Image: Solution Software (4.400 / 10.00 Sec)       Image: Solution Software (4.400 / 10.00 Sec)         Image: Solution Software (4.400 / 10.00 Sec)       Image: Software (4.400 / 10.00 Sec)         Image: Software (4.400 / 10.00 Sec)       Image: Software (4.400 / 10.00 Sec)         Image: Software (4.400 / 10.00 Sec)       Image: Software (4.400 / 10.00 Sec)         Image: Software (4.400 / 10.00 Sec)       Image: Software (4.400 / 10
-	1	Status Message	A message regarding the status, if applicable, will be displayed in this area. Examples of possible messages are: Double Hammer Rejected, Overload Rejected, Reject (Manual Reject Mode), and GAP.
-	2	Acquisition Status	<ul> <li>Indicates the status of the acquisition.</li> <li>Waiting Trigger indicates that a trigger has not been recognized since the Acquire button was clicked.</li> <li>Triggered indicates <i>eZ-Analyst</i> is capturing and processing data based on the setup conditions.</li> <li>Acquiring indicates that data is being acquired, but is not being recorded to disk.</li> <li>Recording indicates that data is being recorded-to-disk, as it is being acquired.</li> <li>Completed indicates <i>eZ-Analyst</i> has finished processing the frame of data. The "Averages Count" increments by 1 at this time.</li> </ul>
-	3	Date/Time	Provides time in the following format: Day-Month-Year, Hour: Minutes: Seconds. When in Record Mode the current time is displayed. When in Playback Mode the measured time is displayed.
-	4	Slider Bar	The sliding bar indicates the relative location of the displayed data. The record number and the number of records in the file are listed to the right. The slider can be used to quickly locate a specific record. Note that both the Record and the Playback mode make use of the slider bar.
	5	Playback / Recording Status	Displays the current record and the total number of records to be collected. Time equivalents are included in parenthesis Example, 12/25 means that the record currently displayed is the 12 <sup>th</sup> record, out of a total of 25 records.
-		Averaging Status	This field shows when the Averaging Mode is used, during the Scope Mode or the Playback Mode. A display of 2/5 would indicate that 2 averages have been performed out of a total of 5 averages to be performed.
-	6	Channels	Each numbered box represents a channel. Drag a channel [channel-box] to the plot area to have its data displayed. That channel's data is plotted in a distinct color and a color-coded channel button is displayed to the right of the plot. Reference channels are bold and italic. The underlined channel is the current reference channel. Use the right mouse button to select current reference channel. Reference channels are specified in the Configuration accessed via the Edit Menu.

## **Playback Mode**

The Playback Mode does not require the presence of physical hardware. When in Playback, *eZ-Analyst* is strictly a post-acquisition display and analysis program. Raw time-domain data, that has been recorded-to-disk, can be played back for analysis repeatedly. For example, a raw signal could be played back several times, each time using a different filtering algorithm to manipulate the original signal. Once the desired results have been achieved the new data can be exported in a new format and to a different file. The original file can remain unchanged, and kept for future analysis.

To activate the Playback Mode, select Playback/Review on the Task Menu. An option is to click the **Change Task Mode**> button (the first button in the tool bar) while in the Measurement Mode. Also, note that when a WaveBook or ZonicBook is not available, *eZ-Analyst* will automatically enter the Playback mode and will display the data that was most recently recorded to disk.



Playback Mode Task Bar

## A Word About Configuration

Option         No.         Active         Label         Channel Type         Response         FSV         BUI         Units         Location         Coordin         Input Type         Pulse           More.         1         IF         Channel Type         Response         +10.0 to 10.0V         EU         gfs         1         X+         Acceleration           More.         2         IF         Channel01         Direct         Response         -10.0 to 10.0V         EU         gfs         1         X+         Acceleration           More.         3         IF         Channel01         Direct         Response         -10.0 to 10.0V         EU         gfs         3         X+         Acceleration           More.         5         IF         Channel01         Direct         Response         -10.0 to 10.0V         EU         gfs         4         X+         Acceleration           More.         6         IF         Channel01         Direct         Response         -10.0 to 10.0V         EU         gfs         5         X+         Acceleration           More.         6         IF         Channel01         Direct         Response         -10.0 to 10.0V         EU         gfs <t< th=""><th></th><th></th><th colspan="5">Block Rejection Miscellaneous</th><th>Ĩ</th><th></th><th>Oc</th><th>tave Setup</th><th></th></t<>			Block Rejection Miscellaneous					Ĩ		Oc	tave Setup		
Option         No.         Active         Label         Channel Type         Response Reference         FSV         EU Mode         Units         Location         Coord         Input Type         Table Type           More.         1         IF         Channel01         Direct         Response         10.01010.0V         EU         gfs         1         X+         Acceleration           More.         2         IF         Channel01         Direct         Response         -10.01010.0V         EU         gfs         1         X+         Acceleration           More.         3         IF         Channel01         Direct         Response         -10.01010.0V         EU         gfs         3         X+         Acceleration           More.         5         IF         Channel01         Direct         Response         -10.01010.0V         EU         gfs         X+         Acceleration           More.         6         IF         Channel01         Direct         Response         +10.010.0V         EU         gfs         X+         Acceleration           More.         6         IF         Channel01         Direct         Response         +10.010.10.0V         EU         gfs         X+			An	alyzer	Y	Input Channels			Recorder Setup				
Nore         1         IF         Channel01         Direct         Response         -10.0 to 10.0 V         EU         gfs         1         X+         Acceleration           More         2         IF         Channel01         Direct         Response         -10.0 to 10.0 V         EU         gfs         1         X+         Acceleration           More         3         IF         Channel01         Direct         Response         -10.0 to 10.0 V         EU         gfs         1         X+         Acceleration           More         4         IF         Channel01         Direct         Response         -10.0 to 10.0 V         EU         gfs         4         X+         Acceleration           More         6         IF         Channel01         Direct         Response         -10.0 to 10.0 V         EU         gfs         5         X+         Acceleration           More         6         IF         Channel01         Direct         Response         -10.0 to 10.0 V         EU         gfs         A         X+         Acceleration           More         16         IF         Channel01         Direct         Response         -10.0 to 10.0 V         EU         gfs         A	Option	No.	Active	Label	Channel Type	Response Reference	FSV	EU Mode	Units	Location	Coord	Input Type	Tac_ Pulse/
More         2         IF         Channel01         Direct         Response         -10.016 10.0V         EU         gfs         2         X+         Acceleration           More         3         IF         Channel01         Direct         Response         -10.016 10.0V         EU         gfs         3         X+         Acceleration           More         4         IF         Channel01         Direct         Response         -10.016 10.0V         EU         gfs         3         X+         Acceleration           More         6         IF         Channel01         Direct         Response         -10.016 10.0V         EU         gfs         5         X+         Acceleration           More         6         IF         Channel01         Direct         Response         -10.016 10.0V         EU         gfs         6         X+         Acceleration           More         6         IF         Channel01         Direct         Response         -10.016 10.0V         EU         gfs         A         Acceleration           More         8         IF         Channel01         Direct         Response         -10.016 10.0V         EU         gfs         A         Acceleration <td>More</td> <td>1</td> <td>9</td> <td>Channel01</td> <td>Direct</td> <td>Response</td> <td>-10.0 to 10.0V</td> <td>EU</td> <td>g's</td> <td>1</td> <td>X+</td> <td>Acceleration</td> <td></td>	More	1	9	Channel01	Direct	Response	-10.0 to 10.0V	EU	g's	1	X+	Acceleration	
Nore         3         IV         Channel01         Direct         Response         -10.0 to 10.0 V         EU         gfs         3         X+         Acceleration           More         4         IV         Channel01         Direct         Response         -10.0 to 10.0 V         EU         gfs         3         X+         Acceleration           More         5         IV         Channel01         Direct         Response         -10.0 to 10.0 V         EU         gfs         5         X+         Acceleration           More         5         IV         Channel01         Direct         Response         -10.0 to 10.0 V         EU         gfs         5         X+         Acceleration           More         7         IV         Channel01         Direct         Response         -10.0 to 10.0 V         EU         gfs         7         X+         Acceleration           More         8         IV         Channel01         Direct         Response         -10.0 to 10.0 V         EU         gfs         8         X+         Acceleration           More         9         IV         Channel01         WEK14         Response         -5.0 to 5.0 V         EU         gfs         11	More	2		Channel01	Direct	Response	-10.0 to 10.0V	EU	g's	2	X+	Acceleration	
More         4         IV         Channel01         Direct         Response         -10.0 to 10.0 V         EU         gfs         4         X+         Acceleration           More         5         IV         Channel01         Direct         Response         -10.0 to 10.0 V         EU         gfs         4         X+         Acceleration           More         5         IV         Channel01         Direct         Response         -10.0 to 10.0 V         EU         gfs         5         X+         Acceleration           More         6         IV         Channel01         Direct         Response         -10.0 to 10.0 V         EU         gfs         7         X+         Acceleration           More         8         IV         Channel01         Direct         Response         -10.0 to 10.0 V         EU         gfs         8         X+         Acceleration           More         10         IV         Channel01         UREK14         Response         -5.0 to 5.0 V         EU         gfs         10         X+         Acceleration           More         11         IV         Channel01         WEK14         Response         -5.0 to 5.0 V         EU         gfs         11	More	3	9	Channel01	Direct	Response	-10.0 to 10.0V	EU	g's	3	X+	Acceleration	
More         5         F7         Channel01         Direct         Response         -10.010.10.0V         EU         gfs         5         X+         Acceleration           More         6         F7         Channel01         Direct         Response         -10.010.10.0V         EU         gfs         5         X+         Acceleration           More         7         F7         Channel01         Direct         Response         -10.010.10.0V         EU         gfs         6         X+         Acceleration           More         8         F7         Channel01         Direct         Response         -10.010.10.0V         EU         gfs         8         X+         Acceleration           More         8         F7         Channel01         Direct         Response         -10.010.01.00V         EU         gfs         8         X+         Acceleration           More         10         F7         Channel01         VMEK14         Response         -5.010.5.0V         EU         gfs         10         X+         Acceleration           More         11         F7         Channel03         VMEK14         Response         -5.010.5.0V         EU         gfs         11         X+ <td>More</td> <td>4</td> <td>9</td> <td>Channel01</td> <td>Direct</td> <td>Response</td> <td>-10.0 to 10.0V</td> <td>EU</td> <td>g's</td> <td>4</td> <td>X+</td> <td>Acceleration</td> <td></td>	More	4	9	Channel01	Direct	Response	-10.0 to 10.0V	EU	g's	4	X+	Acceleration	
More         6         IV         Channel01         Direct         Response         -10.0 to 10.0V         EU         gfs         6         X+         Acceleration           More         7         IV         Channel01         Direct         Response         -10.0 to 10.0V         EU         gfs         7         X+         Acceleration           More         8         IV         Channel01         Direct         Response         -10.0 to 10.0V         EU         gfs         8         X+         Acceleration           More         8         IV         Channel01         WEK14         Response         -10.0 to 5.0V         EU         gfs         8         X+         Acceleration           More         10         IV         Channel02         VEK14         Response         -5.0 to 5.0V         EU         gfs         10         X+         Acceleration           More         11         IV         Channel02         VEK14         Response         -5.0 to 5.0V         EU         gfs         11         X+         Acceleration           More         12         IV         Channel04         VEK14         Response         -5.0 to 5.0V         EU         gfs         11         X+ </td <td>More</td> <td>5</td> <td>2</td> <td>Channel01</td> <td>Direct</td> <td>Response</td> <td>-10.0 to 10.0V</td> <td>EU</td> <td>g's</td> <td>5</td> <td>X+</td> <td>Acceleration</td> <td></td>	More	5	2	Channel01	Direct	Response	-10.0 to 10.0V	EU	g's	5	X+	Acceleration	
Mare         7         IV         Channel01         Direct         Response         -10.0 to 10.0V         EU         gfs         7         X+         Acceleration           More         8         IV         Channel01         Direct         Response         -10.0 to 10.0V         EU         gfs         7         X+         Acceleration           More         9         IV         Channel01         Direct         Response         -5.0 to 5.0V         EU         gfs         9         X+         Acceleration           More         10         IV         Channel01         WEK14         Response         -5.0 to 5.0V         EU         gfs         10         X+         Acceleration           More         11         IV         Channel03         WEK14         Response         -5.0 to 5.0V         EU         gfs         11         X+         Acceleration           More         12         IV         Channel03         WEK14         Response         -5.0 to 5.0V         EU         gfs         11         X+         Acceleration           More         12         IV         Channel04         WEK14         Response         -5.0 to 5.0V         EU         gfs         12         X+ <td>More</td> <td>6</td> <td>₽</td> <td>Channel01</td> <td>Direct</td> <td>Response</td> <td>-10.0 to 10.0V</td> <td>EU</td> <td>g's</td> <td>6</td> <td>X+</td> <td>Acceleration</td> <td></td>	More	6	₽	Channel01	Direct	Response	-10.0 to 10.0V	EU	g's	6	X+	Acceleration	
More         8         F7         Channel01         Direct         Response         -10.0 to 10.0 V         EU         gfs         6         X+         Acceleration           More         0         F7         Channel01         VMEK14         Response         -5.0 to 5.0 V         EU         gfs         8         X+         Acceleration           More         10         F7         Channel01         VMEK14         Response         -5.0 to 5.0 V         EU         gfs         10         X+         Acceleration           More         11         F7         Channel03         VMEK14         Response         -5.0 to 5.0 V         EU         gfs         11         X+         Acceleration           More         11         F7         Channel03         VMEK14         Response         -5.0 to 5.0 V         EU         gfs         11         X+         Acceleration           More         12         F7         Channel04         VMEK14         Response         -5.0 to 5.0 V         EU         gfs         12         X+         Acceleration           VMere         12         F7         Channel04         VMEK14         Response         -5.0 to 5.0 V         EU         gfs         12	More	7	V	Channel01	Direct	Response	-10.0 to 10.0V	EU	g's	7	X+	Acceleration	
More         9         IV         Channel01         WEK14         Response         -5.0 to 5.0V         EU         gfs         9         X+         Acceleration           More         10         IV         Channel02         WEK14         Response         -5.0 to 5.0V         EU         gfs         10         X+         Acceleration           More         11         IV         Channel02         WEK14         Response         -5.0 to 5.0V         EU         gfs         11         X+         Acceleration           More         12         IV         Channel04         WEK14         Response         -5.0 to 5.0V         EU         gfs         11         X+         Acceleration           More         12         IV         Channel04         WEK14         Response         -5.0 to 5.0V         EU         gfs         12         X+         Acceleration	More	8	V	Channel01	Direct	Response	-10.0 to 10.0V	EU	g's	8	X+	Acceleration	
More         10         IV         Channello2         WEK14         Response         -5.0 to 5.0V         EU         g/s         10         X+         Acceleration           More.         11         IV         Channello3         VEK14         Response         -5.0 to 5.0V         EU         g/s         11         X+         Acceleration           More.         12         IV         Channello4         VEK14         Response         -5.0 to 5.0V         EU         g/s         11         X+         Acceleration           More.         12         IV         Channello4         VEK14         Response         -5.0 to 5.0V         EU         g/s         12         X+         Acceleration	More	9	V	Channel01	WBK14	Response	-5.0 to 5.0V	EU	g's	9	X+	Acceleration	
Mare         11         IF         Channel03         VER(14)         Response         -5.0 to 5.0 V         EU         gfs         11         X+         Acceleration           More         12         IF         Channel04         VER(14)         Response         -5.0 to 5.0 V         EU         gfs         11         X+         Acceleration           More         12         IF         Channel04         VER(14)         Response         -5.0 to 5.0 V         EU         gfs         12         X+         Acceleration           More         13         JF         Channel04         VER(14)         Response         -5.0 to 5.0 V         EU         gfs         12         X+         Acceleration	More	10	V	Channel02	WBK14	Response	-5.0 to 5.0V	EU	g's	10	X+	Acceleration	
More.         12         IV         Channel04         WBK14         Response         -5.0 to 5.0 V         EU         g's         12         X+         Acceleration           More.         13         IV         Channel04         WBK14         Response         -5.0 to 5.0 V         EU         g's         12         X+         Acceleration	More	11	V	Channel03	WBK14	Response	-5.0 to 5.0V	EU	g's	11	X+	Acceleration	
More 13 V Chappel/5 WEK14 Response -50 to 50V EU g/s 13 X+ Acceleration	More	12	V	Channel04	WBK14	Response	-5.0 to 5.0V	EU	g's	12	X+	Acceleration	
	More	13	V	Channel05	WBK14	Response	-5.0 to 5.0V	EU	g's	13	X+	Acceleration	

**Configuring Input Channels** 

*eZ-Analyst* makes use of various Windows and menus for the purpose of configuration. Chapter 2, *Menus and Windows*, is the heart of this document and should be referred to in regard to the various configuration aspects.

## ZonicBook, eZ-Analyst Install

Introduction..... 1-5 System Requirements ..... 1-6 Software Installation for Windows 98/Me/2000/XP/NT ..... 1-6 A Special Note for Windows NT Users ..... 1-8 Hardware Setup and DSP-Card Installation..... 1-9 Verifying DSP-Card Installation ..... 1-9 Note: This section does not apply to the "View" applications.

## Introduction

ZonicBook 4, 8, and 16-channel data acquisition modules are built to take advantage of PCs running under Windows operating systems.

Inside each ZonicBook is an analog to digital converter with anti-aliasing filters for each channel. Synchronous sampling of all channels ensures accurate phase relationships and the correlation of data.

The interface between the ZonicBook and the host PC is a type III PCMCIA card, which we will refer to as a "DSP Card" (Digital Signal Processing Card). A proprietary chip set on the card provides the digital signal processing of both time history and *Fast Fourier Transform* (FFT) analysis data. A four-megabyte buffer is used to ensure gap-less data, independent of available processor memory.

Machine conditions and analysis solutions can be shared instantaneously with associates, providing that ZonicBook's host PC is connected to an Ethernet LAN, file server, internet, or intranet.

The ZonicBook is operated via Graphical User Interface (GUI). Prior to using a ZonicBook system, it is essential that:

- the DSP program has been loaded into the DSP Card
- the ZonicBook is initialized
- system communications are working properly



This document discusses the installation of *eZ-Analyst* software. Be sure to install the software prior to performing the hardware installation. In regard to hardware installation, refer to your *ZonicBook User's Manual*, p/n 1086-0901.



#### **Reference Note:**

Adobe Acrobat PDF versions of documents pertaining to ZonicBook are automatically installed onto your PC's hard-drive as a part of product support at the time of software installation. The default location is the Program Files directory, which can be accessed via the *Windows Desktop Start Menu*.

## **System Requirements**

Before setting up the hardware or installing the software, verify that you have the following items.

- ZonicBook Data Acquisition Module
- ZonicBook DSP-Card
- Universal Power Supply with cord (U.S.)
- Data Acquisition CD
- Passwords for purchased software

In addition, verify that your computer meets the following **minimum** requirements.

- Intel<sup>™</sup>, Pentium 90 MHz or equivalent
- a slot for a Type III PCMCIA Card
- 64 MB Memory
- 100 MB Hard Disk space
- Monitor: SVGA, 800 x 600 resolution
- One of the following Microsoft<sup>®</sup> Windows Operating Systems:
  - Windows 98 Windows Me Windows NT Windows 2000 Windows XP



If you purchased software, associated passwords will accompany your installation CD. If this is the case, keep your passwords in a safe place. You will need to enter them once, during an actual run of *eZ-Analyst*.

Note that entry of your Authorization Code is only required once. You can enter the code from the *eZ-Analyst* application during its initial run.

Complete these simple steps to enter the code:

- 1. Open eZ-Analyst.
- 2. From the File Pull-Down menu, select *Authorization*. The *Authorization* dialog box appears (see figure).
- 3. Enter your Authorization Code from the code sheet that was included with your purchase.
- 4. Click the <**Apply Code**> button to enable your new software features.

🗳 Authorization 🛛 🔀
Enter Authorization Code:
Feature Authorization
Apply Code Start 30 Day Trial OK



Authorization Dialog Box

## Software Installation for Windows 98/Me/2000/XP/NT

- 1. Start Windows.
- 2. Close all running applications.
- 3. Insert the Data Acquisition CD into your CD-ROM drive and wait for the CD to auto-run.

If the CD does not start on its own:

- (a) click the desktop's <Start> button
- (b) choose the Run command
- (c) select the CD-ROM drive, then select the setup.exe file
- (d) click  $\langle OK \rangle$

An Opening Screen will appear.

- 4. Click the **<ENTER SETUP>** button.
- 5. On the hardware selection screen [which follows a licensing agreement], select **ZonicBook Systems** from the drop-down list.
- 6. On the resulting software options screen you will see that **eZ-Analyst Real-Time FFT Analyzer Software** has been automatically selected. If applicable to your ZonicBook System, select other install options.
- 7. Click the **<Install**> button; then follow the on screen prompts to complete the installation.



If you purchased software, associated authorization codes will accompany your installation CD. If this is the case, keep your codes in a safe place. You will need to enter them once, during an actual run of *eZ-Analyst*.

## A Special Note for Windows NT Users

If your PC is using Windows NT, perform the following after you have installed the software.

- 1. Verify that you are logged on with Administrator capabilities.
- 2. Verify IRQ and I/O Port availability. This is done as follows:
  - (a) From the Start menu, navigate as follows:
    - **Program**  $\Rightarrow$  Windows NT Diagnostics  $\Rightarrow$  Resources
    - (b) Verify and write down the I/O Port Address; for example: 0110-011F
    - (c) Verify and write down available IRQs; for example: 9, 10, 11.
- 3. Open the *Control Panel*.
- 4. Double-click the CACDSP icon. This opens the CAC API Configuration Utility window.
- 5. In the data entry box, enter the I/O Port Address [from step 8b]. Typically the I/O Port is either 0x0110 or 0x0120.
- 6. In the data entry box, enter an available interrupt (IRQ) for your system [from step 8c]. Typically this is 10 or 11.
- 7. Click the *DSP Tab*.
- 8. Select PCMCIA.
- 9. Click the <ADD> button.
  - **Note**: For Windows NT operating systems, the I/O Port Address and IRQ values do not show up in the menus after you close the window. They are; however, stored in memory.
- 10. Click <OK.>
- 11. Restart your computer.

Your computer is now ready to run ZonicBook software and communicate with the ZonicBook module.

#### If the DSP-Card does not respond in Windows NT, try the following:

1. From the desktop, open the Control Panel. This is done by navigating as follows:

Start  $\Rightarrow$  Settings  $\Rightarrow$  Control Panel  $\Rightarrow$  System  $\Rightarrow$  Device Manager  $\Rightarrow$  CACDSP Note: "CACDSP" represents the DSP-Card device

- 2. Double-click the "CACDSP" (DSP-Card) device.
- 3. Click the <Start> button. This starts the DSP-Card without the need to reboot the computer.
- 4. To enable or disable the DSP-Card, click the <Startup> button, then click the <Enable> or the <Disable> button as applicable.
- 5. Click the <HW Profiles> button.
- 6. If the *Startup* method is not set to "Automatic," set the DSP-Card for "Automatic" startup.

## Hardware Setup and DSP-Card Installation (All Windows Systems)



#### **Reference Note:**

If you have not already set up your hardware and installed your DSP-card, refer to your ZonicBook User's Manual (p/n 1086-0901), and do so at this time.

## **Verifying DSP-Card Installation**

You can use the Window's Device Manager to verify that the DSP-card has been properly installed. The steps for this method are as follows.

- 1. From the Windows Desktop, click <Start>.
- 2. Click Settings.
- 3. Click Control Panel.
- 4. Click the System icon.
- 5. Click the "Device Manager" tab.
- 6. Locate one of the following nodes, as applicable to you Window's operating system.
  - Windows 98 and Windows Me users should locate a node called D32DSP.
  - Windows 2000, Windows XP, Windows NT users should locate a node called **CACDSP**.
- 7. Expand that node by clicking on the "+" symbol.

At this point you should see a screen similar to one of the following, depending on which operating system your PC is using.

System Properties	? ×
General Device Manager Hardware Profiles Performance	
View devices by type     C View devices by connection	
Computer	
D32DSP	
MEDALLION Digitial Signal Processor	
Disculves     Disculves     Disculves     Disculves	

DSP Verification, Windows 98 and Windows Me



**DSP** Verification, Windows 2000



DSP Verification, Windows XP

**Note**: A screen image is not shown for Windows NT. However, Windows NT makes use of a CACDSP node, as do Windows 2000 and Windows NT.

ZonicBook Applications



Note: This section

## WaveBook, eZ-Analyst Install

Introduction..... 1-11 System Requirements ..... 1-11 Software Installation ..... 1-12 Using the Daq Configuration Applet to Check Connections ..... 1-13



*eZ-Analyst* will only work with one WaveBook installed in the Daq Configuration Control Panel.

## Introduction

WaveBooks are 1MHz portable data acquisition devices that can be used in a variety of applications, such as testing engine strain, multi-channel acoustics, mechanical integrity, and vibration/shock/strain. With WaveBook, *eZ-Analyst* offers a channel count of up to 64 channels, relatively high frequency analysis capabilities, and a selection of input channel types, including Analog filtering, Strain Gage, and ICP.

## **System Requirements**

Before setting up the hardware or installing the software, verify that you have the following items.

- WaveBook Data Acquisition System
- Power Supply with cord
- Data Acquisition CD
- Passwords for purchased software

In addition, verify that your computer meets the following **minimum** requirements.

- Intel<sup>™</sup>, Pentium 90 MHz or equivalent
- 64 MB Memory
- 100 MB Hard Disk space
- Monitor: SVGA, 800 x 600 resolution
- One of the following Microsoft<sup>®</sup> Windows Operating Systems:

Windows 98 Windows Me Windows NT Windows 2000 Windows XP

Optional, but recommended: EPP (Enhanced Parallel Port), or ECP (Extended Capabilities Port)



If you purchased software, associated passwords will accompany your installation CD. If this is the case, keep your passwords in a safe place. You will need to enter them once, during an actual run of *eZ-Analyst*.

## **Software Installation**



Remove any previous-installed versions of WaveBook software before installing a new version.

- 1. Start Windows.
- 2. Close all running applications.
- 3. Insert the Data Acquisition CD into your CD-ROM drive and wait for the CD to auto-run.

If the CD does not start on its own:

- (a) click the desktop's <Start> button
- (b) choose the Run command
- (c) select the CD-ROM drive, then select the **setup.exe** file.
- (d) click  $\langle OK \rangle$ .

An Opening Screen will appear.

- 4. Click the **<ENTER SETUP>** button.
- 5. From the hardware selection screen [which follows a licensing agreement], select **WaveBook Systems** from the drop-down list.
- 6. On the resulting software options screen you will see that *WaveView* and *eZ-PostView* have been automatically selected. If you plan to use eZ-Analyst in place of *WaveView*, de-select *WaveView* and *eZ-PostView*; otherwise, keep both options selected.
- 7. Select eZ-Analyst Real-Time FFT Analyzer Software.



If you purchased software, associated authorization codes will accompany your installation CD. If this is the case, keep your codes in a safe place. You will need to enter them once, during an actual run of *eZ-Analyst*.

- 8. If applicable, select other install options.
- 9. Click the **<Install**> button.
- 10. Follow the on-screen prompts to complete the installation process.

Note that the *eZ-Analyst* authorization code is entered via an Authorization Dialog Box, which is accessed from *eZ-Analyst's* File pull-down menu. This is described in the Authorization Certificate that is included with your purchase of eZ-Analyst. Page 1-6 of this chapter contains additional information.



#### **Reference Notes:**

- Adobe Acrobat PDF versions of documents pertaining to WaveBook are automatically installed onto your PC's hard-drive as a part of product support at the time of software installation. The default location is the **Programs** group, which can be accessed via the *Windows Desktop Start Menu*.
- After your software is installed you can setup your WaveBook device and connect it to the host computer. Instructions for *Hardware Setup* are included in your *WaveBook User's Manual*.

## Using the Daq Configuration Applet to Check Connections

The *Daq Configuration* applet, designed for 32-bit Windows 95/98/Me/NT/2000/XP systems, is located in the Windows *Control Panel*. It allows you to add or remove a device and change configuration settings. The included test utility provides feedback on the validity of current configuration settings, as well as performance summaries.

### Device Inventory Dialog Box

Run the applet by double-clicking on the Daq Configuration icon in the Windows Control Panel.

The *Device Inventory* dialog box will open, displaying all currently configured devices. Displayed devices show their name and an icon to identify the device type. If no devices are currently configured, no devices will appear in this field.

The four buttons across the bottom of the dialog box are used as follows:

- **Properties:** Current configuration settings for a device can be changed by first bringing up the corresponding *Properties* dialog box. Open the *Properties* dialog box by double-clicking on the device icon or selecting the device and then clicking on the *Properties* button.
- *Add Device*: The *Add Device* button is used to add a device configuration whenever a new device is added to the system. Failure to perform this step will prevent applications from properly accessing the device. Clicking on the *Add Device* button will open the *Select Device Type* dialog box.
- *Remove:* The *Remove* button is used to remove a device from the configuration. A device may be removed if it is no longer installed, or if the device configuration no longer applies. Since *eZ-Analyst* will only work with one WaveBook in device inventory, if applicable, you will need to remove other WaveBooks.
- **Note:** If a device is removed, applications may no longer access the device. However, the device can be re-configured at any time using the *Add Device* function described above.
- *Close*: The *Close* button may be used at any time to exit the *Daq Configuration* applet.



Daq Configuration - Device Inventory Dialog Box

#### Select Device Type Dialog Box

This dialog box opens when the *Add Device* button of the *Device Inventory* dialog box is selected.

The device type you select for configuring will appear in the main edit box. Clicking on the OK button will then open the Properties dialog box (following figure).

Selec	<b>t Device Type</b>	
	WaveBook	•
	DaqBoard/100A DaqBoard/112A DaqBoard/200A DaqBoard/216A Daq112B Daq216B	
	WaveBook TempBook66	<b></b>
	<u>0</u> K	Cancel

Daq Configuration - Select Device Type Dialog Box

#### **Properties Dialog Box**

This dialog box opens when the *Properties* button of the *Device Inventory* dialog box is selected, or when the *OK* button of the *Select Device Type* dialog box is selected. It displays the properties for the WaveBook device with the default configuration settings. The fields include:

- **Device Name:** The Device Name field is displayed with the default device name. As shown, this field can be changed to any descriptive name as desired. This device name is the name to be used with the **daqOpen** function to open the device. This name will also be displayed in the device lists for opening the device in the WaveView and WaveCal applications.
- **Device Type:** The Device Type field indicates the device type that was initially selected. However, it can be changed here if necessary.
- **Parallel Port:** The Parallel Port field is used to set the parallel port for communicating with the WaveBook.
- **Protocol:** The *Protocol* field is used to set the parallel port protocol for communicating with the WaveBook. Depending on your system, not all protocols may be available. (See following Note).

WaveBook Properties Te:	est Hardware
Device Settings	
Device Name	Wavebooktest
Device Type	WaveBook/512
Parallel Port	LPT2
Protocol	Standard 8-bit
- Device Resources -	SMC666 EPP
Resource Type	Setting
Interrupt Request	05
Input/Output Rang	je 0278 - 027A
(	OK Cancel Apply

**Daq Configuration - Properties Dialog Box** 



In regard to Protocol – If you are using a WBK20A or WBK21, you must select "Fast EPP (wbk/20/21)" to achieve the best performance.

- *Device Resources*: The *Device Resources* field lists settings for various resources, among them Interrupt Request, Input/Output Range, and Direct Memory Access.
- **OK:** Click on the OK button to store the configuration and exit the current dialog box.
- *Cancel:* Click on the *Cancel* button to exit the current dialog box without storing any changes.
- *Apply:* Click on the *Apply* button to store the configuration. Or you can click the following tab:
- *Test Hardware:* Click on the *Test Hardware* tab to test the current stored configuration for the device. This selection will open the *Test Hardware* dialog box.

#### Test Hardware Dialog Box

Before testing WaveBook, make sure the device has been properly installed and powered-on. Make sure the parallel port cable is firmly in place on both the WaveBook and the proper LPT port in the computer.

When testing WaveBook, if the unit does not respond within 30 seconds perform the following steps:

- 1) reboot the system
- 2) upon power-up, re-open the *Daq Configuration* applet
- 3) select another configuration setting
- 4) reinitiate the test

To test the currently stored configuration for the WaveBook device, click the *Test* button. Results should be displayed in a few seconds. The test results have two components: *Resource Tests* and *Performance Tests*.

**<u>Resource Tests</u>**. The resource tests are intended to test system capability for the current device configuration. Resource tests are *pass/fail*. Test failure may indicate a lack of availability of the resource, or a possible resource conflict.

**Base Address Test.** This resource test checks the base address for the selected parallel port. Failure of this test may indicate that the parallel port is not properly configured within the system. See relevant operating system and computer manufacturer's documentation to correct the problem.

**Performance Tests.** These types of tests are intended to check various WaveBook functions, using the current device configuration. Performance tests provide quantitative results for each supported functional group. Test results represent maximum rates the various operations can be performed. The rates depend on the selected parallel port protocol, and vary according to port hardware capabilities.

*WBK30 FIFO Test.* This *performance test* checks the data-storing capabilities of the optional, WBK30 memory card.

Note that the figure to the right represents results from a previous test. Initially, the screen shows no test results.

👷 Daq* Configuration 🛛 🗙
WaveBook Properties Test Hardware
Prior to testing please make sure your device is connected to the PC.
If your computer does not respond for 30 seconds please reboot and change the settings in the configuration utility.
Test Results
WBK30 FIFO Test:
WBK30 FIFO Test> Passed
Besource Test WBK30 FIFO Test
OK Cancel Apply

Daq Configuration - Test Hardware Dialog Box

When the test is completed successfully, the *Daq Configuration Test Dialog Box* indicates a passed condition. For example, in the above figure:

#### WBK30 FIFO Test → Passed.

"Passed" messages indicate that you can exit the test program and run your application.

WaveBook Applications



### Foreword

In addition to use as a reference for *eZ-Analyst*, this chapter can also be used for *eZ-PostView*, *eZ-TimeView*, and *eZ-FrequencyView*. However, there are many cases where a menu or window does not apply to one or more of these "view" applications. In these instances, functions or selection options that can not be used will be either "grayed-out" or hidden in the actual application. The table on page 2-2 can be used as a quick reference as to what features apply to a particular application.

The menus, with exception of the **Task Menu**, are presented in the order that they appear on *eZ-Analyst's* main window. The Task Menu is discussed first since it is from this menu that the user (1) selects **Measurement Mode** or **Playback Mode** and (2) makes use of the **Auto-Ranging** feature for **input channels**.

Note that the "view" programs have no Task Menu. This is because they actually have only one task, "Playback Mode."

## Contents

#### Comparing the "View" Applications to eZ-Analyst ..... 2-2

Task Menu (eZ-Analyst Only).....2-3Measurement Mode......2-3Playback Mode......2-4Input Range (Auto/Manual)......2-4Calibration......2-7

### File Menu ..... 2-11

*Edit Menu ..... 2-13* Configuration Window ..... 2-13 Playback Setup Window ..... 2-37 Display Preferences Window ..... 2-39

Export Menu ..... 2-41

Window Menu ..... 2-43

#### Notes:

- In the View-applications, the "Miscellaneous" tab corresponds to eZ-Analysts "FFT Setup" tab. Appendix C contains a screen shot of the "Miscellaneous" tab.
- In the View-Applications Edit menu, there are two windows that are not seen in eZ-Analyst. These are (a) Window Colors Window and (b) Preferences Window. In eZ-Analyst, the Display Preferences Window covers the functions of these other two windows. View-application users can refer to Appendix C for additional information.
- > At present, *eZ-Analyst* only applies to ZonicBook and WaveBook devices.
- Our other acquisition devices, e.g., LogBooks, DaqBoards, DaqBooks, ChartScans, etc., can not currently use eZ-Analyst, but can make use of one of its derived "view" applications.
- The operational differences between the use of eZ-Analyst in ZonicBook and the WaveBook are minor. However, the differences are noted. For example, the discussion of Autorange is broken down into two sections, one sub-titled "ZonicBook Applications" and the other "WaveBook Applications."

eZ-Analyst Series Comparison Matrix					
Feature	Post-A	e7-Analyst			
	eZ-PostView	eZ-TimeView	eZ-FrequencyView	ew	
File Input Format Support for: DaqView, WaveView, Personal DaqView, ChartView, UFF-58B.	Yes	Yes	Yes	Yes	
File Export to: ME'Scope and SMS Modal, Microsoft Excel, Binary Universal File, and ASCII text files.		Yes	Yes	Yes	
Display Windows, number of	8	8	8	8	
Channel Traces per Display Window	16	16	16	16	
Automatic Data Scaling	Yes	Yes	Yes	Yes	
Simulated Data Playback		Yes	Yes	Yes	
Configurable Data Display for channels and trace colors	Yes	Yes	Yes	Yes	
Multiple Tiling of display windows	Yes	Yes	Yes	Yes	
Cursor Support - for both Single Cursor and Band Cursor		Yes	Yes	Yes	
Data Strip Chart Display		Yes	Yes	Yes	
Peak-to-Peak Calculations		Yes	Yes	Yes	
Peak Searching, minimum and maximum		Yes	Yes	Yes	
Mean Calculations		Yes	Yes	Yes	
RMS Calculations		Yes	Yes	Yes	
Zooming [of the data display]		Yes	Yes	Yes	
Windowed Time Display Function		Yes	Yes	Yes	
Cross Channel Support			FFT, FRF, Cross, Coherence, Transfer Function	FFT, FRF, Cross, Coherence, Transfer Function	
Transfer Function Display Types			Note 1	Note 1	
Complex Function Display Types			Note 2	Note 2	
Scale Types		RMS, Peak, Peak-to-Peak	RMS, Peak, Peak-to-Peak	RMS, Peak, Peak-to-Peak	
Function Display Types		Time, Strip Chart	Note 3	Note 3	
Octave Types			1/3, Full	1/3, Full	
Octave Weighting			Linear, A, B, C	Linear, A, B, C	
Waterfall Plots			Yes	Yes	
Integration/Differentiation (Single/Double)			Yes	Yes	
Response Channel FFT Windows			Note 4	Note 4	
Reference Channel FFT Windows			Rectangular, Cosine Taper	Rectangular, Cosine Taper	
Low-Pass DC Noise Filtering			Yes	Yes	
Spectral Strip Chart Display Synchronization			Yes	Yes	
Octave Strip Chart Display Synchronization			Yes	Yes	
Record and Save Data to Disk				Yes	
"Real Time" Data Display				Yes	

# Comparing the "View" Applications to eZ-Analyst

Notes: 1) *eZ-Analyst* and *eZ-FrequencyView* - each offers the following Transfer Function Display Types: Inertance, Mobility, Compliance, Apparent Mass, Impedance, and Dynamic Stiffness.

2) eZ-Analyst and eZ-FrequencyView - each offers the following Complex Function Display Types: Magnitude, Phase, Real, Imaginary, Nyquist, Magnitude and Phase, and Real and Imaginary.

- 3) eZ-Analyst and eZ-FrequencyView each offers the following Function Display Types: Spectrum, Auto-Spectrum, PSD (Power Spectral Function), Strip Chart.
- 4) eZ-Analyst and eZ-FrequencyView each offers the following Response Channel FFT Windows: Hanning, Flat Top, Exponential, and Blackman-Harris.

## Task Menu

### Task Menu > Measurement Mode

The Measurement Mode is an active data-collecting mode, which, for that reason, requires the use of data acquisition hardware. The Measurement Mode can only be selected if a ZonicBook or WaveBook is available; otherwise, *eZ-Analyst* will run in the Playback Mode only.

The Measurement Mode can run in one of three sub-modes, *Scope-Continuous, Scope-Single*, or *Record*. The first two sub-modes are simple displays that do not log data and are most useful for signal validation and checkout. The Record mode is the same as the two Scope modes, but has the added feature of logging data-to-disk based on additional start and stop criteria.

In addition to being selected from the Task Menu, the Measurement Mode can be selected from the Task Tool Bar by clicking the **<Change Task Mode>** button while in the Playback Mode. Clicking this button from Measurement Mode will change the task mode tool bar to Playback.



Note that *grayed-out* buttons indicate that the associated function is not available due to a prerequisite not being met.

Change Task Mode	-	Changes the task from Measurement Mode to Playback Mode. The Task Bar buttons will change accordingly.		
Record		Starts recording data-to-disk. Note that a ZonicBook or WaveBook must be used to acquire data.		
Scope-Continuous	<b>(</b>	Starts a continuous-time acquisition in Scope mode. This mode does not record data to disk. Note that a ZonicBook or WaveBook must be used to acquire data.		
Scope-Single	3	Starts a single-time run data acquisition in the scope mode. This mode does not record data to disk. Note that a ZonicBook or WaveBook must be used to acquire data.		
Signal Generator		The Signal Generator button toggles between two images and is only active when hardware is present.		
Indicates that the Generator is turned <b>ON</b>	0	The sign wave button indicates that the generator is ON. Clicking on it will turn the generator OFF and the button image will change to a circled red line, indicating that the generator is OFF.		
Indicates that <u></u> the Generator is turned <b>OFF</b>	$\overline{\Theta}$	Clicking the button, while the "Off Status" image is present, will turn the Signal Generator back ON, and will change the button to show the sign wave image.		
		<b>Note</b> : For WaveBook applications you must set the applicable output channel (that is to generate the signal) to "Active." See, <i>Output Channel Setup Tab, 2-24</i> .		
Cursor Lock	<b>F</b>	An active cursor lock button will have the image of an opened or locked padlock. When the padlock is locked (closed), cursors in multiple windows will be synchronized and locked, providing that the windows are of the same time domain, frequency domain, or have the same octave band data.		
		An opened padlock image indicates that cursors in multiple windows have independent cursor movement, i.e., they are unsynchronized.		
Export		This button exports data, if export conditions are set. For details, see the section, <i>Export Menu&gt; Save Export Function Data</i> .		

## Task Menu > Playback / Review Mode

The Playback Mode does not require the presence of physical hardware. When in Playback, *eZ-Analyst* is strictly a post-acquisition display and analysis program. Raw time-domain data, that has been recorded-to-disk, can be played back for analysis repeatedly. For example, a raw signal could be played back several times, each time using a different filtering algorithm to manipulate the original signal. Once the desired results have been achieved the new data can be exported in a new format and to a different file. The original file can remain unchanged, and kept for future analysis.

To activate the Playback Mode, select Playback/Review on the Task Menu. An option is to click the **Change Task Mode**> button (the first button in the tool bar) while in the Measurement Mode. Also, note that when a WaveBook or ZonicBook is not available, *eZ-Analyst* will automatically enter the Playback mode and will display the data that was most recently recorded to disk.



Playback Mode Task Bar

## Task Menu > Input Range (Auto/Manual)

Auto-ranging is a procedure that automatically sets the input full-scale voltage (FSV) range for input channels. The FSV is set by measuring a representative sample of real-time data. Auto-ranging is only performed on active channels.

### WaveBook Applications

Auto-ranging works best if you supply the same type of live data as that which will be captured during the acquisition. Therefore, make the Auto Range **Duration** long enough to apply a typical signal. The maximum duration is 65535 mSecond. Also, make sure that the Auto Range **Analysis Frequency** is fast enough to capture the high frequency component. Typically the **Analysis Frequency** will be the same setting as *eZ-Analyst*'s Acquisition Analysis Frequency.



Auto Range Dialog Box, WaveBook Applications

You can access the dialog box for WaveBook by clicking the **<Auto Range>** button, which is located on the Input/Output Channels tab.

### ZonicBook Applications

Auto-ranging works best if you supply the same type of live data as that which will be captured during the acquisition.

	🔽 Ch.1	🔽 Ch.2	🔽 Ch.3	🔽 Ch.4	🔽 Ch.5	🔽 Ch.6	🔽 Ch.7	🔽 Ch.8
	100%	100%	100%	100%	100%	100%	100%	100%
	80% -	80% -	80% -	80% -	80% -	80% -	80% -	80% -
	60% -	60% -	60% -	60% -	- 60% -	60% -	60% -	60% -
	40% -	40% -	40% -	40% -	40% -	40% -	40% -	40% -
	20% -	20% -	20% -	20% -	20% -	20% -	20% -	20% -
	0% –	0% -	0%-	0% -	0% -	0% -	0% 📕	0% -
FSV	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00
%	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000

#### Auto Range Display

When the Auto Range window opens, there are two numbers at the bottom of each column. The upper number is the **Current FSV (in volts)** and the lower number is the **% of the bar**. These are the same values that were entered in the Vpeak column in the Channel Setup window. The values are immediately replaced when the Auto ranging process begins.

An example is included in the upcoming section, Setup Auto-ranging Parameters for ZonicBook.

#### Monitoring the Instantaneous Signal Level

The instantaneous peak value is graphically displayed in the vertical bars.

Yellow	=	signal range is from 0 to the minimum Full-Scale Voltage set in the Auto-range Setup window.
Green	=	signal range is from the minimum to the maximum of the Full-Scale Voltage set in the Auto-range Setup window.
Red	=	signal range is over the maximum of the Full-Scale Voltage set in the Auto-range Setup window.
#### Setting Up Auto-Range Parameters for ZonicBook Applications

- 1. On the Task Menu select *Input Range (Auto/Manual)* to open the Auto Range Display. The previous figure depicts the *Auto Range Display*.
- 2. Select the **Setup Menu** to open the Auto/Manual Range Setup window. Use this window when you want to change the default values (following figure).
- 3. Enter the desired values and click the <OK> button (following figure).

Auto/Manual Range	Setup	? ×
Maximum FSV	25.7	
Minimum FSV	0.2	
Upper Limit(%)	90	
Lower Limit(%)	10	
Increasing Factor	1.5	
Decreasing Factor	1	
Start FSV ( Cu	urrent C Minimum C	Maximum
ок	Cancel	

Auto/Manual Range Setup

#### Example:

Maximum FSV set at 25.7 V Minimum FSV set at 0.2 V Upper Limit set at 90% Lower Limit set at 10% Increasing Factor set at 1.5 Decreasing Factor set at 1

In this example we have set the radio button for *Current FSV* instead of *Minimum* or *Maximum* (note 2). The starting value, in the example, is 0.20 V.

In the **first iteration** we see that we have a peak of 0.19 V. This falls outside of our band of 0.02 to 0.18 V that was established by our upper and lower limit percentages; i.e., 90% of the Current FSV and 10% of the FSV.

Maximum FSV is the high-end limit for the input voltage. Note that 25.7 V is the highest possible FSV for a ZonicBook.

Minimum FSV is the low-end limit for the input voltage.

**Upper Limit (%)** defines the highest acceptable peak input voltage for the selected FSV, i.e., *Current, Minimum*, or *Maximum*. Thus, if our selected FSV was 0.2 V and we had an upper limit of 90%; then our upper limit in volts would be 0.18 V. An example follows as to how exceeding this value causes a range adjustment.

**Lower Limit (%)** defines the lowest acceptable peak input voltage for the selected FSV, i.e., (*Current, Minimum*, or *Maximum*). Thus, if our selected FSV was 0.2 V and we had a lower limit of 10%; then our actual low limit in volts would be .02 V.

**Increasing Factor** is the factor by which the *Current FSV* will increase, should the peak exceed the upper limit.

**Decreasing Factor** is the factor by which the *Current FSV* will decrease, should the peak not reach the lower limit. Keeping the decrease factor as "1" will result in no decrease of the Current FSV. Setting the Decrease Factor to 0.8 would cause the Current FSV to decrease to 80% of its value if the peak fell short of the low limit.



An Example of Auto-Ranging

As a result, the Current FSV is increased by a factor of 1.5 (our Increasing Factor) and the Current FSV becomes 0.30 V. Our limits, in volts, also changed since we are now looking at percentages of 0.30 volts instead of the same percentages of 0.20 volts.

In the **second iteration** of our example, we see a 0.22 volt peak. This value is within our established limits so the Current FSV does not change.

Note 1: If the Capture Mode is the Input Channel (Trigger Mode), the Auto Range process waits for a trigger.

Note 2: A Start FSV of Minimum or Maximum can selected instead of Current FSV, as in our example. Minimum FSV is the default.

# Task Menu > Calibration

When calibration is performed, a signal of known Peak level [or RMS value] is supplied to a transducer that is connected to an active input channel. An accelerometer calibrator or piston phone is typically used to generate the calibration signal for vibration sensors and microphones, respectively.



#### Examples:

Accelerometer calibrators typically make use of linear engineering units and, as their name implies, are used for calibrating accelerometers.

**Piston phones** are most often used for calibrating microphones. Piston phones typically make use of decibel (**dB**) engineering units.

*eZ-Analyst* includes a Calibration window for selecting the channels to be calibrated and for entering several signal-related parameters. In addition, the calibration is actually started from the window.

You can access the Calibration window from the Task Menu, as well as from the Input/Output Channels tab.

• •	Single C Multiple	hannel Channel	T Auto	Range	C Time Frequecy		1000	(Hz)		
No.	Active	Calibrator Type	Calibrator Scale	EU dB Reference	Calibrator EU	Measured mV	Transducer mV/EU	EU Offset	Transducer Gain	Calibration Date
1	•	RMS	Lin	1.000	1.000	2561.	2561.	0.0000	1.000	09-Apr-2002 11:58:52
2	C	RMS	Lin	1.000	1.000	0.0000	100.0	0.0000	1.000	09-Apr-2002 00:00:00
3	C	RMS	Lin	1.000	1.000	0.0000	100.0	0.0000	1.000	09-Apr-2002 00:00:00
4	C	RMS	Lin	1.000	1.000	0.0000	100.0	0.0000	1.000	09-Apr-2002 00:00:00
5	C	RMS	Lin	1.000	1.000	0.0000	100.0	0.0000	1.000	09-Apr-2002 00:00:00
6	C	RMS	Lin	1.000	1.000	0.0000	100.0	0.0000	1.000	09-Apr-2002 00:00:00
7	C	RMS	Lin	1.000	1.000	0.0000	100.0	0.0000	1.000	09-Apr-2002 00:00:00
8	C	RMS	Lin	1.000	1.000	0.0000	100.0	0.0000	1.000	09-Apr-2002 00:00:00

**Calibration Display Screen** 



- When a channel is calibrated, the number of averages used will be 5, or the number that is designated in the "No. of Averages" field (located on the Analyzer Tab). The greater of the two values will be used, automatically.
- When a channel is calibrated, the blocksize of the acquisition will automatically be 4096, or the blocksize value that is stated on the Analyzer Tab, providing it is 4096 or higher.

A discussion of the various regions of the Calibration window now follows. The section concludes with an example.

#### **Calibration Process**

Single Channel	Used to select one active channel at a time. When the calibrator only has one channel output, the Single Channel method must be used. When Single Channel is selected, the "Active" column shows a radio button next to each channel.
Multiple Channel	Used to select two or more channels for simultaneous calibration. This is only an option when the calibrator offers more than one output. When Multiple Channel is selected, the "Active" column shows a checkbox next to each channel.
Auto Range	Auto-range sets the input full-scale voltage (FSV) range for the input channels to be calibrated. FSV is determined by measuring a representative sample of real-time data.

#### **Calibration Domain**

With the use of *Fourier Transform*, any signal can be viewed from a *time domain* or a *frequency domain*. Either domain can be selected for use in the calibration process.

Time	The overall value is computed using time domain data.
Frequency	The overall value is computed with frequency domain data by summing up frequency component of FFT spectrum.

#### Calibrator Frequency (Hz)

This field is used to enter the frequency setting of the calibrator. The analysis frequency, which is twice this frequency, is used if possible. Otherwise, the maximum allowed analysis frequency is used.

#### **Columns on the Calibration Window**

No.	This column displays channel numbers $[1, 2, 3, etc.]$ for easy reference to their associated cells. The channel numbers, being for display indication only, are fixed and can not be edited.
Active	When " <b>Single Channel</b> " is selected, you can click on a radio button in the "Active" column to enable one channel for calibration. When the calibration is complete, select the radio button for the next channel to be calibrated.
	When " <b>Multiple Channel</b> " is selected, the radio buttons are replaced by checkboxes. Ensure that each channel to be calibrated has the associated box checked, and that the remaining channels remain unchecked. For multiple channel applications note that you can click on the column label, i.e., the word "Active" to simultaneously check or uncheck all channel checkboxes in the column.
	<b>Note</b> : The channel settings in the Calibration window are independent of the selections that appear in the Input Channel Setup window. Only active channel shows up at calibration window.

Calibrator Ty	ре	This column is used to select Peak or RMS* as the calibrator type. Highlight a cell, or range of cells, in the grid, then select Peak or RMS from the popup menu.
	Peak	Uses the peak amplitude of the spectrum around the specified frequency of the calibration signal.
	RMS	Uses a compensated overall level calculation to determine the RMS level of the calibration signal, as specified in the Units field.
		*RMS – <i>Root-mean-square</i> , is the square root of the arithmetic mean of the squares of a set of numbers.
Calibrator Scale	This colun	nn is used to select the calibrator scale to linear or to decibel.
Lin	Select Lin	if the calibrator is in linear scale.
dB	Select dB	if the calibrator scale is dB.
	Note: Wh exp con	ile there are several definitions to dB, in our application we are using dB to press the ratio of the magnitudes of two quantities equal to 20 times the mmon logarithm of the ratio.
	The formu	la for dB is:
		dB = 20 log (x/dBEUref)
EU dB Reference	This field	is used to enter the Engineering Units dB reference.
	dB EU Re This is val	ference is applied to displayed data when the Y-axis scale is set to dB. id only for frequency domain data.
	Note: The asso	e dB Reference (Volt) can be changed simultaneously for all channels from the beiated entry box in the <i>FFT Setup Tab</i> , page 2-31.
	The formu	la for dB display for Unaveraged Spectrum, Averaged Spectrum, and FRF is: dB = 20 log (x/dBEUref)
	The formu	la for dB display for Autospectrum, Cross Spectrum, and PSD is: dB =10 log [x/((dBEUref)^2)]
Calibrator EU	This field	d is used to set the Calibrator's Engineering Units.
Measured mV	Displays	the measured value of the channel in milli-volts.
Transducer mV/EU	The Tran Highligh press the updated	sducer mV/EU value can be entered manually, or by the measurement process. t a cell, or cells, in the grid before typing a value in the data entry box. Then <ok> button to accept the value. All other fields linked to this value are when the value is accepted.</ok>
	mV/EU=	= Volts/Units * Transducer Gain
EU Offset	EU Offse the meas	et is used for DC signal compensation. Offset is added to, or subtracted from ured EU value.
Transducer Gain	Transduc gain. Ga	er Gain is used as auxiliary scaling to compensate for the transducer amplifier in is a multiplied function.

Calibration	This column displays the date and time of the last calibration. If any channel value
Date	changes, even if the original number is restored, the calibration date and time are
	automatically removed for that channel.

Start	Clicking this button starts the calibration process for all selected channels. At the
Calibration	completion of the calibration, the measured mV and the Transducer mV/EU value for
Measurement	the applicable channels are automatically updated.

## **Calibration Procedure, an Example**

Accelerometer type - Piezotronics 303A03 Calibrator - Piezotronics 394B05 - 1.02 G (RMS) at 80Hz Unit of acceleration - in/sec^2

**Note:** 1.02 G RMS is equivalent to 393.811 in/sec^2 (1G=386.089in/sec^2). This is a linear scale, thus we will be selecting Lin in the Calibrator Scale column.

In this example we will be calibrating channel 1.

- 1. Attach the accelerometer to the calibrator (signal source). Connect the other end of the accelerometer cable to the channel 1.
- 2. Set the FSV into a proper range (i.e. 32.4 mV) in the Input Channels Setup window, then click the <Apply> button.
- 3. Set the desired **blocksize** in the Analyzer Tab if a block size of greater than 4096 is desired.
- 4. Set the "No. of Averages" in the Analyzer Tab if an average count of greater than 5 is desired.
- 5. Open the Calibration Window from the Task Menu, or from the Input/Output Channels Tab.
- 6. Select "Single Channel."
- 7. Select "Auto Range," if desired.
- 8. Select a Calibration domain. In this case, either "Time" or "Frequency" can be selected.
- 9. Enter 80 Hz in the *Calibrator Frequency* field.
- 10. Ensure the radio button for *Channel 1* is **enabled** (in the Active column.)
- 11. Select **RMS** for the *Calibrator Type*.
- 12. Select Linear in the Calibrator Scale field.
- 13. Leave EU dB Reference set at 1.000. Note that this step can be skipped when linear scale is used.
- 14. Set *Calibrator EU* at 1.02; implying an engineering unit of 1G.
- 15. Enter 393.811 in the Transducer mv/EU field.
- 16. Leave the EU Offset at 0.0000. We are assuming no offset in this example.
- 17. Leave 1.000 as the Transducer Gain. No amplifier or attenuator is being used in our example.
- 18. Click <Apply> so your new values will not be lost.
- 19. Click the **<Start Calibration Measurement>** button to begin calibration.

# File Menu

The File Menu provides a means to print plotted data, as well as open, save, and export data files.

#### Open Time History Data (.thd or .dsc)

Used to locate and open saved files. ZonicBook uses files with .thd extensions. WaveBook uses files with .dsc extensions.

#### Save [or Open] Multiple Data Set (.mds)

These two menu items provide a means of saving [or opening] function files. Time and auto-spectrum data is saved. If there is any reference channel cross-spectrum is saved for all channel pairs. The file extension is **.mds**.

#### Save [or Recall] Hardware Setup (.set)

These two menu items provide a means of saving [or recalling] current settings and processing conditions. In addition, **.thd** files and **.mds** files can be used to recall setup conditions, because these file-types include setup conditions in addition to measured data. Note that only the setup condition is recalled.

#### Save [or Recall] Plot Setup (.pset)

These two menu items provide a means of saving [or recalling] the current plot condition, such as window locations and window content, including: channel numbers, function type, axis-type, and range. These files can be recalled at a later date to process customized plot conditions.

Without user intervention, the plot setup file is automatically saved with .mds, .dsc, and .thd files.



You can have plot setups automatically recalled whenever you recall data files. To select this option, open the Preferences window [accessed through the Edit pull-down menu] and check the box labeled "Recall Plot Setup When Recall Data Files."

#### Print

The standard print window associated with your specific computer will open. Select a printer and the number of copies needed before clicking <OK>.

Note: In regard to printing, black plot backgrounds changed to white.

#### Authorization\*

Opens an Authorization Dialog box that provides a means of entering an authorization code to enable the features of purchased software, i.e., *eZ-FrequencyView*, *eZ-TimeView*, or *eZ-Analyst*. The dialog box includes an option to run a 30-day trial version of eZ-Analyst.

\*For eZ-Analyst, "Authorization" is located in the Help pull-down menu as this document goes to print.

#### Exit

This menu item closes the *eZ-Analyst* application.



# Edit Menu

The Edit Menu provides a means of configuring *eZ-Analyst* in regard to both functionality and appearance. The menu contains the following selections, each of which is detailed in the subsequent sections:

Configuration Window..... 2-13 Input/Output Channels ..... 2-21 Playback Setup Window..... 2-37 Display Preferences Window..... 2-39

# Edit Menu > Configuration Window

The **Configuration** item provides a means of changing the majority of *eZ-Analyst* settings in regard to collecting data and in determining how the collected data is manipulated. The Configuration selection displays the **Configuration Window** with one of several tab dialogs displayed. Possible tab displays for both *eZ-Analyst* and the "view" programs are as follows:

Edit Menu > Configuration Window		
Tabs in <i>eZ-Analyst</i>	Corresponding Tabs of the "View" Programs	
Analyzer Tab 2-15	Acquisition Setup Tab	
Input/Output Channels Tab 2-21	Input Channels Tab	
Recording Setup Tab 2-25	n/a	
Block Rejection Tab2-29	n/a	
FFT Setup Tab2-31	Miscellaneous Tab Does not apply to <i>eZ-PostView</i> .	
Octave Setup Tab 2-35	Octave Setup Tab Does not apply to <i>eZ-PostView</i> . Does not apply to <i>eZ-TimeView</i> .	

# A Note Regarding Frequency Resolution

This note pertains to frequency resolution and is related to the values seen in the Analyzer Tab's Acquisiton Panel (next two figures). The frequency resolution is related to the Analysis Frequency (bandwidth) and the Blocksize (the number of data points in one block of data). The following equations apply.

Note: With other factors unchanged -

Increasing Blocksize increases Frequency Resolution.

The lower the "Delta X" frequency, the higher the

Frequency Resolution. Thus, a Delta X of 5 Hz indicates

a higher frequency resolution than does a Delta X of 80 Hz.

Increasing Analysis Frequency decreases Frequency Resolution.

w = b / 2.56f

Where: w = Frame Width b = Blocksize 2.56 is a constant f = Analysis Frequency

Delta X = 1/w

Where:

Delta X is the frequency resolution w = Frame Width the lower the Delta X, the higher the resolution.

With these equations we can see how the Frame Width and Delta X are calculated.



Higher frequency resolutions indicate that the signal trace will be based on more data points for a given time frame. The higher the frequency resolution, the smoother the trace will be.

# Edit Menu > Configuration >

# **Analyzer Tab**



Analyzer Tab

# Edit Menu > Configuration > Analyzer Tab: Acquisition Panel

The Acquisition Panel provides a means of setting Analysis Frequency and Blocksize. A note regarding the relationship of Analysis Frequency and Blocksize, to Frame Width and Delta X, is located on the preceding page.

**Analysis Frequency**: This section of the Acquisition Panel is used to set the maximum bandwidth for analysis. Frequency components above the Analysis Frequency setting will result in aliasing errors in the data. The bandwidth measurement can be set for Hertz (Hz) or Cycles Per Minute (CPM) by use of radio buttons. Note that the processing time for a selected blocksize is fixed by CPU speed.

Increasing the analysis frequency results in: (a) the hardware streaming packets of data more frequently to the software, (b) a greater demand placed on the software to process the data blocks, and (c) less time between data blocks available for task performance

**Blocksize**: This section of the Acquisition Panel is used to set the number of data points in a frame or block of data. Acceptable blocksizes range from 128 to 16384 data points.

Blocksize can be viewed as chunks, or packets of data, that move through *eZ-Analyst*'s software algorithms. As blocksize increases, the amount of data increases, the time required to acquire a block of data increases, and the amount of space required to save the data increases.

Effects of Ch	nanging Analysis F	requency or Blocks	ize (Note)	
Changing: Analysis Frequency	File Size (Recorded Data)	Block Acquisition-Time*	Data Displayed in Scope Mode	Frequency Resolution
Increase	Larger disk file	Faster	Faster screen updates	Lower (higher Delta X)
Decrease	Smaller disk file	Slower	Slower screen updates	Higher (lower Delta X)
Changing: Blocksize	File Size (Recorded Data)	Block Acquisition-Time*	Data Displayed in Scope Mode	Frequency Resolution
Increase	Larger disk file	Slower	Slower screen updates	Higher (lower Delta X)
Decrease	Smaller disk file	Faster	Faster screen updates	Lower (higher Delta X)

**Note:** The effects indicated by the table pertain to changing the Analysis Frequency while the Blocksize remains unchanged, and visa versa. If both the Analysis Frequency and the Blocksize are changed [for the same acquisition] the effect on the other variables can differ, depending on the magnitude and direction of change that was made to Analysis Frequency and Blocksize.

\*Block Acquisition-Time: The time it takes to acquire one block of data.

# Edit Menu > Configuration > Analyzer Tab: Trigger Panel

The Trigger Panel provides a means of setting and defining trigger-related parameters.

Triggering defines how *eZ-Analyst* is to begin the task of capturing and processing data.. To capture data without using a trigger, select *Free Run* from the pull-down list. To capture transient data, select *Input Channel* from the pull-down list [as indicated in the figure to the right] and specify the applicable parameters.



Trigger Panel on the Analyzer Tab

	A Breakdown of the Analyzer Tab's Trigger Panel
Category	Description
Туре	If " <b>Free Run</b> " is selected as the Type, the data acquisition and processing will begin as soon as the <acquire> button is clicked. Select "Free Run" if you want to measure data in a <i>continuous or Scope mode manner</i> [from an active system].</acquire>
	If " <b>Input Channel</b> " is selected as the Type, the data acquisition and processing begin after the signal on the specified channel reaches the defined trigger conditions. Select "Input Channel" if you want to capture transient data.
Channel No.	Specifies the channel that the trigger condition applies to.
Level	This value is the point that the signal must pass through to be considered as a candidate for a trigger. When using a ZonicBook this value is entered as a percentage of FSV. When using the WaveBook this value is entered as volts and must be within the select FSV.
Slope	The slope radio buttons are used to selects the " <b>Positive</b> " increasing (rising), or "Negative" decreasing (falling) slope of the signal that defines a trigger condition. The signal must be on the defined slope before it can be considered for use as a trigger
Delay	Selecting the " <b>Pre-Trigger</b> " radio button instructs the system to <b>capture</b> a specified percentage of data [a specified percent of the frame size] <b>prior</b> to the <i>start of trigger event</i> . In the previous figure we see that "Pre Trigger" is selected for 10.00 (%).
	Selecting the <b>"Trigger Delay"</b> radio button instructs the system to <b>skip</b> a specified percentage of data [a specified percent of the frame size] <b>after</b> the <i>start of trigger event</i> . If we selected "Trigger Delay" and entered 10.00 in the percent box, we would see 10% of the data skipped, in relation to frame size.
Beep Sound	If desired, check a box so a "beep" will sound when the <i>Trigger is Ready</i> , or when the system has <i>Triggered</i> . If rapid triggering/acquiring data events are taking place in succession, then the beep sound may become erratic.



Select *Free Run* from the Analyzer Tab's Trigger Panel if you want to measure data in a *continuous or Scope mode manner* [from an active system].

To capture transient data, go to the Configuration dialog found under the Edit menu and on the Analyzer tab select *Input Channel* and specify the applicable channel and conditions.



Trigger-related items [in the *Analyzer Tab* or *Recording Setup Tab*] being locked-out indicates that the current mode is for *playback operation*. If so, perform the following:

- (1) close the Configuration Window
- (2) select "Measurement Mode" from the Task pull-down menu
- (3) open the Configuration window

## **Capturing Transient Data**

Setting *eZ-Analyst* to trigger on an Input Channel captures transient data when the associated parameters are correctly specified. The following sections discuss the associate parameter and how they apply to a signal such as an impact hammer striking an object. The signal show is from an accelerometer located in the hammer's head.

#### Set Trigger level:

The first and most important parameter is the trigger level. This parameter specifies the level in which the signal must pass through in order for an acquisition process to begin. An ideal level will assure that the signal is well above any noise or erroneous movement that will cause a trigger. An ideal level will also assure that the level is not above the maximum output of the signal source. Violating these ideal conditions can result in either a premature trigger or no triggering at all. For example, if a signal has a noise floor of 0.5 volts and the trigger level is set to 0.2 volts the acquisition will always trigger for obvious reasons. Conversely, if the maximum signal output is 5.0 volts and the trigger is set to 5.5 volts the acquisition will never trigger.



#### Shifting a Waveform with Pre-Trigger and Trigger Delay

#### (A) Setting Signal Position

Once an acceptable trigger level has been ascertained, positioning the signal within a block of sampled data (and in the display window) is the next consideration. Often it is necessary to capture the events that lead up to the trigger point. If this is the situation then positioning should be set for Pre-trigger capturing. On the other hand, if the signal of interest occurs after the trigger point, then positioning should be set for Trigger-Delay capturing.

#### (B) Normal Trigger

Normal Triggering is obtained by specifying zero for the Pre-Trigger and zero for the Trigger Delay; where the trigger point occurs at the first sample point as pictured in the figure to the left.

## (C) Pre-Triggering

To capture information before the trigger point, select Pre-Trigger and specify a percentage of the blocksize (see note). For example, if the blocksize was set at 1024 samples, then setting the Pre-Trigger to 10% would result in capturing 102 sample points that exist prior to the trigger point. This has the effect of shifting the waveform to the right as pictured in the figure.

## (D) Trigger Delay

Trigger Delay is the opposite of Pre-Trigger. The Delay causes *eZ-Analyst* to wait "n%" samples before it begins filling a block of data. This has the effect of shifting the signal to the left.

**Note:** For **ZonicBook** applications, the trigger level is specified in **percentage** of full-scale voltage (FSV). For **WaveBook** applications, the trigger level is an **absolute signal level** that must be within the physical input range (also FSV).



#### **Reference Notes:**

The following sections of this document contain information that closely relates to the subject of Capturing Transient Data. Reading over the following material should improve your understanding of the important concepts involved.

- ➤ Capturing Transient Data, page 2-17.
- ➤ Block Rejection Tab, page 2-29.
- > Considerations Regarding Double Hammer Rejection, page 2-30.
- ➤ *Recording Setup*, page 2-25.

# Edit Menu > Configuration > Analyzer Tab: Averaging Panel

The Averaging Panel is used to select the type of averaging that will be calculated during data acquisition.



- To apply averaging to time-demand data, the Function View Window must be changed to a Windowed "Time Function," otherwise all averaging will be applied to a spectral date.
- > Averaging can be used to decrease the noise in a measurement.

In the figure to the right, the first scenario shows the pull-down menu expanded, revealing the types of averaging that can be selected. The second scenario shows that "Exponential" has been selected. Exponential makes use of a Weighting Factor, which is not used by the other averaging types.

Exponential	Exponential 🗾 💌
None	
Linear(+) 5	No. of Average: 5
Exponential Dook Hold	
Linear(-)	Weighting Factor: .05
Time Sync.	
- Continuous	- Continuous
Measurement	Measurement

Averaging Panel of Analyzer Tab (2 Scenarios)

A brief description of averaging types and other panel terms now follows.

Linear (+): All blocks of data are treated equally in terms of their effect on the averaged result.

**Exponential**: Similar to linear averaging, Exponential requires a weighting factor that either increases or decreases the effect of each new data block on the resultant average.

Weighting Factor: The Weighting Factor either increases or decreases the effect of each new data block on the resultant average when Exponential Averaging is used.

#### New Average = ((New Data) \* A.W.F.) + (Old Average \* (1-A.W.F))

**Peak Hold**: The resultant block of data is a collection of points that represent the peak amplitude for each point in the block. With each new block of data, the current data is compared with the new data on a point by point basis. The highest amplitude for each point in the block is retained.

Linear (-): Also known as Negative Averaging; Linear (-) Averaging is a technique used to identify the natural frequencies of in-service machines that cannot be shut down for analysis. Linear (-) Averaging is a two step process. First, a reference average is acquired. Second, a normal linear average is acquired for each frame. The running average is subtracted from the reference average and the result is displayed. The first time you attempt to start data acquisition after you select Linear (-) averaging, the Negative Averaging Setup/ Measurement window opens.

**Time Sync**: Time synchronous averaging uses a keyway, or a similar point of reference, as a trigger. The blocksize is set to allow enough time for at least one full revolution. This must be performed in Scope Mode. Channel trigger mode should be used in conjunction with this selection.

**Number of Averages**: This number specifies the condition for terminating a data acquisition sample. After the number of averages (blocks/frames of data) have been captured and averaged, the *eZ-Analyst* will automatically stop taking new data. This sample can then be saved. If the number of averages is set to zero, acquisition is continuous and must be halted by the user.

**Continuous Measurement**: Checking this option restarts the *averaging process* without user intervention. Note that the data itself is not continuous between measurements. This option is not meaningful for *non-averaging* operations. The section entitled *Measurement Panel*, on page 2-46, contains additional information.



## **Reference Notes**:

The following sections of this document contain information that closely relates to the subject of Averaging. Reading over the following material should improve your understanding of the important concepts involved.

- ➤ Capturing Transient Data, page 2-17.
- ➤ Block Rejection Tab, page 2-29.
- > Considerations Regarding Double Hammer Rejection, page 2-30.
- ➤ Recording Setup, page 2-25.



# Edit Menu > Configuration >

# Input / Output Channels Tab

The Input/Output Channels panel displays the current setup conditions of the input channels on a channel-bychannel basis. Changes are accepted as soon as they are *applied* or *okayed*. In addition, the Input/Output Channels Tab provides a means of configuring outputs for ZonicBook and WaveBook applications.

#### The "Output" aspect of the tab only applies to eZ-Analyst.



When using WaveBook hardware, *eZ-Analyst* supports up to 64 channels of input. If your WaveBook's hardware configuration has more than 64 channels, *eZ-Analyst* will display an error message, then go to into the Playback mode. If you wish to run in the Measurement mode you will have to reduce the channel count by removing expansion modules. To remove the extra expansion modules you must physically disconnect them from the WaveBook.

		Block	Rejection	ĭ	0	ctave Setup		ľ		FFT Set	qu	
		Anal	yzer	ĭ	Input / Output Channels			Recording Setup				
put Cha	nnel	s										
Option	No.	Active	Label	Channel Type	Response Reference	FSV	EU Mode	mV/EU	EU Offset	Units	Location	Coorc
More	1	1	Channel01	Direct	Response	-5.0 to 5.0V	EU	100.0	0.0000	V	1	X+
More	2		Channel01	Direct	Response	-5.0 to 5.0V	EU	100.0	0.0000	V	2	X+
More	3		Channel01	Direct	Response	-5.0 to 5.0V	EU	100.0	0.0000	V	3	X+
More	4		Channel01	Direct	Response	-5.0 to 5.0V	EU	100.0	0.0000	V	4	X+
More	5		Channel01	Direct	Response	-5.0 to 5.0V	EU	100.0	0.0000	V	5	X+
More	6		Channel01	Direct	Response	-5.0 to 5.0V	EU	100.0	0.0000	V	6	X+
More	7		Channel01	Direct	Response	-5.0 to 5.0V	EU	100.0	0.0000	V	7	X+
More	8		Channel01	Direct	Response	-5.0 to 5.0V	EU	100.0	0.0000	V	8	X+
More	9		Port 0	WaveBookDirect	Response	N/A	EU	100.0	0.0000	g's	9	X+ 🚬
	4											•

Input / Output Channels Tab Selected – WaveBook Application\*

\*Note: For a screen image of ZonicBook's Input/Output Channels Tab, see page 2-23.

- **No.**: This column lists all available channels.
- Active: Initially all input channels are active. Set unused channels to OFF by removing the check from the "Active" column's checkbox.
- Label: This should be a meaningful name that you assign to the signal received on a channel. The channel number is automatically assigned. Highlight a cell before typing a label. When you press the Enter key, the value is accepted.

Channel<br/>Type<br/>(WaveBook Only)This column applies to WaveBook systems. It does not apply to ZonicBook applications.<br/>The column consists of a fixed label, which indicates each channel's parent hardware. Main<br/>unit channels, i.e., those that connect directly to a WaveBook [as opposed to an expansion<br/>module] are denoted by the label, "Direct". Channel Type can not be edited.

- ResponseThere are two types of channels, Response and Reference. All channels are initialized asReferenceResponse channels. If you are using a force channel, then (1) highlight that channel's<br/>Response/Reference cell, and (2) select Reference on the resulting popup menu.
- FSV: Full-Scale Voltage. The cells in this column are used to set the FSV value in Volts.
- EU Mode: E(ngineering) U(nits): Select EU or Volt.



**Reference Note**: Gain and offset adjustments are made from the *Calibration display screen*, see page 2-7. The following parameters apply:

- mV/EU to set the scaling factor of millivolts to Engineering Units.
- EU Offset to set the offset factor that is to be applied to the Engineering Units.
- **dB EU Ref**: is applied to displayed data when the Y-axis scale is set to dB. This is valid only for frequency domain data.

Units:	Enter the measurement units you will be using.
Location:	This is a simple numbering system. The channel number is the default value for location. However, you can highlight a cell and type a different location number. When you press the Enter key, the value is accepted.
Coord:	This is the axial direction of the transducer connected to the channel. Make your selection on the popup menu that appears after clicking in the applicable cell.
Input Type:	This is the type of instrument attached to the channel. Menu selections include: Acceleration, Velocity, Displacement, Force, Pressure, Stress, Strain, General, and Tach (Tachometer). The later is detailed in the following sub-section, entitled, <i>Tach Channel</i> <i>Setup</i> .

# **Tach Channel Setup**

Tach Channels are selected by changing the **Input Type** to "**Tach**" on the Input/Output Channels tab. Once the Tach Channel type is selected, columns are enabled for Pulses per Revolution, Trigger Level, Trigger Slope, and Conversion. The table below explains each tachometer-related property that is displayed by the Input/Output Channels tab.

Locat	tion Coor	d Input Type
1	X+	Tach 💌
2	X+	Velocity
3	X+	Force
4	X+	Pressure
5	X+	Strain
6	X+	General
7	X+	Acceleration

Selecting Tach Channel Setup

Tachometer P	roperties
Tach- Pulse/Rev	Displays the number of pulses per revolution.
Tach- Trigger Level	Specifies the pulse level that the RPM algorithm considers valid.
Tach- Trigger Slope	Specifies whether counting is <i>active on rising</i> signal levels, or <i>active on falling</i> signal levels.
Tach- Conversion	This column is used for entering a <i>tachometer-conversion</i> value for converting RPM into other units. For example, you can enter a value to convert RPM to Miles per Hour, Revolutions Per Second, or HZ. The desired conversion factor is entered as a multiplier. To divide, you would simply enter an appropriate decimal, e.g., to divide by 2 you would enter a value of 0.5.

#### **ZonicBook Applications**



**Reference Note**: This section only pertains to ZonicBook applications. For WaveBook applications refer to page 2-24.

In regard to ZonicBook, the Internal Signal Generator is set up in the Output Channel panel. The output waveform (Sine, Random, or Sine+Random) is selected from the pull-down menu (see figure).

		Block Reject	tion	ľ	Oc	tave Setup		Ť			FFT Setup
		Analyzer		, I	nput / Out	put Cha	nneis			Reco	rding Setup
put C	hannels										
No.	Active	Label	Response Reference	FSV	EU Mode	mV/EU	EU Offset	Units	Location	Coord	Input Type
1	•	Channel 1	Response	20.00	Volt	200.0	0.0000	mils	1	X+	Displacement
2	•	Channel 2	Response	20.00	Volt	200.0	0.0000	mils	2	X+	Displacement
3	V	Channel 3	Response	20.00	Vott	100.0	0.0000	g's	3	X+	Acceleration
4	2	Channel 4	Response	20.00	Volt	100.0	0.0000	g's	4	X+	Acceleration
5	2	Channel 5	Response	20.00	Vott	100.0	0.0000	g's	5	X+	Acceleration
6	<b>v</b>	Channel 6	Response	20.00	Volt	1000.	0.0000	Volts	6	X+	Acceleration
7	•	Channel 7	Response	20.00	Volt	1000.	0.0000	Volts	7	X+	Acceleration
8	•	Channel 8	Response	20.00	Volt	1000.	0.0000	Volts	8	X+	Acceleration

Input / Output Channels Tab – ZonicBook Applications

Output Wave Type	Text Box Entries (see figure)				
Sine Waveform	<b>Amplitude:</b> The maximum amplitude range is 1.4 volts zero-to-peak. The value is typed in the text-box. The units are volts.				
	<b>Frequency:</b> This is the frequency, in Hz, of a sine waveform. The maximum value is 2000 Hz. The value is typed in the text-box.				
Random Waveform	<b>Amplitude</b> : This is the amplitude variance for the Random output signal. The maximum value is 1.4 volts zero-to-peak. The value is typed in the text-box. The units are volts.				
Sine + Random	Displays text box areas for the Sine Waveform and Random Waveform signal types just described.				



The signal output option is only valid when the analysis frequency is less than, or equal to, 4000Hz. Thus, whenever analysis frequency is set above 4000Hz, the signal generator button is disabled.

#### WaveBook Applications

In regard to WaveBook applications, Analog Output is only supported when *eZ-Analyst* detects a WBK14 expansion unit, and only one output is available from each WBK14. The Excitation Source can be for either Random or Sine wave output. Instead of an Output Channel Tab, as seen in the previous figure, *eZ-Analyst* brings up a Output Channel Setup box similar to that shown in the following figure.

H	Active	Signal Type	Frequency(Hz)	Amplitude(V) 0 to Peak	Offset(V)
	V	Random	100.0	0.8000	1.5000
2	Γ	Random 💌	20.00	0.0000	0.0000
}	Г	Random 💌	20.00	0.0000	0.0000
	Г	Random 💌	20.00	0.0000	0.0000

**Output Channel Setup** 

Channel 1 selected as an active output channel.

WaveBook applications Only. The figure does not apply to ZonicBook applications.

Setup Category	Description (see figures)
СН	Identifies the output channel. These numbers are a fixed part of the screen image and can not be changed by the user.
Active	Place a check in the "Active" box for each applicable output channel. In the above example, only Channel 1 is "Active."
Signal Type	<b>Frequency (Hz)</b> : This is the frequency, in Hz, for a Sine waveform. The maximum value is 100000 Hz (100 kHz).
Sine	<b>Amplitude (V) 0 to Peak</b> : This is the amplitude for the Sine waveform output signal. The maximum value is <b>5.00 volts zero-to-peak</b> .
	<b>Offset (V)</b> : This is the DC offset voltage that is applied to the output signal. The maximum value is $\pm 5.0$ volts.
Signal Type	<b>Frequency (Hz)</b> : This is the frequency, in Hz, for a Sine waveform. The maximum value is 100000 Hz (100 kHz).
Random	<b>Amplitude (V) 0 to Peak</b> : This is the amplitude for the Random output signal. The maximum value is <b>0.85 volts zero-to-peak</b> .
	<b>Offset (V)</b> : This is the DC offset voltage that is applied to the output signal. The maximum value is ±5.0 volts.

## Edit Menu > Configuration >



**Recording Setup Tab** 

## Edit Menu > Configuration > Recording Setup Tab: Start Recording Panel

Provide a means of setting the following parameters that pertain directly to the start condition. Note that the Start Recording panel is not available for WaveBook applications.

**PreAcq-Trigger** – select this function to include [with the recording] data that precedes the trigger event by the set number of seconds.

**PostAcq-Trigger** – select this function to exclude [from the recording] data that follows the trigger event by the set number of seconds.

Note: You can not set a Start Delay for the start recording if PreAcq-Trigger is selected, and visa versa.

**Enable Start Trigger** – if the checkbox is checked, *amplitude-based data* can be set as a PreAcq-Trigger condition to Start Recording. The following options are provided.



**Understanding Total Measured Data** 

In this figure, the Start Recording panel's PreAcq-Trigger data and the Stop Recording Panel's Trigger Delay data are both saved as part of the total measured data.

# Edit Menu > Configuration > Recording Setup Tab: Stop Recording Panel

Provide a means of setting the following parameters that pertain directly to stop recording:

**Recording Duration** sets a "time-out" option, for which the recording event is not to exceed. If an acquisition has been triggered, the measurement will run until either (a) the amplitude-based Enable Stop Trigger Condition is met, or (b) the Recording Duration is met, whichever occurs first. When the Recording Duration value is met, the recording event is aborted.

Note: Entering a value of "0" in the Recording Duration block sets the duration to infinity.

**Enable Stop Trigger** – if the checkbox is checked, *amplitude-based data* can be set as a **stop condition** for the recording. The following options are provided.



**Delay (sec)** – this function is used to include [with the recording] data that follows the stop trigger event by the set number of seconds, as specified by the delay.



Maximum Duration Limit Terminating a Measurement



Understanding Total Measured Data

In this figure, the Start Recording's PreAcq-Trigger data and the Stop Recording's Delay data are both saved as part of the total measured data.

# Edit Menu > Configuration > Recording Setup Tab: Scheduled Recording Panel

The Scheduled Recording panel includes a checkbox to enable the "scheduled recording" function. It also includes three text fields (see following figure). The panel provides a means of setting time conditions for starting and stopping a recording. dT is the delay time in seconds.

- Enable Sched	ule Start Date / Time	End Date / Time	dT (sec)
Recording			

Scheduled Recording Panel



- When using Scheduled Recording, you need to set up the recording options for automatic .thd file creation. This is done in the Recording Setup Tab's "File Name Options" panel, discussed below.
- When using WaveBook hardware, features of the Start Recording panel are not available.

# Edit Menu > Configuration > Recording Setup Tab: File Name Options

	Browse
🥅 File Name Prompt	🔽 Auto Increase
Measurement Prompt	Number

#### File Name Options Panel

When using the Scheduled Recording feature the following steps should be taken to ensure that each file will be automatically named by the program.

From the File Name Options panel, at the upper left of the Recording Setup Tab, verify that the following is true. Make changes if needed.

- File Name Prompt Not Checked
- Measurement Prompt Not Checked
- Auto Increase Checked
- Date/Time Select the "Date/Time" radio-button if you want the Filenames to automatically increase by a Date/Time convention, otherwise select "Number."
- Number Select the "Number" radio-button if you want the Filenames to automatically increase by a numerical sequence (1, 2, 3, ....N) convention, otherwise select "Date/Time."



An Example of Filename Auto-Incrementing by Number

# Edit Menu > Configuration > Recording Setup Tab: Comments Panel

The comments panel can be used to enter a variety of information regarding the recording. For example, you may want to include the environmental conditions that existed at the time of the recording, the phase of the project, or a problem that is being investigated. Note that the comments are saved as part of the data file.

# Edit Menu > Configuration > Block Rejection Tab eZ-Analyst Only

The Block Rejection Tab exists to allow the software (or user) to reject blocks of data that result from hammer double strikes, overloads, or simply because the data block "doesn't look right." There are three block rejection modes: **Double Hammer** protects measurements against double hammering. **Overload** protects the measurement by automatically rejecting overloaded data, and **Manual** allows you to inspect a measurement and optionally reject it. You can select any or all of the rejection modes. Also see: *Considerations Regarding Double Hammer Rejection*, page 2-30.

# Note: The Block Rejection panel is only active when "Measurement Mode" is selected from the Task menu.

Analyzer	Input / Output Channels	Recording Setup
Block Rejection	Octave Setup	FFT Setup
	Node ble Hammer Rejection Setup Axis Limits (% of Blocksize) Y Axis Limits (% 5.000 15.00 -5.000 5	of FS) 5.000

**Block Rejection Tab** 

Block rejection looks at the acceptable parameters for a block, and rejects blocks that do not meet those parameters.

- DoubleA double hammer occurs when a signal goes outside of the acceptable range that is set up inHammer:the Hammer Rejection section. Click in the Double Hammer box to turn the Double<br/>Hammer option ON and OFF. When the box is checked, the option is ON.
- **Overload**: An overload is any input signal that reaches or exceeds the specified input Full Scale range. Click in the Overload box to turn the Overload Rejection option ON and OFF. When the box is checked, the option is ON.
- Manual:This option allows you to review each block of data before acquiring the next block. When<br/>manual rejection is selected, a  $\langle Reject? \rangle$  button is activated in the main window. At the<br/>end of each average, if you want to reject that measurement, click on the  $\langle Reject? \rangle$  button.<br/>eZ-Analyst will then reject the current frame of data. The data and average counter will go<br/>back to the previous measurement. Click in the Manual box to turn the Manual option ON<br/>or OFF. When the box is checked, the option is ON.



Block Rejection is used in conjunction with *Capturing Transient Data* (Input Channel triggering) and *Averaging*. These topics are discussed on pages 2-17 and 2-18, respectively.

# Edit Menu > Configuration > Block Rejection Tab: <u>Hammer Rejection Panel</u>

This panel is used to define the acceptable range for a hammer signal. Any signal outside of the defined range is detected as a *double hammer*. The acceptable range will appear as a rectangle whose boundaries are defined by high and low limits for the blocksize, and by high and low limits for scale. Respectively, these are x- and y- axis limits.

**X-axis Limits (% of blocksize)**: Used to set a Low point and a High point along the x-axis, for which the hammer impact must occur to be acceptable. An example setting is 5% to 15% (of blocksize).

**Y-axis Limits (% of F(ull) S(cale)**: Used to set a Low point and a High point along the y-axis, for which the hammer impact must occur to be acceptable. An example is -5.000 to + 5.000 (% of Full Scale).

#### **Considerations Regarding Double Hammer Rejection**

There are three major interrelated components to consider when setting up a double-hammer rejection condition. These are:

- Trigger Mode and Delay
- Force Window
- Double Hammer Region

A trigger is used to ensure time synchronous measurements across all the active channels.

As indicated in the *Trigger Panel* section of this document (beginning on page 2-16), a **pre-trigger** indicates that data captured before a trigger event [the amount of which is specified by the delay] will be prefixed to the data following the trigger event. Also, a **trigger delay** [in reference to the Start Trigger Condition] indicates that a specified amount of data after the start trigger [the amount of which is specified by the delay] will be skipped (ignored) before a block of data is captured.

**Double hammer reject is only meaningful with the pre-trigger specified**. Double hammer rejection protects the measurement from a bad hammering.

It is desirable to set the pre-trigger to fall within the hammer region, since it is a common practice to set the trigger channel to an impact channel.

#### Example

In this example, a test engineer is looking for a trigger event that occurs somewhere after 10% of the data block, but before 15% of the block. Therefor:

- (1) Pre-Trigger is set for 10% Delay, using the Trigger Panel (on the Analyzer Tab).
- (2) A Rectangular Force Window is selected and set for a Start point of 9% and a Stop point of 15%. This is done in the FFT Setup Tab's *FFT Window (Reference) Panel*. Page 2-32 contains additional information.



When impact testing we want to make sure that a double hammer does not occur. Through trial and error we may start by setting the Double Hammer range at 12% and 14%, or 11% and 13% of the block. Typically this range is fine tuned using sample acquisitions prior to starting a real test.

# Edit Menu > Configuration > FFT Setup Tab Applies to eZ-Analyst & eZ-FrequencyView\*

Ar	halyzer		Input / Output Channels		Recording Setup		
Block F	Rejection	<u> </u>	Octave Set	di di	FFT Setup		
FT Window Funtio	ns			-Bank(Lo	cation) Control		
Response Chnis	Reference Chnis	Start (%)	Stop (%)	- Auto	Auto Bank Increase with		
Hanning	Rectangular	5.000	15.00	Auto	matic Saving Data		
FFT Integration				Resp     C Refe	oonse Increase		
Unit Conversion HPF Int1 (Hz)		z) HPF Int2	?(Hz)				
g's-ips-mils	5.	000	20.00				
fach Channel Setur	o ————			Low Fre	quency Cutoff		
Channel Labe	el Pulse/Rev	Trig Level	Trig Slope Tach Cor		(Hz) <ul> <li>Skip Data</li> <li>Zero Data</li> </ul>		
				dB Refe	rence(Volt) volt for 0 dbV		

#### FFT Setup Tab\*

\*<u>eZ-FrequencyView User's</u>: The associated tab in eZ-FrequencyView is labeled "Miscellaneous" and the layout differs. Appendix C includes a screen shot of the Miscellaneous tab.

# Edit Menu > Configuration > FFT Setup Tab: FFT Window Functions / Response Channels

The FFT (Response) window is a time-domain, weighting window. A response window is usually applied to data to reduce FFT leakage errors. FFT theory assumes that the signal being analyzed is periodic in the data acquisition block. When this is not the case, energy from a signal at a specified frequency can leak into nearby spectral bins causing spectral amplitude inaccuracies. Applying a windowing function controls, but doesn't completely eliminate, the error by multiplying each data frame by a suitable time-domain weighting window. This calculation reduces the amplitude/magnitude of the data near the ends of each data frame prior to performing the FFT and forces the data to be nearly periodic in the window, thus reducing leakage errors. Response window options are as follows:

Response Chnis	Referen	nce Chrils S	tart (%)	Stop (%)
Exponential 💌	Rectang	gular	5.000	15.00
None Hanning Flat Top				
Exponential Bloken Horrio	ł	HPF Int1 (Hz)	HPF Int2	(Hz)
d's-ins-mils		5.000		20.00

FFT Window Functions, Response Channels Pull-down List

None:	No weighting window is applied.
Hanning:	The Hanning window is typically used to analyze continuous signals. It offers a reasonable trade-off of frequency accuracy versus amplitude accuracy.
FlatTop:	Compared to the very similar 4-term "Max Flat Top," this window also has a very low peak amplitude error, and its frequency resolution is somewhat better. Its side lobes are considerably higher. Its effective noise bandwidth is still almost twice that of the Hanning window, therefore this window is used mainly to measure accurate peak amplitudes of discrete spectral components that are known to be separated by several spectral lines.
Blackman- Harris:	This window function was designed to provide the minimum side lobe level of any three- term window. Compared with the very similar Hanning window, it has a slightly wider main lobe but much better dynamic range. This window has the smallest 60 dB bandwidth of any window listed. The Blackman-Harris window may be preferred over the Hanning for measurements requiring better dynamic range.

- **Exponential**: An exponential weighting window is equal to 1.0 at the beginning of the block and decays exponentially to a smaller value at the end of the block. Exponential is used only with transient data that is captured with pre-trigger to assure that the initial values in all data channels are very close to zero. Exponential can be used with all transient excitation methods in order to force the signals to decay close to zero, (See Response Decay Percent,) even if the block length is not sufficient to capture all of the naturally occurring response. If the data decays naturally to a low amplitude within the block, so that leakage is not significant, exponential windowing can improve the signal-to-noise ratio by giving reduced weight to the very low-amplitude data at the end of the block.
- **Decay %**: Decay Percent is used when an Exponential Window is applied to the Response Channel. It is the weighting factor present at the last block value. For example, a decay of 5% means that the weighting factor at the beginning of block is 100% and that the weighting factor of the last block is 5%. In other words, the weighting factor dropped (decayed) to 5% through the length of block.

# Edit Menu > Configuration > FFT Setup Tab: FFT Window Functions / Reference Channels

The FFT Reference Window is applied to the output of a transducer to avoid collecting extraneous signals caused by an excitation device, such as an impulse hammer. Possible selections are: Response, Rectangular, and Cosine Taper.

When **Rectangular** is selected, specify the Start(%) and End(%) of the rectangle as a percentage of the Frame Period.

When **Cosine Taper** is selected, specify the Start(%), End(%), and Edge(%) the Cosine Taper as a percentage of the Frame Period.

Response Chnis	Reference Ch	inls	Start (%)	Stop (%)	Edge (%)
Hanning	Response	•	5.000	15.00	3.000
FFT Integration —	Response Rectangular				
i i i i i i ogi dillori i	Cosine Taper				

FFT Window Functions, Reference Channels Pull-Down List

- **Start (%)**: The percent of the Frame Period at which the Rectangular and Cosine Taper Windowing functions start.
- **Stop (%)**: The percent of the Frame Period at which the Rectangular and Cosine Tape Windowing functions stop.
- Edge (%):This is the percent of the Frame Period during which the<br/>Cosine Taper Windowing function tapers up and down.

# Edit Menu > Configuration > FFT Setup Tab: Integration Panel / Unit Conversion



Integration Panel – 2 Views

The left-hand view is with the scrollbar up, the right-hand view is with the scrollbar down.

**Integration**: Provides the means to select an integration, such as **g's-ips-mils** or **g's-ips-in**. Several other possibilities exist, as can be seen in the above images of the Integration Panel.

## Edit Menu > Configuration > FFT Setup Tab: Integration Panel / HPF Int1 and Int2\*

The High Pass Filter Integration 1 (HPF Int1) and Integration 2 (HPF Int2) are used to remove the low frequency effects of integration. All data points that exist below the specified value are set to zero. When "Hz" is selected for the Acquisition Analysis Frequency via radio button on the Analyzer Tab, "Hz" is selected for the Acquisition Analysis Frequency via radio button on the Analyzer Tab, "CPM" is selected for the Acquisition Analysis Frequency via radio button on the Analyzer Tab, "CPM" appears as the HPF units.

\*<u>eZ-FrequencyView Users</u>: In eZ-FrequencyView, the associated panel is in the Miscellaneous Tab and appears in a "Low Frequency Cutoff" panel within an Integration panel. HPF Int1 is referred to as "Single" for single-integration and HPF Int2 is referred to as "Double" for double-integration. See Appendix C.

Unit Conversion	HPF Int1 (Hz)	HPF Int2 (Hz)
a's-ips-mils	5.000	20.00

Low Frequency Cutoff Panel – 2 Views

HPF Int1 (Hz):	Enter a value for the cutoff amount for the first integration.
HPF Int2 (Hz):	Enter a value for the cutoff amount for the second integration.

# Edit Menu > Configuration > FFT Setup Tab: Bank (Location) Panel

## Bank Location does not apply to eZ-PostView or to eZ-TimeView.

This panel relates to the Modal Locations window, which is accessed from *eZ-Analyst* Window's pull-down menu. The Bank (Location) Control Panel contains one check box and two radio buttons. Descriptions of each follow.



Bank (Location) Control Panel

Note: This option is only effective when the averaging mode is used.

Auto Bank Increase with Automatic Saving Data:	A Bank is a set of response channels. You can have <i>eZ-Analyst</i> increment the banks automatically after each measurement, or you can manually increment the banks. The number of active channels is used as the skip factor for bank switching.
	If the Auto Bank Increase checkbox is checked, then the bank is automatically incremented, but only when the automatic saving data option is selected at Setup Export Function Data menu.
<b>Response Increase</b> :	If the <i>Response Increase</i> radio-button is selected, the reference channel's location doesn't change. The response's location(s) are increased [or decreased] for next available location numbers.
Reference Increase:	If the <i>Reference Increase</i> radio-button is selected, the response channel's location doesn't change. The reference's location(s) are increased [or decreased] for next available location numbers.

**Note**: Decreasing location numbers are only available with the manual bank <Down> button on the Modal Locations window. Modal Locations is accessed from *eZ-Analyst* Windows pull-down menu.

# Edit Menu > Configuration > FFT Setup Tab: <u>dB Reference (Volt) Panel</u>

# dBReference (Volt) does not apply to eZ-PostView or to eZ-TimeView.

dBReference (Volt) is applied to all channels of displayed data when the Y-axis scale is set to dB and EU/Volt mode set to Volt. This is valid only for frequency domain data.

	Lunk Key O alles
200	Volt for U db

dB Reference (Volt) Panel

Reference Note: The dB EU Reference Volt *column* is located in the Input/Output Channels Tab.



Analyzer	Input / Output Chann	els	Re	ecording Setup
Block Rejection	Octave Setup	Ľ	F	FT Setup
Processing Mode		Filter		
Single Band C Dua	Band (Buffered Measurement)	Weighting	None (LIN)	
Low Band Range(Hz)	5 <b>F</b> 1000 <b>F</b>	Filter:	Analog 💌	
High Band Range (Hz) 5	00 🔽 16000 💌	Bar Type —		_
		C Line		
		C Solid		

Octave Setup Tab

# Edit Menu > Configuration > Octave Setup Tab: Processing Mode Panel

Single Band:	Single Band is the conventional mode, and as the name suggests, is used for single band processing. When Single Band is selected, lower and upper limits can be set for the High Band Range only.
Dual Band (Buffered Measurement):	Dual Band, also referred to as "Buffered Measurement," provides for octave band processing with a wide band limit for a lower frequency range. This mode uses buffer memory for processing the lower frequency limit. Dual Band uses 32 block sizes; thus making it possible for <i>eZ-Analyst</i> to simultaneously process 32 "time segments" of the lower frequency range.
	ck
One block to be proc High Band.	essed for
	20 kHz
	1 Block Processed for High Band
1st Bio 32 blocks to be proc Low Band.	essed for $20 \text{ kHz} / 32 = 625 \text{ Hz}$

32 Blocks Processed for Low Band



Octave Band Plot from Dual Band Processing

Dual Band processing provides the following benefits:

- A wider range of octave band data with no increase in block size.
- A much wider range of data, in comparison to the data from the Single Band mode.
- The use of buffered data means that High Band and Low Band data can be captured simultaneously.
- When compared to Single Band, the Dual Band processing mode produces more stable, precise data, at a lower range of frequency.

## Edit Menu > Configuration > Octave Setup Tab: Filter Panel

Weighting:	Provides the means to select one of four weighting possibilities: None (LIN), A, B, or C
Filter:	Provides the means to select Analog Filter or Digital Filter.

# Edit Menu > Configuration > Octave Setup Tab: Bar Type Panel

Line:	Selecting "Line" sets the Octave Plot to appear in line format.
Solid:	Selecting "Solid" sets the Octave Plot to appear filled-in solid, as opposed to a line plot.

# Edit Menu >

# **Playback Setup Window**

a appearant o o a op		<u></u>
Source Information		
Filename:	C:\Program	
Files\eZAnalyst\eZAna	lyst.thd	
Active Channels:	8	
Analysis Freq (Hz):	1000	
Blocksize:	2048	
Blocks Recorded:	12	
Recorded Time (Sec):	9.6	
Comments: Test file for eZ-An	nalayst Program	
Playback Mode	-	
Playback Mode Anal. Freq: 1000	×	
Playback Mode Anal. Freq: 1000 Blocksize: 2048		
Playback Mode Anal. Freq: 1000 Blocksize: 2048 Play Speed: C No delay		200

**Playback Setup Window** 

# Edit Menu > Playback Setup Window: Source Information Panel

Provides general file related information such as filename, file location, the number of active channels, analysis frequency, block size, blocks recorded, and record time. The panel includes a Comments box for user remarks.

## Edit Menu > Playback Setup Window: Playback Mode Panel

After you open a recorded file to be played back, you have the option to change the following for viewing purposes:

**Anal. Freq. (Frequency Range)** - selections are from recorded frequency range to 20Hz by dividing by 2. For example: recorded 4000hz and options are 4000, 2000, 1000, 500, 250, 125, 62.5, 31.25.

**Blocksize** - selections are from recorded blocksize to 16384 by multiplying by 2. For example: recorded 1024 then options are 1024, 2048, 4096, 8192, 16384.

Play Speed – No Delay, Real Speed, or Delay (mSec)



# Edit Menu >

# **Display Preferences\***

🎨 Display Preferences	<u>? ×</u>
Plot Window Colors	Channel Colors
Frame Border Plot Background Grid Lines	< 1 2 3 4 > 5 6 7 8 9 10 11 12 13 14 15 16
Cursor-1       2       3       nX	Peak Pick Options Spectral Width 0 (Spectral Lines) 0 Auto Cursor-1 Tracking Cursor-2
Cursors Cursor Label Colors	Cursor Movement Pick/Drag Pick Only Drag Only
Recall Plot Setup with Data Files	Cancel Apply

#### **Display Preferences**

\*<u>View Progam Users</u>: In eZ-PostView, eZ-FrequencyView, and eZ-TimeView, functionality of "display preferences" is handled by a separate *Plot Colors* window and a *Preferences* Window. See Appendix C for details and screen images. Functionality remains the same.

Plot window defaults are:	Cursor types include:
Frame Border = Grey	Single cursor
Plot Background = Black	Band cursors
Grid Lines = Grey	Peak cursor
Cursor = White	Harmonic cursor

- 1. To change a Plot Window display color, click on the button that applies to the display characteristic, for example, <Plot Background>. A Color Palette will open.
- 2. Select a color by clicking on a color square, or by defining a Custom Color.
- 3. Click <OK>.
- 4. Repeat the steps 1 through 3 for each Plot Window color that you want to change.
- 5. When finished, click <OK> in Colors [Color Palette] window.

\*<u>eZ-FrequencyView users</u>: In eZ-FrequencyView, the associated panel is in the Miscellaneous Tab and appears in a "Low Frequency Cutoff" panel within an Integration panel. HPF Int1 is referred to as "Single" for single-integration and HPF Int2 is referred to as "Double" for double-integration. See Appendix C.

Trace Colors:	Defines colors for Pick a new color,	traces. Click on a channel's color chip to open a color palette. then click <ok>.</ok>
Labels Colors:	Defines colors for Pick a new color,	<i>on-plot</i> text labels. Click on a color chip to open a color palette. then click <ok>.</ok>
Monitor Window:	Sets how the mon	itor window displays information.
Cursor Movement Control:	Sets the cursor's a <b>Pick/Drag</b> : Make <b>Pick Only</b> : Click: instantaneously w when the mouse i <b>Drag Only</b> : Move change to a "Left location.	action. Options are: <i>Pick/Drag</i> , <i>Pick Only</i> , and <i>Drag Only</i> . s use of both the Pick Mode and the Drag Mode. ing the left mouse button allows the cursor to move ith the band cursor. The chosen cursor moves to the location s clicked. e the mouse pointer to the cursor location. The pointer will and Right Arrow." Click and drag the cursor to the designated
Peak Search Options:	Peak averages are number of spectra used to set the pre	evaluated by first finding a peak and then averaging the specified al lines on either side of the peak. This section of the window is efferences regarding peak search. Options are as follows:
	Minimum:	Used to set the Minimum threshold value for peak searching, i.e., the lowest value of data to be considered for the search. "Minimum is typically set above the extraneous noise level.
	<b>Band (+ - Bin)</b> : [ <i>Peak Search</i> ]	Sets the <i>eZ-Analyst</i> to search data, according to a cursor- selected range (band). The band takes into account the Minimum threshold value for peak searching, if defined. The default setting for <b>Band (+- Bin)</b> is 3. This number specifies the number of data bins used for peak searching. For example, "3" indicates that the peak value will be searched at the current cursor position and the $\pm$ 3 adjacent positions.
	Sort By:	Specifies the order of the data in the peak search table. Sorting will be done by <i>Frequency/Time</i> , or by <i>Amplitude</i> .
	Peak Pick: Band (+ - Bin):	This mode sets the system to search for a peak within the pre- defined band (data range) only when the cursor is moved, or clicked. This is a manual method, when compared with Auto- Tracking.
	Auto Tracking	Selects Cursor-1 and/or Cursor-2 to automatically search for peaks. The feature makes use of range definitions for "+" and "-" Bin numbers, for example: $\pm 5$ indicates that the peak value will be searched at the current cursor position and the $\pm 5$ adjacent positions. The cursor automatically moves to the peak position within the specified range.

# Export Menu > Export

Filename:		eZAnaly	st.thd				
Active Channe	1=-	8	so.ond				
Analysis Fred	(Hz) -	1000					
Blocksize:		2048					
Blocks Record	led:	12					
Recorded Time	(Sec):	9.60					
estination Informati	ion						
File Format	• THD	(Binary)	ΟT	ext (ASCI	)		
Filename:					[	Browse	1
	8						
E	xample file fo	r eZ-Recor	d/eZ-Anal	ayst Progr	am		
Comments:	xample file fo	r eZ-Recor	d/eZ-Anal	ayst Progr	am		
Comments:	xample file fo	r eZ-Recor	d/eZ-Anal	ayst Progr	am		
Comments:	xample file fo	r eZ-Recor	d/eZ-Anal	ayst Progr	am		
Comments:	xample file fo	r eZ-Recor	rd/eZ-Anal	ayst Progr	am		
Comments:	xample file fo 2 🔽 3	r eZ-Recor	rd/eZ-Anal	ayst Progr	am	8 🟹	
Comments:	xample file fo 2 <b>⊽</b> 3	r eZ-Recor	rd/eZ-Anal	ayst Progr	am	8	
Comments:	xample file fo 2	r eZ-Recor	rd/eZ-Anal	ayst Progr F 6 F 14	am 7 15	▼ 8 16	
Comments:	xample file fo 2	r eZ-Recor	rd/eZ-Anal 5 13	ayst Progr G 14	am 7 15	₩ 8 ₩ 16	
Comments:	xample file fo 2	r eZ-Recor	rd/eZ-Anal ♥ 5 ■ 13 <0.0000	ayst Progr	am 7 15	₩ 8 ₩ 18	
Comments:	xample file fo 2 🔽 3 10 🗖 11	r eZ-Recor	rd/eZ-Anal ♥ 5 ■ 13 (0.0000	ayst Progr F 6 14 sec)	am 7 15	₩ 8 10	
Comments: E	xample file fo 2 7 3 10 11 1	r eZ-Recor	d/eZ-Anal ♥ 5 13 (0.0000	ayst Progr	am	₩ 8 ₩ 18	
Comments: E	xample file fo 2	r eZ-Recor	d/eZ-Anal	ayst Progr 6 14 sec)	am	♥ 8 ■ 16	
Comments: E	xample file fo 2	v eZ-Recor	rd/eZ-Anal	ayst Progr 6 14 sec)	am	₽ 8 □ 16	

This menu item is for exporting Recorded Files.

۹o.	Gain Factor	Offset(EU)
1	1.000	0.0000
2	1.000	0.0000
3	1.000	0.0000
4	1.000	0.0000
5	1.000	0.0000
6	1.000	0.0000
7	1.000	0.0000
8	1.000	0.0000

**Convert Data Window** 

Accessed via the Export Window's <Convert> button.

**Export Window** 

# Export Menu > Export > Destination Information Panel

- 1. Select the type of file you want. There are two choices of file format:
  - THD (Time History Data), which is Binary
  - Text (ASCII)
- 2. In the Filename data entry box, type the directory path and file name for the recorded file, or use the <Browse> button to locate the desired file. The correct file extension will be appended to the file name when the <OK> button is clicked.
- 3. If desired, enter remarks in the Comments data entry box.
- 4. Specify the channels of interest. Click to place a checkmark in the channel box for each of the channels you want to export. The selected channels will be adjusted to continuous channels starting with channel 1, but all the properties [including labels] will retain the old definition. For example, selected channels 1,3,5,6,8,16 will be adjusted to channels 1,2,3,4,5,6 in the exported file.
- 5. Specify the First (Starting) and Last (Ending) records (blocks) that you want saved. In the first figure above, "1" is specified for the Starting Block and "12" is specified for the Ending Block.
- 6. Click the <OK> button.

# Export Menu > Export > Convert

The upper left corner of the Export window includes a **<Convert>** button. Note that the outline of the button appears only when the mouse cursor passes over it.

Click on the <Convert> button to bring up a second window (see upper right-hand figure). From this window you can adjust the channel data value prior to exporting it. Data adjustments can be accomplished by setting channel offset and/or gain.
# Export Menu > Export > Setup Export Function Data\*

This menu item is for exporting function files.

Export Function D	Jata		?
le Name			Browse
File Type			
Universal (ASC)	l) C Universal (I	Binary) C Excel	
C MEScope	C SMS Modal		
C Automatic Save	after Averaging		
Warn on Non-S	Saved Averaged Measur	ement	
1 Warner of the	area Arenagea measar	omoria	
Channel & Function S	Selection		
All Ch. Pairs	C Displayed Ch. & Fi	unctions	
Time	AutoSpec	FRF	Cctave
	🗖 Spectrum	Coherance	🗂 1/3 Octave
	F PSD	Cross	
Time Averaged	Unaveraged     Spectrum	Reference Spe Spectrum	ectrum -
	opeenan	opoorium	
Jadifier / Casta 9 Dir	if the h		
Scale RMS	Diff / Int None	e 🗾 🗖 dB S	Scale

**Export Function Data** 

- **\*View-Program Users**: The Export Function Data Screen has a slightly different appearance in eZ-TimeView and eZ-FrequencyView. The export function does not apply to eZ-PostView.
  - 1. Type the directory path and file name for the function file, or use the <Browse> button to locate the desired file.
- 2. Select the type of file you want.
- 3. If you want to have records automatically appended to the specified file, select *Automatic Save after Averaging*.
- 4. Specify either All Ch. Pairs, or Displayed Ch. & Functions.
  - All Ch. Pairs exports all the data for all the channels pairs so that all functions can be retrieved if desired.
  - **Displayed Ch. & Functions** exports only the data for the displayed functions.
- 5. Click to place a checkmark by each of the functions to be saved. See the following note.
- 6. Click <OK>.
- **Note**: Selected functions can not be saved without the display of a *warning prompt*. This is in case the selection is not valid. For example: if the functions FRF, Cross, and Coherence were selected, but no reference channels were selected, then the three functions could not be saved. This is because these three functions require a reference channel.

# Window Menu

```
Menu Items
Add Function View (FV) ..... 2-43
Add Strip Chart ..... 2-43
Delete Window ..... 2-44
Channel Buttons ..... 2-44
Modal Locations ..... 2-44
Input Channels ..... 2-45
Measurement Panel ..... 2-46
Tachometer ..... 2-47
Cascade ..... 2-47
Tile Vertically ..... 2-47
Tile Horizontally ..... 2-48
Refresh Windows ..... 2-48
```



## **Reference Note:**

For information regarding the interactive features of Plot Display Windows, refer to chapter 3. The interactive features are not selected from the Window Menu, but are accessed via mouse buttons and/or hotkeys. Appendix A provides tables of the various hotkey functions.

# Window Menu > Add Function View (FV)

This menu selection opens an additional plot window.



**Example of an Added Function View** 

# Window Menu > Add Strip Chart

This menu selection opens a strip chart plot window. This feature does not apply to eZ-PostView.



Example of an Added Strip Chart

## Window Menu > Delete Window

Deletes the window that is currently in focus. When multiple plot windows are open, one is always the "focus window. When a window does not have focus, its title bar is dimmed. To change the "focus window," simply click on top or side border of the window of interest.

## Window Menu > Channel Buttons

Brings up a display showing squares for all channel buttons. The buttons are used in the exact same manner as the 16 channel buttons that are located on *eZ-Analyst*'s main window, just below the Date/Time region.

- **To add a channel**: use the mouse to click and drag a channel box from the complete channel button display into the plot area.
- **To remove a channel**: use the mouse to click and drag a channel box (from the right-side of the plot) into the plot area.

## Window Menu > Modal Locations Window

This window displays the current modal locations. The window only applies to *eZ-Analyst* and to *eZ-FrequencyView*.

Chnl	Label	Location
1	Channel01	1 X+
2	Channel01	2 X+
3	Channel01	3 X+
		-
		0

Modal Locations Window, As it appears in eZ-Analyst

<u>않</u> し	ocations <b>?</b> 🗙		
Ch 01	Location 1 X+		
02	2 X+		
03	3 X+		
04	5 X+		
06	6 X+		
07	7 X+ 8 X+		
Up			
Down			

Modal Locations Window, As it appears in eZ-FrequencyView

Clicking on the left or right arrow keys [ <Up> or <Down> buttons in eZ-FrequencyView] increments or decrements the modal locations based on the bank setup criteria set in the Configuration - FFT Setup Tab. The change in locations is dependent upon the active reference and response channels, and whether Response Increase or Reference Increase is selected.

# Window Menu > Input Channels

The Input Channels window is selected from the *eZ-Analyst Windows* pull-down menu. This Window only applies to *eZ-Analyst*.

The Input Channels window (following figure) uses a chart to indicate the followings:

- Volts linear
- percent of the Full-Scale Voltage (FSV)

The status window includes "maximum" bars to show the highest level of signal value reached by each channel during the measurement process.

Chni	Label	Meas V	+/- FSV	Delta %
1	Channel01	2.686	5.000	53.72
2	Channel01	n/a	5.000	
3	Channel01	n/a	5.000	
4	Channel01	n/a	5.000	
5	Channel01	n/a	5.000	
6	Channel01	n/a	5.000	
7	Channel01	n/a	5.000	
8	Channel01	n/a	5.000	
9	Port 0	n/a	0.0000	

### Input Channels

- Meas V Measured Voltage
- +/- FSV The Full-Scale Voltage
- **Delta %** The percentage difference between the measured voltage and the Full-Scale voltage, such that Meas V is n% of FSV; with n being the value of Delta %.

## Window Menu > Measurement Panel



The Measurement Status Panel and Modal Locations Window on Top of a Plot Window

Note: The bracketed letters pertain to definitions provided in the following text.

The Measurement Status Panel only applies to *eZ-Analyst*. It provides basic, but important information, including trigger and processing conditions, and reference and response coordinates. Status Areas of the panel are as follows:

- [A] Averaging Status. Displays the number of measurements completed followed by the total number of measurements. For example, "1/6" indicates that 1 of 6 measurements has been completed.
- [B] Trigger/Processing Status. Displays the following:
  - T Triggered
  - W- Waiting for Trigger
  - S Saved the data
  - **C** Completed measurement
  - $\mathbf{O}$  Overload rejected
  - **D** (with yellow background) Double Hammer Rejected
- [C] First Response Coordinate. Shows the channel number and the modal location. (Note 1)
- **[D]** First Reference Coordinate. Shows the channel number and the modal location. (Note 1)
- **Note 1**: A Response or a Reference Coordinate with a yellow background indicates that the field is used for the "increasing" method. For example, the Response Field (figure, item "C") with a yellow background means that the response increase method is being used. This is discussed in the *FFT Setup Tab* section of the document, beginning on page 2-31.
- Note 2: Measurement Status indicators are disabled when recording.

The large size of the status areas allows the user to see the measurement status from a relatively long distance, i.e., as compared to the very limited viewing range offered by standard-sized GUI text display fields. The feature has proven useful in one-man "impact-testing" operations pertaining to modal type measurements.

## Window Menu > Tachometer

Chnl	Label	RPM	
2	Channel01	3527.	

Tachomet	er	
CH: 1	129.3474	Y
CH: 2	0	v

Tachometer, as seen in eZ-Analyst

Tachometer, as seen in eZ-TimeView and eZ-FrequencyView

This window displays three fields: tachometer channel number, measurement, and units. Tachometer channels are set up in the *Input Channels Window*. See page 2-22, *Tach Channel Setup*, for additional information. Tachometer does not apply to *eZ-PostView*.

## Window Menu > Cascade

When you have multiple plot windows open, this menu selection arranges them on you screen as shown.



Example of using Cascade with three Plot Windows

## Window Menu > Tile Vertically

When you have multiple plot windows open, this menu selection arranges them on your screen as shown.



*Example of using Vertical Tile with two Plots* Each plot is longer in the "vertical" direction.

# Window Menu > Tile Horizontally

When you have multiple plot windows open; this menu selection arranges them on your screen as shown.



*Example of using Horizontal Tile with two Plots* Each plot is longer in the "horizontal" direction.

## Window Menu > Refresh Windows

Used to refresh a window; for example, to refresh a Strip Chart. In this case, the refresh function blanks out the present Strip Chart, essentially providing you with a new, clean window.

How to Change Plot Display Characteristics ......3-2 How to Change "Focus" ...... 3-2 How to Add or Remove Channels ...... 3-2 How to Change Display Functions ...... 3-3 Complex Displays ...... 3-4 Transfer Type ...... 3-5 Octave Type ...... 3-5 Integration / Differentiation ...... 3-6 Scale Type ...... 3-7 Copy ...... 3-8 Label / List ...... 3-10 Displaying Channel Pairs ...... 3-11 Changing the Display Range ...... 3-11

Changing Plot Format / Scale / Grid ..... 3-12

# How to Change Plot Display Characteristics

To change a plot's display characteristics; it must be the "focus plot." Then, you can either use the mouse or key commands to make changes. "Focus" is explained in the following section.



**Open Plot Display Characteristics Menu:** Press "**D**" or right click with the cursor hovering over the plotted data.

Use the down arrow key to highlight a menu option, then press "**Enter**". Note that in some cases you can press the first letter of an option to open its sub menu, for example, pressing the "**S**" key opens the Scale Type sub menu.



*Two Plot Windows* In this figure, the upper plot has the "focus."

# How to Change "Focus"

Focus can refer to the window that is in focus, as well as to a plot that is in focus. When multiple plot windows are open, one is always the "**focus window**." In the following figure, the window with the dark title bar (top window) is the window that currently has "focus." When a window does not have focus, its title bar is dimmed. **To change the "focus window," simply click on top or side border of the window of interest.** 

When multiple plot windows are open, a plot *other than the one* in the "focus" window can be the "**focus plot**." You would typically do this when you want to change a plot's characteristics. To change the "focus plot," **click in the plotted area of the window of interest**. Note that the window must be in focus at the time.

# How to Add and Remove Channels

**To add a channel to a plot ...** With your mouse, click and drag a **channel box** from *above the plot* to the plot area.

**To remove a channel from a plot . . .** With your mouse, click and drag a **channel box** from the *right of the plot* into the plot area. To ADD a channel, click-on the desired "channel box" in this area and drag it into the plot region.

1 11 12 13 14 15 16 >

To REMOVE a channel, click on the desired "channel box" in this area and drag it into the plot region.

# How to Change Display Functions



Open Function Menu: Right-click on the plot.

Using Key Commands: Press "D" + "F". Use the arrow keys to highlight your selection and press "Enter". Note that in some cases you can press the first letter of an option to select it.

The data type determines the functions available for display.

Time:	A single-channel display function. Displays a time domain waveform of filtered, sampled data scaled in either Volts or EUs.
Spectrum:	A dual-channel display function. Displays averaged linear spectrum computed as the square root of the averaged autospectrum. This function is calibrated in peak engineering units (EU).
Auto Spec:	A single-channel display function. Displays the square of the magnitude of the complex (one-side) Fourier spectrum of $x(t)$ . Autospectra are calibrated so that if A is the peak amplitude of a sinusoidal signal $x(t)$ , then the autospectrum has the value A*A (or use A power 2) at the sinusoidal frequency.
PSD:	A single-channel display function. It is the Fourier Transform of the Auto- correlation function. This normalization should be used with continuous random signals.
Coherence:	A dual-channel display function. At each frequency, the coherence is a value between 0.0 and 1.0, which indicates the degree of consistent linear relationship between two signals during the averaging process. A value of less than one indicates that phase cancellation occurred during cross-spectrum averaging, which may be due to uncorrelated noise on one or both signals or to a nonlinear relationship between signals.
FRF:	A dual-channel function for the single-input, single-output (SISO) frequency response function between two specified input channels. FRF is the averaged cross-spectrum divided by the averaged autospectrum of the input (the second named channel).
Cross:	A dual-channel display function in the frequency domain. It is equal to the product of the complex Fourier spectrum of $y(t)$ (the numerator or first named channel) times the complex conjugate of the Fourier spectrum of $x(t)$ (the denominator or second named channel). The special case $y=x$ yields the autospectrum. Averaging of these functions (frequency-domain averaging) forms the basic foundation on which virtually all other multichannel, frequency-domain analysis is built. The cross spectrum is calibrated in units of (peak EUy) (peak EUx).
Octave:	Many sounds, including audible noise for a transmission line, are broad band, having components that are continuously distributed over a range of frequencies. The spectrum of such a sound can be approximated in terms of a series of octave band or one-third octave band pressure levels. A band is designated by its center frequency, $f_0$ , which is the geometric mean of the upper and lower frequencies of the band. (See ANSI/ASC S1.6-1984.)
	Activates the Octave Type menu. Select the desired Octave Type on the Octave Type menu.

Transfer:	Activates the Transfer Type menu option. Select the desired Transfer Type on the Transfer Type menu.
Unaveraged Spectrum:	A display function of the magnitude of instantaneous unaveraged spectrum.
Averaged Time:	A single-channel display function. Displays a time domain waveform of filtered, averaged, sampled data scaled in either Volts or EUs.
Reference Spectrum minus Current Spectrum:	<i>Reference Spectrum minus Current Spectrum</i> displays the difference between the Reference Spectrum and the Current Spectrum when the following is specified: Linear (-), Negative Averaging
Windowed Time:	Applies to the FFT Response window specified in the Miscellaneous Tab of the Configuration window to time data.

# **Complex Displays**

✓ Magnitude Open Complex Display Menu: Press "D" + "C" + "Enter".			
Phase	Use the down arrow key to highlight your selection, then press "Enter".		
Heal Imaginary Magnitude+Phase Real+Imaginary Nyquist	Options on the Complex Display menu are only available when a function with complex data is displayed. The following options are available.		
Magnitude:	Plots only the magnitude of real or complex data.		
Phase:	Plots only the phase of complex data.		
Real:	Plots only the Real numbered data.		
Imaginary:	Plots only the imaginary numbered data.		
Magnitude + Phase:	Plots both Magnitude and Phase data.		
<b>Real + Imaginary:</b>	Plots both Real and Imaginary data.		
Nyquist:	A Nyquist plot is another way to display real and imaginary data. The real numbered data is plotted on the X-axis and the imaginary numbered data is plotted on the Y-axis with consecutive points joined by line segments. From basic vibration theory, a Nyquist plot of a mobility function should trace out a circle (counter-clockwise) as the frequency is increased through an isolated structural resonance.		

# Transfer Type

 Inertance Mobility Compliance App Mass Impedance Dyn Stiff Open Transfer Type Menu: Press "**D**" + "**T**".

Use the down arrow key to highlight your selection and press "Enter".

These functions are calculated by dividing the cross spectrum of the channel pair by the auto spectrum of the reference (force) channel.

Inertance (acceleration/force) Mobility (velocity/force) Receptance or Compliance (displacement/force)

The following *reciprocal* functions are derived from Inertance, Mobility, and Receptance, respectively. To derive the reciprocal function, take the inverse of the magnitude, then multiple the phase angle by "-1."

Apparent Mass (force/acceleration) Impedance (force/velocity) Dynamic Stiffness (force/displacement)



Transfer function displays assume the reference channel is a force channel. You MUST define the response channels to be the correct type of data (acceleration, velocity, or displacement) that you are acquiring. Define these in the data type column of the Calibration window. This allows the data to be integrated or differentiated correctly to derive the desired transfer function.

# **Octave Type**

Many sounds, including audible noise for a transmission line, are broad band, having components that are continuously distributed over a range of frequencies. The spectrum of such a sound can be approximated in terms of a series of octave band or one-third octave band pressure levels. A band is designated by its center frequency,  $f_0$ , which is the geometric mean of the upper and lower frequencies of the band. (See ANSI/ASC S1.6-1984.)



**Open Octave Menu:** Press "**D**" + "**O**".

Use the down arrow key to highlight your selection and press "Enter".

- **Full:** An octave band extends from a lower frequency,  $f_0^2$  to twice the lower frequency  $(2f_0)$ .
- **Third:** A one-third octave band extends from a lower frequency  $(f_0/2)$  to 32 times the lower frequency  $({}^{6}2f_0)$ . The Octave (one-third octave) band sound-pressure level is the integrated sound-pressure level of all spectral components in the specified octave or one-third octave band.

# Integration / Differentiation

Dilf-2 Dilf-1 ✓ None Int-1 Int-2 **Open Int/Diff Menu:** Press "D" + "I".

Use the down arrow key to highlight your selection and press "Enter".

This is for display purpose only and does not modify the data. Differentiation/Integration is only active when frequency domain data is displayed. Select single or double integration, single or double differentiation or none. Make your selection on the popup menu.

Differentiation and Integration are calculated by dividing each element of the function by  $(jw)^n$ , where j is the square root of -1; w is the product of 2 pi times the frequency of the block element; and n is an integer from +2 to -2.

**n** = 2 is double integration

- **n** = 1 is single integration
- n = 0 has not effect
- **n** = -1 is single differentiation
- n = -2 is double differentiation

If the signal is acceleration, then single integration (Int1) results in velocity, and double integration (Int2) results in displacement. If the signal is displacement, then single differentiation (Diff1) results in velocity, and double differentiation (Diff2) results in acceleration.



Engineering Units change if instrument type is Acceleration and double integration is selected.

# Scale Type



**Open Scale Type Menu:** Press "**D**" + "**S**". Use the down-arrow key to highlight your selection and press "**Enter**".

**RMS**: (Root Mean Square): The square root of the average of the square of the value of the function taken throughout one period.







**Pk-Pk**: Peak to Peak





To Open the **Copy** Menu: Press "**D**" + "**C**," then release the keys. The **Copy** selection will be highlighted. Press "**Enter**." Next, use the down arrow key to select the item you desire to copy: **Data**, **Plot Window**, or **Screen**, then press "**Enter**."

You can paste the copied item into other applications. For example, plotted data can be copied into Notepad, Word, or Excel for use in reports or in the case of Excel further calculations.

The plot window and full screen can be copied and then pasted into any application that accepts graphics, such as MSPaint or Word.

Function Type:Octave 1/3:None (LIN)			
	g's <lin> [RMS]</lin>		
Overai	10.00603		
Freq.	CH:2		
500.0	0.00097		
630.0	0.00171		
800.0	0.00132		
1000.	0.00114		
1250.	0.00117		
1600.	0.00160		
2000.	0.00135		
2500.	0.00182		
3150.	0.00191		
4000.	0.00197		
5000.	0.00177		
6300.	0.00196		
8000.	0.00241		

*Plot Window Data* Copied and Pasted into Word

# Cursor



To open the **Cursor** Menu: Press "**D**" + "**C**," then release the keys. Then use the downarrow key to highlight **Cursor** and press "**Enter**."

Next use the down arrow key to select, **Cursor Off**, **Single Cursor**, or **Band Cursor**, **Harmonic**, or **Peak**; then press "Enter."

When **Single Cursor** is selected, a cursor appears at the far left of the plot and cursor controls and cursor information are added below the plot. Click on the plot where you want the cursor. To fine-tune the cursor location, use the right and left arrows at the bottom. Use the X and Y information for additional help. If you have multiple channels in the graph, use the up and down arrows to move the cursor from plot to plot. Press "C" to toggle the cursor on and off.



Plot Window with Single Cursor

Plot Window with Band Cursor

When **Band Cursor** is selected, two cursors appear at the far left of the plot and cursor controls and cursor information are added below the plot. Click on the plot where you want the first cursor, then click on the plot where you want the second cursor. Press "C" to toggle the cursor through the following cycle: on (add a cursor), add a second cursor, off.

When **Harmonic** is selected data points are marked on the plot, at x-axis values which are a multiple of the cursor. For example, if the cursor was at 0.12, the next harmonic would be at 0.24, then 0.36, followed by 0.48, and so on. A data text box lists the harmonic cursor values.



Example of a Plot with "Harmonic" Cursor Selected

When **Peak** is selected, data points are marked on the plot in relation to the y-axis, at the highest amplitude for a given spectrum (see figure). A data text box lists the peak cursor values.



Example of a Window Plot with "Peak" Cursor Selected

Daia Text To Open the **Label/List** Menu press "**D**" + "**L**," then release the keys. **Label/List** will be highlighted. Press "**Enter**."

Using the down arrow key, select Data or Text, then press "Enter."

**Data** places up to 10 cursor values on your plot. After you select data, a temporary cursor is placed on the plot and the x, y data values are shown for that location. As you move your mouse, the temporary cursor will move across the plot with data values continuously updated. When you have the cursor where you want it, click on the mouse to place the label. Another temporary cursor immediately appears. When you are finished labeling values, right-click and select Pointer to return to a normal state.



## Adding Data Point Cursors and Text

**Text** places a comments text box on the plot. After you select text, click on the plot and start typing. You are limited to 26 character places. Click on the right corner of the text box to move it anywhere on the plot window.

# **Displaying Channel Pairs**

A channel pair is a reference channel and a response channel used to display a dual channel function, such as an FRF.

In the Input channel configuration panel, set at least one channel as a reference channel. After you click OK and look at the channel buttons in the main window, you will notice that each reference channel now has a bold number. One of them also is underlined. That channel will be used as the reference channel for any dual function displays.

To change to another reference channel, right click on the channel of interest. It will now be underlined.



All channels are response channels, even those that have been designated as reference channels.

# **Changing the Display Range**

To change the maximum or minimum range value: Left-click on upper or lower scale value that is to be changed, then enter the new value. An example follows.

<sup>3</sup> ISLOOD

3

3.800





**To change the X-Axis:** Hold down the **<Ctrl>** key, at the same time, left-click and drag the mouse cursor horizontally on the plot. Two vertical cursor lines will define the new x-axis end points.



**To change the Y-Axis:** Hold down the **<Alt>** key, at the same time, left-click and drag the mouse cursor vertically on the plot. Two horizontal cursor lines will define the new Y-axis end-points.



To simultaneously change the X & Y Axes: Hold down the <Ctrl> and <Alt> keys, at the same time, left-click and drag the mouse cursor diagonally on the plot. A rectangle will define the new area of the plot.



# Changing the Plot's Format / Scale / Grid

Right-Click on the plot's border to open a popup menu (see figure). If you want to change the y-axis, right-click on the plots left border. If you want to change the x-axis, right-click on the plot's bottom border.



Changing the plot Format, Scale, or Grid affects the display only. It does not change the real data.



## Format

The Format menu allows you to change the axis format of the plotted data. Choices are Linear, Log, and dB (valid on for the y-axis).

## Scale

The Scale menu allows you to change the plot scale to AutoScale, FixedScale, or Manual. Autoscale ensures that all the captured data is visible on the plot.

## Grid

The Grid menu allows you to place and remove grid lines from the graph of plotted data. You can also turn the grid on and off by pressing the "G" hot key.

This appendix consists of several hot key tables for the benefit of those who prefer to use keys in place of mouse/cursor interaction with a GUI. However, for certain functions, such as changing axis scales, a mouse will be needed. Mouse use is pointed out in the tables, when applicable.

Record / Playback Control		
Keys	Function	Comments
р	Play Forward	
<shift> + p</shift>	Play Backward	
0	Step Forward and Record	
<shift> + o</shift>	Step Backward and Record	
Н	Halt Playback	

Measurement, Scope, and Generator Control		
Keys	Function	Comments
Н	Halt the measurement	
R	Start recording	
S	Start Scope Mode (Measurement)	
w	Turn the signal generator On	

Menu and Window Control		
Keys	Function	Comments
Alt + E	Presents the Edit Menu.	
C	Presents the <b>Plot Window <u>Colors</u></b> window.	After pressing <b>Alt + E</b> to access the Edit Menu, press <b>C</b> to get the Colors Window. Use the Tab key to select a characteristic, then hit <enter>.</enter>
<b>M</b>	Presents the <b>Configuration</b> window.	After pressing <b>Alt + E</b> to access the Edit Menu, press <b>M</b> to get the Configuration Window. You will need a mouse to access all panels. Also, see Ctrl + M.
P	Presents the <b>Playback Setup</b> window.	After pressing <b>Alt + E</b> to access the Edit Menu, press <b>P</b> to get the Playback Setup Window. Use the Tab and arrow keys to make selections within this window. Then hit <enter>.</enter>
Alt + F	Presents the File Menu.	
Alt + W	Presents the Window Menu.	You will need a mouse to make selections.
Ctrl + M	Presents the <b>Configuration</b> window.	You will need a mouse to access all panels. An alternative to Ctrl + M is to press M when the Edit Menu is open.
Ctrl + O	Presents the <b>Open File Dialog</b> window.	From within the window, use the Tab and arrow keys. An alternative to Ctrl + O is to press O when the File Menu is open.
Ctrl + P	Presents the <b>Print Dialog</b> window.	An alternative to Ctrl + P is to press P when the File Menu is open.
D	Presents the <b>Display Menu</b> , also referred to as the Plot Display Characteristics Menu.	Refer to the following table for control options related to the Display Menu.

Α

Display Menu Control				
Keys	Function	Comments		
D	Opens the Plot Display Characteristics Menu	Option: "Right-clicking" the mouse, while the cursor is over the plot will also open this menu.		
<b>D + C</b> (3 functions)	Used to open the <b>Complex Type Display Menu.</b> This option is only available when a function with complex data is displayed. Menu choices are: Magnitude, Phase, Real, Imaginary, Magnitude + Phase, Real + Imaginary, and Nyquist	Press D + C; release, then press <enter>. The Complex Type Display Menu will open. Use the arrow keys to highlight the type of display, then press <enter>.</enter></enter>		
	Used to open the <i>Copy Menu</i> . Menu choices are: Data, Plot Window, Screen.	Press D + C; release, then use the arrow key to select Copy. After selecting Copy, press <enter>.</enter>		
	Used to open the <i>Cursor Menu</i> . Menu choices are: Single Cursor, Band Cursor, or Cursor Off.	Press D + C; release, then use the arrow key to select Cursor. After selecting Cursor press <enter>.</enter>		
D+F	Opens the <i>Display Functions Menu</i> . Note that right-clicking on the plot will also open this menu.	Use arrow keys to highlight your selection, then press <enter>. In some cases you can select the first letter of an option to select it.</enter>		
D+I	Opens the Integration/Differentiation Menu.	Use arrow keys to highlight your selection, then press <enter>.</enter>		
D+L	Opens the Label / List Menu.	Use arrow keys to highlight your selection, then press <enter>.</enter>		
D + O	Opens the Octave Menu.	Use arrow keys to highlight your selection, then press <enter>.</enter>		
D + S	Opens the Scale Type Menu. Menu choices are RMS, Peak, Pk-Pk.	Use arrow keys to highlight your selection, then press <enter>.</enter>		
D + T	Opens the Transfer Type Menu.	Use arrow keys to highlight your selection, then press <enter>.</enter>		

Plot Display Controls (Note)		
Keys	Function	Comments
Mouse-Click Bottom Border	Change the <b>X-axis</b> in regard to format, scale, and grid.	Right-click on the plot's bottom border to access a menu for changing the X-axis in regard to Format, Scale, and Grid.
Mouse-Click Left Border	Change the <b>Y-axis</b> in regard to format, scale, and grid.	Right-click on the plot's left border to access a menu for changing the Y-axis in regard to Format, Scale, and Grid.
,	Moves the primary cursor left along the trace.	When in Band Cursor mode, the comma moves the primary cursor to the left.
•	Moves the primary cursor right along the trace.	When in Band Cursor mode, the period moves the primary cursor to the right.
<	Moves the secondary cursor left along the trace.	When in Band Cursor mode, the "<" moves the secondary cursor to the left.
>	Moves the secondary cursor right along the trace.	When in Band Cursor mode, the ">" moves the secondary cursor to the right.
<shift></shift>	Peak search.	Press the <shift> key while depressing the left mouse button to search for peaks along the trace.</shift>

**Note**: Also see the Display Menu Control Table.

Continued

**Reference Note**: For more detailed information, which includes graphics, refer to chapter 3, *Interactive Features of the Plot Display Window*.

Plot Display Control (Note)		
Keys	Function	Comments
Α	Turns Auto-scale On.	
Alt	Expands or contracts the <b>Y-Axis</b> .	(a) While holding down the <alt> key, place the cursor at the desired start point of the Y-axis, (b) click the left mouse button, (c) drag the mouse vertically until the cursor is at the new end point of the scale.</alt>
b	Bank up.	
<shift> + b</shift>	Bank down.	
C	Toggles the cursor On or Off; or cycles the cursor options as follows (if Band Cursor is selected): Adds a Cursor, Adds a second Cursor, turns both cursors Off.	When Band Cursor is selected, the "C" key cycles through On (add a cursor), add a second cursor, and Off.
Ctrl	Expands or contracts the <b>X-Axis</b> .	(a) While holding down the <ctrl> key, place the cursor at the desired start point of the X-axis, (b) click the left mouse button, (c) drag the mouse horizontally until the cursor is at the new end point of the scale.</ctrl>
Ctrl + Alt	Simultaneously expands [or contracts] both the <b>X</b> and <b>Y axes</b> .	(a) While holding down both the <ctrl> and <alt> keys, place the cursor at the desired start point on the plot, (b) click the left mouse button, (c) drag the mouse diagonally until the cursor is at the new end point of the scale.</alt></ctrl>
<b>F2</b> or <b>Z</b> (2 functions)	Zooms in or out.	When you depress one of these keys, while dragging with the right mouse button depressed, you will zoom in or out, according to the cursor-defined region.
	Pan along the X-axis, Y-axis, or both.	By depressing one of these keys, while dragging with the left mouse button depressed, you can pan in the direction of the drag.
F3	Zoom in or out.	Use F3 with the left mouse button to zoom in our out.
G	Turns Plot Grid On or Off.	Toggles the grid to On or Off.
L	Changes the Scale to Linear or to Log.	Toggles the scale to Linear or to Log.
R	Start Recording	
S	Start Scope Mode (Measurement)	
X	Presents the X-Axis Menu	
Y	Presents the Y-Axis Menu	
<b>Z</b> or <b>F2</b>	Zooming or Panning.	See " <b>F2</b> ."

Note: Also see the Display Menu Control Table.



**Reference Note**: For more detailed information, which includes graphics, refer to chapter 3, *Interactive Features of the Plot Display Window*.



A Bank is defined as a group of signals that are selected for simultaneous measurement, together with all the associated transducer definitions and channel assignment information. He concept of "banks" is helpful with a modal test where the number of transducers on the test article exceeds the number of input channels on your analyzer.

You can have the analyzer increment your banks automatically after each measurement, or you can manually increment the banks. The Skip Factor is typically the number of measurement points in a bank.

Use the buttons in the Modal Location window to increment or decrement your banks. The Bank control options are set up in the FFT Setup tab at WaveBook configuration window. Increment or decrement the Bank by the Skip Factor. The number of channels [associated with a bank] is based on the Response Channel and the Skip Factor.

1	Channel01	1 X+
2	Channel01	2 X+
3	Channel01	3 X+
		2. 

в

Modal Locations Window

# Hints for Setting up Banks and Skip Factors

Visualize a test object with 27 transducer locations in 3 rows of 9. You have 1 reference, and 27 responses. Using all 8 channels you can build channel pairs with channel 1 as the reference, and 2 through 8 as the responses. Your 7 channel pair relationships would be 2,1 3,1 4,1 5,1 6,1 7,1 and 8,1

In the Channel Pairs window specify channel 1 as a reference channel; then click the Build Pairs Button to create the channel pairs listed above.

In the Input Channel tab at the WaveBook configuration window, select Reference for Channel 1 and select Response for other active channels, i.e., Channels 2 through 8, inclusive.

Bank	Reference channel/location	<b>Response channel/location</b>
1	1/1	2/2, 3/3, 4/4/, 5/5, 6/6, 7/7, 8/8
2	1/1	2/9, 3/10, 4/11, 5/12, 6/13, 7/14, 8/15
3	1/1	2/16, 3/17, 4/18, 5/19. 6/20, 7/21, 8/22
4	1/1	2/23, 3/24, 4/25, 5/26, 6/27

Before starting the data acquisition, use the increase or decrease button at the Modal Location window. After each acquisition, click the <Export> button to create an FRF file for each channel pair, or use the *automatic saving option* to save data and bank up to the next locations.

Each file name uses the function abbreviation to identify:

- the Reference Location and the orientation
- the Response Location and the orientation

The function abbreviations differ, depending on the file format used.

The file type is selected in the "*Setup Export Function Data window*," as discussed in the Export Menu section of chapter 2.



As this document goes to print there are differences between the Configuration Window Tabs of eZ-Analyst and the eZ-Analyst Series "View" applications, i.e., eZ-PostView, eZ-TimeView, and eZ-FrequencyView. The Configuration Window Tabs are accessed through the Edit pull-down menu.

In addition, note that the view applications use both a Window Colors window and a Preferences window, whereas eZ-Analyst makes use of one "Display Preferences" window, which has the combined functionality of the others.

Due to these differences, this appendix was created to provide the following:

- Screen images and text pertaining to the Miscellaneous Tab. The tab appears in eZ-FrequencyView and is related to the FFT Setup Tab found in eZ-Analyst.
- Screen images and text pertaining to the Window Colors and Preferences windows. These are related to the Display Preferences window found in eZ-Analyst.

# Edit Menu > Configuration > Miscellaneous Tab

Applies to eZ-FrequencyView

Analyzer		put Channels	Recorder Setup	Block Rejecti
utput Channel	Misc	ellaneous	Octave Setup	
FFT Window Hanning FFT Window Rectang Start(%	v (Response) v (Reference) gular v 6) 5.000	Integration	Bank(Location) Con Auto Bank Incre V with Automatic Saving Data 0.00 HZ C Response Incre	trol ase ase
Stop(%	3) 15.00	dB Reference(Volt)	r0 db∨	

**Miscellaneous** Tab

# Edit Menu > Configuration > Miscellaneous Tab: FFT Window (Response) Panel

The FFT (Response) window is a time-domain, weighting window. A response window is usually applied to data to reduce FFT leakage errors. FFT theory assumes that the signal being analyzed is periodic in the data acquisition block. When this is not the case, energy from a signal at a specified frequency can leak into nearby spectral bins causing spectral amplitude inaccuracies. Applying a windowing function controls, but doesn't completely eliminate, the error by multiplying each data frame by a suitable time-domain weighting window. This calculation reduces the amplitude/magnitude of the data near the ends of each data frame prior to performing the FFT and forces the data to be nearly periodic in the window, thus reducing leakage errors. Response window options are as follows:

### FFT Window (Response) Panel

None: No weighting wi	ndow is applied.
-----------------------	------------------

- **Hanning**: The Hanning window is typically used to analyze continuous signals. It offers a reasonable trade-off of frequency accuracy versus amplitude accuracy.
- **FlatTop**: Compared to the very similar 4-term "Max Flat Top," this window also has a very low peak amplitude error, and its frequency resolution is somewhat better. Its side lobes are considerably higher. Its effective noise bandwidth is still almost twice that of the Hanning window, therefore this window is used mainly to measure accurate peak amplitudes of discrete spectral components that are known to be separated by several spectral lines.
- **Blackman-Harris**: This window function was designed to provide the minimum side lobe level of any threeterm window. Compared with the very similar Hanning window, it has a slightly wider main lobe but much better dynamic range. This window has the smallest 60 dB bandwidth of any window listed. The Blackman-Harris window may be preferred over the Hanning for measurements requiring better dynamic range.
- **Exponential:** An exponential weighting window is equal to 1.0 at the beginning of the block and decays exponentially to a smaller value at the end of the block. Exponential is used only with transient data that is captured with pre-trigger to assure that the initial values in all data channels are very close to zero. Exponential can be used with all transient excitation methods in order to force the signals to decay close to zero, (See Response Decay Percent,) even if the block length is not sufficient to capture all of the naturally occurring response. If the data decays naturally to a low amplitude within the block, so that leakage is not significant, exponential windowing can improve the signal-to-noise ratio by giving reduced weight to the very low-amplitude data at the end of the block.
- **Decay %**: Decay Percent is used when an Exponential Window is applied to the Response Channel. It is the weighting factor present at the last block value. For example, a decay of 5% means that the weighting factor at the beginning of block is 100% and that the weighting factor of the last block is 5%. In other words, the weighting factor dropped (decayed) to 5% through the length of block.

# Edit Menu > Configuration > Miscellaneous Tab: FFT Window (Reference) Panel

The FFT Reference Window is applied to the output of a transducer to avoid collecting extraneous signals caused by an excitation device, such as an impulse hammer. Possible selections are: Response, Rectangular, and Cosine Taper.

When **Rectangular** is selected, specify the Start(%) and End(%) of the rectangle as a percentage of the Frame Period.

When **Cosine Taper** is selected, specify the Start(%), End(%), and Edge(%) the Cosine Taper as a percentage of the Frame Period.

- **Start (%)**: The percent of the Frame Period at which the Rectangular and Cosine Taper Windowing functions start.
- **Stop (%)**: The percent of the Frame Period at which the Rectangular and Cosine Tape Windowing functions stop.
- **Edge (%)**: This is the percent of the Frame Period during which the Cosine Taper Windowing function tapers up and down.



FFT Window (Reference) Panel

# Edit Menu > Configuration > Miscellaneous Tab: Integration Panel



Integration Panel – 2 Views

The left-hand view is with the scrollbar up, the right-hand view is with the scrollbar down.

**Integration**: Provides the means to select an integration, such as **g's-ips-mils** or **g's-ips-in**. Several other possibilities exist, as can be seen in the above images of the Integration Panel.

## Edit Menu > Configuration > Miscellaneous Tab: Low Frequency Cutoff Panel

Low frequency cutoff is used to remove the low frequency effects of integration. All data points that exist below the specified value are set to zero. When "Hz" is selected for the Acquisition Analysis Frequency via radio button on the Analyzer Tab, "Hz" appears on the Low Frequency Cutoff Panel (following figure, left image). When "CPM" is selected for the Acquisition Analysis Frequency via radio button on the Analyzer Tab, "Hz" appears on the Low Frequency via radio button on the Analyzer.



Low Frequency Cutoff Panel – 2 Views

Single (Hz):	Enter a value for the cutoff amount for single integration.
Double (Hz):	Enter a value for the cutoff amount for double integration.

## Edit Menu > Configuration > Miscellaneous Tab: Bank (Location) Panel

## Bank Location does not apply to eZ-PostView or to eZ-TimeView.

This panel relates to the Modal Locations window, which is accessed from *eZ-Analyst* Window's pulldown menu. The Bank (Location) Control Panel contains one check box and two radio buttons. Descriptions of each follow.

	Auto Bank Increase
7	with Automatic
	Saving Data
•	Response Increase
o	Reference Increase

**Bank (Location) Control Panel** 

Note: This option is only effective when the averaging mode is used.

Auto Bank Increase with Automatic Saving Data:	A Bank is a set of response channels. You can have <i>eZ-Analyst</i> increment the banks automatically after each measurement, or you can manually increment the banks. The number of active channels is used as the skip factor for bank switching.	
	If the Auto Bank Increase checkbox is checked, then the bank is automatically incremented, but only when the automatic saving data option is selected at Setup Export Function Data menu.	
Response Increase:	If the <i>Response Increase</i> radio-button is selected, the reference channel's location doesn't change. The response's location(s) are increased [or decreased] for next available location numbers.	
Reference Increase:	If the <i>Reference Increase</i> radio-button is selected, the response channel's location doesn't change. The reference's location(s) are increased [or decreased] for next available location numbers.	

**Note**: Decreasing location numbers are only available with the manual bank <Down> button on the Modal Locations window. Modal Locations is accessed from the Windows pull-down menu.

# *Edit Menu > Configuration > Miscellaneous Tab:* <u>dB Reference (Volt) Panel</u> dBReference (Volt) does not apply to eZ-PostView or to eZ-TimeView.

dBReference (Volt) is applied to all channels of displayed data when the Y-axis scale is set to dB and EU/Volt mode set to Volt. This is valid only for frequency domain data.



dB Reference (Volt) Panel



Reference Note: The dB EU Reference Volt column is in the Input Channels Tab.

# Edit Menu >



## **Plot Window Colors**

Plot window defaults are:	The four possible types of cursor are:
Frame Border = Grey	Single cursor
Plot Background = Black	Second cursor of band cursors
Grid Lines = Grey	Peak Search cursor
Cursor = White	Data List

- 1. To change a Plot Window display color, click on the button that applies to the display characteristic, for example, <Plot Background>.
- 2. Click <OK>. The Color Palette will open.



Color Palette

- 3. Select a color by clicking on a color square, or by defining a Custom Color.
- 4. Click <OK>.
- 5. Repeat steps 1 through 4 for each Plot Window color that you want to change.
- 6. When finished, click <OK> in Colors [Color Palette] window.

# Edit Menu >

The Preferences window provides a means of setting several options.

Preferences	
Trace Colors < 234	5 6 7 8 5 11 12 13 14 15 16 > Change Now
Label Colors Background	Foreground
Cursor Movement Control	Pick/Drag 🔿 Pick Only 🔿 Drag Only
Export Funcitons 🔽 Warning Measurer	on Non-Saved Averaged Lower Frequency Cutoff
Recall Plot Setup When Recal	I Data Files C Zero Data
- Channel Status Window	
- Alwans	C Percentage(%) FSV 📕 Maximum 📕 Current 📕
Top • Volt	
Peak Search Options	
Peak Search Options	.0000 Band (+-Bin) 3 Sort By: C Frequency/Time C Data Value

Preferences

Trace Colors:	Defines colors for traces. Click on a channel's color chip to open a color palette. Pick a new color, then click <ok>.</ok>			
Labels Colors:	Defines colors for <i>on-plot</i> text labels. Click on a color chip to open a color palette. Pick a new color, then click <ok>.</ok>			
Monitor Window:	Sets how the monitor window displays information.			
Cursor Movement Control:	<ul> <li>Sets the cursor's action. Options are: <i>Pick/Drag</i>, <i>Pick Only</i>, and <i>Drag Only</i>.</li> <li>Pick/Drag: Makes use of both the Pick Mode and the Drag Mode.</li> <li>Pick Only: Clicking the left mouse button allows the cursor to move instantaneously with the band cursor. The chosen cursor moves to the location when the mouse is clicked.</li> <li>Drag Only: Move the mouse pointer to the cursor location. The pointer will change to a "Left and Right Arrow." Click and drag the cursor to the designated location.</li> </ul>			
Export Functions:	<b>Warning on Non-Saved Averaged Measurement</b> : If the associated check-box is selected, a warning message box displays to notify you when averaged data is not being saved. The message repeats each time an averaged data measurement is not saved.			
Export Functions	selected, a warning message box displays to notify you when averaged data is not being saved. The message repeats each time an averaged data measurement is not saved.			
Export Functions do not apply to <i>eZ-PostView</i> .	<ul> <li>selected, a warning message box displays to notify you when averaged data is not being saved. The message repeats each time an averaged data measurement is not saved.</li> <li>Lower Cutoff Frequency (Hz): Used to set the value for minimum frequency for processing data and plotting. The feature is useful in eliminating unwanted DC or low-frequency components.</li> </ul>			
Export Functions do not apply to <i>eZ-PostView</i> .	<ul> <li>selected, a warning message box displays to notify you when averaged data is not being saved. The message repeats each time an averaged data measurement is not saved.</li> <li>Lower Cutoff Frequency (Hz): Used to set the value for minimum frequency for processing data and plotting. The feature is useful in eliminating unwanted DC or low-frequency components.</li> <li>Skip Data – activate this radio button to make <i>eZ-Analyst</i> skip all the data that exists below the cutoff frequency.</li> </ul>			
Export Functions do not apply to <i>eZ-PostView</i> .	<ul> <li>selected, a warning message box displays to notify you when averaged data is not being saved. The message repeats each time an averaged data measurement is not saved.</li> <li>Lower Cutoff Frequency (Hz): Used to set the value for minimum frequency for processing data and plotting. The feature is useful in eliminating unwanted DC or low-frequency components.</li> <li>Skip Data – activate this radio button to make <i>eZ-Analyst</i> skip all the data that exists below the cutoff frequency.</li> <li>Zero Data – activate this radio button to have <i>eZ-Analyst</i> use a value of "0" to override all data that exists below the cutoff frequency.</li> </ul>			

Channel Status Window:	In the Channel Status Window, the x-axis is used to indicate Channels, and the y-axis to indicate Volts. (Note 1).		
	This section of the Preferences Window allows you to select display preferences for the Channel Status Window's bar-graph. The user can select to display volts in one of three formats: linear, logarithmic, or percent of Full-Scale Voltage (FSV). You can adjust status-related colors via the three color tiles labeled: FSV, Maximum, and Current.		
	<b>Note 1</b> : The Channel Status window is accessed by selecting "Channel Monitor" from <i>eZ-Analyst</i> Windows pull-down menu.		
Peak Search Options:	Peak averages are evaluated by first finding a peak and then averaging the specified number of spectral lines on either side of the peak. This section of the window is used to set the preferences regarding peak search. Options are as follows:		
	Minimum:	Used to set the Minimum threshold value for peak searching, i.e., the lowest value of data to be considered for the search. "Minimum is typically set above the extraneous noise level.	
	<b>Band (+ - Bin)</b> : [Peak Search]	Sets the <i>eZ-Analyst</i> to search data, according to a cursor- selected range (band). The band takes into account the Minimum threshold value for peak searching, if defined. The default setting for <b>Band</b> (+- <b>Bin</b> ) is 3. This number specifies the number of data bins used for peak searching. For example, "3" indicates that the peak value will be searched at the current cursor position and the $\pm$ 3 adjacent positions.	
	Sort By:	Specifies the order of the data in the peak search table. Sorting will be done by <i>Frequency/Time</i> , or by <i>Data Value</i> .	
	Peak Pick: Band (+ - Bin):	This mode sets the system to search for a peak within the pre- defined band (data range) only when the cursor is moved, or clicked. This is a manual method, when compared with Auto- Tracking.	
	Auto Tracking	Selects Cursor-1 and/or Cursor-2 to automatically search for peaks. The feature makes use of range definitions for "+" and "-" Bin numbers, for example: $\pm 5$ indicates that the peak value will be searched at the current cursor position and the $\pm 5$ adjacent positions. The cursor automatically moves to the peak position within the specified range.	



### Accelerometer

A type of transducer that produces an output voltage proportional to acceleration.

### Acquisition

A collection of scans acquired at a specified rate as controlled by the sequencer.

### Analog Signal

A signal of varying voltage or current, resistance, temperature such as the output of a sensor. Many analog signals are in the form of sine waves.

### **Apparent Mass**

Force/Acceleration. A *transfer type* that is the reciprocal function of Inertance. Apparent Mass is derived by taking the inverse of the magnitude, and multiplying the phase angle by "-1."

### **Auto-Spectrum Function**

A single-channel display function. Displays the square of the magnitude of the complex (one-side) Fourier spectrum of x(t). Autospectra are calibrated so that if A is the peak amplitude of a sinusoidal signal x(t), then the autospectrum has the value A\*A (or use A power 2) at the sinusoidal frequency.

### **Averaged Time Function**

A single-channel display function. Displays a time domain waveform of filtered, averaged, sampled data scaled in either Volts or Engineering Units (EUs).

### Bank

A set of response channels.

### **Blackman-Harris**

An FFT window function. This window function was designed to provide the minimum side lobe level of any three-term window. Compared with the very similar Hanning window, it has a slightly wider main lobe but much better dynamic range. This window has the smallest 60 dB bandwidth of any window listed. The Blackman-Harris window may be preferred over the Hanning for measurements requiring better dynamic range.

### Channel

A single *input*, or *output* for the acquisition device. In a broader sense, an *input channel* is a signal path between the transducer at the point of measurement and the data acquisition system. A channel can go through various stages (buffers, multiplexers, or signal conditioning amplifiers and filters). Input channels are periodically sampled for readings. An *output channel* from a device can be digital or analog. Outputs can vary in a programmed way in response to an input channel signal.

### **Coherence Function**

A dual-channel display function. At each frequency, the coherence is a value between 0.0 and 1.0, which indicates the degree of consistent linear relationship between two signals during the averaging process. A value of less than one indicates that phase cancellation occurred during cross-spectrum averaging, which may be due to uncorrelated noise on one or both signals or to a nonlinear relationship between signals.

### Compliance, also referred to as Receptance

Displacement/Force. The *transfer type* function is calculated by dividing the *cross spectrum* of the channel pair by the *auto spectrum* of the reference (force) channel.

### СРМ

Cycles per Minute. 60 CPM is equal to 1 Hz.

### **Cross Spectrum Function, or Cross Function**

A dual-channel display function in the frequency domain. It is equal to the product of the complex Fourier spectrum of y(t) (the numerator or first named channel) times the complex conjugate of the Fourier spectrum of x(t) (the denominator or second named channel). The special case y=x yields the auto spectrum. Averaging of these functions (frequency-domain averaging) forms the basic foundation on which virtually all other multi-channel, frequency-domain analysis is built. The cross spectrum is calibrated in units of (peak EUy) (peak EUx).

## Crosstalk

An undesired transfer of signals between system components or channels. Crosstalk often causes signal interference, more commonly referred to as *noise*.

## dB

Decibels. A logarithmic unit of amplitude for noise or vibration. While there are several definitions to dB, in our application we are using dB to express the ratio of the magnitudes of two quantities equal to 20 times the common logarithm of the ratio.

## dB = 20 log (x/dBEUref)

In this equation, "x" refers to the value of the voltage being measured and "dBEUref" refers to the reference voltage.

## Decay %

Decay %, also referred to as Response Decay Percent, is used when an Exponential Window is applied to the FFT Response Channel. It is the weighting factor present at the last block value. For example, a decay of 5% means that the weighting factor at the beginning of block is 100% and that the weighting factor of the last block is 5%. In other words, the weighting factor dropped (decayed) to 5% over the length of block.

## Digital

A digital signal is one of discrete value, in contrast to a varying signal. Digital data is represented by combinations of binary digits (0s and 1s).

## **Dynamic Stiffness**

Force/Displacement. A *transfer type* that is the reciprocal function of Receptance. Dynamic Stiffness is derived by taking the inverse of the magnitude, and multiplying the phase angle by "-1."

## EU

Engineering Unit.

### Excitation

Some transducers [e.g. strain gages, thermistors, and resistance temperature detectors (RTDs)] require a known voltage or current input in order for the sensor to operate. This known input is called the Excitation.

### **Exponential Weighting Window**

An exponential weighting window is equal to 1.0 at the beginning of the block and decays exponentially to a smaller value at the end of the block (see *Decay* %). Exponential is used only with transient data that is captured with pre-trigger to assure that the initial values in all data channels are very close to zero. Exponential can be used with all transient excitation methods in order to force the signals to decay close to zero, even if the block length is not sufficient to capture all of the naturally occurring response. If the data decays naturally to a low amplitude [within the block], so that leakage is not significant, exponential windowing can improve the signal-to-noise ratio by giving reduced weight to the very low-amplitude data at the end of the block.

## Fast Fourier Transform (FFT)

An efficient technique for calculating the frequency of components in a time-domain waveform based on digitized voltage measurements. The result is a display of amplitude versus frequency and phase versus frequency.

**Fast Fourier Transform (FFT) Reference Window** is applied to the output of a transducer to avoid collecting extraneous signals caused by an excitation device, such as an impulse hammer. Possible selections are: Response, Rectangular, and Cosine Taper.

## Fast Fourier Transform (FFT) Response Window

The FFT (Response) window is a time-domain, weighting window. A response window is usually applied to data to reduce FFT leakage errors. FFT theory assumes that the signal being analyzed is periodic in the data acquisition block. When this is not the case, energy from a signal at a specified frequency can leak into nearby spectral bins causing spectral amplitude inaccuracies. Applying a windowing function controls, but doesn't completely eliminate, the error by multiplying each data frame by a suitable time-domain weighting window. This calculation reduces the amplitude/magnitude of the data near the ends of each data frame prior to performing the FFT and forces the data to be nearly periodic in the window, thus reducing leakage errors. Response window options include Flat-Top, Blackman-Harris, and Hanning.

### Flat-Top Window, also written as Flattop Window

An FFT window function that provides accurate measurement of peak-amplitude. Compared to the very similar 4-term "Max Flat Top," this window also has a very low peak amplitude error, and its frequency resolution is somewhat better. Its side lobes are considerably higher. Its effective noise bandwidth is still almost twice that of the Hanning window, therefore this window is used mainly to measure accurate peak amplitudes of discrete spectral components that are known to be separated by several spectral lines.

### Free Run (Free Running)

A state in which a data acquisition device acquires the next block of data when it has finished the previous block. Free Run is a continuous collection of data, with a constant display update.

### **Frequency-Domain**

A domain where amplitudes are graphed in relation to frequency. Also see *Time-Domain*.

### **FRF** (Frequency Response Function)

A dual-channel function for the single-input, single-output (SISO) frequency response function between two specified input channels. FRF is the averaged cross-spectrum divided by the averaged autospectrum of the input (the second named channel).

### FSV (Full Scale Volts)

Maximum FSV refers to the high-end limit for the input voltage. Minimum FSV is the low-end limit for the input voltage.

## g

Acceleration due to gravity. In relation to earth's gravity,  $1 g = 980 \text{ cm/sec}^2$ , or  $32.2 \text{ ft/sec}^2$ .

### Gain

The degree to which a signal is amplified (or attenuated) to allow greater accuracy and resolution; can be expressed as  $\times n$  or  $\pm dB$ .

### Hanning

An FFT window function. The Hanning window is typically used to analyze continuous signals. The Hanning function reduces leakage and provides a relatively good compromise between frequency resolution and amplitude accuracy.

## Hz

Hertz, one cycle per second. Also, see CPM.

### Impedance

Force/Velocity. A *transfer type* that is the reciprocal function of Receptance. Impedance is derived by taking the inverse of the magnitude, and multiplying the phase angle by "-1."

### Inertance

Acceleration/Force. The *transfer type* function is calculated by dividing the *cross spectrum* of the channel pair by the *auto spectrum* of the reference (force) channel.

### Integration/Differentiation

Integration/Differentiation is for display purpose only and does not modify the data. It is only active when frequency domain data is displayed. Select single or double integration, single or double differentiation or none. Make your selection on the popup menu. Differentiation and Integration are calculated by dividing each element of the function by  $(jw)^n$ , where j is the square root of -1; w is the product of 2 pi times the frequency of the block element; and n is an integer from +2 to -2.

- **n** = 2 is double integration
- **n** = 1 is single integration
- n = 0 has not effect
- n = -1 is single differentiation
- n = -2 is double differentiation.

*If the signal is acceleration*, then single integration (Int1) results in velocity, and double integration (Int2) results in displacement.

*If the signal is displacement*, then single differentiation (Diff1) results in velocity, and double differentiation (Diff2) results in acceleration.
#### Isolation

The arrangement or operation of a circuit so that signals from another circuit or device do not affect the *isolated* circuit. *Isolation* usually refers to a separation of the direct link between the signal source and the analog-to-digital converter (ADC). Isolation is necessary when measuring high common-mode voltage.

#### Leakage

Leakage refers to an error in the FFT process due to the use of finite time blocks that do not match at the blocks' ends. At lower amplitudes, leakage results in a smearing of frequency lines. FFT window functions, such as Hanning, can be used to minimize the error that is introduced by leakage.

#### Linearization

Some transducers produce a voltage in linear proportion to the condition measured. Other transducers (e.g., thermocouples) have a nonlinear response. To convert nonlinear signals into accurate readings requires software to calibrate several points in the range used and then interpolate values between these points.

#### Mobility

Velocity/Force. The *transfer type* function is calculated by dividing the *cross spectrum* of the channel pair by the *auto spectrum* of the reference (force) channel.

#### Nyquist Plot

A Nyquist plot is one method used to simultaneously display real and imaginary data. The real numbered data is plotted on the X-axis and the imaginary numbered data is plotted on the Y-axis. Line segments are used to join consecutive points. From the perspective of basic vibration theory, a Nyquist plot of a mobility function should trace out a circle (counter-clockwise) as frequency is increased through an isolated structural resonance.

#### Octave

The interval between two frequencies, where one frequency is twice the value of the other. For example, frequencies of 500 Hz and 1 kHz are one octave apart; and 1 kHz and 2kHz are one octave apart. Many sounds are broad band, having components that are continuously distributed over a range of frequencies. The spectrum of such a sound can be approximated in terms of a series of octave band or one-third octave band pressure levels. A band is designated by its center frequency,  $f_0$ , which is the geometric mean of the upper and lower frequencies of the band. (See ANSI/ASC S1.6-1984.)

#### **PSD Function**

Power Spectral Function. A single-channel display function. It is the Fourier Transform of the Autocorrelation function. This normalization should be used with continuous random signals.

#### **Receptance**, *also referred to as* **Compliance**

Displacement/Force. The *transfer type* function is calculated by dividing the *cross spectrum* of the channel pair by the *auto spectrum* of the reference (force) channel.

#### **Response Decay Percent**

See Decay %.

#### Sample (reading)

The signal value that is observed on a channel at an instant in time. When triggered, the analog-to-digital converter [of the data acquisition device] reads the channel and converts the sampled value into a digital representation.

#### Scan

A series of measurements across a pre-selected sequence of channels.

#### **Spectrum Function**

A dual-channel display function. Displays averaged linear spectrum computed as the square root of the averaged autospectrum. This function is calibrated in peak engineering units (EU).

#### **Time-Domain**

A domain where amplitudes are graphed in relation to time. Also see Frequency-Domain.

#### Time Function:

A single-channel display function. Displays a time domain waveform of filtered, sampled data scaled in either Volts or Engineering Units (EUs).

#### **Transfer Type Functions**

Functions that are calculated by dividing the *cross spectrum* of the channel pair by the *auto spectrum* of the reference (force) channel. The following are transfer type functions: Inertance (acceleration/force), Mobility (velocity/force), and Receptance or Compliance (displacement/force). Reciprocal functions can be derived by taking the inverse of the magnitude, and multiplying the phase angle by "-1." Apparent Mass (force/acceleration), Impedance (force/velocity), and Dynamic Stiffness (force/displacement) are reciprocal functions of Inertance, Mobility, and Receptance, respectively.

**Note**: *Transfer function displays* assume that the reference channel is a force channel. You MUST define the response channels to be the correct type of data (acceleration, velocity, or displacement) that you are acquiring. These are defined in the data type column of the Calibration window. This allows the data to be integrated or differentiated correctly to derive the desired transfer function.

#### Trigger

An event to start a scan or mark an instant during an acquisition. A trigger can be a TTL signal, a specified signal level, a button manually or mechanically engaged, or a software command.

#### **Unaveraged Spectrum**

A display function of the magnitude of instantaneous unaveraged spectrum.

#### Windowed Time

Time data which determined by the FFT Response window; specified in the Miscellaneous Tab (of the Configuration window).



## WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **13 months** from date of purchase. OMEGA Warranty adds an additional one (1) month grace period to the normal **one (1) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit should malfunction, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of being damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components which wear are not warranted, including but not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by it will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

### **RETURN REQUESTS/INQUIRIES**

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting OMEGA:

- 1. P.O. number under which the product was PURCHASED,
- 2. Model and serial number of the product under warranty, and
- 3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

- 1. P.O. number to cover the COST of the repair,
- 2. Model and serial number of the product, and
- 3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 1996 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without prior written consent of OMEGA ENGINEERING, INC.

# Where Do I Find Everything I Need for Process Measurement and Control? OMEGA...Of Course! Shop online at omega.com

### **TEMPERATURE**

- Itermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- ☑ Wire: Thermocouple, RTD & Thermistor
- Calibrators & Ice Point References
- Recorders, Controllers & Process Monitors
- Infrared Pyrometers

### **PRESSURE, STRAIN AND FORCE**

- Transducers & Strain Gages
- 🕑 Load Cells & Pressure Gages
- Displacement Transducers
- Instrumentation & Accessories

### **FLOW/LEVEL**

- 🗹 Rotameters, Gas Mass Flowmeters & Flow Computers
- 🗹 Air Velocity Indicators
- Turbine/Paddlewheel Systems
- Totalizers & Batch Controllers

### pH/CONDUCTIVITY

- PH Electrodes, Testers & Accessories
- Benchtop/Laboratory Meters
- Controllers, Calibrators, Simulators & Pumps
- Industrial pH & Conductivity Equipment

### DATA ACQUISITION

- ☑ Data Acquisition & Engineering Software
- Communications-Based Acquisition Systems
- Plug-in Cards for Apple, IBM & Compatibles
- Datalogging Systems
- Recorders, Printers & Plotters

### **HEATERS**

- 🕑 Heating Cable
- Cartridge & Strip Heaters
- Immersion & Band Heaters
- Flexible Heaters
- Laboratory Heaters

### ENVIRONMENTAL MONITORING AND CONTROL

- Metering & Control Instrumentation
- Refractometers
- Pumps & Tubing
- 🗹 Air, Soil & Water Monitors
- 🗹 Industrial Water & Wastewater Treatment
- PH, Conductivity & Dissolved Oxygen Instruments