

# User's Guide



**Shop online at**

***www.omega.com***

***e-mail: info@omega.com***



## **OME-PIO-DA16/DA8/DA4 PCI-Bus Analog Output Board Software Manual**



**OMEGAnet® Online Service**  
**www.omega.com**

**Internet e-mail**  
**info@omega.com**

### **Servicing North America:**

**USA:**  
ISO 9001 Certified

One Omega Drive, P.O. Box 4047  
Stamford CT 06907-0047  
TEL: (203) 359-1660 FAX: (203) 359-7700  
e-mail: info@omega.com

**Canada:**

976 Bergar  
Laval (Quebec) H7L 5A1, Canada  
TEL: (514) 856-6928 FAX: (514) 856-6886  
e-mail: info@omega.ca

### **For immediate technical or application assistance:**

**USA and Canada:** Sales Service: 1-800-826-6342 / 1-800-TC-OMEGA®  
Customer Service: 1-800-622-2378 / 1-800-622-BEST®  
Engineering Service: 1-800-872-9436 / 1-800-USA-WHEN®  
TELEX: 996404 EASYLINK: 62968934 CABLE: OMEGA

**Mexico:**

En Español: (001) 203-359-7803 e-mail: espanol@omega.com  
FAX: (001) 203-359-7807 info@omega.com.mx

### **Servicing Europe:**

**Benelux:**

Postbus 8034, 1180 LA Amstelveen, The Netherlands  
TEL: +31 (0)20 3472121 FAX: +31 (0)20 6434643  
Toll Free in Benelux: 0800 0993344  
e-mail: sales@omegaeng.nl

**Czech Republic:**

Frystatska 184, 733 01 Karviná, Czech Republic  
TEL: +420 (0)59 6311899 FAX: +420 (0)59 6311114  
Toll Free: 0800-1-66342 e-mail: info@omegashop.cz

**France:**

11, rue Jacques Cartier, 78280 Guyancourt, France  
TEL: +33 (0)1 61 37 29 00 FAX: +33 (0)1 30 57 54 27  
Toll Free in France: 0800 466 342  
e-mail: sales@omega.fr

**Germany/Austria:**

Daimlerstrasse 26, D-75392 Deckenpfronn, Germany  
TEL: +49 (0)7056 9398-0 FAX: +49 (0)7056 9398-29  
Toll Free in Germany: 0800 639 7678  
e-mail: info@omega.de

**United Kingdom:**

ISO 9002 Certified

One Omega Drive, River Bend Technology Centre  
Northbank, Irlam, Manchester  
M44 5BD United Kingdom  
TEL: +44 (0)161 777 6611 FAX: +44 (0)161 777 6622  
Toll Free in United Kingdom: 0800-488-488  
e-mail: sales@omega.co.uk

---

It is the policy of OMEGA to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct, but OMEGA Engineering, Inc. accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

**WARNING:** These products are not designed for use in, and should not be used for, patient-connected applications.

# OME-PIO-DA

---

## Software Manual

[For Windows 95/98/NT/2000]

## Table of Contents

<b>1.</b>	<b>INTRODUCTION.....</b>	<b>4</b>
<b>2.</b>	<b>DECLARATION FILES .....</b>	<b>5</b>
2.1	PIODA.H.....	6
2.2	PIODA.BAS.....	9
2.3	PIODA.PAS .....	13
<b>3.</b>	<b>DEMO RESULT .....</b>	<b>19</b>
<b>4.</b>	<b>FUNCTION DESCRIPTIONS .....</b>	<b>22</b>
4.1	TEST FUNCTIONS.....	23
4.1.1	PIODA_GetDllVersion.....	23
4.1.2	PIODA_ShortSub .....	23
4.1.3	PIODA_FloatSub.....	25
4.2	I/O FUNCTIONS .....	26
4.2.1	PIODA_OutputByte .....	26
4.2.2	PIODA_InputByte .....	26
4.2.3	PIODA_OutputWord .....	28
4.2.4	PIODA_InputWord.....	28
4.2.5	PIODA_DO.....	30
4.2.6	PIODA_DI.....	30
4.3	DRIVER FUNCTIONS .....	32
4.3.1	PIODA_GetDriverVersion.....	32
4.3.2	PIODA_DriverInit .....	32
4.3.3	PIODA_DriverClose.....	34
4.3.4	PIODA_GetConfigAddressSpace.....	34
4.3.5	PIODA_GetBaseAddress.....	36
4.3.6	PIODA_SearchCard .....	36
4.3.7	PIODA_SetCounter .....	37
4.4	EEPROM FUNCTIONS.....	38
4.4.1	PIODA_EEP_Read.....	38
4.4.2	PIODA_EEP_Write.....	38
4.4.3	PIODA_EEP_WR_EN.....	40
4.4.4	PIODA_EEP_WR_DIS .....	40
4.5	DA FUNCTIONS .....	41
4.5.1	PIODA_Voltage.....	41

4.5.2	PIODA_Current.....	41
4.5.3	PIODA_CalVoltage.....	43
4.5.4	PIODA_CalCurrent.....	43
4.6	INTERRUPT FUNCTIONS.....	44
4.6.1	PIODA_IntInstall.....	44
4.6.2	PIODA_IntRemove.....	45
4.6.3	PIODA_IntGetCount.....	46
4.6.4	PIODA_IntResetCount.....	46
4.6.5	Architecture of Interrupt mode.....	47
<b>5.</b>	<b>PROGRAM ARCHITECTURE.....</b>	<b>49</b>
<b>6.</b>	<b>CONTACT US.....</b>	<b>50</b>

# 1. Introduction

The software is a collection of digital I/O subroutines for the OME-PIO-DIO series add-on cards for Windows 95/98/NT/2000 applications. These subroutines are written with C language and perform a variety of digital I/O operations.

The subroutines in PIODA.DLL are user friendly. It provides powerful, easy-to-use subroutine for developing your data acquisition application. Your program can call these DLL functions by VC++, VB, Delphi, and BORLAND C++ Builder easily. To speed-up your developing process, some demonstration source program are provided.

Please refer to the following user manuals:

- **PnPInstall.pdf:**

To install the PnP (Plug and Play) driver for PCI card under Windows 95/98.

- **SoftInst.pdf:**

To install the software package under Windows 95/98/NT/2000.

- **CallDll.pdf:**

To call the DLL functions with VC++5, VB5, Delphi3 and Borland C++ Builder 3.

- **ResCheck.pdf:**

To check the resources I/O Port address, IRQ number and DMA number for add-on cards under Windows 95/98/NT/2000.

- **OME-PIO-DAHW.pdf:**

OME-PIO-DA16/DA8/DA4 Hardware manual.

## 2. Declaration Files

--\Driver	← some device driver
--\BCB3	← for Borland C++ Builder 3
--\PIODA.H	← Header file
+--\PIODA.LIB	← Linkage library for BCB3 only
--\Delphi3	← for Delphi 3
+--\PIODA.PAS	← Declaration file
--\VB5	← for Visual Basic 5
+--\PIODA.BAS	← Declaration file
+--\VC5	← for Visual C++ 5
--\PIODA.H	← Header file
+--\PIODA.LIB	← Linkage library for VC5 only

## 2.1 PIODA.H

```
#ifdef __cplusplus
    #define EXPORTS extern "C" __declspec (dllimport)
#else
    #define EXPORTS
#endif

// return code
#define PIODA_NoError                0
#define PIODA_DriverOpenError       1
#define PIODA_DriverNoOpen          2
#define PIODA_GetDriverVersionError 3
#define PIODA_InstallIrqError       4
#define PIODA_ClearIntCountError    5
#define PIODA_GetIntCountError      6
#define PIODA_RegisterApcError      7
#define PIODA_RemoveIrqError        8
#define PIODA_FindBoardError        9
#define PIODA_ExceedBoardNumber    10
#define PIODA_ResetError            11

#define PIODA_EEPROMDataError       12
#define PIODA_EEPROMWriteError      13

// to trigger a interrupt when high -> low
#define PIODA_ActiveLow              0
// to trigger a interrupt when low -> high
#define PIODA_ActiveHigh             1

// ID
#define PIO_DA                        0x800400

// Test functions
EXPORTS float        CALLBACK PIODA_FloatSub(float fA, float fB);
```



```

EXPORTS short      CALLBACK PIODA_ShortSub(short nA, short nB);
EXPORTS WORD      CALLBACK PIODA_GetDllVersion(void);

// Driver functions
EXPORTS WORD      CALLBACK PIODA_DriverInit(void);
EXPORTS void      CALLBACK PIODA_DriverClose(void);
EXPORTS WORD      CALLBACK PIODA_SearchCard
                  (WORD *wBoards, DWORD dwPIOCardID);
EXPORTS WORD      CALLBACK PIODA_GetDriverVersion
                  (WORD *wDriverVersion);
EXPORTS WORD      CALLBACK PIODA_GetConfigAddressSpace
                  (WORD wBoardNo,  DWORD *wAddrBase, WORD *wIrqNo,
                  WORD *wSubVendor, WORD *wSubDevice, WORD *wSubAux,
                  WORD *wSlotBus,  WORD *wSlotDevice );
EXPORTS WORD      CALLBACK PIODA_ActiveBoard( WORD wBoardNo );
EXPORTS WORD      CALLBACK PIODA_WhichBoardActive(void);
EXPORTS WORD      CALLBACK PIODA_SetCounter(WORD wBoardNo,
                  WORD wWhichCounter, WORD bConfig, DWORD wValue);
EXPORTS DWORD     CALLBACK PIODA_GetBaseAddress
                  (WORD wBoardNo);

// EEPROM functions
EXPORTS WORD      CALLBACK PIODA_EEP_READ
                  (WORD wBoardNo, WORD wOffset, WORD *bHi, WORD *bLo);
EXPORTS WORD      CALLBACK PIODA_EEP_WR_EN(WORD wBoardNo);
EXPORTS WORD      CALLBACK PIODA_EEP_WR_DIS(WORD wBoardNo);
EXPORTS WORD      CALLBACK PIODA_EEP_WRITE
                  (WORD wBoardNo, WORD wOffset, WORD HI, WORD LO);

// DA functions
EXPORTS WORD      CALLBACK PIODA_Voltage
                  (WORD wBoardNo, WORD wChannel, float fValue);
EXPORTS WORD      CALLBACK PIODA_Current
                  (WORD wBoardNo, WORD wChannel, float fValue);
EXPORTS WORD      CALLBACK PIODA_CalVoltage
                  (WORD wBoardNo, WORD wChannel, float fValue);
EXPORTS WORD      CALLBACK PIODA_CalCurrent
                  (WORD wBoardNo, WORD wChannel, float fValue);

```

// DIO functions

```
EXPORTS void CALLBACK PIODA_OutputWord
    (DWORD wBaseAddress, DWORD wOutData);
EXPORTS void CALLBACK PIODA_OutputByte
    (DWORD wBaseAddress, WORD bOutputValue);
EXPORTS DWORD CALLBACK PIODA_InputWord
    (DWORD wBaseAddress);
EXPORTS WORD CALLBACK PIODA_InputByte(DWORD wBaseAddress);
EXPORTS WORD CALLBACK PIODA_DI
    (WORD wBoardNo, DWORD *wVal);
EXPORTS WORD CALLBACK PIODA_DO
    (WORD wBoardNo, DWORD wDO);
```

// Interrupt functions

```
EXPORTS WORD CALLBACK PIODA_IntInstall
    (WORD wBoardNo, HANDLE *hEvent,
     WORD wInterruptSource, WORD wActiveMode);
EXPORTS WORD CALLBACK PIODA_IntRemove(void);
EXPORTS WORD CALLBACK PIODA_IntResetCount(void);
EXPORTS WORD CALLBACK PIODA_IntGetCount(DWORD *dwIntCount);
```

## 2.2 PIODA.BAS

Attribute VB\_Name = "PIODA"

Global Const PIODA\_NoError = 0  
Global Const PIODA\_DriverOpenError = 1  
Global Const PIODA\_DriverNoOpen = 2  
Global Const PIODA\_GetDriverVersionError = 3  
Global Const PIODA\_InstallIrqError = 4  
Global Const PIODA\_ClearIntCountError = 5  
Global Const PIODA\_GetIntCountError = 6  
Global Const PIODA\_RegisterApcError = 7  
Global Const PIODA\_RemoveIrqError = 8  
Global Const PIODA\_FindBoardError = 9  
Global Const PIODA\_ExceedBoardNumber = 10  
Global Const PIODA\_ResetError = 11

Global Const PIODA\_EEPROMDataError = 12  
Global Const PIODA\_EEPROMWriteError = 13

' to trigger a interrupt when high -> low

Global Const PIODA\_ActiveLow = 0

' to trigger a interrupt when low -> high

Global Const PIODA\_ActiveHigh = 1

' ID

Global Const PIO\_DA = &H800400 ' OME-PIO-DA16/DA8/DA4

' The Test functions

Declare Function PIODA\_ShortSub Lib "PIODA.dll" \_  
    (ByVal a As Integer, ByVal b As Integer) As Integer

Declare Function PIODA\_FloatSub Lib "PIODA.dll" \_  
    (ByVal a As Single, ByVal b As Single) As Single

Declare Function PIODA\_GetDllVersion Lib "PIODA.dll" () As Integer

' The Driver functions

Declare Function PIODA\_DriverInit Lib "PIODA.dll" () As Integer

Declare Sub PIODA\_DriverClose Lib "PIODA.dll" ()

Declare Function PIODA\_SearchCard Lib "PIODA.dll" \_

(wBoards As Integer, ByVal dwPIOPISOCARDID As Long) As Integer

Declare Function PIODA\_GetDriverVersion Lib "PIODA.dll" \_

(wDriverVersion As Integer) As Integer

Declare Function PIODA\_GetConfigAddressSpace Lib "PIODA.dll" ( \_

ByVal wBoardNo As Integer, wAddrBase As Long, wlrqNo As Integer, \_  
wSubVendor As Integer, wSubDevice As Integer, wSubAux As Integer, \_  
wSlotBus As Integer, wSlotDevice As Integer) As Integer

Declare Function PIODA\_ActiveBoard Lib "PIODA.dll" \_

(ByVal wBoardNo As Integer) As Integer

Declare Function PIODA\_WhichBoardActive Lib "PIODA.dll" () As Integer

Declare Function PIODA\_SetCounter Lib "PIODA.dll" \_

(ByVal wBoardNo As Integer, ByVal wWhichCounter As Integer, \_  
ByVal bConfig As Integer, ByVal wValue As Long) As Long

Declare Function PIODA\_GetBaseAddress Lib "PIODA.dll" \_

(ByVal wBoardNo As Integer) As Long

' EEPROM functions

Declare Function PIODA\_EEP\_READ Lib "PIODA.dll" \_

(ByVal wBoardNo As Integer, ByVal wOffset As Integer, \_  
bHi As Integer, bLo As Integer) As Integer

Declare Function PIODA\_EEP\_WR\_EN Lib "PIODA.dll" \_

(ByVal wBoardNo As Integer) As Integer

Declare Function PIODA\_EEP\_WR\_DIS Lib "PIODA.dll" \_

(ByVal wBoardNo As Integer) As Integer

Declare Function PIODA\_EEP\_WRITE Lib "PIODA.dll" \_

(ByVal wBoardNo As Integer, ByVal wOffset As Integer, \_  
ByVal HI As Integer, ByVal LO As Integer) As Integer

' DA functions

Declare Function PIODA\_Voltage Lib "PIODA.dll" \_

(ByVal wBoardNo As Integer, ByVal wChannel As Integer, \_  
ByVal fValue As Single) As Integer

```
Declare Function PIODA_Current Lib "PIODA.dll" _  
    (ByVal wBoardNo As Integer, ByVal wChannel As Integer, _  
    ByVal fValue As Single) As Integer  
Declare Function PIODA_CalVoltage Lib "PIODA.dll" _  
    (ByVal wBoardNo As Integer, ByVal wChannel As Integer, _  
    ByVal fValue As Single) As Integer  
Declare Function PIODA_CalCurrent Lib "PIODA.dll" _  
    (ByVal wBoardNo As Integer, ByVal wChannel As Integer, _  
    ByVal fValue As Single) As Integer
```

' DIO functions

Declare Sub Pioda\_OutputByte Lib "PIODA.dll" \_  
    (ByVal wBaseAddress As Long, ByVal dataout As Integer)

Declare Sub Pioda\_OutputWord Lib "PIODA.dll" \_  
    (ByVal wBaseAddress As Long, ByVal dataout As Long)

Declare Function Pioda\_InputByte Lib "PIODA.dll" \_  
    (ByVal wBaseAddress As Long) As Integer

Declare Function Pioda\_InputWord Lib "PIODA.dll" \_  
    (ByVal wBaseAddress As Long) As Long

Declare Function Pioda\_DI Lib "PIODA.dll" \_  
    (ByVal wBoardNo As Integer, wVal As Long) As Integer

Declare Function Pioda\_DO Lib "PIODA.dll" \_  
    (ByVal wBoardNo As Integer, ByVal wDO As Long) As Integer

' Interrupt functions

Declare Function Pioda\_IntInstall Lib "PIODA.dll" \_  
    (ByVal wBoard As Integer, hEvent As Long, \_  
    ByVal wInterruptSource As Integer, \_  
    ByVal wActiveMode As Integer) As Integer

Declare Function Pioda\_IntRemove Lib "PIODA.dll" () As Integer

Declare Function Pioda\_IntResetCount Lib "PIODA.dll" () As Integer

Declare Function Pioda\_IntGetCount Lib "PIODA.dll" \_  
    (dwIntCount As Long) As Integer

## 2.3 PIODA.PAS

```
unit Pioda;      { Pioda.dll interface unit }
```

```
interface
```

```
const
```

```
PIODA_NoError           =0;
PIODA_DriverOpenError   =1;
PIODA_DriverNoOpen     =2;
PIODA_GetDriverVersionError =3;
PIODA_InstallIrqError   =4;
PIODA_ClearIntCountError =5;
PIODA_GetIntCountError  =6;
PIODA_RegisterApcError  =7;
PIODA_RemoveIrqError    =8;
PIODA_FindBoardError    =9;
PIODA_ExceedBoardNumber =10;
PIODA_ResetError       =11;
```

```
PIODA_EEPROMDataError   =12;
PIODA_EEPROMWriteError  =13;
```

```
// to trigger a interrupt when high -> low
```

```
PIODA_ActiveLow         =0;
```

```
// to trigger a interrupt when low -> high
```

```
PIODA_ActiveHigh       =1;
```

```
// ID
```

```
PIO_DA                  = $800400; // PIO-DA16/DA8/DA4
```

```
// Test functions
```

```
function Pioda_ShortSub(nA : smallint; nB : smallint) :smallint; StdCall;
```

```
function Pioda_FloatSub(fA : single; fB : single) :single; StdCall;
```

```
function Pioda_GetDllVersion : word; StdCall;
```

```

// Driver functions
function PIODA_DriverInit : word; StdCall;
procedure PIODA_DriverClose ; StdCall;
function PIODA_SearchCard
    (var wBoards:WORD; dwPIOPISOCARDID:LongInt):WORD; StdCall;
function PIODA_GetDriverVersion(var wDriverVer: word):WORD; StdCall;
function PIODA_GetConfigAddressSpace
    (wBoardNo:word; var wAddrBase:LongInt; var wIrqNo:word;
    var wSubVerdor:word; var wSubDevice:word; var wSubAux:word;
    var wSlotBus:word; var wSlotDevice:word ): word; StdCall;
function PIODA_ActiveBoard(wBoardNo:Word) :WORD; StdCall;
function PIODA_WhichBoardActive :WORD; StdCall;
function PIODA_SetCounter(wBoardNo:WORD; wWhichCounter:WORD;
    bConfig:WORD; wValue:LongInt): WORD; StdCall;
function PIODA_GetBaseAddress(wBoardNo:WORD):LongInt; StdCall;

// EEPROM functions
function PIODA_EEP_READ(wBoardNo:WORD; wOffset:WORD;
    var bHi:WORD; var bLo:WORD):WORD; StdCall;
function PIODA_EEP_WR_EN(wBoardNo:WORD):WORD; StdCall;
function PIODA_EEP_WR_DIS(wBoardNo:WORD):WORD; StdCall;
function PIODA_EEP_WRITE( wBoardNo:WORD; wOffset:WORD;
    HI:WORD; LO:WORD):WORD; StdCall;

// DA functions
function PIODA_Voltage
    (wBoardNo:WORD; wChannel:WORD; fValue:Single):WORD; StdCall;
function PIODA_Current
    (wBoardNo:WORD; wChannel:WORD; fValue:Single):WORD; StdCall;
function PIODA_CalVoltage
    (wBoardNo:WORD; wChannel:WORD; fValue:Single):WORD; StdCall;
function PIODA_CalCurrent
    (wBoardNo:WORD; wChannel:WORD; fValue:Single):WORD; StdCall;

// DIO functions
procedure PIODA_OutputByte
    (wBaseAddress :LongInt; bOutputVal :Word); StdCall;

```



procedure PIODA\_OutputWord

(wBaseAddress :LongInt; wOutputVal :LongInt); StdCall;

function PIODA\_InputByte(wBaseAddress :LongInt ) :word; StdCall;

function PIODA\_InputWord(wBaseAddress :LongInt ) :LongInt; StdCall;

function PIODA\_DI(wBoardNo:WORD; var wVal:LongInt) :word; StdCall;

function PIODA\_DO(wBoardNo:WORD; wDO:LongInt) :word; StdCall;

// Interrupt functions

```
function PIODA_IntInstall(wBoard:Word; var hEvent:LongInt;
    wInterruptSource:Word; wActiveMode:Word):Word; StdCall;
function PIODA_IntRemove : WORD; StdCall;
function PIODA_IntResetCount : WORD; StdCall;
function PIODA_IntGetCount(var dwIntCount:LongInt) : WORD; StdCall;
```

implementation

// Test functions

```
function PIODA_ShortSub;
    external 'PIODA.DLL' name 'PIODA_ShortSub';
function PIODA_FloatSub;
    external 'PIODA.DLL' name 'PIODA_FloatSub';
function PIODA_GetDllVersion;
    external 'PIODA.DLL' name 'PIODA_GetDllVersion';
```

// Driver functions

```
function PIODA_DriverInit;
    external 'PIODA.DLL' name 'PIODA_DriverInit';
procedure PIODA_DriverClose;
    external 'PIODA.DLL' name 'PIODA_DriverClose';
function PIODA_SearchCard;
    external 'PIODA.DLL' name 'PIODA_SearchCard';
function PIODA_GetDriverVersion;
    external 'PIODA.DLL' name 'PIODA_GetDriverVersion';
function PIODA_GetConfigAddressSpace;
    external 'PIODA.DLL' name 'PIODA_GetConfigAddressSpace';
```

```
function PIODA_ActiveBoard;
    external 'PIODA.DLL' name 'PIODA_ActiveBoard';
function PIODA_WhichBoardActive;
    external 'PIODA.DLL' name 'PIODA_WhichBoardActive';
function PIODA_SetCounter;
    external 'PIODA.DLL' name 'PIODA_SetCounter';
function PIODA_GetBaseAddress;
```

```
    external 'PIODA.DLL' name 'PIODA_GetBaseAddress';

// EEPROM functions
function PIODA_EEP_READ;
    external 'PIODA.DLL' name 'PIODA_EEP_READ';
function PIODA_EEP_WR_EN;
    external 'PIODA.DLL' name 'PIODA_EEP_WR_EN';
function PIODA_EEP_WR_DIS;
    external 'PIODA.DLL' name 'PIODA_EEP_WR_DIS';
function PIODA_EEP_WRITE;
    external 'PIODA.DLL' name 'PIODA_EEP_WRITE';
```


```
// DA functions
function PIODA_Voltage;
    external 'PIODA.DLL' name 'PIODA_Voltage';
function PIODA_Current;
    external 'PIODA.DLL' name 'PIODA_Current';
function PIODA_CalVoltage;
    external 'PIODA.DLL' name 'PIODA_CalVoltage';
function PIODA_CalCurrent;
    external 'PIODA.DLL' name 'PIODA_CalCurrent';

// DIO functions
procedure PIODA_OutputByte;
    external 'PIODA.DLL' name 'PIODA_OutputByte';
procedure PIODA_OutputWord;
    external 'PIODA.DLL' name 'PIODA_OutputWord';
function PIODA_InputByte;
    external 'PIODA.DLL' name 'PIODA_InputByte';
function PIODA_InputWord;
    external 'PIODA.DLL' name 'PIODA_InputWord';
function PIODA_DI;
    external 'PIODA.DLL' name 'PIODA_DI';
function PIODA_DO;
    external 'PIODA.DLL' name 'PIODA_DO';


// Interrupt functions
function PIODA_IntInstall;
    external 'PIODA.DLL' name 'PIODA_IntInstall';
function PIODA_IntRemove;
    external 'PIODA.DLL' name 'PIODA_IntRemove';
function PIODA_IntGetCount;
    external 'PIODA.DLL' name 'PIODA_IntGetCount';
function PIODA_IntResetCount;
    external 'PIODA.DLL' name 'PIODA_IntResetCount';

end.
```


### 3. Demo Result




Diagnostic Program




DA Demo for BCB 3




DI/DO Demo for Delphi 3



DI/DO Demo for VB 5



DI/DO Demo for VC 5



DA Demo for VC 5

## 4. Function Descriptions

In this chapter, we use some keywords to indicate the attribute of Parameters.

Keyword	User needs to Set parameter before calling this function?	User gets the data/value from this parameter after calling this function?
[Input]	Yes	No
[Output]	No	Yes
[Input, Output]	Yes	Yes

Note: All of the parameters need to be allocated spaces by the user.



## 4.1 Test Functions

---

### 4.1.1 PIODA\_GetDllVersion

- **Description:**  
To get the version number of PIODA.DLL
- **Syntax:**  
WORD PIODA\_GetDllVersion(Void)
- **Parameter:**  
None
- **Return:**  
200(hex) for version 2.00

---

### 4.1.2 PIODA\_ShortSub

- **Description:**  
To perform the subtraction as  $nA - nB$  in short data type. This function is provided for testing DLL linkage purpose.
- **Syntax:**

short PIODA\_ShortSub(short nA, short nB)

- **Parameter:**

nA       : [Input] 2 bytes short data type value

nB       : [Input] 2 bytes short data type value

- **Return:**

The value of nA - nB

### 4.1.3 PIODA\_FloatSub

- **Description:**

To perform the subtraction as  $fA - fB$  in float data type. This function is provided for testing DLL linkage purpose.

- **Syntax:**

float PIODA\_FloatSub(float fA, float fB)

- **Parameter:**

fA : [Input] 4 bytes floating point value  
fB : [Input] 4 bytes floating point value

- **Return:**

The value of  $fA - fB$

## 4.2 I/O Functions

---

### 4.2.1 PIODA\_OutputByte

- **Description :**

This subroutine will send the 8 bits data to the desired I/O port.

- **Syntax :**

```
void PIODA_OutputByte(DWORD wPortAddr, WORD bOutputVal);
```

- **Parameter :**

wPortAddr : [Input] I/O port addresses, please refer to function PIODA\_GetConfigAddressSpace.  
Only the low WORD is valid.

bOutputVal : [Input] 8 bit data send to I/O port.  
Only the low BYTE is valid.

- **Return:**

None

---

### 4.2.2 PIODA\_InputByte

- **Description :**

This subroutine will input the 8 bit data from the desired I/O port.

- **Syntax :**

```
WORD PIODA_InputByte(DWORD wPortAddr);
```

- **Parameter :**

wPortAddr : [Input] I/O port addresses, please refer to  
function

PIODA\_GetConfigAddressSpace().  
Only the low WORD is valid.

- **Return:**

16 bits data with the leading 8 bits are all 0.  
(Only the low BYTE is valid.)

### 4.2.3 PIODA\_OutputWord

- **Description :**

This subroutine will send the 16 bits data to the desired I/O port.

- **Syntax :**

```
void PIODA_OutputWord(DWORD wPortAddr, DWORD wOutputVal);
```

- **Parameter :**

wPortAddr : [Input] I/O port addresses, please refer to function PIODA\_GetConfigAddressSpace().

Only the low WORD is valid.

wOutputVal : [Input] 16 bit data send to I/O port.

Only the low WORD is valid.

- **Return:**

None

---

### 4.2.4 PIODA\_InputWord

- **Description :**

This subroutine will read the 16 bit data from the desired I/O port.

- **Syntax :**

```
DWORD PIODA_InputWord(DWORD wPortAddr);
```

- **Parameter :**

wPortAddr : [Input] I/O port addresses, please refer to  
function

PIODA\_GetConfigAddressSpace().  
Only the low WORD is valid.

- **Return:**

16 bit data. Only the low WORD is valid.

## 4.2.5 PIODA\_DO

- **Description :**

This subroutine will send the 16 bits data to the desired card.

- **Syntax :**

WORD PIODA\_DO(WORD wBoardNo, DWORD wDO);

- **Parameter :**

wBoardNo : [Input] Which board to active.

wDO : [Input] The 16-bit data to Digital-Output.  
Only the low WORD is valid.

- **Return:**

PIODA\_NoError : OK

---

## 4.2.6 PIODA\_DI

- **Description :**

This subroutine will read the 16 bit data from the desired card.

- **Syntax :**

WORD PIODA\_DI(WORD wBoardNo, DWORD \*wVal);

- **Parameter :**

wBoardNo : [Input] Which board to active.

wVal : [Output] Stores the Digital-Input value after



called this function.  
Only the low WORD is valid.

- **Return:**

PIODA\_NoError : OK

## 4.3 Driver Functions

---

### 4.3.1 PIODA\_GetDriverVersion

- **Description :**

This subroutine will read the version number of PIODA driver.

- **Syntax :**

WORD PIODA\_GetDriverVersion(WORD \*wDriverVersion);

- **Parameter :**

wDriverVersion : [Output] address of wDriverVersion

- **Return:**

PIODA\_NoError : OK

PIODA\_DriverNoOpen : The PIODA driver no open

PIODA\_GetDriverVersionError : Read driver version error

---

### 4.3.2 PIODA\_DriverInit

- **Description :**

This subroutine will open the PIODA driver and allocate the resource for the device. This function must be called once before calling other PIODA functions.

- **Syntax :**

WORD PIODA\_DriverInit();

- **Parameter :**

None

- **Return:**

PIODA\_NoError : OK

PIODA\_DriverOpenError : open PIODA Driver error

### 4.3.3 PIODA\_DriverClose

- **Description :**

This subroutine will close the PIODA Driver and release the resources from the device. This function must be called once before exiting the user's application.

- **Syntax :**

```
void PIODA_DriverClose();
```

- **Parameter :**

None

- **Return:**

None

---

### 4.3.4 PIODA\_GetConfigAddressSpace

- **Description :**

Get the I/O address of PIODA board n.

- **Syntax :**

```
WORD PIODA_GetConfigAddressSpace
    ( WORD wBoardNo,  DWORD *wAddrBase,  WORD *wIrqNo,
      WORD *wSubVendor, WORD *wSubDevice,  WORD *wSubAux,
      WORD *wSlotBus,  WORD *wSlotDevice);
```

- **Parameter :**

wBoardNo : [Input] PIODA board number

wAddrBase : [Output] The base address of PIODA board.

Only the low WORD is valid.

wIrqNo : [Output] The IRQ number that the PIODA board using.  
wSubVendor : [Output] Sub Vendor ID.  
wSubDevice : [Output] Sub Device ID.  
wSubAux : [Output] Sub Aux ID.  
wSlotBus : [Output] Slot Bus number.  
wSlotDevice : [Output] Slot Device ID.

● **Return:**

PIODA\_NoError : OK  
PIODA\_FindBoardError : handshake check error  
PIODA\_ExceedBoardError : wBoardNo is invalidated

## 4.3.5 PIODA\_GetBaseAddress

- **Description :**

Get the I/O address of PIODA board n.

- **Syntax :**

DWORD PIODA\_GetBaseAddress( WORD wBoardNo);

- **Parameter :**

wBoardNo : [Input] PIODA board number

- **Return:**

0 : Error

Other values : The base-address of that board.

---

## 4.3.6 PIODA\_SearchCard

- **Description :**

Search the cards by specified Card-ID. This function will automatically read the EEPROM data for each board that found. And will automatically enable the each board.

- **Syntax :**

WORD PIODA\_SearchCard(WORD \*wBoards, DWORD dwPIOCardID);

- **Parameter :**

wBoards : [Output] How many cards be found.

dwPIOCardID : [Input] What kinds of card to find?

The user must fill this with PIO\_DA.

- **Return:**

PIODA\_NoError : OK

## 4.3.7 PIODA\_SetCounter

- **Description :**

Set the value to the specified Counter for the Interrupt using.

- **Syntax :**

```
WORD PIODA_SetCounter(WORD wBoardNo,  
                      WORD wWhichCounter, WORD bConfig, DWORD wValue);
```

- **Parameter :**

wBoardNo : [Input] PIODA board number  
wWhichCounter : [Input] Counter number. (0 to 2)  
bConfig : [Input] Configuration code. Please refer to 8254 spec.  
wValue : [Input] Counter value to be set.  
Only the low-part of word is valid. (16-bit)

- **Return:**

PIODA\_NoError : OK

## 4.4 EEPROM Functions

---

### 4.4.1 PIODA\_EEP\_Read

- **Description:**  
Read the EEPROM data for the specified board and offset.
- **Syntax:**  
WORD PIODA\_EEP\_READ  
(WORD wBoardNo, WORD wOffset, WORD \*bHi, WORD \*bLo);
- **Parameter:**  
wBoardNo : [Input] Which board to be used.  
wOffset : [Input] The offset address for the EEPROM. (0 to 63)  
bHi : [Output] 8-bit data. The high-part of EEPROM data.  
bLo : [Output] 8-bit data. The low-part of EEPROM data.
- **Return:**  
PIODA\_NoError : OK

---

### 4.4.2 PIODA\_EEP\_Write

- **Description:**  
Write data into the EEPROM for the specified board and offset. **The wrong data may cause the board to output the wrong value (voltage/current).** It's recommended not to use this function. Before using the "PIODA\_EEP\_Write()" function to write the data into EEPROM, the user must call the "PIODA\_EEP\_WR\_EN()" function once firstly.
- **Syntax:**  
WORD PIODA\_EEP\_Write  
(WORD wBoardNo, WORD wOffset, WORD HI, WORD LO);



- **Parameter:**

wBoardNo : [Input] Which board to be used.  
wOffset : [Input] The offset address for the EEPROM. (0 to 63)  
HI : [Input] 8-bit data. The high-part of EEPROM data.  
LO : [Input] 8-bit data. The low-part of EEPROM data.

- **Return:**

PIODA\_NoError : OK

### 4.4.3 PIODA\_EEP\_WR\_EN

- **Description:**

This function will enable the capability of the specified board to write data into EEPROM. The user must call this function once before calling the PIODA\_EEP\_Write() function.

- **Syntax:**

WORD PIODA\_EEP\_WR\_EN(WORD wBoardNo);

- **Parameter:**

wBoardNo : [Input] Which board to be used.

- **Return:**

PIODA\_NoError : OK

---

### 4.4.4 PIODA\_EEP\_WR\_DIS

- **Description:**

This function will disable the capability of the specified board to write data into EEPROM.

- **Syntax:**

WORD PIODA\_EEP\_WR\_DIS(WORD wBoardNo);

- **Parameter:**

wBoardNo : [Input] Which board to be set.

- **Return:**

PIODA\_NoError : OK

## 4.5 DA Functions

---

### 4.5.1 PIODA\_Voltage

- **Description:**

This function will output the value of voltage (without the calibration) to the specified board and channel.

- **Syntax:**

```
WORD PIODA_Voltage  
    (WORD wBoardNo, WORD wChannel, float fValue);
```

- **Parameter:**

wBoardNo : [Input] Which board to be used.  
wChannel : [Input] Which channel to output.  
fValue : [Input] What voltage value to output.

- **Return:**

PIODA\_NoError : OK

---

### 4.5.2 PIODA\_Current

- **Description:**

This function will output the value of current (without the calibration) to the specified board and channel.

- **Syntax:**

```
WORD PIODA_Current  
    (WORD wBoardNo, WORD wChannel, float fValue);
```

- **Parameter:**

wBoardNo : [Input] Which board to be used.  
wChannel : [Input] Which channel to output.  
fValue : [Input] What current value to output.

- **Return:**

PIODA\_NoError : OK

### 4.5.3 PIODA\_CalVoltage

- **Description:**

This function will output the value of voltage to the specified board and channel. This function uses the EEPROM data to do the calibration.

- **Syntax:**

```
WORD PIODA_CalVoltage  
    (WORD wBoardNo, WORD wChannel, float fValue);
```

- **Parameter:**

wBoardNo : [Input] Which board to be used.  
wChannel : [Input] Which channel to output.  
fValue : [Input] What voltage value to output.

- **Return:**

PIODA\_NoError : OK

---

### 4.5.4 PIODA\_CalCurrent

- **Description:**

This function will output the value of current to the specified board and channel. This function uses the EEPROM data to do the calibration.

- **Syntax:**

```
WORD PIODA_CalCurrent  
    (WORD wBoardNo, WORD wChannel, float fValue);
```

- **Parameter:**

wBoardNo : [Input] Which board to be used.  
wChannel : [Input] Which channel to output.  
fValue : [Input] What current value to output.

- **Return:**

PIODA\_NoError : OK

---

## 4.6 Interrupt Functions

---

### 4.6.1 PIODA\_IntInstall

- **Description:**

This subroutine will install the IRQ service routine.

- **Syntax:**

```
WORD PIODA_IntInstall(WORD wBoardNo, HANDLE *hEvent,
                     WORD wInterruptSource, WORD wActiveMode);
```

- **Parameter:**

wBoardNo : [Input] Which board to be used.

hEvent : [Input] Address of a Event handle. The user's program must call the Windows API function "CreateEvent()" to create the event-object.

wInterruptSource : [Input] What the Interrupt-Source to be used ? Please refer to hardware's manual for the detail information.

Card No.	wInterruptSource	Description
OME-PIO-DA16/DA8/DA4	0	INT0
	1	INT1

wActiveMode : [Input] When to trigger the interrupt ?

This can be PIODA\_ActiveHigh or PIODA\_ActiveLow.

- **Return:**

PIODA\_NoError : OK

PIODA\_InstallIrqError : IRQ installation error

---

## 4.6.2 PIODA\_IntRemove

- **Description:**  
This subroutine will remove the IRQ service routine.
- **Syntax:**  
WORD PIODA\_IntRemove( void );
- **Parameter:**  
None
- **Return:**  
PIODA\_NoError : OK

### 4.6.3 PIODA\_IntGetCount

- **Description:**

This subroutine will read the **dwIntCount** defined in device driver.

- **Syntax :**

WORD PIODA\_IntGetCount(WDORD \*dwIntCount);

- **Parameter:**

dwIntCount : [Output] Address of dwIntCount, which will stores the counter value of interrupt.

- **Return:**

PIODA\_NoError : OK  
PIODA\_GetIntCountError : **dwIntCount** read error

---

### 4.6.4 PIODA\_IntResetCount

- **Description:**

This function is used to clear the counter on the device driver for the interrupt.

- **Syntax:**

WORD PIODA\_IntResetCount(void);

- **Parameter:**


None

- **Return:**

PIODA\_NoError : OK  
PIODA\_ResetError : can't reset the counter



## 4.6.5 Architecture of Interrupt mode



Please refer to the following Windows API functions:

The following description of these functions was extracted from MSDN. For the detailed and completely information, please refer to MSDN.

### CreateEvent( )

The CreateEvent function creates or opens a named or unnamed event object.

```
HANDLE CreateEvent(
    // pointer to security attributes
    LPSECURITY_ATTRIBUTES lpEventAttributes,
    BOOL bManualReset,    // flag for manual-reset event
    BOOL bInitialState,  // flag for initial state
    LPCTSTR lpName       // pointer to event-object name
);
```

## CreateThread( )

The CreateThread function creates a thread to execute within the virtual address space of the calling process.

To create a thread that runs in the virtual address space of another process, use the CreateRemoteThread function.

```
HANDLE CreateThread(  
    // pointer to security attributes  
    LPSECURITY_ATTRIBUTES lpThreadAttributes,  
    DWORD dwStackSize,      // initial thread stack size  
    // pointer to thread function  
    LPTHREAD_START_ROUTINE lpStartAddress,  
    LPVOID lpParameter,     // argument for new thread  
    DWORD dwCreationFlags,  // creation flags  
    LPDWORD lpThreadId      // pointer to receive thread ID  
);
```

## WaitForSingleObject( )



The WaitForSingleObject function returns when one of the following occurs:

- The specified object is in the signaled state.
- The time-out interval elapses.

To enter an alertable wait state, use the WaitForSingleObjectEx function. To wait for multiple objects, use the WaitForMultipleObjects.

```
DWORD WaitForSingleObject(  
    HANDLE hHandle,        // handle to object to wait for  
    DWORD dwMilliseconds  // time-out interval in  
    milliseconds  
);
```

# 5. Program Architecture



## 6. Contact Us

Technical support is available at no charge as described below. The best way to report problems is send electronic mail to **das@omega.com** on the Internet.

When reporting problems, please include the following information:

- 1) Is the problem reproducible? If so, how?
- 2) What kind and version of Operation Systems that you running? For example, Windows 3.1, Windows for Workgroups, Windows NT 4.0, etc.
- 3) What kinds of our products that you using? Please see the product's manual.
- 4) If a dialog box with an error message was displayed, please include the full text of the dialog box, including the text in the title bar.
- 5) If the problem involves other programs or hardware devices, what devices or version of the failing programs that you using?
- 6) Other comments relative to this problem or any Suggestions will be welcomed.

After we received your comments, we will take about two business days to testing the problems that you said. And then reply as soon as possible to you. Please check that we have received your comments? And please keeping contact with us.

E-mail: [das@omega.com](mailto:das@omega.com)

Web-Site: <http://www.omega.com>

## WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **13 months** from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal **one (1) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components which wear are not warranted, including but not limited to contact points, fuses, and triacs.

**OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by it will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESS OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.**

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

## RETURN REQUESTS/INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of the product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 2002 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.

# Where Do I Find Everything I Need for Process Measurement and Control? **OMEGA...Of Course!**

*Shop online at [www.omega.com](http://www.omega.com)*

## **TEMPERATURE**

- Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- Wire: Thermocouple, RTD & Thermistor
- Calibrators & Ice Point References
- Recorders, Controllers & Process Monitors
- Infrared Pyrometers

## **PRESSURE, STRAIN AND FORCE**

- Transducers & Strain Gages
- Load Cells & Pressure Gages
- Displacement Transducers
- Instrumentation & Accessories

## **FLOW/LEVEL**

- Rotameters, Gas Mass Flowmeters & Flow Computers
- Air Velocity Indicators
- Turbine/Paddlewheel Systems
- Totalizers & Batch Controllers

## **pH/CONDUCTIVITY**

- pH Electrodes, Testers & Accessories
- Benchtop/Laboratory Meters
- Controllers, Calibrators, Simulators & Pumps
- Industrial pH & Conductivity Equipment

## **DATA ACQUISITION**

- Data Acquisition & Engineering Software
- Communications-Based Acquisition Systems
- Plug-in Cards for Apple, IBM & Compatibles
- Datalogging Systems
- Recorders, Printers & Plotters

## **HEATERS**

- Heating Cable
- Cartridge & Strip Heaters
- Immersion & Band Heaters
- Flexible Heaters
- Laboratory Heaters

## **ENVIRONMENTAL MONITORING AND CONTROL**

- Metering & Control Instrumentation
- Refractometers
- Pumps & Tubing
- Air, Soil & Water Monitors
- Industrial Water & Wastewater Treatment
- pH, Conductivity & Dissolved Oxygen Instruments