

Digital Pressure Gauges

DPG3500, DPG3600, DPG5500, DPG5600 Series



**DPG5500
DPG5600**



**DPG3500 NEMA 4X
DPG3600 NEMA 4X**

INSTRUCTION SHEET

M4094/0818

Shop online at omega.com e-mail: info@omega.com
For latest product manuals: www.omegamanual.info

- DPG3500** Battery Powered, Min/Max/Zero, NEMA 4X
- DPG3600** Battery Powered, Min/Max/Zero, NEMA 4X, Display Backlighting
- DPG5500** Battery Powered, Min/Max/Zero
- DPG5600** Battery Powered, Min/Max/Zero, Display Backlighting

Range Code after model number	Default Units	Selectable Units
03G	0-3.000 psig	
85INH20G	0-85.0 inches of water	psig, inHg, inH ₂ O, oz/in ² , g/cm ² , mmHg, torr, mbar, cmH ₂ O, mmH ₂ O, ftH ₂ O, kPa
05G	0-5.000 psig	
140INH20G	0-140.0 inches of water	psig, inHg, inH ₂ O, oz/in ² , g/cm ² , mmHg, torr, mbar, cmH ₂ O, mmH ₂ O, ftH ₂ O, kPa
15A	15.00-0 psi absolute	
760TORRA	760.0-0 torr absolute	absolute: psia, inHg _a , inH ₂ O _a , oz/in ² _a , g/cm ² _a , mmHg _a , torra, mbara, cmH ₂ O _a , mmH ₂ O _a , ftH ₂ O _a , kPaa, MPaa, bara, kg/cm ² _a , atma
30INHGVAC	0-30.00 inHg vac	vacuum: psig, inHg, inH ₂ O, oz/in ² , g/cm ² , mmHg, torr, mbar, cmH ₂ O, mmH ₂ O, ftH ₂ O, kPa, MPa, bar, kg/cm ² , atm
30V15G	-30.00 inHg vac to 15.00 psig	±psig, ±inHg, ±inH ₂ O, ±oz/in ² , ±g/cm ² , ±mmHg, ±torr, ±mbar, ±cmH ₂ O, ±mmH ₂ O, ±ftH ₂ O, ±kPa, ±MPa, ±bar, ±kg/cm ² , ±atm
15G	0-15.00 psig	
1BARG	0-1.000 bar	psig, inHg, inH ₂ O, oz/in ² , g/cm ² , mmHg, torr, mbar, cmH ₂ O, mmH ₂ O, ftH ₂ O, kPa, MPa, bar, kg/cm ² , atm
30A	30.00-0 psi absolute	absolute: psia, inHg _a , inH ₂ O _a , oz/in ² _a , g/cm ² _a , mmHg _a , torra, mbara, cmH ₂ O _a , mmH ₂ O _a , ftH ₂ O _a , kPaa, MPaa, bara, kg/cm ² _a , atma
30G	0-30.00 psig	psig, inHg, inH ₂ O, oz/in ² , g/cm ² , mmHg, torr, mbar, cmH ₂ O, mmH ₂ O, ftH ₂ O, kPa, MPa, bar, kg/cm ² , atm
60G	0-60.00 psig	psig, inHg, inH ₂ O, oz/in ² , g/cm ² , mmHg, torr, mbar, cmH ₂ O, mmH ₂ O, ftH ₂ O, kPa, MPa, bar, kg/cm ² , atm
30V100G	-30.0 inHg vac to 100.0 psig	±psig, ±inHg, ±inH ₂ O, ±oz/in ² , ±g/cm ² , ±mmHg, ±torr, ±mbar, ±cmH ₂ O, ±mmH ₂ O, ±ftH ₂ O, ±kPa, ±MPa, ±bar, ±kg/cm ² , ±atm
100G	0-100.0 psig	
7BARG	0-7.000 bar	psig, inHg, inH ₂ O, oz/in ² , g/cm ² , mmHg, torr, mbar, cmH ₂ O, mmH ₂ O, ftH ₂ O, kPa, MPa, bar, kg/cm ² , atm
30V200G	-30.0 inHg vac to 200.0 psig	±psig, ±inHg, ±inH ₂ O, ±oz/in ² , ±ftH ₂ O, ±kPa, ±MPa, ±bar, ±kg/cm ² , ±atm
200G	0-200.0 psig	
14BARG	0-14.00 bar	psig, inHg, inH ₂ O, oz/in ² , ftH ₂ O, kPa, MPa, bar, kg/cm ² , atm
300G	0-300.0 psig	psig, inHg, oz/in ² , ftH ₂ O, kPa, MPa, bar, kg/cm ² , atm
500G	0-500.0 psig	psig, inHg, ftH ₂ O, kPa, MPa, bar, kg/cm ² , atm
1KG	0-1000 psig	psig, inHg, ftH ₂ O, kPa, MPa, bar, kg/cm ² , atm
2KG	0-2000 psig	psig, inHg, ftH ₂ O, MPa, bar, kg/cm ² , atm
3KG	0-3000 psig	psig, inHg, ftH ₂ O, MPa, bar, kg/cm ² , atm
5KG	0-5000 psig	psig, MPa, bar, kg/cm ² , atm

Ranges and Resolution

See table above for ranges and user selectable units
Units are user selectable via internal buttons
Resolution is fixed for each engineering unit

Accuracy

Includes linearity, hysteresis, repeatability
±0.25% of full scale ±1 least significant digit
Sensor hysteresis: ±0.015% FS, included in accuracy
Sensor repeatability: ±0.01% FS, included in accuracy

Display

3 readings per second nominal display update rate
4 digit LCD, 0.5" H and 5 character 0.25" H alphanumeric
DPG3600, DPG5600: Red LED backlight

Batteries, Battery Life, Low Battery Indication

2 AA alkaline included. Approx. 2000 hours battery life
DPG3600, DPG5600: 150-1500 hrs. depending on backlight usage

Low battery symbol on display

Controls & Functions

Front button turns gauge on or off, zeros gauge reference gauges, and cycles through min/max functions
Internal push buttons for selection of engineering units and auto shutoff times, pass code protected setup and calibration.
DPG3600, DPG5600: Front button activates backlighting for 1 minute

Min/Max Functions

Minimum and maximum readings stored 3 times per second
Front button cycles through min display, max display, clear
Configurable for min only, max only, min/max, or none, clear min/max at power off or retain min/max at power off

Calibration

Pass code protected calibration
Non-interactive zero, span, and linearity, ±10% of range

Auto Shutoff

User selectable 1 minute to 8 hours or front button on/off
Factory default 5 minutes

Weight

Gauge: 9 ounces (approximately)
Shipping: 1 pound (approximately)

Housing

Extruded aluminum case, epoxy powder coated, ABS/ polycarbonate bezel, front and rear gaskets, polycarbonate label
DPG3500, DPG3600: ABS/polycarbonate NEMA 4X case, rear gasket, polycarbonate label

Connection and Material

1/4" NPT male fitting, 316L stainless steel
All wetted parts are 316L stainless steel

Overpressure, Burst, Vacuum


Ranges using 3000 psig sensor: 5000 psig
Ranges using 5000 psig sensor: 7500 psig
All others: 2 X pressure range
3000 psi, 5000 psi, and 4 digit ranges 112.5% full scale out-of-range display: 1- - - or 1- - - -
4 X sensor burst pressure rating, or 10,000 psi, whichever is less

Vacuum service: ±15 psig, 15 psig, 15 psia, 30 psia, 100 psig, 100 psia, 200 psig sensors.

Under-range display (non-vacuum sensors): -Err

Environmental

Storage temperature: -40 to 203°F (-40 to 95°C)
Operating temperature: -4 to 185°F (-20 to 85°C)
Compensated temperature: 32 to 158°F (0 to 70°C)



Installation and Precautions

- ✓ Read these instructions before using the gauge. Configuration may be easier before installation. Contact the factory for assistance.
- ✓ These products do not contain user-serviceable parts. Contact us for repairs, service, or refurbishment.
- ✓ Gauges must be operated within specified ambient temperature ranges.
- ✓ Outdoor or wash down applications require a NEMA 4X gauge or installation in a NEMA 4X housing.
- ✓ Use a pressure or vacuum range appropriate for the application.
- ✓ Use fittings appropriate for the pressure range of the gauge.
- ✓ Due to the hardness of 316 stainless steel, it is recommended that a thread sealant be used to ensure leak-free operation.
- ✓ For contaminated media use an appropriate screen or filter to keep debris out of gauge port.
- ✓ Remove system pressures before removing or installing gauge.
- ✓ Install or remove gauge using a wrench on the hex fitting only. Do not attempt to turn gauge by forcing the housing.
- ✓ Good design practice dictates that positive displacement liquid pumps include protection devices to prevent sensor damage from pressure spikes, acceleration head, and vacuum extremes.
- ✗ Avoid permanent sensor damage! Do not apply vacuum to non-vacuum gauges or hydraulic vacuum to any gauges.
- ✗ Avoid permanent sensor damage! NEVER insert objects into gauge port or blow out with compressed air.
- ⚠ Gauges are not for oxygen service. Accidental rupture of sensor diaphragm may cause silicone oil inside sensor to react with oxygen.



WARNING: This product can expose you to chemicals including lead, nickel and chromium, which are known to the State of California to cause cancer or birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov

Types of Gauges

Gauge reference models read zero with the gauge port open.

Compound ranges read vacuum in inches of Mercury, pressure in psig, and zero with the gauge port open.

1000 psi and higher sensors are a sealed reference type. They read zero with the gauge port open are internally referenced to 14.7 psi. They are functionally similar to gauge reference sensors.

Absolute reference gauges read zero at full vacuum and atmospheric pressure with the gauge port open. Note atmospheric pressure varies continuously.

Power-Up and Operation

Press and hold the front button for approximately 1 second.

The display is tested, the default full-scale range is indicated, the full-scale range in the selected units are indicated, the display is tested again, then the actual pressure and units are displayed.

Function	Button	Prompt (Release Button)
On	Press for 1 second	Display test > default units > selected units <i>FULL SCALE</i> > display test > actual reading
Zero (gauge ref. only)	Press and hold	Display test > <i>0000</i> > default units > selected units <i>FULL SCALE</i> > display test > actual reading
Hi reading	Press/hold	<i>MAX</i> > max. reading & units
Lo reading	Press/hold	<i>MIN</i> > min. reading & units
Exit Hi/Lo	Press/hold	<i>****</i> > actual reading
Clear Hi/Lo	Press/hold	<i>MAX</i> > <i>CLR</i> <i>MAX/MIN</i> > actual reading
Clear, off	Press/hold	<i>MAX</i> > <i>CLR</i> <i>MAX/MIN</i> > <i>OFF</i>

Power-Up With Zero (Gauge Reference Ranges Only)

Be sure the gauge port is exposed to normal atmospheric pressure and no pressure is applied. The zeroing function is only activated at each power-up and the stored zero correction is erased when the gauge is shut off.

Press and hold the front button. The display is tested and then *0000* is displayed. The gauge is now zeroed. Release the button and the full-scale range in the selected units are indicated, the display is tested again, then the actual pressure and units are displayed.

Attempting to zero the gauge with pressure greater than approximately 3% of full-scale pressure or vacuum applied will result in an error condition, and the display will alternately indicate *Err 0* and the actual measured pressure. The gauge must be powered down to reset the error condition.

Normal Operation

Following the start-up initialization, the display indicates the pressure reading updated approximately 3 times per second. The auto shutoff timer starts when the gauge is powered up or whenever the button is pushed, unless the gauge shutoff time was set to zero for on/off operation.

If excessive vacuum is applied to a pressure-only gauge, the display will indicate *-Err* until the vacuum is released. Applying vacuum to a gauge designed for pressure may damage the pressure sensor.

If excessive pressure is applied (112.5% over range), an out-of-range indication of *1---* or *1.---* will be displayed depending on model.

Operation—continued

Display Backlighting (DPG3600, DPG5600 models only)

Display backlighting can be turned on by momentarily pressing the front button whenever the gauge is on. The backlighting will turn on for one minute and then automatically shut off. This also restarts the auto shutoff timer. The display backlighting will not be apparent under bright lighting conditions.

Minimum and Maximum Readings

Gauges are normally configured with minimum and maximum capture functions enabled. One or both can be disabled in the Advanced Configuration mode.

Minimum and maximum readings are continuously stored and updated whenever the gauge is on. The stored readings can be manually cleared if desired. The *MAX* and *MIN* memory is also cleared whenever the gauge is off unless configured to save the readings.

Press and hold the button for about 1 second until *MAX* is displayed alternating with the units. The maximum reading will be continuously updated. The gauge may be left in this mode.

After *MAX* is displayed, press and hold the button for about 1 second until *MIN* is displayed alternating with the units. The minimum reading will be continuously updated. The gauge may be left in this mode. If excessive vacuum is applied to a pressure-only gauge while in this mode, the display will indicate *-Err* until the *MAX/MIN* readings are cleared.

After *MIN* is displayed, press and hold the button again for about 1 second until ***** is displayed. The *MAX* and *MIN* memory is not erased and the gauge returns to normal operation with the display indicating the current reading.

Press and continue to hold the button until the display indicates *clr MX/MN* (about 3 seconds total) and then release the button. Both maximum and minimum values are cleared and the gauge returns to the normal mode and displays the current pressure.


Shut-Down

To shut off the gauge manually at any time, press and hold the button until the display indicates *OFF* (about 5 seconds) and then release.

When an auto shutoff timer is used, the display indicates *OFF* five seconds prior to auto shutoff. The button can be pressed to keep the gauge on. The auto shutoff and backlight (if equipped) timers are reset whenever the button is pressed and released.

If the gauge is set up without auto shutoff (on/off operation) it will stay on until manually shut off or until the batteries are depleted. Turn gauge off when not in use to conserve battery life.

Basic Configuration



Engineering Unit Selection

Engineering unit selection is done via internal buttons to help prevent accidental or unauthorized changes. The selected engineering unit is stored in non-volatile memory and will be retained even with the gauge off or batteries removed. The available engineering units depend on the sensor range and available display resolution.

Compound (inHg/PSIG) gauges must be changed to display single-unit vacuum/pressure readings in the Advanced Configuration mode before different engineering units can be selected.

The default engineering units are mathematically converted to the newly selected engineering unit. When the gauge is powered up, the originally configured range is displayed and then the conversion with the selected engineering unit is displayed.

To change engineering units remove the rear cover to gain access to the two internal buttons located near the lower right and left corners of the circuit board.

With the gauge powered up, press and hold the *UP* button. Release the button when the engineering units begin to flash.

Use the *UP* and *DOWN* buttons to scroll through the list of engineering units available for the pressure range of the sensor.

When the desired units are displayed, press and release the front button to save the selection and return to normal operation.

Note: The gauge will automatically revert to normal operation if no buttons are operated for approximately 15 seconds.

Replace the rear cover taking care not to pinch the power wires between the cover and the case.

Basic Configuration—continued

Auto Shutoff Time Selection

Auto shutoff time selection is done via internal buttons to help prevent accidental or unauthorized changes. The selected shut off time is stored in non-volatile memory and will be retained even with the battery off or batteries removed.

Remove the rear cover to gain access to the two internal buttons located near the lower right and left corners of the circuit board.

With the gauge powered up, press and hold the *DOWN* button. Release the button when the auto shutoff time is displayed.

The lower display will indicate *AST M* if the time displayed is in minutes, and *AST H* if it is in hours.

An auto shutoff time of 0 signifies that the auto shutoff feature is disabled and the front button turns the gauge on and off.

Use the *UP* and *DOWN* buttons to select 0, 1, 2, 5, 10, 15, 20 or 30 minutes, or 1, 2, 4, or 8 hours.

When the desired time is displayed, press and release the front button to save the selection and return to normal operation.

Note: The gauge will automatically revert to normal operation if no buttons are operated for approximately 15 seconds.

Replace the rear cover taking care not to pinch the power wires between the cover and the case.

Advanced Configuration

Advanced configuration requires a pass code for access and allows more features to be configured.

Remove the rear cover to gain access to the buttons located near the lower right and left corners of the circuit board.

With the gauge off, press and hold the *UP* button. Then press the front button. Release all buttons when the display indicates *CFG* and the program version then the full-scale range is indicated and the display is tested.

The display then indicates *_ _ _ _* with the first underscore blinking, and with *CFGPC* (configuration pass code) on the character segments.

Note: The gauge will automatically revert to normal operation if no buttons are operated for approximately 15 seconds. To cancel and return to normal operation, press and release the front button without entering any pass code characters.

Pass Code Entry

The factory default is 3510, but this may be changed by the user under the Pass Code Configuration section.

1. Use the *UP* or *DOWN* buttons to set the left-most digit to 3.
2. Press and release the front button to move to the next position. The 3 will remain, and the second position will be blinking.
3. Use the *UP* or *DOWN* buttons to select 5.
4. Press and release the front button to index to the next position. 35 will remain, and the third position will be blinking.
5. Use the *UP* or *DOWN* buttons to select 1.
6. Press and release the front button to index to the next position. 351 will remain, and the fourth position will be blinking.
7. Use the *UP* or *DOWN* buttons to select 0.
8. Press and release the front button to proceed with configuration procedures.

If an incorrect pass code is entered, the gauge will return to the start of the pass code entry sequence.

Factory/User Configuration

The upper display section will be blank, and the lower section will display either *USER_* or *FCTRY*.

If *USER_* is selected, the user configuration can be modified as described in the following steps.

To select *USER_*, press and release the *DOWN* button.

The lower display will indicate *USER_*.

Press and release the front button to continue.

If *FCTRY* is selected, the existing user configuration will be replaced by the original factory configuration.

To select *FCTRY*, press and release the *UP* button.

The lower display will indicate *FCTRY*.

Press and release the front button to restore the factory configuration and restart the gauge.

Max/Min Configuration

Use the *UP* and *DOWN* buttons to select from the following:

MX/MN Both highest and lowest values will be captured

MX--- Only highest value will be captured

--/MN Only lowest value will be captured

--- Capture feature is disabled

Press and release the front button to move to the next parameter.

Advanced Configuration—continued

Max/Min Memory

The upper display section will indicate clr.

Use the UP and DOWN buttons to select from the following:

AUTO Automatically clear max. and min. values when the gauge is powered off

MAN Manually clear max. and min. values

Press and release the front button to move to the next parameter.

Gauge Type Configuration

This will only appear with 15, 100, or 200 psig ranges that were originally ordered as compound gauges.

Use the UP and DOWN buttons to select from the following:

-/+EU Vacuum is indicated as negative pressure in the selected engineering units

CMPND Vacuum is negative INHG, pressure is PSIG. This setting will disable engineering unit selection.

Press and release the front button to save the user configuration and restart the gauge.

Replace the rear cover taking care not to pinch the power wires between the cover and the case.

Battery Replacement

A low battery indication will be shown in the upper left-hand corner of the display when the battery voltage falls sufficiently. The battery should be replaced soon after the indicator comes on or unreliable readings may result.

1. Remove the 6 Phillips screws on the back of the unit.
2. Remove batteries by lifting up the positive end of the battery (opposite the spring) taking care not to bend the battery holder spring.
3. Discard old batteries properly, do not discard into fire, sources of extreme heat, or in any hazardous manner.
4. Always replace both batteries at the same time with high quality alkaline batteries. Install batteries with correct orientation. The negative (flat) end of each battery should be inserted first facing the battery holder spring.
5. Replace the back cover, including the rubber gasket.

Calibration Preparation

Gauges are calibrated at the factory using equipment traceable to NIST. There is no need to calibrate the gauge before putting it into service. Calibration intervals depend on your quality control program requirements, although many customers calibrate annually.

Calibration should only be performed by qualified individuals using appropriate calibration standards and procedures. The calibration equipment should be at least four times more accurate than the gauge being calibrated.


The calibration system must be able to generate and measure pressure/vacuum over the full range of the gauge.

A vacuum pump able to produce a vacuum of 100 microns (0.1 torr or 100 millitorr) or lower is required for vacuum and absolute gauges. Warning: application of vacuum to non-vacuum models may result in irreparable damage to the sensor.

Allow the gauge to acclimate to ambient temperature for 20 minutes.

Remove the rear cover to gain access to the UP and DOWN buttons located near the lower right and left corners of the circuit board.

Install fresh batteries.



Calibration

Entering Calibration Mode

With the gauge off, press and hold the DOWN button. Then press the front button. Release all buttons when the display indicates CAL.

The display begins by indicating the full-scale positive pressure rating of the gauge in the engineering units as configured by the factory, and then shows all display.

Calibration—continued

Before the gauge enters the Calibration Mode, the display initially indicates _ _ _ _ with the first underscore blinking, and with CALPC (calibration pass code) on the lower display.

Note: The gauge will automatically revert to normal operation if no buttons are operated for approximately 15 seconds. To cancel and return to normal operation, press and release the front button without entering any pass code characters.

Enter the User-Modifiable Pass Code

The factory default is 3510, but this is user changeable.

1. Use the UP or DOWN buttons to set the left-most digit to 3.
2. Press and release the front button to move to the next position. The 3 will remain, and the second position will be blinking.
3. Use the UP or DOWN buttons to select 5.
4. Press and release the front button to index to the next position. 35 will remain, and the third position will be blinking.
5. Use the UP or DOWN buttons to select 1.
6. Press and release the front button to index to the next position. 351 will remain, and the fourth position will be blinking.
7. Use the UP or DOWN buttons to select 0.
8. Press and release the front button to proceed with configuration procedures.

If an incorrect pass code is entered, the gauge will return to the start of the pass code entry sequence.

Calibration Mode

The gauge enters and remains in the calibration mode until restarted manually or power is removed. Features not related to calibration are disabled and compound range models are set for the same engineering units for pressure and for vacuum.

The calibration may be performed in any of the available engineering units as well as percent (PCT). For greatest accuracy, use the UP and DOWN buttons to select engineering units for calibration with highest resolution (highest number of display counts). Press and release the front button when the appropriate engineering units are displayed. Suggested units are listed below.

Sensor	Suggested units for calibration
5 PSI	5.000 PSI
15 PSI	775.7 MMHG (TORR)
30 PSI	61.08 INHG
50 PSI	50.00 PSI
60 PSI	60.00 PSI
100 PSI	7.031 KG/CM2
200 PSI	407.2 INHG
300 PSI	610.8 INHG
500 PSI	500.0 PSI
1000 PSI	70.31 KG/CM2
2000 PSI	4072 INHG
3000 PSI	6108 INHG
5000 PSI	5000 PSI
Any	100.00 PCT (percent)

The display will then indicate the currently applied pressure in the engineering units selected for calibration.

UP and DOWN Button Operation

Each time one of the calibration buttons is pressed and released quickly, a small change is made to the digitized pressure signal. It may take more than one of these small changes to result in a single digit change on the display.

To make larger changes, press and hold the appropriate calibration button. After about one second, the display will begin to change continuously. Release the button to stop. Then make fine adjustments by pressing and quickly releasing the calibration buttons as previously described.

Gauge Reference Pressure Gauges

Apply zero pressure by venting the gauge port to atmosphere. The character display will alternate between ZERO and CAL. Adjust for a display indication of zero using the UP and the DOWN buttons.

Apply full-scale pressure. The character display will alternate between +SPAN and CAL. Adjust for a display indication of full-scale pressure using the UP and the DOWN buttons.

Apply 50% full-scale pressure. The character display will alternate between +MID and CAL. Adjust for a display indication equal to 50% of full-scale pressure using the UP and the DOWN buttons.

Gauge Reference Vacuum Gauges

Apply zero pressure by venting the gauge port to atmosphere. The character display will alternate between ZERO and CAL. Adjust for a display indication of zero using the UP and the DOWN buttons.

Apply full-scale vacuum. The character display will alternate between +SPAN and CAL. Adjust for a display indication of full-scale vacuum using the UP and the DOWN buttons.

Apply 50% full-scale vacuum. The character display will alternate between +MID and CAL. Adjust for a display indication equal to 50% of full-scale vacuum using the UP and the DOWN buttons.

Calibration—continued

Absolute Reference Gauges

Apply full vacuum to the gauge. The character display will alternate between ZERO and CAL. Press the UP and DOWN buttons to obtain a display indication of zero.

Apply full-scale pressure. The character display will alternate between +SPAN and CAL. Press the UP and DOWN buttons to obtain a display indication equal to full-scale pressure.

Apply 50% of full-scale pressure. The lower display will alternate between +MID and CAL. Press the UP and DOWN buttons to obtain an indication equal to 50% of full-scale pressure.

Compound and Bipolar Gauges

In addition to the steps described above for pressure gauges, apply full-scale vacuum. The character display will alternate between -SPAN and CAL. Adjust for a display indication of actual applied vacuum using the UP and the DOWN buttons.

For bipolar and -30.00inHg/+15.00psig compound range models only, apply 50% full-scale vacuum. The character display will alternate between -MID and CAL. Adjust for a display indication equal to 50% of full-scale vacuum using the UP and the DOWN buttons.

Save Calibration

Once the adjustments are complete, press and hold the front button until the display indicates _ _ _ _ then release the button to store the calibration parameters in non-volatile memory and restart the gauge.

Verify the pressure indications at 0%, 25%, 50%, 75% and 100% of full scale.

Replace the rear cover taking care not to pinch the wires between the cover and the case.

Remove the rear cover to access the buttons located near the lower right and left corners of the circuit board.

User-Defined Pass Code Configuration

View or Change User Configuration Pass Code

Remove the rear cover to access the buttons located near the lower right and left corners of the circuit board.

With the unit off, press and hold the UP button, then press the front button.

Release all buttons when the display indicates CFG.

View or Change User Calibration Pass Code

With the unit off, press and hold the DOWN button, then press the front button.

Release all buttons when the display indicates CAL.

Enter Access Code 1220

Before the unit enters the view or change pass code mode, the display initially indicates _ _ _ _ with the first underscore blinking, and with CFGPC or CALPC on the character display.

Note: The gauge will automatically revert to normal operation if no buttons are operated for approximately 15 seconds.

To cancel and return to normal operation, press and release the POWER button without entering any pass code characters.

1. Use the UP and DOWN buttons to set the left-most digit to 1.
2. Press and release the front button to move to the next position. The 1 will remain, and the second position will be blinking.
3. Use the UP and DOWN buttons to select 2.
4. Press and release the front button to index to the next position. 12 will remain, and the third position will be blinking.
5. Use the UP and DOWN buttons to select 2.
6. Press and release the front button to move to the next position. 1 2 2 will remain, and the fourth position will be blinking.
7. Use the UP and DOWN buttons to select 0.
8. Press and release the front button to proceed.

Note: If an incorrect access code was entered, the gauge will return to the start of the access code entry sequence.

Once the access code has been entered correctly, the display will indicate the existing user-defined pass code with CFGPC or CALPC on the character segments.

1. Operate the UP or DOWN button to select the first character of the new pass code.
2. When the correct first character is being displayed, press and release the front button to proceed to the next pass code character.
3. Repeat above until the entire pass code is complete.
4. To exit, press and hold the front button. Release the button when the display indicates _ _ _ _ to restart the gauge.
5. Replace the rear cover taking care not to pinch the power wires between the cover and the case.

WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **13 months** from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal **one (1) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components in which wear is not warranted, include but are not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by the company will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

RETURN REQUESTS/INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of the product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 2017 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.