



User's Guide

Series

Shop on line at

omega.com®

omega.com

e-mail: info@omega.com

iSeries info:

www.omega.com/specs/iseries



iDRA Controller
DIN Rail Temperature/Process
with Isolated Analog Output



OMEGAnet® On-Line Service www.omega.com

Internet e-mail info@omega.com

Servicing North America:

USA: One Omega Drive, P.O. Box 4047

ISO 9001 Certified Stamford CT 06907-0047

TEL: (203) 359-1660 FAX: (203) 359-7700

e-mail: info@omega.com

Canada: 976 Bergar

Laval (Quebec) H7L 5A1

TEL: (514) 856-6928 FAX: (514) 856-6886

e-mail: info@omega.ca

For immediate technical or application assistance:

USA and Canada: Sales Service: 1-800-826-6342 / 1-800-TC-OMEGA®

Customer Service: 1-800-622-2378 / 1-800-622-BEST® Engineering Service: 1-800-872-9436 / 1-800-USA-WHEN®

Mexico and TEL: (001)800-TC-OMEGA® FAX: (001) 203-359-7807

Latin American: En Español: (001) 203-359-7803

e-mail: espanol@omega.com

Servicing Europe:

Czech Republic: Frystatska 184, 733 01 Karviná

TEL: +420 59 6311899 FAX: +420 59 6311114

e-mail: info@omegashop.cz

Germany/Austria: Daimlerstrasse 26, D-75392 Deckenpfronn, Germany

TEL: +49 7056 9398-0 FAX: +49 7056 9398-29

Toll Free in Germany: 0800 639 7678

e-mail: info@omega.de

United Kingdom: One Omega Drive

ISO 9002 Certified River Bend Technology Centre

Northbank, Irlam Manchester M44 5BD United Kingdom

TEL: +44 161 777 6611 FAX: +44 161 777 6622

Toll Free in England: 0800 488 488

e-mail: sales@omega.co.uk

It is the policy of OMEGA to comply with all worldwide safety and EMC/EMI regulations that apply.

OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct, but OMEGA Engineering, Inc. accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

WARNING: These products are not designed for use in, and should not be used for, patient-connected applications.

A This device is marked with the international caution symbol. It is important to read the Setup Guide before installing or commissioning this device as the guide contains important information relating to safety and EMC.

TABLE OF CONTENTS

Part 1:				
	1.1	Descri	ption	2
	1.2	Safety	Considerations	3
	1.3	Before	You Begin	4
			J	
Part 2:	Setup			5
	2.1	Option	al Remote Programmer Front Panel	5
	2.2	Front I	Panel Connections	6
	2.3		cal Installation	
	2.0		Power Connections	
		2.3.2	Thermocouple - Input Connection	g
		2.3.2	Two / Three / Four Wire RTD-Hookup	0
		2.3.4	Process Current - Wiring Hookup	3 10
		2.3.4		
			Process Voltage - Wiring Hookup	10
		2.3.6	Wiring Outputs - Wiring Hookup	11
	_		en 41 55 1	
Part 3:		tion: Co	onfiguration Mode	14
	3.1	Introdu	uction	14
			Turning your Instrument On for the First Time	
			Buttons Functions in Configuration Mode	
	3.2	Menu (Configuration	15
		3.2.1	ID Number	16
		3.2.2	Set Points	17
		3.2.3	Configuration Menu	18
		3.2.4	Input Type Menu	18
			Input Type (Thermocouple)	19
			Input Type (RTD)	20
			Input Type (Process)	21
		3.2.5	Reading Configuration Menu	21
		3.2.6	Alarm 1 Menu	25
		3.2.7	Alarm 2 Menu	20
		3.2.8	Loop Break Time Menu/Field Calibration	23
		3.2.9	Output 1 Manu	30
			Output 1 Menu	32
		3.2.10	Analog Output (Retransmission)	38
		3.2.11	Ramp and Soak Menu	41
		3.2.12	ID Code Menu	43
		3.2.13	Communication Options Menu	45
		3.2.14	Display Color Selection Menu	51
Part 4:	Specif	fication	s	54
	-		et Values	
		-		
CE Ap	proval	Informa	ation	61

LIST OF FIGURES:

Figure 2.1	Optional Remote Programmer Front Panel	5
Figure 2.2	Input and Output Connections	6
Figure 2.3	Main Power Connections	7
Figure 2.4	Thermocouple Wiring Hookup	
Figure 2.5	Two/Three/Four-wire RTD	
J	a) RTD-1000 ohm and 500 ohm Wiring Hookup	9
	b) RTD-100 ohm Wiring Hookup	9
Figure 2.6	Process Current Wiring Hookup	
	(Internal and External Excitation)	10
Figure 2.7	Process Voltage Wiring Hookup	
90 0	a) With Sensor Excitation	10
	b) Without Sensor Excitation	10
Figure 2.8	Output Connections:	
90 00	a) Mechanical Relay and SSR Outputs – Wiring Hookup .	11
	b) Pulse Outputs – Wiring Hookup	11
Figure 2.9	Isolated Analog Output Wiring Hookup	11
Figure 2.10	Snubber Circuits Wiring Hookup	12
Figure 2.11	Typical Application	
Figure 2.12	Communication Outputs:	
9	a) RS-232 Output – Wiring Hookup	13
	b) RS-485 Output – Wiring Hookup	.13
Figure 2.13	Excitation Output	13
Figure 3.1	Flow Chart for ID and Set Points Menu	15
Figure 3.2	Flow Chart for Configuration Menu	18
Figure 3.3	Flow Chart for Input Type Menu	18
Figure 3.4	Flow Chart for Reading Configuration Menu	21
Figure 3.5	Flow Chart for Alarm 1 Menu	25
Figure 3.6	Flow Chart for Alarm 2 Menu	
Figure 3.7	Flow Chart for Loop Break Time/Field Calibration	30
Figure 3.8	Flow Chart for Output 1 Menu	
Figure 3.9	Flow Chart for Analog Output Menu	39
Figure 3.10	Flow Chart for Ramp and Soak Menu	41
Figure 3.11	Flow Chart for ID Code Menu	
Figure 3.12	Flow Chart for Communication Option Menu	
Figure 3.13	Flow Chart for Display Color Selection Menu	
J	, ,	
	LIST OF TABLES:	
Table 2.1	Optional Remote Programmer Front Panel Annunciators.	5
Table 2.2	Connectors	6
Table 2.3	Fuse Requirement	7
Table 2.4	TC Wire Color Chart	8
Table 3.1	Button Function in Configuration Mode	14
Table 3.2	Conversion Table	24
Table 4.1	Input Properties	
Table 5.1	Factory Preset Values	59
	-	

NOTES, WARNINGS and CAUTIONS

Information that is especially important to note is identified by following labels:

- NOTE
- WARNING or CAUTION
- IMPORTANT
- TIP



NOTE: Provides you with information that is important to successfully setup and use the Programmable Digital Meter.



CAUTION or WARNING: Tells you about the risk of electrical shock.



CAUTION, WARNING or IMPORTANT: Tells you of circumstances or practices that can effect the instrument's functionality and must refer to accompanying documents.



TIP: Provides you helpful hints.

PART 1 INTRODUCTION 1.1 Description



This device can be purchased as a controller, with outputs or as a signal conditioner.

- The iSeries offers unparalleled flexibility in process measurement. Each unit allows the user to select the input type, from 10 thermocouple types (J, K, T, E, R, S, B, C, N and J DIN), Pt RTDs (100, 500 or 1000 Ω, with either 385 or 392 curve), DC voltage, or DC current. The voltage/current inputs are fully scalable to virtually all engineering units, with selectable decimal point, perfect for use with pressure, flow or other process input.
- The temperature control can be achieved by using on/off or PID heat/cool
 control strategy. Control can be optimized with an auto tune feature. The
 instrument offers a ramp to setpoint with timed soak period before switching
 off the output.
- The standard features include three outputs with a choice of relay, SSR, or dc pulse outputs and isolated analog voltage or current output. Options include programmable RS-232 or RS-485 serial communication or excitation. Analog Output is fully scalable and may be configured as retransmission to follow your display. Universal power supply accepts 90 to 240 Vac. Low voltage power option accepts 24 Vac or 20 to 36 Vdc.
- The optional Remote Programmer features a large, three color programmable display with capability to change a color every time the Alarm is triggered.

1.2 Safety Considerations



This device is marked with the **International Caution Symbol**. It is **important to read** this manual before installing or commissioning this device as it contains important information relating to **Safety and EMC** (Electromagnetic Compatibility).

This instrument is a panel mount device protected in accordance with EN 61010-1:2001, electrical safety requirements for electrical equipment for measurement, control and laboratory. Installation of this instrument should be done by qualified personnel. In order to ensure safe operation, the following instructions should be followed.



This instrument has **no power-on switch**. An external **switch or circuit-breaker** shall be included in the building installation as a disconnecting device. It shall be marked to indicate this function, and it shall be in close proximity to the equipment within easy reach of the operator. The switch or circuit-breaker shall meet the relevant requirements of IEC 947–1 and IEC 947–3 (International Electrotechnical Commission). The switch shall not be incorporated in the main supply cord.



Furthermore, to provide protection against **excessive energy** being drawn from the main supply in case of a fault in the equipment, an **overcurrent** protection device shall be installed.



- Do not exceed voltage rating on the label located on the top of the instrument housing.
- Always disconnect power before changing signal and power connections.
- Do not use this instrument on a work bench without its case for safety reasons.
- Do not operate this instrument in flammable or explosive atmospheres.
- Do not expose this instrument to rain or moisture.
- Unit mounting should allow for adequate ventilation to ensure instrument does not exceed operating temperature rating.
- Use electrical wires with adequate size to handle mechanical strain and power requirements. Install without exposing bare wire outside the connector to minimize electrical shock hazards.

EMC Considerations

- Whenever EMC is an issue, always use shielded cables.
- Never run signal and power wires in the same conduit.
- Use signal wire connections with twisted-pair cables.
- Install Ferrite Bead(s) on signal wires close to the instrument if EMC problems persist.

Failure to follow all instructions and warnings may result in injury!

1.3 Before You Begin

Inspecting Your Shipment:

Remove the packing slip and verify that you have received everything listed. Inspect the container and equipment for signs of damage as soon as you receive the shipment. Note any evidence of rough handling in transit. Immediately report any damage to the shipping agent. The carrier will not honor damage claims unless all shipping material is saved for inspection. After examining and removing the contents, save the packing material and carton in the event reshipment is necessary.

Customer Service:

If you need assistance, please call the nearest Customer Service Department, listed in this manual.

Manuals. Software:

The latest Operation and Communication Manual as well as free software are available from the website listed in this manual or on the CD-ROM enclosed with your shipment.



For first-time users: Refer to the QuickStart Manual for basic operation and set-up instructions.



The following steps in this manual for configuring your device are explained by using the optional **Remote Programmer Display** (iDRP).

If you have the **Serial Communications Option** (-C24) you can easily configure the controller on your computer or on-line.

To Disable Outputs:

To ensure that menu changes are properly stored. Standby Mode should be used during setup of the instrument. During Standby Mode, the instrument remains in a ready condition, but all outputs are disabled. Standby Mode is useful when maintenence of the system is necessary.

When the instrument is in "RUN" Mode, push **2** twice to disable all outputs and alarms. It is now in "STANDBY" Mode. Push 2 once more to resume "RUN" Mode.



PUSH 2 TWICE to disable the system during an **EMERGENCY**.

To Reset the Meter:

When the controller is in the "MENU" Mode, **push once** to direct controller one step backward of the top menu item.

after "Alarms", that will go to the "Run" Mode without resetting the controller.

PART 2 SETUP



Refer to the Quick Start Guide for assembly and disassembly instructions.

2.1 Optional Remote Programmer Front Panel




Figure 2.1 Optional Remote Programmer Front Panel

Table 2.1
Optional Remote Programmer Front Panel Annunciators

Output 1/Setpoint 1/ Alarm 1 indicator
Output 2/Setpoint 2/ Alarm 2 indicator
°C unit indicator
°F unit indicator
Changes display to Configuration Mode and
advances through menu items*
Used in Program Mode and Peak Recall*
Used in Program Mode and Valley Recall*
Accesses submenus in Configuration Mode
and stores selected values*

^{*} See Part 3 Operation: Configuration Mode

2.2 Front Panel Connections

The front panel connections are shown in Figures 2.2 and 2.3.




Figure 2.2 Input and Output Connections

Table 2.2 Connectors

POWER	AC/DC Power Connector: All models
INPUT	Input Connector: All models TC, PR (Process), RTD
OUTPUT 1	Based on one of the following models: Relay SPDT Solid State Relay Pulse
OUTPUT 2	Based on one of the following models: Relay SPDT Solid State Relay Pulse
OUTPUT 3	Isolated Analog Output (Voltage and Current)
OPTION	Based on one of the following models: RS-232C and RS-485 Excitation

2.3 Electrical Installation

2.3.1 Power Connections



Caution: Do not connect power to your device until you have completed all input and output connections. Failure to do so may result in injury!

Connect the main power connections as shown in the figure below.




Figure 2.3 Main Power Connections

Table 2.3 Fuse Requirement (see specifications)

FUSE	Connector	Output Type	For 115Vac	For 230Vac	DC
FUSE 1	Power	N/A	100 mA(T)	63 mA(T)	63 mA(T)
FUSE 2	Power	N/A	N/A ` ´	N/A`	400 mA(Ť)



For the low voltage power option, in order to maintain the same degree of protection as the standard high voltage input power units (90 - 240 Vac), always use a Safety Agency Approved DC or AC source with the same Overvoltage Category and pollution degree as the standard AC unit (90 - 240 Vac).



The Safety European Standard EN61010-1 for measurement, control, and laboratory equipment requires that fuses must be specified based on IEC127. This standard specifies for a Time-lag fuse, the letter code "T". The above recommended fuses are of the type IEC127-2-sheet III. Be aware that there are significant differences between the requirements listed in the UL 248-14/CSA 248.14 and the IEC 127 fuse standards. As a result, no single fuse can carry all approval listings. A 1.0 Amp IEC fuse is approximately equivalent to a 1.4 Amp UL/CSA fuse. It is advised to consult the manufacturer's data sheets for a cross-reference.

2.3.2 Thermocouple Input

The figure below shows the wiring hookup for any thermocouple type.

For example, for Type K hookup, connect the yellow wire to the "2" terminal and the red wire to the "1(-)" terminal.

When configuring your controller, select **Thermocouple** and **Thermocouple Type** in the Input Type menu (see **Part 3**).




Figure 2.4 Thermocouple Wiring Hookup

Table 2.4 TC Wire Color Chart


TYPE	Input Co	nnector	Jacket (external insulation)	
	Terminal 1 (-)	Terminal 2 (+)	Extension	Grade
J	Red	White	dark-Brown	Black
K	Red	Yellow	dark-Brown	Yellow
Т	Red	Blue	dark-Brown	Blue
E	Red	Purple	dark-Brown	Purple
N	Red	Orange	dark-Brown	Brown
R	Red	Black	-	Green
S	Red	Black	-	Green
В	Red	Gray	_	Black



If the input wires of the meter get disconnected or broken, it will display "Input (+) Open" message. For safety purpose you may want to set up your alarm to be triggered when input is open. See Alarm 1 and 2 chapters for details.

2.3.3 Two/Three/Four-Wire RTD

The figures below show the input connections and input connector jumpers (shown in bold lines) required to hookup a 2-, 3- or 4-wire RTD.



The **two-wire** connection is simplest method, but does not compensate for lead-wire temperature change and often requires calibration to cancel lead-wire resistance offset.

The **three-wire** connection works best with RTD leads closely equal in resistance. The device measures the RTD, plus upper and lower lead drop voltage and the subtracts twice the measured drop in the lower supply current lead producing excellent lead-resistance cancellation for balanced measurements.

The **four-wire** RTD hookup is applicable to unbalanced lead resistance and enables the device to measure and subtract the lead voltage, which produces the best lead-resistance cancellation.

When configuring your controller, select **RTD Type** and **RTD value** in the Input Type menu (see **Part 3**).



If the input wires of the meter get disconnected or broken, it will display FOPN "Input (+) Open" message except in case of 500/1000 Ω 2-wire RTD. In this case the display shows FOPN "Input (-) Open" message. For safety purpose you may want to set up your alarm to be triggered when input is open. See Alarm 1 and 2 chapters for details.

2.3.4 Process Current

The figure below shows the wiring hookup for Process Current 0 - 20 mA.




Figure 2.6 Process Current Wiring Hookup (Internal and External Excitation)

When configuring your instrument, select **Process Type** in the Input Type Menu (see **Part 3**).

2.3.5 Process Voltage

The figure below shows the wiring hookup for Process Voltage 0 - 100 mV, 0 - 1 V, 0 - 10 V.




Figure 2.7 Process Voltage Wiring Hookup (with Sensor Excitation and without Sensor Excitation)

RL - Voltage limited resistor, which allows to convert 24 Vdc internal excitation voltage to the appropriate process input value. For instance: if the potentiometer value is equal to 10 k Ω , the minimum RL is 14 k Ω for 10 V process input.

When configuring your instrument, select **Process Type** in the Input Type Menu (see **Part 3**).

2.3.6 Wiring Outputs

This meter has three factory installed outputs.

Output 1 can be configured as Control Output or Alarm Output with SPDT Mechanical Relay, SPST Solid State Relay, or Pulse.

Output 2 is an Alarm Output with SPDT Mechanical Relay, SPST Solid State Relay, or Pulse.

Output 3 is Isolated Analog (retransmission) Voltage and Current Output. Connections are shown below.




Figure 2.8
a) Mechanical Relay and SSR
Outputs Wiring Hookup

b) Pulse Output Wiring Hookup




Figure 2.9 Isolated Analog Output Wiring Hookup.

This device has snubber circuits designed to protect the contacts of the mechanical relays when it switches to inductive loads (i.e. solenoids, relays). These snubbers are internally connected between the Common (C) and Normally Open (NO) relay contacts of Output 1 and Output 2.



If you have an inductive load connected between Common (C) and Normally Closed (NC) contacts of the mechanical relays and you want to protect them from the rush current during the switching period, you have to connect an external snubber circuit between Common (C) and Normally Closed (NC) contacts as indicated in the figure below.






Figure 2.10 Snubber Circuits Wiring Hookup

dc CONTROLLED SSR USED WITH TEMPERATURE CONTROLLER WITH dc VOLTAGE SSR DRIVER OUTPUT



ac CONTROLLED SSR USED WITH TEMPERATURE CONTROLLER WITH MECHANICAL RELAY OUTPUT



ac CONTROLLED SSR USED WITH TEMPERATURE CONTROLLER WITH TRIAC OUTPUT




Figure 2.11 Typical Applications

This device may have a programmable serial communication output. The RS-232 and RS-485 Output Connections are shown below.




Figure 2.12 Serial Communication a) RS-232 Output Wiring Hookup b) RS-485 Output Wiring Hookup

This device has built-in excitation. The connections are shown below.




Figure 2.13 Excitation Output

PART 3

OPERATION: Configuration Mode

3.1 Introduction

The following configuration section is explained by using the Optional Remote Programmer Display, you may also configure your device on your computer using the Serial Communications Option.

The instrument has two different modes of operation. The first, Run Mode, is used to display values for the Process Variable, and to display or clear Peak and Valley values. The other mode, Menu Configuration Mode, is used to navigate through the menu options and configure the controller. Part 3 of this manual will explain the Menu Configuration Mode. For your instrument to operate properly, the user must first "program" or configure the menu options.

Turning your Controller On for the First Time



The device becomes active as soon as it is connected to a power source. It has no On or Off switch. The device at first momentarily shows the software version number, followed by reset R5E, and then proceeds to the Run Mode

For first-time users: Refer to the QuickStart Manual for basic operation and set-up instructions.

Table 3.1 Button Function in Configuration Mode

 To enter the Menu, the user must first press button. Use this button to advance/navigate to the next menu item. The user can navigate through all the top level menus by pressing . While a parameter is being modified, press to escape without saving the parameter.
 Press the up button to scroll through "flashing" selections. When a numerical value is displayed press this key to increase value of a parameter that is currently being modified. Holding the button down for approximately 3 seconds will speed up the rate at which the set point value increments. In the Run Mode press causes the display to flash the PEAK value – press again to return to the Run Mode.
 Press the down button to go back to a previous Top Level Menu item. Press this button twice to reset the controller to the Run Mode. When a numerical value is flashing (except set point value) press to scroll digits from left to right allowing the user to select the desired digit to modify. When a setpoint value is displayed press to decrease value of a setpoint that is currently being modified. Holding the button down for approximately 3 seconds will speed up the rate at which the setpoint value is decremented. In the Run Mode press causes the display to flash the VALLEY value – press again to return to the Run Mode.
 Press the enter D button to access the submenus from a Top Level Menu item. Press to store a submenu selection or after entering a value — the display will flash a SER message to confirm your selection. To reset flashing Peak or Valley press D. In the Run Mode, press twice to enable Standby Mode with flashing SEBS.



Reset: Except for Alarms, modifying any settings of the menu configuration will reset the instrument prior to resuming Run Mode.

3.2 Menu Configuration

It is required that you put the controller in the Standby Mode for any configuration change other than Setpoints & Alarms.




Figure 3.1 Flow Chart for ID and Set Points

3.2.1 ID Number

SEE ID MENU SELECTION IN CONFIGURATION SECTION FOR ENABLE/DISABLE OR CHANGE ID CODE.



If ID Code is **Disabled** or set as **Default** (0000) the menu will skip ID step to Set Point Menu.

If ID Code is set to **Full** Security Level and user attempts to enter the Main Menu, they will be prompted for an ID Code.

If ID Code is set to **Setpoint/ID** Security Level and user attempts to enter the Configuration Menu, they will be prompted for an ID Code.

ENTERING YOUR NON-DEFAULT FULL SECURITY ID NUMBER.

Press **1**) Display shows **1**3.

Press • & • 3) Press • to increase digit 0-9. Press • to activate next digit (flashing). Continue to use • and • to enter your 4-digit ID code.

4) If the correct ID code is entered, the menu will advance to the Setpoint 1 Menu, otherwise an error message ERRo will be displayed and the instrument will return to the Run Mode.

Note To change ID Code, see ID Menu in the Configuration section.

ENTERING YOUR NON-DEFAULT SETPOINT/ID SECURITY ID NUMBER.

Press **5**) Display shows **5**P **1** Setpoint 1 Menu.

Press **6**) Display shows **5**P2 Setpoint 2 Menu.

Press **7**) Display shows Id ID Code Menu.

Press **②** 8) Display advances to **……**.

Press • & • 9) Use • and • to change your ID Code.

Press • 10) If correct ID Code is entered, the disp

10) If correct ID Code is entered, the display will advance to the TNPE Input Menu, otherwise the error message ERRO will be displayed and the controller will return to the Run Mode.



To prevent unauthorized tampering with the setup parameters, the controller provides protection by requiring the user to enter the ID Code before allowing access to subsequent menus. If the ID Code entered does not match the ID Code stored, the controller responds with an error message and access to subsequent menus will be denied.



Use numbers that are easy for you to remember. If the ID Code is forgotten or lost, call customer service with your serial number to access and reset the default to 0000.

3.2.2 Set Points

SETPOINT 1:

Press 1) Press 2, if necessary until 5P1 prompt appears.

Press 2 2) Display shows previous value of "Setpoint 1" with 1st digit

flashing.

Press • & • 3) Press • and • to increase or decrease Setpoint 1 respectively.



Holding • & • buttons down for approximately 3 seconds will speed up the rate at which the set point value increments or decrements.

Press 2

Press • 4) Continue to use • and • to enter your 4-digit Setpoint 1 value.

5) Display shows 5 to Rd stored message momentarily and then advance to 522 only, if a change was made, otherwise press 2 to advance to 5P2 Setpoint 2 Menu.

SETPOINT 2:

Press 2 6) Display shows previous value of "Setpoint 2" with 1st digit flashina.

Press • & • 7) Press • and • to increase or decrease Setpoint 2 respectively.



Holding **O** & **O** buttons down for approximately 3 seconds will speed up the rate at which the setpoint value increments or decrements.

Press 2 8) Display shows 5 to red message momentarily and then advances to ENFC only, if a change was made, otherwise press **2** to advance to ENF Configuration Menu.

3.2.3 Configuration Menu




Figure 3.2 Flow Chart for Configuration Menu

Enter Configuration Menu:

- 1) Press ②, if necessary, until ENF © prompt appear.
 2) Display advance to INPE Input Menu. Press
- Press 2
- 3) Pressing and releasing to scroll through all available Press menus of Configuration section.

3.2.4 Input Type Menu




Figure 3.3 Flow Chart for Input Type Menu

Input Type (Thermocouple)

ENTER INPUT TYPE MENU:

Press 1) Press **②**, if necessary, until **CNFG** prompt appears.

Press 2

2) Display advance to TNPE Input Menu.
3) Display flashes E.c., RED or PROC (Thermocouple, RTD or Press **②** Process). If the displayed input type is **E.c.**, press **②** to skip to step 6 (E.c stops flashing).

THERMOCOUPLE SUBMENU:

4) Scroll through the available selection to [... (flashing). Press •

Press 2 5) Display shows 5 to Rd stored message momentarily and then اعداد (not flashing).

Press 2 6) Display flashes previous thermocouple type selection. i.e. (see below for types).

7) Scroll through the available thermocouple types to the Press • selection of your choice.

8) Display shows 5 E R d stored message momentarily and then Press **②** advances to the Rate Reading Configuration Menu.

Use the Input Type (Thermocouple) (RTD) or (Process) and verify your Note 🖙 Electrical Installation (see Section 2.3). See the following pages for (TC). (RTD), (Process) menus.

J, K, T, E, N, DIN J, R, Thermocouple Types: Display:

Input Type (RTD)

ENTER INPUT TYPE MENU:

Press 1) Press ②, if necessary, until [NFC] prompt appears.

Press 2

2) Display advances to THPE Input Menu.
3) Display flashes E.c., RED or PROC (Thermocouple, RTD or Press 🖸

Process). If the displayed input type is REd, press 2 to skip to step 6 (REd stops flashing).

RTD SUBMENU:

4) Scroll through the available selection to REd (flashing). Press •

Press 2 5) Display shows 5 ER d stored message momentarily and then

RED (not flashing).

Press 2 6) Display flashes previous RTD type selection i.e. 392.2

(see below for RTD types selection).

Press • 7) Scroll through the available RTD types to the selection of

vour choice.

8) Display shows 5 to red message momentarily and then Press 2

advances to RED RTD value.

Two, Three or Four-wire RTD Types: 392 385

392.2, 392.3, 392.4, 385.2, 385.3, 385.4 Display:

Note Last digit indicates: 2-, 3- or 4-wire input.

RTD VALUE SUBMENU:

9) Display flashes previous RTD value selection i.e. 1001 Press 2

(see below for RTD value selection).

10) Scroll through the available RTD values to the selection of Press •

your choice.

Press 2 11) Display shows 5 E R d stored message momentarily and then

advances to Red G Reading Configuration Menu.

RTD Values: 100 ohm 500 ohm 1000 ohm Display: 100_ 500

Input Type (Process)

ENTER INPUT TYPE MENU:

Press **1**) Press **9**, if necessary, until **CHFG** prompt appears.

Press 2 2) Display advance to THPE Input Menu.

Press **3)** Display flashes **E.c.**, **RED** or **PROC** (Thermocouple, RTD or Process). If the displayed input type is **PROC**, press **3** to skip to step 6 (**PROC** stops flashing).

PROCESS SUBMENU:

Press 4) Scroll through the available selection to PROE (flashing).

Press 2 5) Display shows 5 t Rd stored message momentarily and then PROC (not flashing).

Press **© 6)** Display flashes previous Process type selection. i.e. **0 -** 10 (see below for Process types selection).

Press • 7) Scroll through the available Process types to the selection of your choice.

Press 2 8) Display shows 5 to red message and then advances to Reading Configuration Menu.

Process Types: 100 mV 1 V 10 V 0 - 20 mA Display: 0-0.1 0-1.0 0-10 0-20

For 4-20 mA Input select 0-20 mA and adjust the Input/Reading accordingly. To adjust 4-20 mA input, see example under Input/Reading Submenu.

3.2.5 Reading Configuration Menu

Note ^ເ

It is required that you put the controller in the Standby Mode for any configuration change other than Set Points & Alarms.




Figure 3.4 Flow Chart for Reading Configuration Menu

ENTER READING CONFIGURATION MENU:

- Press **1**) Press **2**, if necessary, until **ENFC** prompt appears.
- Press 2 2) Display advances to THPE Input Menu.
- Press **②** 3) Display advances to Reading Configuration Menu.
- Press 2 4) Display advances to decimal Point.

DECIMAL POINT SUBMENU:

- Press **5**) Display flashes previous selection for Decimal location.
- Press 6) Scroll though the available selections and choose Decimal
 - location: FFFF or FFF.F (also FF.FF and F.FFF if PROC
 - Process type was selected in the Input Type Menu).
- 7) Display shows 5 t Rd stored message momentarily and then advances to E E RD Temperature Unit.
 - Note: Decimal Point for Process Input Type is passive.

TEMPERATURE UNIT SUBMENU:

- Press **3** Display flashes previous Temperature Unit selection.
- 9) Scroll though the available selections to the Temperature Unit of your choice: For ...
- Press **10)** Display shows **5** E R d stored message momentarily and then advances to **F** L E R Filter Constant.

FILTER CONSTANT SUBMENU:

Tip 🖾

- Press 2 11) Display flashes previous selection for Filter Constant.
- Press 12) Scroll though the available selections: 0001, 0002, 0004,
 - 0008, 0016, 0032, 0064, 0128. Default is 0004
- Press 2 13) Display shows 5 E R 3 stored message momentarily only, if a change was made, otherwise press 2 to advance to the next menu.
 - If Process was selected in the Input Type Menu the display will advance to IN.Rd Input/Reading Submenu, otherwise the display advances to the RER I Alarm 1 Menu.

The Filter Constant Submenu allows the user to specify the number of readings stored in the Digital Averaging Filter.

For PID control select filter value 0001-0004. A filter value of 2 is approximately equal to 1 second RC low pass time constant.

Reading Configuration (If Process was selected)

INPUT/READING (SCALE AND OFFSET) SUBMENU:

Input Voltage or Current can be converted or scaled into values appropriate for the process or signal being measured. So, a reading may be displayed, for example, in units of weight or velocity instead of in amperes or volts.

The instrument determines Scale and Offset values based on two user-provided input values entered with the corresponding readings. Note that "In1" Input 1 and "In2" Input 2 are represented and entered as a product of the input voltage/current and the conversion number from the Table 3.1.



The following instructions include details for a specific scenario in which a **4-20 mA** input (in the 20 mA Process Mode) is to be represented as a measurement of **0-100** percent.

Press 2 at the IN.Rd prompt. Display shows IN Input 1 Submenu.

Press **2 15)** Display shows Input 1 value with 1st digit flashing. Press **2 4 5 16)** Use **4** and **5** buttons to enter **1** value.

The Wil value = min. input value * conversion number.

Note 🖾

Disregard the position of the decimal point (2000 counts may actually appear as "2000", "200.0", "20.00", or "2.000").

Example: 4 mA as $4(\text{mA}) \times 500 = 2000$.

Press **17)** Display advances to Reading 1 Submenu.

Press • & • 18) Use • and • buttons to enter Rd value.

This value represents in terms of some meaningful engineering units. To show the 4 mA as zero percent enter value = 0000.

Example: Red value = 0000.

Press 2 19) Display III2 Input 2 Submenu.

Press 2 20) Display shows Input 2 value with 1st digit flashing. The value = max. input value * conversion number.

Example: 20(mA) x 500 = 10000 (9999).

Press • & • 21) Use • and • buttons to enter WE value.

Press 2 22) Display advances to Reading 2 Submenu.

Press • & • 23) Use • and • buttons to enter 22 value.

Example: **₽ 2** value = 0100.

Press 2 24) Display flashes 5 to red message momentarily and then advances to 6 to advance to



Conversion number is a coefficient of conversion between input values and real full display range (10000 counts, shown as 9999). See Table 3.2 below for proper conversion number.

Table 3.2 Conversion Table

RANGE	CONVERSION NUMBER
100 mV	10000 / (100 x 1) = 100
1 V	$10000 / (1000 \times 1) = 10$
10 V	10000 / (1000 x 10) = 1
0 -20 mA	$10000 / (20 \times 1) = 500$

Example =

0 - 1 V = 0 - 100.0

ln 1 = 0

Rd 1 = 0

lnp 2 = 9999

Rd 2 = 100.0

3.2.6 Alarm 1

This unit is equipped with three physical outputs that can only be configured as follows:

- a) Alarm 1, Alarm 2 & Analog Output
- b) Output 1, Alarm 2 & Analog Output



Alarm must be DISABLED if Ramp is ENABLED.




Figure 3.5 Flow Chart for Alarm 1

ENTER ALARM 1 MENU:

- Press **1**) Press **2**, if necessary, until **ENF** prompt appears.
- Press 2 Display advances to INPE Input Menu.
- Press **② 3)** Press **②**, if necessary, until Display advances to **BLR** Alarm 1 Menu.
- Press **4**) Display advances to Alarm 1 ENGL Enable or Submenu and flashes the previous selection.

ALARM 1 ENABLE/DISABLE SUBMENU:

Press • 5) Scroll though the available selection until ENDL displays to use Alarm 1.

6) Display shows 5 to stored message momentarily and then advances to 850 only, if it was changed, otherwise press to advance to 850 Alarm 1 Absolute/Deviation Submenu.



If d5bL Alarm 1 Disabled was selected, all submenus of Alarm 1 Menu will be skipped and meter advances to Menu. If ENBL Alarm 1 Enabled was selected, Output 1 would be automatically disabled, and reassigned as Alarm 1.

ALARM 1 ABSOLUTE/DEVIATION SUBMENU:

Press **7)** Display flashes previous selection. Press **6** to Absolute or Absolute or Deviation.

8) Display shows **5** ER stored message momentarily and then advances to **L** E c H only, if it was changed, otherwise press **2** to advance to **L** E c H Alarm 1 Latch/Unlatch Submenu.

Absolute Mode allows Alarm 1 to function independently from Setpoint 1. If the process being monitored does not change often, then "Absolute" Mode is recommended.

Deviation Mode allows changes to Setpoint 1 to be made automatically to Alarm 1. Deviation Mode is typically the ideal mode if the process temperature changes often. In Deviation Mode, set Alarm 1 a certain number of degrees or counts away from Setpoint 1 — this relation remains fixed even if Setpoint 1 is changed.

ALARM 1 LATCH/UNLATCH SUBMENU:

Press **9**) Display flashes previous selection. Press **6** to **LECH** Latched or **UNLE** Unlatched.

Press **10)** Display shows **5** to Rd stored message momentarily and then advances to **[t.[t]** only, if it was changed, otherwise press **2** to advance to **[t.[t]** Contact Closure Submenu.

Latched Mode: Relay remains "latched" until reset. To reset already latched alarm, select Alarm Latch and press Max twice (i.e. Unlatch and then back to Latch) or from a Run Mode, push • twice to put the controller in Standby Mode and then push • one more time to return to the Run Mode.

Unlatched Mode: Relay remains latched only as long as the alarm condition is true.

CONTACT CLOSURE SUBMENU:

Press • 11) Display flashes previous selection. Press • to •.c. Normally Closed or •.o. Normally Open.

Press **12)** Display shows **5** E R a stored message momentarily and then advances to **R** c E V Active Submenu.

Normally Open: If this feature is selected, then the relay is "energized" only when an alarm condition occurs.

Normally Closed: "Fail Safe" Mode. Relay is energized under "normal" conditions and becomes de-energized during alarm or power failure.

ACTIVE SUBMENU:

Press 2 13) Display flashes previous selection. Press 2 to scroll through the available selections: Bbo\ Above, bELo Below, HILO HI/Low and balld Band. (Band is active if below Deviation was selected).

Press **14)** Display shows **5 E R d** stored message momentarily and then advances to **B P o M** Alarm Enable/Disable at Power On Submenu.

Above: Alarm 1 condition triggered when the process variable is greater than the Alarm Hi Value (Low value ignored).

Below: Alarm 1 condition triggered when the process variable is less than the Alarm Low Value (Hi value ignored).

Hi/Low: Alarm 1 condition triggered when the process variable is less than the Alarm Low Value or above the Hi Value.

Band: Alarm 1 condition triggered when the process variable is above or below the "band" set around Setpoint 1. Band equals Hi Value (Low Value ignored). A "band" is set around the Setpoint by the instrument only in the "Deviation" Mode.

The Band for the AL 1 would be following the Setpoint 1 value

The Band for the AL 2 would be following the Setpoint 2 value.

The Band or the Deviation Value should be entered under:

AL1 High (if they want Alarm 1)

AL2 High (if they want Alarm 2)

AL Low value is ignored in the Band mode.

Example: if customer requires a Deviation Value of ±10 degrees around a setpoint (using Output 2 as alarm)

Alarm 2: - Deviation

Contact Closure type: Deviation---Band

AL2 High: 10 (Band they want around Setpoint 2)

Then the Band Value is to be entered under AL2 HI: 10 not 80+10 = 90

ALARM ENABLE/DISABLE AT POWER ON:

Press 2 15) Display flashes previous selection. Press 2 to ENEL enable or 356L disable.

Press • 16) Display shows 5 to stored message. momentarily and then advances to 6 to advance to the 6 to the 6



If the alarm is enabled at Power On, the alarm will be active right after reset. If the alarm is disabled at Power On, the alarm will become enabled when the process value enters the non alarm area. The alarm is not active while the process value is approaching Setpoint 1.

ALARM 1 LOW VALUE SUBMENU:

Press • 17) Display flashes 1st digit of previous value. Use • and • to enter new value.

Press • & • 18) Use • and • to enter Alarm 1 Low Value.

Press **19)** Display shows **5** E R J storage message momentarily and then advances to **B** E R J only, if it was changed, otherwise press **9** to advance to **B** E R J Alarm 1 Hi Value Submenu.

ALARM 1 HI VALUE SUBMENU:

Press **20)** Display flashes 1st digit of previous value. Use **2** and **3** to enter new value.

Press ◆ & ▼ 21) Use ◆ and ▼ to enter Alarm1 Hi Value.

Press 2 22) Display shows 5 E Rd stored message momentarily and then advances to the next menu only, if it was changed, otherwise press 2 to advance to the next menu.

3.2.7 Alarm 2

This unit is equipped with three physical outputs that can only be configured as:

- a) Alarm 1, Alarm 2 & Analog Output
- b) Output 1, Alarm 2 & Analog Output



Alarm must be DISABLED if Ramp is ENABLED.




Figure 3.6 Flow Chart for Alarm 2

ENTER ALARM 2 MENU:

Press **1**) Press **2**, if necessary, until **CHFG** prompt appears.

Press 2 2) Display advances to INPE Input Menu.

Press **② 3)** Press **②**, if necessary, until Display advances to **BLR2** Alarm 2 Menu.

Press **4)** Display advances to Absolute/Deviation Submenu.



Alarm 2 menu items are identical to Alarm 1 Menu, except Alarm 2 does not have Alarm enable/disable at Power On submenu item. Modifying Alarm Settings will not reset the instrument.

3.2.8 Loop Break Time/Field Calibration




Figure 3.7 Flow Chart for Loop Break Time/Field Calibration

ENTER LOOP BREAK TIME MENU:

Press

Press 🔮	2) Display advances to THPE Input Menu.
Press	3) Press ②, if necessary, until Display advances to LOGP Loop
	Break Time Menu.
Press 2	4) Display advances to Loop Break Time ENBL Enable or #5bL
	Disable Submenu and flashes the previous selection.

1) Press 2, if necessary, until [NF 6] prompt appears.

LOOP BREAK ENABLE/DISABLE SUBMENU:

Press •	5) Scroll through the available selections: ENDL or EDDL.
Press 🔮	6) Display shows 5분유명 stored message momentarily and then
	advances to 6.5 1ft Loop Break Time Value Submenu.

Loop Break is an additional safety feature intended to monitor the rate of change of the process value, while approaching the SP1. It is strictly intended as an additional warning system, therefore its use is entirely optional. An active Loop Break will cause the Process Value digits to blink in a rotating pattern. If the process value reaches the set point the blinking will stop and **5.6 Iff** is completed successfully, otherwise **68.81** Break Alarm warning will flash, and Output 1 will be turned off.

LOOP BREAK TIME VALUE SUBMENU:

Press 🔮	7) Display flashes 1 st digit of previous Loop Value.
Press • & •	8) Press • and • buttons to enter a new Loop Value (0 to 99.59).
Press 🔮	9) Display shows 5 to red message momentarily and then
	advances to R.Ad J Reading Adjust Submenu.

Loop Break Time Value allows the user to determine the time interval in MM:SS (from zero to 99 minutes and 59 seconds) that the Process Value changes at least 10 counts or if the Input Type is either RTD or Thermocouple, the value changes 4° Fahrenheit or 2° Celsius. At the specified time interval, if the process value change is less than the stated rate, flashing will be displayed, the output 1 will be de-energized, and Alarm 1 energized. Loop break time will be disabled when the Process Value (PV) enters the control band.

READING ADJUST SUBMENU:

Press **10** Display flashes 1st digit of previous reading adjust value.

Press • & • 11) Press • and • buttons to enter a new Reading Adjust value (-1999 to 9999).

Press **12)** Display shows **5** E Rd stored message momentarily and then advances to **5** P.d. Setpoint Deviation Menu.

Reading Offset Adjust allows the user to fine tune a minor error of the transducer, however some applications may require a large offset adjust.

(Displayed Process Value = Measured Process Value ± R.ADJ).

Reading Adjust is adjustable between -1999 to 9999. For Temperature reading only, not Process.

SETPOINT DEVIATION ENABLE/DISABLE SUBMENU:

Press 2 13) Display advances to Setpoint Deviation ENDL Enable or Disable Submenu and flashes the previous selection.

Press • 14) Scroll through the available selections: ENEL or #56L.

Press **15)** Display shows **5** t Rd stored message momentarily and then advances to the **ERL*** Menu.

Setpoint Deviation Submenu, if "enabled", allows changes to Setpoint 1 to be made automatically to Setpoint 2. This mode is very helpful if the Process Value changes often. In Setpoint Deviation Mode, set SP2 a certain number of degrees or counts away from SP1 - this relation remains fixed when SP1 is changed. For instance: Setting SP1=200 and SP2=20 and enabling **5P.d.4** means that the absolute value of SP2=20. Moving SP1 to 300, the absolute value of SP2 becomes 320.

THERMOCOUPLE FIELD CALIBRATION SUBMENU:



CAUTION: Do not perform the following steps until you fully understand this entire section.



RTD and Process are perfectly calibrated. This section is applicable to Thermocouple (TC) calibration *only*.

Be sure that the TC being used to calibrate the meter is of the type selected in the TC submenu. Place the TC in an ice-bath (or other **0°C / 32°F** environment). In ambient temperature conditions: connect the TC to the meter, apply power to the meter.



CAUTION: Do not proceed with TC calibration unless the above conditions have been in effect for at least one hour.

Press **16)** Display shows **ERL***.

Press 2 17) Display shows flashing 0000

Press **18)** Display will still show flashing **0000**.


Press **19**) Display shows **BUE I** (meaning Calibration is complete)

* If you accidently engage the flashing (CAL° alert) simply re-press the last button you pressed, to avoid unintentionally mis-calibrating your meter.

3.2.9 Output 1

This unit is equipped with three physical outputs that can only be configured as follows:

- a) Alarm 1, Alarm 2 & Analog Output
- b) Output 1, Alarm 2 & Analog Output






Figure 3.8 Flow Chart for Output 1

ENTER OUTPUT 1 MENU:

Press **1**) Press **9**, if necessary, until **CHFG** prompt appears.

Press 2 Display advances to THPE Input Menu.

Press **② 3)** Press **②**, if necessary, until Display advances to **DUE I** Output 1 Menu.

Press • 4) Display advances to **SELF** Self Submenu.

SELF SUBMENU:

The Self Option allows the output of the instrument to be controlled manually from the front panel.

Press **5**) Display flashes the current setting of Self, ENDL Enabled or **5**bt Disabled.

Press • 6) Press the • button to select between Enable and Disable.

Press • 7) If Self • Bub • Enabled was selected, display shows • Bub • Enabled was selected.

stored message momentarily and then advances to the next menu (Output 1 setting is completed).

The output is now under the direct control of the operator and can be adjusted in the Run Mode (₱₱₱.₺ to ₱₱₱.๑), by pressing the ♠ and ♠ buttons, where M calls for the Manual (Self) Control. For example, setting of ₱₱₱.₺ of an Output make it ON 50% of the time.

8) If Self d56L Disabled was selected, display shows 56Rd stored message momentarily and then advances to Minimum/Percent Low Submenu of Output 1 Menu.



There is a shorter way to Enable or Disable Self Mode. From a Run Mode, press ② and then press ②. Self Mode is Enabled now. Press ③ or ③ to display MXX.X. To disable Self, press ② and then press ②. Display goes to the Run Mode. Self Mode is Disabled now.

MINIMUM/PERCENT LOW SUBMENU:

Specify in percent, the minimum value (0000) for control output. If the output is time proportional (Relay, SSR or Pulse), then the minimum duty-cycle, in percent, is specified.

Press **9**) Display flashes 1st digit of previous "Percent Low" setting.

Press • & • 10) Use • and • buttons to enter a new value for "Percent Low".

Press **11)** Display shows **5** t **R** d stored message momentarily and then advances to **6** P H Maximum/Percent High Submenu.

MAXIMUM/PERCENT HIGH SUBMENU:

Specify in percent, the maximum value (99) for control output. If the output is time proportional (Relay, SSR, or Pulse), then the maximum duty-cycle, in percent, is specified.

Press ② 12) Display flashes 1st digit of previous "Percent High" setting.
Press ③ & ♥ 13) Use ⑤ and ⑥ buttons to enter a new value for "Percent High".
14) Display shows 5 to enter a new value for "Percent High".
14) Display shows 5 to enter a new value for "Percent High".
15) To enter a new value for "Percent High".
16) Display flashes 1st digit of previous "Percent High" setting.
17) To enter a new value for "Percent High".
18) Display flashes 1st digit of previous "Percent High" setting.
19) Display flashes 1st digit of previous "Percent High" setting.
19) Display flashes 1st digit of previous "Percent High" setting.
19) Display flashes 1st digit of previous "Percent High" setting.
19) Display flashes 1st digit of previous "Percent High" setting.
19) Display flashes 1st digit of previous "Percent High" setting.
19) Display shows 5t Rel Control Type Submenu.

Example: On an Analog Output of 0~10 Vdc, a setting of %LO = 10 and %HI = 90, cause the minimum on the control output to be 1 V and the maximum on the control output to be 9 V. The same setting on a time proportional output, will cause 10% duty cycle for the minimum control output and 90% duty cycle for maximum control output. To disable %LO/HI, set LO to 00 and HI to 99. If %LO/HI is at other values than the default (%LO = 00, %HI = 99), **SDRK** is disabled.

*CONTROL TYPE OUTPUT: (Relay, SSR, or Pulse)

Press 🛛	15) Display flashes On/Off or Proportional, Integral,
	Derivative.
Press	16) Scroll through the available selections: "ON/OFF" or "PID".
Press 2	17) Display flashes 5 to red message momentarily and
	then advances to Betto only, if it was changed, otherwise press
	to advance to ☐ E E N Action Type Submenu.

The **ON/OFF** control is a coarse way of controlling the process. The "Dead Band" improves the cycling associated with the On/Off control. The **PID** control is best for processes where the set point is continuously changing and/or a tight control of the process variable is required. PID control requires tuning and adjustment of the "Proportional", "Integral or Reset" and "Derivative or Rate" terms by a trial-and-error method. The instrument provides an "Auto Tuning" feature making the tuning process automatic, possibly optimum.

ACTION TYPE SUBMENU:

Drocc A

The error that results from the measurement of the Process Variable may be positive or negative since it may be greater or smaller than the Setpoint. If a positive error should cause the instrument output to increase (i.e. cooling), it would be called **Direct Acting**. If a negative error should cause the output to increase (i.e. heating), it would be called **Reverse Acting**.

riess 😈	16) Display liasties by L.E. Direct of K. Vy J. Neverse.
Press	19) Scroll through the available selections: "Direct" or "Reverse".
Press 🔮	20) Display shows 5 to Rd stored message momentarily and then
	advances to AUE of only, if it was changed, otherwise press 2 to
	advance to BUE Auto PID Submenu (if PID Control Type was
	selected).

18) Display flashos 39 - 5 Direct or 8485 Poverse



If "ON/OFF" was selected in the Control Type, the display skips to the Dead Band Submenu.

AUTO PID SUBMENU:

Press 2 21) Display flashes ENGL or 356L.

Press 22) Scroll through the available selections: "Enable" or "Disable".

Press 2 23) Display shows 5 to stored message momentarily and then advances to AMEL only, if it was changed, otherwise press 2 to

advance to FNEL Anti Integral Submenu.



If **"Enabled"**, the controller can determine, by enabling Start PID, the optimum values for the three adjustments — Proportional, Reset and Rate corresponding to P, I, and D. These values may be changed once the Auto Tuning is complete.

If "**Disabled**" is selected, the user will manually enter these three adjustment values. If you want the instrument to do the Auto PID and the P, PI or PID, first select Auto Disable and enter 0000 for unwanted parameter. i.e. for PI enter 0000 for the rate.

ANTI INTEGRAL SUBMENU:

Press 2 24) Display flashes ENEL or 456L.

Press 25) Scroll through the available selections: "Enable" or "Disable".

Press 26) Display shows 55 88 stored message momentarily and then

26) Display shows 5t Rd stored message momentarily and then advances to 5t Rt only, if it was changed, otherwise press to advance to 5t Rt to Start Auto Tune PID Submenu (If Auto PID was Enabled).

Note 🕸

If Auto PID was disabled display advances to PROP Proportional Band Submenu.



If Anti Integral (Anti Windup) Submenu "**Enabled**", this feature allows the error term outside the proportional band to be calculated and accumulated for integration. This may be an important feature in applications where fast response time is desirable.

START AUTO TUNE PID:

Press 2 27) Display flashes ENBL or 356L.

Press **28**) Scroll through the available selections: "Enable" or "Disable".

Press **29)** Display shows **5** E R **3** stored message momentarily and then advances to **EYEL** only, if it was changed, otherwise press **29** to advance to **EYEL** Cycle Time Submenu.

Note ு

If "Enabled", the controller is ready to calculate P, PI or PID parameters. The instrument performs this by activating the output and observing the delay and rate at which the Process Value changes. The setpoints must be at least 18°F or 10°C above the (PV) Process Value in order to perform Auto Tune, otherwise an error message will be displayed.

To start Auto Tune PID select PID, enable Auto PID and enable Start PID. Sometimes Auto PID parameter needs fine tuning i.e. for each 5°F over shoot increase the Proportional Band (PB) by 15% and for each ±1°F fluctuation at the Setpoint (SP) increase reset by 20%.

Once started, display shows A.EUN with letters blinking in the rotating pattern. When auto tune stops, display will show process value. Do not perform any operations or settings before first stopping Auto Tune. Any alarms or other output is disabled during Auto Tune.



If "AUTO PID" was "DISABLED", the display will show the following three submenus. This allows the user to manually enter values for Proportional, Reset and Rate terms corresponding to P, I, and D. It also can be used for Auto PID for disabling unwanted parameter i.e. PI enter 0000 for Rate.

PROPORTIONAL BAND SUBMENU:

Press **30)** Display flashes 1st digit of the previous **P** Proportional band value.

Press ◆ & ◆ 31) Press ◆ and ◆ buttons to enter a new "Proportional Band" value.

Press ② 32) Display shows 5 t Rd stored message momentarily and then advances to RESt only, if it was changed, otherwise press ② to advance to RESt Reset Setup Submenu.

Proportional Band is in degrees of temperature or counts of process. Proportional Band is defined, as the change in the instrument input to cause a 100% change in the controller output.

RESET SETUP SUBMENU:

Press **33**) Display flashes 1st digit of the previous I RESE Reset value.

Press • & • 34) Press • and • buttons to enter a new "Reset" value.

Press **35)** Display shows **5** to Rd stored message momentarily and then advances to **RALE** only, if it was changed, otherwise press **2** to advance to **RALE** Rate Setup Submenu.

Reset unit is in seconds 0-3999.

RATE SETUP SUBMENU:

Press **36)** Display flashes 1st digit of previous **D RALE** Rate value.

Press • & • 37) Press • and • buttons to enter a new RAFE value.

Press **38)** Display shows **5** to ed message momentarily and then advances to the **EYEL** only, if it was changed, otherwise press **9** to advance to **EYEL** Cycle Time submenu for RTD and

Thermocouple types.

Rate unit is in seconds 000.0-399.9.

CYCLE TIME SUBMENU:

Press **39)** Display flashes 1st digit of the previous **EYEL** Cycle Time value.

Press ◆ & **40)** Press ◆ and ◆ buttons to enter a new "Cycle Time" value. (1 to 199 seconds)

Press **41)** Display shows **5 E Rd** stored message momentarily and then advances to **BPND** only, if it was changed, otherwise press **2** to advance to **BPND** Damping Factor Submenu.

A Cycle Time selected between 1 and 199 seconds determines the total On/Off time of each proportional cycle. For example, a 15 second cycle time means that every 15 seconds the output will turn on for part or all of the cycle. For Relay control outputs, do not select a cycle time of less than 7 seconds or the relays' lifetime will be shortened. For a cycle time of less than 7 seconds select SSR or DC pulse. Use an external SSR with the DC pulse option for higher currents (higher than 1 Amp).

DAMPING FACTOR SUBMENU:

Press 🕶	42) Display flashes the previous "Damping Factor" selection.
Press	43) Scroll through the available selections: 0000, 0001, 0002,
	<u>0003, 0004, 0005, 0006, 0007</u> .
Press 🔮	44) Display flashes 5분유리 stored message and then advances
	to BNLC only, if it was changed, otherwise press 2 to advance
	to BULE Analog Output Menu.

Damping Factor is a measure of speed, overshoot, and undershoot in which the process variable responds to the output changes of the instrument, which were used during the Auto Tune. This value is typically set to the ratio of Rate to Reset. This Default value is (0003). For fast response time, this value should be decreased while for slow response time it should be increased.



The "DEADBAND" Submenu will only appear if "ON/OFF" was selected from the "Control Type" Menu.

DEADBAND SUBMENU:

45) Display flashes 1st digit of the previous de Ad Deadband Press 2

Press **②**

Press ◆ & ◆ 46) Press ◆ and ◆ buttons to enter a new "Deadband" value. 47) Display shows 5 to display s BUL 6 only, if it was changed, otherwise press 2 to advance to ANL 6 Analog Output Menu.

Dead Band units are the same as Proportional Band units.



The Dead Band or neutral zone is the number of degrees or counts (if Input Type is Process) around the set point which the Process Variable must pass above or below the set point, before the output changes state.

3.2.10 Analog Output (Retransmission)

This unit is equipped with three physical outputs that can only be configured as follows:

- a) Alarm 1, Alarm 2 & Analog Out
- b) Output 1, Alarm 2 & Analog Out



Analog Output is available only if the Analog Output option board is factory installed.



It is required that you put the controller in the Standby Mode for any configuration change other than Set Points & Alarms.




Figure 3.9 Flow Chart for Analog Output (Retransmission)

ENTER ANALOG OUTPUT MENU:

- Press **②** 1) Press **②**, if necessary, until **ENFG** prompt appears.
- Press 2 2) Display advances to The Input Menu.
- Press (a) Press (b), if necessary, until Display advances to Analog Output Menu.
- Press 2 4) Display advances to Analog Output CURR or Current/Voltage Submenu and flashes the previous selection.

CURRENT/VOLTAGE SUBMENU:

- Press **5)** Display flashes **CURR** Current or **Volle** Voltage.
- Press **6**) Scroll through the available selection: Current or Voltage. (Example **Voltage**).
- 7) Display shows 5 to stored message momentarily and then advances to 3 Submenu only if it was changed, otherwise press to advance to 3 Reading 1 Submenu.

READING 1:

Press **3** Display flashes 1st digit of previous "Reading 1" value.

Press • & • 9) Enter "Reading 1" value. (Example 0000).

Press 2 10) Display advances to 0011 Out 1 Submenu.

OUT 1:

Press **11)** Display flashes 1st digit of previous "Out 1" value.

Press • & • 12) Enter "Out 1" value. (Example 00.00).

Press **13)** Display advances to Reading 2 Submenu.

READING 2:

Press **4 14)** Display flashes 1st digit of previous "Reading 2" value.

Press **△** & **◯** 15) Enter "Reading 2" value. (Example 9999).

Press 2 16) Display advances to ULE Out 2 Subménu.

OUT 2:

Press **4** 17) Display flashes 1st digit of previous "Out 2" value.

Press **△** & **√ 18**) Enter "Out 2" value. (Ĕxample 10.00)

Press • 19) Display advances to the BLR2 Alarm 2 Menu.



The above example is for 0-10 V of the entire range of the Process Input and Analog Output. For 0-20 mA output you need to set "Analog Type" to Current and OUT 2 to 20.00.

3.2.11 Ramp & Soak

Note ு

Alarm must be DISABLED if Ramp is ENABLED.



It is required that you put the controller in the Standby Mode for any configuration change other than Set Points & Alarms.




Figure 3.10 Flow Chart for Ramp and Soak

ENTER RAMP AND SOAK MENU:

Press **②** 1) Press **②**, if necessary, until **ENFG** prompt appears.

Press 2) Display advances to INPE Input Menu.

Press (a) Press (b), if necessary, until Display advances to Ramp and Soak Menu.

RAMP ENABLE/DISABLE SUBMENU:

Press **4)** Display advances to "Ramp Enable/Disable" Submenu and flashes **ENAL** or **356L**.

Press • 5) Scroll through the available selections: "Enable" or "Disable".

Press **6)** Display shows **5** E R **3** stored message momentarily and then advances to **50** R Soak Enable/Disable Menu.

Note 🖼

If **RAMP Disable** was selected, display skips to the next menu item (ID Code).

SOAK ENABLE/DISABLE SUBMENU:

Press **2** 7) Display flashes **ENBL** or **45bL**.

Press **S** Scroll through the available selections: "Enable" or "Disable".

Press **9)** Display shows **5** E R **3** stored message momentarily and then advances to "Ramp Value" Submenu.

Ramp & Soak provides users with the flexibility to slowly bring the Process Variable (PV) to the desired setpoint. Ramp & Soak values are specified in HH.MM format. The Ramp value indicates the time specified to bring the process variable to Setpoint 1 (SP1). Once the set point is reached, the PID takes over and the Process Variable will be controlled at the desired set point indefinitely. If Soak is enabled, PID will control the Process Variable at the specified Setpoint for the duration of Soak time and then will turn off Output 1. To start a new Ramp/Soak cycle, reset the instrument by pressing ② and then ③ button.

An active Ramp/Soak will change SP1 one degree above the PV and will cause the most significant digit to blink. The SP1 will be incremented by one degree until it reaches the original SP1. The minimum Ramp time must be at least twice the time that it will take the PV to reach the Setpoint Value (SV) with OUT 1 fully ON.

RAMP VALUE SUBMENU:

Press 2	10) Display flashes 1st digit of previous stored "Ramp Value".
Press • & •	11) Press • and • buttons to enter a new "Ramp Value".

Press **12)** Display shows **5**ER**3** stored message momentarily and then advances to "Soak Value" Submenu.

SOAK VALUE SUBMENU:

Press 🕶	13) Display flashes 1 st digit of previous stored "Soak Value".
Press • & •	14) Press • and • buttons to enter a new "Soak Value".
Press 2	15) Display shows 5 to Rd stored message and advances to the
	ID Code Menu.

The Ramp and Soak time is 00:00 to 99:59 i.e. HH.MM. (from zero to 99 hours and 59 minutes) During Ramp & Soak do not perform any operations or settings before first stopping it. Any alarms or other output are disabled during this time. To stop Ramp & Soak first put instrument into Standby Mode, then go to Ramp & Soak Menu and disable it.

3.2.12 ID CODE




Figure 3.11 Flow Chart for ID Code

ENTER ID CODE MENU:

- Press **②** 1) Press **②**, if necessary, until **ENFG** prompt appears.
- Press 2 Display advances to INPE Input Menu.
- Press **② 3)** Press **②**, if necessary, until Display advances to **III** ID Code Menu.

ENTERING OR CHANGING YOUR (NON-DEFAULT) ID CODE:

- Press **4**) Display advances to **11** with 1st under score flashing.
- Press & 5) Press and to enter your 4-digit "ID Code" number.

 Press (a) Display advances to (b) Change ID Code Submenu.
- If entered "ID Code" is incorrect display shows ERRo Error
 - Moteral II entered "ID Code" is incorrect display shows Error message momentarily and then skips to the Run Mode.
- Press **7)** Display flashes the first digit of previous entered "ID Code" number.
- Press & 8) Press and buttons to enter your new "ID Code" number.
- 9) Display shows **SERD** stored message momentarily and then advances to the **FULL** Full Security Submenu.

ENTERING OR CHANGING YOUR (DEFAULT) ID CODE:

Enter menu (Repeat steps from 1 to 3).

Press **10)** Display advances to [H. 13] Change ID Code Submenu.

Press **11**) Display shows **0000** message with flashing 1st digit.

If you want to change your default "ID Code" you can do it now, otherwise press ② and menu will skip to FULL Full Security Submenu.

Press • & • 12) Press • and • buttons to enter your new "ID Code" number. Press • 13) Display shows • stored message momentarily and then

advances to the FULL Full Security Submenu.

FULL SECURITY LEVEL SUBMENU:

Press 2 14) Display flashes ENGL Enable or 456L Disable.

Press **15**) Scroll through the available selections: "Enable" or "Disable".

Press **16**) Display shows **5** t Rd stored message momentarily and then advances to **5** P. Id Setpoint/ID Submenu.

If "Full" Security Level is "Enabled" and the user attempts to enter the Main Menu, they will be prompted for an ID Code. The ID Code should be correct to enter the instrument Menu item.

SETPOINT/ID SECURITY LEVEL SUBMENU:

Note 🖙

This Security Level can be functional only if **FULL** Security Level is Disabled.

Press • 17) Display flashes ENGL Enable or #56L Disable.

Press • 18) Scroll through the available selections: "Enable" or "Disable".

Press • 19) Display shows • stored message momentarily and then

19) Display shows 5 t Rd stored message momentarily and then advances to 6000 Communication Submenu.

If "Setpoint/ID" Security Level is "Enabled" and the user attempts to advance into the ENFC Configuration Menu, he will be prompted for ID Code number. The ID Code should be correct to proceed into the Configuration Menu, otherwise display will show an Error and skip to the Run Mode.

If "Full" and "Setpoint/ID" Security Levels are "Disabled", the ID code will be "Disabled" and user will not be asked for ID Code to enter the Menu items ("ID" Submenu will not show up in "ID/Setpoint" Menu).

3.2.13 COMMUNICATION OPTION

Purchasing the controller with Serial Communications permits an instrument to be configured or monitored from an IBM PC compatible computer using software available at the website listed on this manual or on the CD-ROM enclosed with your shipment. For complete instructions on the use of the Communications Option, refer to the Serial Communications Reference Manual.




Figure 3.12 Flow Chart for Communication Option

ENTER COMMUNICATION OPTION MENU:

Press **② 1)** Press **②**, if necessary, until **ENFG** prompt appears.

Press 2 2) Display advances to THPE Input Menu.

Press (a) Press (b), if necessary, until Display advances to Communication Options Menu.

Press **4)** Display advances to C.PAR Communication Parameters Submenu.

If Communication Option is not installed, the display shows NOVE and skips to the Color Display Menu.

COMMUNICATION PARAMETERS SUBMENU:

Allows the user to adjust Serial Communications Settings of the instrument. When connecting an instrument to a computer or other device, the Communications Parameters must match. Generally the default settings (as shown in Section 5) should be utilized.

Press • 5) Display advances to **BAUJ** Baud Submenu.

BAUD SUBMENU:

Press **② 6)** Display flashes previous selection for **BRUB** value.

7) Scroll through the available selections: 300_, 600_, 1200, 2400, 4800, 9600, 19.2 k.

8) Display shows 5 to stored message momentarily and then advances to PRty only, if it was changed, otherwise press 2 to advance to PRty Parity Submenu.

PARITY SUBMENU:

Press **9** Display flashes previous selection for "Parity".

Press • 10) Scroll through the available selections: NO, ODD, EVEN.

Press **11)** Display shows **5** to Rd stored message momentarily and then advances to **BRER** only, if it was changed, otherwise press **2** to advance to **BRER** Data Bit Submenu.

DATA BIT SUBMENU:

Press **12)** Display flashes previous selection for "Data Bit".

Press • 13) Scroll through the available selections: 7-BIT, 8-BIT.

Press **14)** Display shows **5** to Rd stored message and then advances to **5** to P only, if it was changed, otherwise press **2** to advance to **5** to P Stop Bit Submenu.

STOP BIT SUBMENU:

Press • 15) Display flashes previous selection for "Stop Bit".

Press • 16) Scroll through the available selections: 1-BIT, 2-BIT.

BUS FORMAT SUBMENU:

Determines Communications Standards and Command/Data Formats for transferring information into and out of the controller via the Serial Communications Bus. Bus Format submenus essentially determine how and when data can be accessed via the Serial Communications of the device.

Press **18)** Display advances to **9.685** Modbus Submenu.

MODBUS PROTOCOL SUBMENU:

Press 2 19) Display flashes previous selection for 19.6 U.S.

Press 2 20) Scroll through the available selections: NO, YES.

Press 2 21) Display shows 5 to red message momentarily and then

advances to LFL only, if it was changed, otherwise press to advance to LFL Line Feed submenu.

advance to _____ Line i eed subment

To select iSeries Protocol, set Modbus submenu to "No". To select Modbus Protocol, set Modbus submenu to "Yes".

If Modbus Protocol was selected, the following Communications Parameters must be set as: No Parity, 8-bit Data Bit, 1-Stop Bit. Do not attempt to change these parameters.

LINE FEED SUBMENU:

Note 🖼

Determines if data sent from the instrument will have a Line Feed appended to the end - useful for viewing or logging results on separate lines when displayed on communications software at a computer.

Press 2 22) Display flashes previous selection for "Line Feed".

Press 23) Scroll through the available selections: NO, YES.

Press **24)** Display shows **5ERd** stored message momentarily and then advances to **ECHO** only, if it was changed, otherwise press **2** to advance to **ECHO** Echo Submenu

ECHO SUBMENU:

When valid commands are sent to the instrument, this determines whether the command will be echoed to the Serial Bus. Use of echo is recommended in most situations, especially to help verify that data was received and recognized by the controller.

Press ②
25) Display flashes previous selection for "Echo".
Press ③
26) Scroll through the available selections: NO, YES.
Press ④
27) Display flashes 5 € ₹ 3 stored message momentarily and then advances to 5 € ₹ 3 communication Standard Submenu.

COMMUNICATION INTERFACE STANDARD SUBMENU:

Determines whether device should be connected to an RS-232C serial port (as is commonly used on IBM PC-compatible computers) or via an RS-485 bus connected through appropriate RS-232/485 converter. When used in RS-485 Mode, the device must be accessed with an appropriate Address Value as selected in the Address Submenu described later.

FICSS 🔾	20) Display liastics previous selection for Standard.						
Press 🔷	29) Scroll through the available selections: 232C, 485.						
Press 🔮	30) Display shows 5 to red message momentarily and then						
	advances to ModE only, if it was changed, otherwise press to						
	advance to TodE Data Flow Mode Submenu.						

29) Display flashes provious coloction for "Standard"

DATA FLOW MODE SUBMENU:

Press 🖸

Press 😃

Determines whether the instrument will wait for commands and data requests from the Serial Bus or whether the instrument will send data automatically and continuously to the Serial Bus. Devices configured for the RS-485 Communications Standard operate properly only under Command Mode.

Press \Delta	32) Scroll through the available selections: [10] "Command",
	CONE "Continuous".
Press 🔮	33) Display shows 5 E R d stored message momentarily and then
	advances to SEPR only, if it was changed, otherwise press ② to
	advance to 5 F P R Data Separation Submenu.

31) Display flashes previous selection for "Mode".

DATA SEPARATION CHARACTER SUBMENU:

Determines whether data sent from the device in Continuous Data Flow Mode will be separated by spaces or by Carriage Returns.

Press 🛡	35) Scroll through the available selections: 5755 "Space" or
	_ c R _ "Carriage Return".
Press 2	36) Display shows 5 to red message momentarily and then
	advances to dat. F only, if it was changed, otherwise press 2 to
	advance to dRF E Data Format Submenu

34) Display flashes previous selection for "Separation" Submenu.

DATA FORMAT SUBMENU:

Preformatted data can be sent automatically or upon request from the controller. Use the Data Format Submenus to determine what data will be sent in this preformatted data string. Refer to the iSeries Communications Manual for more information about the data format. At least one of the following suboptions must be enabled and hence output data to the Serial Bus.

Note This menu is applicable for Continuous Mode of RS-232 communication.

Press **37**) Display advances to **5**E **RE** Alarm Status Submenu.

ALARM STATUS SUBMENU:

Includes Alarm Status bytes in the data string.

Press **38)** Display flashes previous selection for "Status" (alarm status).

Press **39**) Scroll through the available selections: NO, YÈS.

Press **40)** Display shows **5** E Rd stored message momentarily and then advances to RdNC only, if it was changed, otherwise press **2** to advance to RdNC Reading Submenu.

MAIN READING SUBMENU:

Includes Main Reading in the data string.

Press **41)** Display flashes previous selection for "Reading".

Press 42) Scroll through the available selections: NO, YES.

Press 2 43) Display shows 5 E Rd stored message momentarily and then advances to PERK only, if it was changed, otherwise press 2 to advance to PERK Peak Submenu.

PEAK VALUE SUBMENU:

Includes Peak Value in the data string.

Press **44**) Display flashes previous selection for **PERK** Submenu.

Press 45) Scroll through the available selections: NO, YES.

Press **46**) Display shows **5** L R d stored message momentarily and then advances to **VALY** only, it was changed, otherwise press **2** to advance to **VALY** Valley Submenu.

VALLEY VALUE SUBMENU:

Includes Valley Value in the data string.

Press **47)** Display flashes previous selection for "Valley".

Press 48) Scroll through the available selections: NO, YES.

Press **② 49)** Display shows **5** E R **3** stored message momentarily and then advances to **□** I E only, if it was changed, otherwise press **②** to advance to **□** I E Temperature Unit Submenu.

TEMPERATURE UNIT SUBMENU:

Includes a byte in the data string to indicate whether reading is in Celsius or Fahrenheit.

Press **50**) Display flashes previous selection for **UN 1E**.

Press • 51) Scroll through the available selections: NO, YES.

Press ② 52) Display shows 5 t Rd stored message momentarily and then advances to RddR only, if it was changed, otherwise press ② to advance to RddR Address Setup Submenu.

ADDRESS SETUP SUBMENU:

Note This menu is applicable to the RS-485 Option only.

Press **53)** Display advances to "Address Value" (0000 to 0199) Submenu.

ADDRESS VALUE SUBMENU:

Press **4** Display flashes 1st digit of previously stored Address Value.

Press • & • 55) Press • and • to enter new "Address Value".

Press • 56) Display shows 5 to stored message momentarily and then advances to to the stored message momentarily and then advance to the stored message momentarily and then advances to the stored message momentarily and the stored message momentarily and the stored message momentarily and the stored message message momentarily and the stored message me

TRANSMIT TIME INTERVAL SUBMENU:



This menu is applicable if "Continuous" Mode was selected in the "Data Flow Mode" Submenu and the device is configured as an RS-232C Standard device. Also, one or more options under the Data Format Submenu must be enabled.

Press **57)** Display advances to "Transmit Time Value" Submenu.

TRANSMIT TIME INTERVAL VALUE SUBMENU:

Determines the interval at which data will be emitted to the RS-232 Serial Bus when the instrument is in Continuous Data Flow Mode.

Press **58)** Display flashes 1st digit of previous "Transmit Time Value" in seconds.

Press ● & ● 59) Press ● and ● to enter new "Transmit Time Value", e.g. 0030 will send the data every 30 seconds in Continuous Mode.

Press • 60) Display shows **SERD** stored message momentarily and then advances to **EDLR** only, if it was changed, otherwise press • to advance to **EDLR** Color Display Selection Menu.



For more details, refer to the Communication Manual available at the website listed on the cover page of this manual or on the CD-ROM enclosed with your shipment.

3.2.14 DISPLAY COLOR SELECTION

This submenu allows the user to select the color of the display.




Figure 3.13 Flow Chart for Display Color Selection

ENTER DISPLAY COLOR SELECTION MENU:

Press 🕖	1) Press ②, if necessary, until Large prompt appears.
Press 2	2) Display advances to THPE Input Menu.
Press	3) Press ②, if necessary, until Display advances to COLR
	Display Color Selection Menu.
Press 🖸	4) Display advances to H.E.L.R. Normal Color Submenu

NORMAL COLOR DISPLAY SUBMENU:

Press 🔮	5) Display flashes the previous selection for "Normal Color".						
Press	6) Scroll through the available selections: [FR], RED or ANDR.						
Press 2	7) Display shows 5분유리 stored message momentarily and then						
	advances to I.ELR only, if it was changed, otherwise press to						
	advance to I.CLR Alarm 1 Display Color Submenu.						

The menu below allows the user to change the color of display when alarm is triggered.

ALARM 1 DISPLAY COLOR SUBMENU:

Dress A

1 1000	bisplay hashes previous selection for Alaim 1 Color Display .
Press	9) Scroll through the available selections: GRN, RED or AMBR.
Press 🔮	10) Display shows 5 to red message momentarily and then
	advances to P.CLR only, if it was changed, otherwise press to
	advance to 2.55 R Alarm 2 Display Color Submenu.

8) Display flashes previous selection for "Alarm 1 Color Display"

ALARM 2 DISPLAY COLOR SUBMENU:

Press O

11) Display flashes previous selection for "Alarm 2 Color Display".

Press O

12) Scroll through the available selections: GRN, RED or AMBR.

13) Display shows SERD stored message momentarily and then momentarily shows the software version number, followed by Reset, and then proceeds to the Run Mode.



IN ORDER TO DISPLAY ONE COLOR, SET THE SAME DISPLAY COLOR ON ALL THREE SUBMENUS ABOVE.



If user wants the Display to change color every time when both Alarm 1 and Alarm 2 are triggered, the Alarm values should be set in such a way that Alarm 1 value is always on the top of Alarm 2 value, otherwise value of Alarm 1 will overwrite value of Alarm 2 and Display Color would not change when Alarm 2 is triggered.


Example 1:

Output 1 & Alarm 2: SSR

<u>Alarm Setup</u>: Absolute, Above, Alarm 2 HI Value "ALR.H" = 200, Alarm 1 HI Value "ALR.H" = 400

Color Display Setup: Normal Color "N.CLR" = Green, Alarm 1 Color "1.CLR" = Amber, Alarm 2 Color "2.CLR" = Red

Display Colors change sequences:



Example 2:

Output 1 & Alarm 2: Pulse

Alarm Setup: Absolute, Below, Alarm 2 Low Value "ALR.L" = 300, Alarm 1 Low Value "ALR.L" = 100

Color Display Setup: "N.CLR" = Green, "1.CLR" = Amber, "2.CLR" = Red

Display Colors change sequences:



Example 3:

Output 1: Relay, Setpoint 1: 200 Alarm 2: Relay, Setpoint 2: 200

Alarm 1 Setup: Deviation, Band, "ALR.H" = 20 Alarm 2 Setup: Deviation, Hi/Low, "ALR.H" = 10, "ALR.L" = 5

Color Display Setup: "N.CLR" = Green, "1.CLR" = Amber, "2.CLR" = Red

Display colors change sequences:

AMBER	RE	_	EN GR		_	AMBER	
0	180	195	200	210	220		•



Reset: The instrument automatically resets after the last menu of the Configuration Mode has been entered. After the instrument resets, it advances to the Run Mode.

PART 4 **SPECIFICATIONS**

Accuracy

±0.5°C temp; 0.03% reading process

Resolution

1°/0.1°; 10 µV process

Temperature Stability

1) RTD: 0.04°C/°C

2) TC @ 25°C (77°F): 0.05°C/°C Cold Junction Compensation

3) Process: 50 ppm/°C

NMRR 60 dB

CMRR 120 dB

A/D Conversion

Dual slope

Reading Rate

3 samples per second

Digital Filter

Programmable

Remote Programmer Display (optional)

4-digit, 9-segment LED, 21mm (0.83") red, green and amber programmable colors for process variable, set point and temperature units

Warm up to Rated Accuracy 30 min.

INPUT Input Types

Thermocouple, RTD, Analog Voltage, Analog Current

Thermocouple Type (ITS90) J, K, T, E, R, S, B, C, N, L

Thermocouple Lead Resistance 100 ohm max

RTD Input (ITS 68)

100/500/1000 Ω Pt sensor, 2-, 3- or 4-wire; 0.00385 or 0.00392 curve

Voltage Input

0 to 100 mV, 0 to 1 V, 0 to 10 Vdc

Input Impedance

10 M Ω for 100 mV 1 MΩ for 1 or 10 Vdc

Current Input

0 to 20 mA (5 ohm load)

Configuration

Single-ended

Polarity

Unipolar

Step Response

0.7 sec for 99.9%

Decimal Selection

None, 0.1 for temperature None, 0.1, 0.01 or 0.001 for process

Setpoint Adjustment

-1999 to +9999 counts

Span Adjustment 0.001 to 9999 counts

Offset Adjustment -1999 to +9999

CONTROL

Action: Reverse (heat) or direct (cool) **Modes**

Time and Amplitude Proportional Control Modes; selectable Manual or Auto PID, Proportional, Proportional with Integral, Proportional with Derivative with Anti-reset Windup and ON/OFF

Rate

0 to 399.9 seconds

Reset

0 to 3999 seconds

Cycle Time

1 to 199 seconds; set to 0 for ON/OFF operation

Gain

0.5 to 100% of span; Setpoints 1 or 2

Damping 0000 to 0008

Soak

00.00 to 99.59 (HH:MM), or OFF

Ramp to Setpoint

00.00 to 99.59 (HH:MM), or OFF

Auto Tune

Operator initiated from front panel

CONTROL OUTPUT 1

Configurable as Alarm 1, On/Off, PID and Ramp and Soak

Relay

SPDT type, 250 Vac or 30 Vac @ 3 A (Resistive Load);

SSR

20-265 Vac @ 0.05-0.5 A (Resistive Load); continuous

DC Pulse

Non-Isolated; 10 Vdc @ 20 mA

ALARM 1 & 2(programmable):

Type

Same as Output 1 & 2

Operation High/low, above/below, band, latch/unlatch, normally open/normally closed and process/deviation; front panel configurations

OUTPUT 3

ANALOG OUTPUT (programmable) Isolated, Retransmission 0 to 10 Vdc or 0 to 20 mA, $500~\Omega$ max. Accuracy is 1% of FS, for Scaling Gain from 0.03 to 100 mV per count Isolation is 1000 Vdc Linearity is 0.2%

COMMUNICATIONS (Optional in place of excitation)

RS-232/RS-422/RS-485/MODBUS:

Selectable from menu; both ASCII and modbus protocol selectable from menu. Programmable 300 to 19.2 K baud; complete programmable setup capability; program to transmit current display, alarm status, min/max, actual measured input value and status.

RS-485 Addressable from 0 to 199

EXCITATION

24 Vdc @ 25 mA

<u>Not available for:</u>
Low Power Option (**-DC**) or
Serial Communication Option (**-C24**)

INSULATION

Power to Input/Output

2300 Vac per 1 min. test 1500 Vac per 1 min. test (Low Voltage/Power Option)

Power to Relays/SSR Outputs 2300 Vac per 1 min. test

Relays/SSR to Relay/SSR Outputs 2300 Vac per 1 min. test

RS-232/485 to Inputs/Outputs 500 Vac per 1 min. test

Approvals

UL, C-UL, and see CE Approval Section

GENERAL

Line Voltage/Power

90-240 Vac +/-10%, 50-400 Hz* 110-375 Vdc, equivalent voltage **5 W**, power consumption * *No CE compliance above 60 Hz*

Low Voltage/Power Option

20-36 Vdc, **4 W****, power consumption External power source must meet Safety Agency Approvals.

** Units can be powered safely with 24 Vac but, no Certification for CE/UL are claimed.

External Fuse Required

Time-Delay, UL 248-14 listed:
100 mA/250 V
400 mA/250 V (Low Voltage/Power Option)
Time-Lag, IEC 127-3 recognized:
100 mA/250 V
400 mA/250 V (Low Voltage/Power Option)

Environmental Conditions

0 to 55°C (32 to 131°F), 90% RH non-condensing 0 to 50°C (32 to 122°F) for UL only. 90% RH non-condensing

Dimensions iDRA

92.5H x 125.2D x 32.1 mm W (3.64 x 4.93 x 1.27") 204g (0.45lb)

Optional Remote Programmer **iDRP**: 48H x 96x 39 mm D (1.89 x 3.78 x 1.55") 159g (0.35lb)

1/8 DIN Panel Cutout

Optional Remote Programmer **iDRP**: 45 H x 92 mm W (1.772" x 3.622 ")

Table 4.1 Input Properties

TC	Input Type	Range	Accuracy
_	Iron-Constantan	-210 to 760°C	0.4°C
J		-346 to 1400°F	0.7°F
		-270 to -160°C	1.0°C
K	CHROMEGA®-	-160 to 1372°C	0.4°C
	ALOMEGA®	-454 to -256°F	1.8°F
		-256 to 2502°F	0.7°F
		-270 to -190°C	1.0°C
T	Copper-Constantan	-190 to 400°C	0.4°C
T		-454 to -310°F	1.8°F
		-310 to 752°F	0.7°F
		-270 to -220°C	1.0°C
E	CHROMEGA-	-220 to 1000°C	0.4°C
	Constantan	-454 to -364°F	1.8°F
		-364 to 1832°F	0.7°F
		-50 to 40°C	1.0°C
D	Pt/13%Rh-Pt	40 to 1788°C	0.5°C
R		-58 to 104°F	1.8°F
		104 to 3250°F	0.9°F
		-50 to 100°C	1.0°C
S	Pt/10%Rh-Pt	100 to 1768°C	0.5°C
3		-58 to 212°F	1.8°F
		212 to 3214°F	0.9°F
		200 to 640°C	1.0°C
В	30%Rh-Pt/	640 to 1820°C	0.5°C
D	6%Rh-Pt	212 to 1184°F	1.8°F
		1184 to 3308°F	0.9°F
	5%Re-W/	0 to 2354°C	0.4°C
C	26%Re-W	32 to 4253°F	0.7°F
		-250 to -100°C	1.0°C
N	Nicrosil-Nisil	-100 to 1300°C	0.4°C
14		-418 to -148°F	1.8°F
		-148 to 2372°F	0.7°F
	J	-200 to 900°C	0.4°C
	DIN	-328 to 1652°F	0.7°F
RTD	Pt, 0.00385, 100 Ω,	200 to 900°C	0.4°C
KID	500 Ω, 1000 Ω	-328 to 1652°F	0.7°F
DTD	Pt, 0.00392, 100 Ω ,	-200 to 850°C	0.4°C
RTD	500 Ω, 1000 Ω	-328 to 1562°F	0.7°F
PROCESS	Voltage	0 to 100 mV, 0 to 1 V,	0.03% rdg
		0 to 10 Vdc	0.03% rdg
PROCESS	Current	0 to 20 mA, 4 to 20 mA	0.03% rdg

PART 5 FACTORY PRESET VALUES

Table 5.1 Factory preset value

MENU ITEMS	FACTORY PRESET VALUES	NOTES
Set Point 1 (SP1)	000.0	
Set Point 2 (SP2)	000.0	
Input:		
Input Type (INPT)	TC, type K	
Reading Configuration (RDG):		
Decimal Point (DEC.P)	FFF.F	
Temperature unit (TEMP)	°F	
Filter value (FLTR)	0004	
Alarm 1 & 2:		
Alarm 1 (ALR1)	Disable (DSBL)	
Alarm 2 (ALR2)	Enable (ENBL)	
Absolute/Deviation (ABSO/DEV)	Absolute (ABSO)	
Latch/Unlatch (LTCH/UNLT)	Unlatch (UNLT)	
Contact Closure (CT.CL)	Normally Open (N.O.)	
Active (ACTV)	Above (ABOV)	
Alarm At Power On (A.P.ON)	Disable (DSBL)	Alarm 1 only
Alarm Low (ALR.L)	-100.0	,
Alarm High (ALR.H)	400.0	
LOOP:		
Loop Break Time (LOOP)	Disable (DSBL)	
Loop Value (B.TIM)	00:59	
Reading Adjust Value (R.ADJ)	000.0	
Setpoint Deviation (SP.dV)	Disable (DSBL)	
OUTPUT 1:		
Self (SELF)	Disabled (DSBL)	
% Low Value (%LO)	0000	
% High Value (%HI)	0099	
Control Type (CTRL)	On/Off	
Action Type (ACTN)	Reverse (RVRS)	
Dead Band (DEAD)	020.0	
PID Auto (AUTO)	Disable (DSBL)	
Anti Integral (ANTI)	Disable (DSBL)	
Proportion Value (PROP)	020.0	
Reset Value (REST)	0180	
Rate Value (RATE)	0000	
Cycle Value (CYCL)	0007	
Damping Factor (DPNG)	0003	
ANALOG OUTPUT (Retransmission)		
Analog Output (ANLG)	Enabled (ENBL)	
Current/Voltage (CURR/VOLT)	Voltage (VOLT)	
Scale and Offset	Reading: 0 - 999.9 cts, Output: 0) - 10 V

MENU ITEMS	FACTORY PRESET VALUES	NOTES
Ramp & Soak (RAMP):		
Ramp (RAMP)	Disable (DSBL)	
Soak (SOAK)	Disable (DSBL)	
Ramp Value (RAMP)	00:00	
Soak Value (SOAK)	00:00	
ID:		
ID Value	0000	
Full ID (FULL)	Disable (DSBL)	
Set Point ID (ID.SP)	Disable (DSBL)	
Communication Parameters:		
Baud Rate (BAUD)	9600	
Parity (PRTY)	Odd	
Data bit (DATA)	7 bit	
Stop Bit	1 bit	
Modbus Protocol (M.BUS)	No	
Line Feed (LF)	No	
Echo (ECHO)	Yes	
Standard Interface (STND)	RS-232 (232C)	
Command Mode (MODE)	Command (CMD)	
Separation (SEPR)	Space (SPCE)	
Alarm Status (STAT)	No	
Reading (RDNG)	Yes	
Peak	No	
Valley (VALY)	No	
Units (UNIT)	No	
Multipoint Address (ADDR)	0001	
Transmit Time (TR.TM)	0016	
Display Color (COLR):		
Normal Color (N.CLR)	Green (GRN)	
Alarm 1 Color (1.CLR)	Red (RED)	
Alarm 2 Color (2.CLR)	Amber (AMBR)	

PART 6 CE APPROVALS INFORMATION



This product conforms to the EMC directive 89/336/EEC amended by 93/68/EEC, and with the European Low Voltage Directive 72/23/EEC.

Electrical Safety EN61010-1:2001

Safety requirements for electrical equipment for measurement, control and laboratory.

Double Insulation

Pollution Degree 2

Dielectric withstand Test per 1 min

Power to Input/Output: 2300Vac (3250Vdc)
 Power to Input/Output: 1500Vac (2120Vdc)
 (Low Voltage dc Power Option*)

Power to Relays/SSR Output: 2300Vac (3250Vdc)
 Ethernet to Inputs: 1500Vac (2120Vdc)
 Isolated RS232 to Inputs: 500Vac (720Vdc)
 Isolated Analog to Inputs: 500Vac (720Vdc)
 Analog/Pulse to Inputs: No Isolation

Measurement Category I

Category I are measurements performed on circuits not directly connected to the Mains Supply (power). Maximum Line-to-Neutral working voltage is 50Vac/dc. This unit should not be used in Measurement Categories II, III, IV.

Transients Overvoltage Surge (1.2 / 50uS pulse)

Input Power: 2500V
 Input Power: 1500V
 (Low Voltage dc Power Option*)

Ethernet: 1500VInput/Output Signals: 500V

Note: *Units configured for external low power dc voltage, 20-36Vdc

EMC EN61326:1997 + and A1:1998 + A2:2001

Immunity and Emissions requirements for electrical equipment for measurement, control and laboratory.

- EMC Emissions Table 4, Class B of EN61326
- EMC Immunity** Table 1 of EN61326

Note: **I/O signal and control lines require shielded cables and these cables must be located on conductive cable trays or in conduits. Furthermore,

the length of these cables should not exceed 30 meters

 $\hat{\mathbf{I}}$

Refer to the EMC and Safety installation considerations (Guidelines) of this manual for additional information.

NOTES

NOTES

NOTES



WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **one (1) year** from the date of purchase. In addition to OMEGA's standard warranty period, OMEGA Engineering will extend the warranty period for **four (4) additional years** if the warranty card enclosed with each instrument is returned to OMEGA.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components which wear are not warranted, including but not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by it will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESS OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTYDISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

RETURN REQUESTS/INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR <u>WARRANTY</u> RETURNS, please have the following information available BEFORE contacting OMEGA:

- Purchase Order number under which the product was PURCHASED,
- Model and serial number of the product under warranty, and
- Repair instructions and/or specific problems relative to the product.

FOR <u>NON-WARRANTY</u> REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

- 1. Purchase Order number to cover the COST of the repair,
- 2. Model and serial number of product, and
- Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

© Copyright 2006 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING. INC.

TRADEMARK NOTICE: Ω^{e} , omega.com^e, Ω^{e} OMEGA*, and \hat{l}_{e} are Trademarks of OMEGA ENGINEERING, INC.

PATENT NOTICE: This product is covered by one or more of the following patents: U.S. Pat. No. Des. 336,895; 5,274,577; 6,243,021 / CANADA 2052599; 2052600 / ITALY 1249456; 1250938 / FRANCE BREVET No. 91 12756 / SPAIN 2039150; 2048066 / UK PATENT No. GB2 249 837; GB2 248 954 / GERMANY DE 41 34398 C2. The "Meter Bezel Design" is a Trademark of NEWPORT Electronics, Inc. Used under License. Other US and International Patents pending or applied for.

Where Do I Find Everything I Need for Process Measurement and Control? OMEGA...Of Course! Shop on line at omega.com

TEMPERATURE

- Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- ✓ Wire: Thermocouple, RTD & Thermistor
- Calibrators & Ice Point References
- Recorders, Controllers & Process Monitors
- Infrared Pyrometers

PRESSURE, STRAIN AND FORCE

- Transducers & Strain Gauges
- Displacement Transducers
- ☑ Instrumentation & Accessories

FLOW/LEVEL

- Rotameters, Gas Mass Flowmeters & Flow Computers
- Air Velocity Indicators
- Turbine/Paddlewheel Systems
- Totalizers & Batch Controllers

pH/CONDUCTIVITY

- pH Electrodes, Testers & Accessories
- ☑ Benchtop/Laboratory Meters
- Controllers, Calibrators, Simulators & Pumps
- Industrial pH & Conductivity Equipment

DATA ACQUISITION

- Data Acquisition & Engineering Software
- ☑ Communications-Based Acquisition Systems
- Plug-in Cards for Apple, IBM & Compatibles
- Datalogging Systems
- Recorders, Printers & Plotters

HEATERS

- Heating Cable
- Cartridge & Strip Heaters
- ☑ Immersion & Band Heaters
- Flexible Heaters
- Laboratory Heaters

ENVIRONMENTAL MONITORING AND CONTROL

- ☑ Metering & Control Instrumentation
- ☑ Refractometers
- Pumps & Tubing
- Air, Soil & Water Monitors
- Industrial Water & Wastewater Treatment
- pH, Conductivity & Dissolved Oxygen Instruments