


# User's Guide



## FPUDVS2000 SERIES

Digital Variable Speed Peristaltic Injector Pump  
With external signal inputs  
Operating Manual

Shop online at

***omega.com***<sup>®</sup>

Ω OMEGA<sup>®</sup>

Omega.com

e-mail: [info@omega.com](mailto:info@omega.com)

For latest product manuals:

[Omegamanual.info](http://Omegamanual.info)

**ISO 9001**

CERTIFIED  
CORPORATE QUALITY

STAMFORD, CT

**ISO 9002**

CERTIFIED  
CORPORATE QUALITY

MANCHESTER, UK



**OMEGAnet® Online Service**  
**Omega.com**

**Internet e-mail**  
**info@omega.com**

**Servicing North America:**

**U.S.A.:**  
ISO 9001 Certified

One Omega Drive, P.O. Box 4047  
Stamford, CT 06907-0047  
TEL: (203) 359-1660  
E-mail: info@omega.com

FAX: (203) 359-7700

**Canada:**

976 Bergar  
Laval (Quebec) H7L5A1, Canada  
TEL: (514) 856-6928  
E-mail: info@omega.ca

FAX: (514) 856-6886

**For immediate technical or application assistance:**

**U.S.A. And Canada:** Sales Service: 1-800-826-6342 / 1-800-TC-OMEGA®  
Customer Service: 1-800-622-2378 / 1-800-622-BEST®  
Engineering Service: 1-800-872-9436 / 1-800-USA-WHEN®

**Mexico:**

En Espanol: (001) 203-359-7803  
FAX: (001) 203-359-7807

e-mail: espanol@omega.com  
info@omega.com.mx

**Service Europe:**

**Benelux:**

Postbus 8034, 1180 LA Amstelveen, The Netherlands  
TEL: +31 (0)20 3472121  
Toll Free in Benelux: 0800 0993344  
E-mail: sales@omega.fr

FAX: +31 (0)20 6434643

**Czech Republic:**

Frystatska 184, 733 01 Karvina, Czech Republic  
Tel: +420 (0)59 6311899  
Toll Free: 0800-1-66342

FAX: +420 (0)59 6311114  
e-mail: info@omegashop.cz

**France:**

11, rue Jacques Cartier, 78280 Guyancourt, France  
TEL: +33 (0)1 61 37 2900  
Toll Free in France: 0800 466 342  
E-mail: sales@omega.fr

FAX: +33 (0)1 30 57 5427

**Germany/Austria:**

Daimlerstrasse 26, D-75392 Deckenpfronn, Germany  
TEL: +49 (0)7056 9398-0  
Toll Free in Germany: 0800 639 7678  
E-mail: info@omega.de

FAX: +49 (0)7056 9398-29

**United Kingdom:**  
ISO 9002 Certified

One Omega Drive, River Bend Technology Centre  
Northbank, Irlam, Manchester  
M44 5BD United Kingdom  
TEL: +44 (0)161 777 6611  
Toll Free in United Kingdom: 0800-488-488  
E-mail: sales@omega.uk

FAX: +44 (0)161 777 6622

---

## TABLE OF CONTENTS

<u>SECTION</u>	<u>HEADING</u>	<u>PAGE</u>
1	Introduction	2
2	Specifications	3
3	Features	3
4	How to install the pump	4
4.1	Mounting location	4
4.2	Electrical connections	6
4.3	How to install the tubing and fittings	8
5	How to operate the pump	9
5.1	Description of Pump Output Adjustment Controls	9
5.2	Mode 1 - Manually Adjusting the output	10
5.3	Mode 2 - 4-20 mA input	10
5.4	Mode 3 - 0-10 VDC input	12
5.5	Mode 4 - Frequency/Pulse (Hz) input	13
6	Alarms	14
6.1	Tube Failure Detection (TFD) system	14
7	How to maintain the FPUDVS2000	15
7.1	Routine inspection and cleaning	15
7.2	How to clean and lubricate the FPUDVS2000	15
7.3	500 hour service warning timer	15
7.4	How to replace the pump tube	16
	Replacement parts drawing	17
	Replacement parts list	18

### 1.0 Introduction


Congratulations on purchasing the pump variable speed Peristaltic Metering Pump. The pump is designed to inject chemicals into piping systems. The pump has been tested by NSF International for use with 12 ½% Sodium Hypochlorite. The pump is equipped with external input control circuitry which allows the pumps output to be externally controlled by either a 4-20mA input signal, a 0-10V DC input signal or a pulsed frequency input signal.

## 2.0 Specifications

<b>Maximum Working Pressure</b>	100 psig / 6.9 bar*
<b>Maximum Fluid Temperature</b>	130° F / 54° C
<b>Ambient Temperature Range</b>	14 to 110° F / -10 to 43° C
<b>Duty Cycle</b>	Continuous
<b>Maximum Solids</b>	50% by volume
<b>Maximum Viscosity</b>	5,000 Centipoise
<b>Maximum Suction Lift</b>	up to 30 ft. water
<b>Power Requirements</b>	115V60Hz, 220V50Hz, 230V60Hz
<b>Shipping Dimensions</b>	18" x 14" x 10"
<b>Shipping Weight</b>	14 lb.

## 3.0 Features

- Peristaltic Pump Tube does not require valves.
- High outlet pressure capability of 100 psig.\*
- High inlet suction lift capability of 30 feet.
- Tube Failure Detection (TFD) system (patent pending).
- Quick-Disconnect inlet and outlet fittings available.
- Easy servicing.
- Includes suction tube strainer, tube weight, suction tubing, discharge tubing and injection fitting with internal back-flow check valve and mounting hardware.
- Digital electronic feed rate control.
- Pump Tube failure warning timer.
- 20:1 adjustment turn down ratio.
- Corrosion proof Valox housing.
- Tamper resistant electronic control panel cover.
- Output verification sensor system.



\* Most models.  
 \*\* Slide both top & bottom clamps to the left only far enough to open the control cover.

**FIG. 3.0 PARTS LOCATOR DRAWING**

## 4.0 How To Install the pump

**CAUTION: PROPER EYE AND SKIN PROTECTION MUST BE WORN WHEN INSTALLING AND SERVICING THE FPUDVS2000**


**Note:** All diagrams are strictly for guideline purposes only. Always consult an expert before installing the pump into specialized systems.

The pump should be **serviced by qualified persons only.**


### 4.1 Mounting Location

Choose an area located near the chemical supply tank, chemical injection point and electrical supply. Although the pump is designed to withstand outdoor conditions, a cool, dry, well ventilated location is recommended. Install the pump where it can be easily serviced.


- Mount the pump to a secure surface or wall using the enclosed hardware. Wall mount to a solid surface only. Mounting to drywall with anchors is not recommended.
- Keep the outlet (discharge) tubing as short as possible. Longer tubing increases the back pressure at the pump tube.
- Do not mount the pump directly over your chemical container. Chemical fumes may damage the unit. Mount the pump off to the side or at a lower level than the chemical container.
- Mounting the pump lower than the chemical container will gravity feed the chemical into the pump. This “flooded suction” installation can reduce the time required to prime the pump. Install a shut-off valve, pinch clamp or other means to halt the gravity feed to the pump during servicing.
- Your solution tank should be sturdy. Keep the tank covered to reduce fumes.
- Be sure your installation does not constitute a cross connection with the drinking water supply. Check your local plumbing codes.



**FIG. 4.0 INJECTOR MOUNTING**



**FIG. 4.1 SWIMMING POOL INSTALLATION**



**FIG. 4.2 TYPICAL INSTALLATION**

## 4.2 Electrical Connections

### 4.2.1 Input Power Connections -

Be certain to connect the pump to the proper supply voltage. Using the incorrect voltage will damage the pump and may result in injury. The voltage requirement is printed on the pump serial label.

### WARNING-RISK OF ELECTRICAL SHOCK

Jumper pins on the circuit board are factory preset for the correct voltage. See Fig. 4.4, page 7 for details.

The pump is supplied with a ground wire conductor and a grounding type attachment plug (power cord). To reduce the risk of electric shock, be certain that the power cord is connected only to a properly grounded, grounding type receptacle.

**Note:** *When in doubt regarding your electrical installation, contact a licensed electrician.*

### 4.2.2 External Input Signal Connections -

The pump will accept any one of three different types of external input signals; 4-20 mA, 0-10 VDC, or frequency. The 4-20mA and 0-10 VDC loops must be powered. Two types of frequency inputs, AC sine waves (magnetic coils type outputs) and Digital Square waves (Hall Effect signals, contact closures), are acceptable. A jumper plug located on the circuit board is factory pre-set for AC sine wave signals, the jumper must be re-positioned when digital square wave signals are being used. (See Fig. 4.4, page 7, "Hz input jumper settings")


All wiring connections are to be made inside of the junction box located on the side of the pump. A liquid-tite connector is supplied and should be used for the external signal cable. The signal input wires are color coded to the type of signal being used.

INPUT SIGNAL TYPE	POSITIVE WIRE COLOR	NEGATIVE WIRE COLOR
4-20 mA	BLUE (non-powered)	BLACK
0-10 V DC	ORANGE (non-powered)	BLACK
AC sine wave, Digital square wave	WHITE	BLACK

**FIG. 4.3 WIRING CHART - INPUT SIGNAL WIRE COLORS**

**SIGNAL INPUT MODES / FUNCTIONS & WIRING COLOR CODES**

INPUT MODE / FUNCTION	WIRES REQUIRED
MANUAL	NO CONNECTIONS
4-20 mA	BLUE (+) & BLACK (-)
0-10 VDC	ORANGE (+) & BLACK (-)
FREQUENCY	WHITE (+) & BLACK (-)
ALARM RELAY	PURPLE & PURPLE
FLOW VERIFICATION SENSOR (Digital square waves)	RED (+ 20VDC) & BLACK (-) & YELLOW (signal)
MOTOR ON SIGNAL	BROWN (+) & BLACK (-)



**FIG. 4.4 WIRING DIAGRAM - CIRCUIT BOARD**



## 4.3 How To Install the Tubing and Fittings

**CAUTION: PROPER EYE AND SKIN PROTECTION MUST BE WORN WHEN INSTALLING AND SERVICING THE FPUDVS2000**

**4.3.1 Inlet Tubing** - Locate the inlet fitting of the Pump Tube, see fig 4.6. Remove the tube nut. Push the clear PVC suction tubing onto the compression barb of the fitting. Use the tube nut to secure the tube. Hand tighten only.

**4.3.2 Strainer** - Trim the inlet end of the suction tubing so that the strainer will rest approximately two inches from the bottom of the solution tank. This will prevent sediment from clogging the strainer. Slip the ceramic weight over the end of the suction tube. Press the strainer into the end of the tube. Secure the ceramic weight to the strainer. Drop the strainer into the solution tank.


**4.3.3 Outlet Tubing** - Locate the outlet fitting of the Pump Tube, see fig 4.6. Remove the tube nut. Push the opaque outlet (discharge) tubing onto the compression barb of the fitting. Use the tube nut to secure the tube. Hand tighten only. Trim the other end of the outlet tube leaving only enough slack to connect it to the injection/check valve fitting. Increasing the outlet tube length increases the pressure at the pump tube, particularly with viscous fluids.

**Keep the outlet tube as short as possible.**


**4.3.4 Injection/Check Valve Fitting Installation** - The Injection/Check valve fitting is designed to install directly into either 1/4" or 1/2" female pipe threads. This fitting will require periodic cleaning, especially when injecting fluids that calcify such as sodium hypochlorite. These lime deposits and other build ups can clog the fitting increasing the back pressure and interfering with the check valve operation. See section 7.0.

Install the Injection/Check valve directly into the piping system. Do not use a pipe stud with a tee for insertion of the injection valve. The solution must inject directly into the flow stream.



Use Teflon thread sealing tape on the pipe threads. Push the opaque outlet (discharge) tubing onto the compression barb of the Injection/Check valve fitting. Use the tube nut to secure the tube. Hand tighten only.



**FIG. 4.5**



**FIG. 4.6**



**EXPLODED VIEW**

**FIG. 4.7 INJECTION FITTING INSTALLATION AND EXPLODED VIEW**

## 5.0 How To Operate The Pump

### 5.1 Description of Pump Output Adjustment Controls -

Open the control panel door by sliding the upper and lower slide clamps to the left. FIG. 5.2

- **RUN/STANDBY** Button -
  - ❖ Press to start and stop the pump. The **ARROW** next to the word RUN will light when in the run mode. The **ARROW** next to the word STAND-BY will blink when in the stand-by mode.
  - ❖ Press to clear **ALARM**.
  - ❖ When pressed with the FIELD Button, initiates a 99 second prime cycle which temporarily overrides the mode setting and runs the pump motor at 100% speed. The **ARROW** next to the word PRIME will blink.
  - ❖ When pressed with the DIGIT button, resets the 500 hour service warning timer to zero.
  - ❖ When pressed with the MODE button, initiates the programming mode. The **ARROW** next to the word PROGRAM will blink.
- **FIELD** Button -
  - ❖ In the programming mode, selects the digit to be changed.
  - ❖ When pressed with the DIGIT button, initiates the Flow Verification Sensor feature and allows programming the alarm delay from 1-256 seconds.
- **DIGIT** Button -
  - ❖ In the programming mode, increases the selected digit.
  - ❖ When pressed with the MODE Button, toggles the display from % motor speed to input signal value.
- **MODE** Button -
  - ❖ Used to select one of four operating modes.

**Mode 1** - Manual Adjustment (external input disabled)  
**Mode 2** - 4-20mA input  
**Mode 3** - 0-10VDC input  
**Mode 4** - Frequency (Hz) input




FIG. 5.1




FIG. 5.2

Slide both top & bottom clamps to the left only far enough (as shown) to open the control cover

## 5.2 OPERATING MODE 1 - Output adjusted manually -

In this mode, the pump's motor speed is adjusted manually using the front panel touch pad. The motor speed can be adjusted from 0-100%. To adjust the speed:

- ❖ **Set the pump for mode 1.** Press the MODE button until **MODE 1** is shown on the LCD display. The **%SPEED** icon will light. The large **3-DIGIT LCD** will indicate the currently programmed percentage of speed.
- ❖ **Enter the programming mode.** At the same time, press the RUN/STANDBY button and the MODE button. A blinking **ARROW** will point to the word PROGRAM indicating the program mode has been activated.
- ❖ Press the FIELD button to select the digit to program. The digit will blink when selected.
- ❖ Press the DIGIT button to change the selected digit.
- ❖ Repeat until all digits are programmed.
- ❖ To exit the programming mode, press the RUN/STANDBY button and the MODE button at the same time. The arrow next to the word PROGRAM will disappear.


- ✓ **NOTE:** If while in the program mode no buttons are pressed within 20 seconds, the circuitry will automatically return to the run mode, without saving changes.

## 5.3 OPERATING MODE 2 - Output adjusted by 4-20 mA input signal


In this mode, the pump's motor speed is adjusted automatically based on the value of the 4-20 mA input signal. Any motor speed can be assigned to either the minimum or maximum milliamp input values. However, **the programmed minimum mA value must be less than the programmed maximum mA value.** The **ALARM** and **SERVICE** icons will blink if the programming is in error. To assign the minimum and maximum motor speed and the minimum and maximum mA input signal values:

- ❖ **Set the pump for mode 2.** Press the MODE button until **MODE 2** is shown on the LCD display. The **%SPEED** or **mA** icon will light depending on the current display setting. The large **3-DIGIT LCD** will indicate the current motor speed or the current mA input value.
- ❖ **Enter the programming mode.** At the same time, press the RUN/STANDBY and MODE buttons. A blinking **ARROW** will point to the word PROGRAM indicating the program mode is activated. A blinking **ARROW** will point to the word MINIMUM indicating the minimum value is ready to be programmed. The **% SPEED** icon will blink indicating the percentage of speed is ready to be programmed.
- ❖ **Enter the motor speed at the minimum mA input signal value.** Press the FIELD button to select the digit to program. The digit will blink when selected.
- ❖ Press the DIGIT button to change the selected digit.
- ❖ Repeat until all digits are programmed.
- ❖ Press the mode button. The **% SPEED** icon will stop blinking and the **mA** icon will blink indicating the minimum mA value is ready to be programmed. The currently programmed minimum value is shown on the **3-DIGIT LCD**.
- ❖ **Enter the minimum mA input signal value.** Note: this value must be


### RUN MODE 1




### PROGRAM MODE 1 constant speed % setting




### RUN MODE 2



### PROGRAM MODE 2 % speed at the minimum input





### PROGRAM MODE 2 minimum input value







less than the maximum mA input signal value. Press the FIELD button to select the digit to program. The digit will blink when selected.

- ✘ Press the DIGIT button to change the selected digit.
- ✘ Press the mode button. The **Ma** icon will stop blinking and the **% SPEED** icon will blink. The **ARROW** next to the word MAXIMUM will blink indicating the maximum value is ready to be programmed. The currently programmed maximum motor speed value is shown on the **3-DIGIT LCD**.
- ✘ Enter the motor speed at the maximum mA input signal value. Press the FIELD button to select the digit to program. The digit will blink when selected.
- ✘ Press the DIGIT button to change the selected digit.
- ✘ Repeat until all digits are programmed.
- ✘ Press the mode button. The **% SPEED** icon will stop blinking and the **mA** icon will blink indicating the maximum mA value is ready to be programmed. The currently programmed maximum value is shown on the **3-DIGIT LCD**.
- ✘ Enter the maximum mA input signal value. Note: this value must be greater than the minimum mA input signal value. Press the FIELD button to select the digit to program. The digit will blink when selected..
- ✘ Press the DIGIT button to change the selected digit.
- ✘ Repeat until all digits are programmed.
- ✘ Press the mode button. Programming is complete.
- ✘ To exit the programming mode, press the RUN/STANDBY button and



MODE 2 PROGRAMMING EXAMPLES








## 5.4 OPERATING MODE 3 - Output adjusted by 0-10VDC input signal -

In this mode, the pump's motor speed is adjusted automatically based on the value of the 0-10VDC input signal. Any motor speed can be assigned to either the minimum or maximum DC input signal values. However, **the programmed minimum VDC value must be less than the programmed maximum VDC value.** The **ALARM** and **SERVICE** icons will blink if the programming is in error. To assign the minimum and maximum motor speed and the minimum and maximum VDC input signal values:

- ❖ **Set the pump for mode 3.** Press the MODE button until **MODE 3** is shown on the LCD display. The **% SPEED** or **VDC** icon will light depending on the current display setting. The large **3-DIGIT LCD** will indicate the current motor speed or the VDC input value.
- ❖ **Enter the programming mode.** At the same time, press the RUN/STANDBY and MODE buttons. A blinking **ARROW** will point to the word PROGRAM indicating the program mode is activated. A blinking **ARROW** will point to the word MINIMUM indicating the minimum value is ready to be programmed. The **% SPEED** icon will blink indicating the percentage of speed is ready to be programmed.
- ❖ **Enter the motor speed at the minimum VDC input signal value.** Press the FIELD button to select the digit to program. The digit will blink when selected.
  - ❖ Press the DIGIT button to change the selected digit.
  - ❖ Repeat until all digits are programmed.
  - ❖ Press the mode button. The **% SPEED** icon will stop blinking and the **VDC** icon will blink indicating the minimum VDC value is ready to be programmed. The currently programmed minimum value is shown on the **3-DIGIT LCD**.
- ❖ **Enter the minimum VDC input signal value.** Note: this value must be less than the maximum VDC input signal value. Press the FIELD button to select the digit to program. The digit will blink when selected.
  - ❖ Press the DIGIT button to change the selected digit.
  - ❖ Repeat until all digits are programmed.
  - ❖ Press the mode button. The **VDC** icon will stop blinking and the **% SPEED** icon will blink. The **ARROW** next to the word MAXIMUM will blink indicating the maximum value is ready to be programmed. The currently programmed maximum motor speed value is shown on the **3-DIGIT LCD**.
- ❖ **Enter the motor speed at the maximum VDC input signal value.** Press the FIELD button to select the digit to program. The digit will blink when selected.
  - ❖ Press the DIGIT button to change the selected digit.
  - ❖ Repeat until all digits are programmed.
  - ❖ Press the mode button. The **% SPEED** icon will stop blinking and the **VDC** icon will blink indicating the maximum VDC value is ready to be programmed. The currently programmed maximum value is shown on the **3-DIGIT LCD**.
- ❖ **Enter the maximum VDC input signal value.** Note: this value must be greater than the minimum VDC input signal value. Press the FIELD button to select the digit to program. The digit will blink when selected.
  - ❖ Press the DIGIT button to change the selected digit.
  - ❖ Repeat until all digits are programmed.
  - ❖ Press the mode button. Programming is complete.
  - ❖ To exit the programming mode, press the RUN/STANDBY button and the MODE button at the same time. The PROGRAM arrow will disappear.

RUN MODE 3






PROGRAM MODE 3  
% speed at the minimum inputPROGRAM MODE 3  
minimum input valuePROGRAM MODE 3  
% speed at the maximum inputPROGRAM MODE 3  
maximum input value

## 5.5 OPERATING MODE 4 - Output adjusted by frequency (Hz) input signal

In this mode, the pump's motor speed is adjusted automatically based on the frequency (Hz) of the input signal. Any motor speed can be assigned to either the minimum or maximum Hz input signals. However, **the programmed minimum Hz value must be less than the programmed maximum Hz value.** The **ALARM** and **SERVICE** icons will blink if the programming is in error. To assign the minimum and maximum motor speed and the minimum and maximum Hz input signal values:

- ❖ **Set the pump for mode 4.** Press the MODE button until **MODE 4** is shown on the LCD display. The **% SPEED** or **Hz** icon will light depending on the current display setting. The large **3-DIGIT LCD** will indicate the current motor speed or the Hz input value.
- ❖ **Enter the programming mode.** At the same time, press the RUN/STANDBY and MODE buttons. A blinking **ARROW** will point to the word PROGRAM indicating the program mode is activated. A blinking **ARROW** will point to the word MINIMUM indicating the minimum value is ready to be programmed. The **% SPEED** icon will blink indicating the percentage of speed is ready to be programmed.
- ❖ **Enter the motor speed at the minimum Hz input signal value.** Press the FIELD button to select the digit to program. The digit will blink when selected.
  - ❖ Press the DIGIT button to change the selected digit.
  - ❖ Repeat until all digits are programmed.
  - ❖ Press the mode button. The **% SPEED** icon will stop blinking and the **Hz** icon will blink indicating the minimum Hz value is ready to be programmed. The currently programmed minimum value is shown on the **3-DIGIT LCD**.
- ❖ **Enter the minimum Hz input signal value (to the nearest 10 Hz).** Note: this value must be less than the maximum Hz input signal value. Press the FIELD button to select the digit to program. The digit will blink when selected.
  - ❖ Press the DIGIT button to change the selected digit.
  - ❖ Repeat until all digits are programmed.
  - ❖ Press the mode button. The **Hz** icon will stop blinking and the **% SPEED** icon will blink. The **ARROW** next to the word MAXIMUM will blink indicating the maximum value is ready to be programmed. The currently programmed maximum motor speed value is shown on the **3-DIGIT LCD**.
- ❖ **Enter the motor speed at the maximum VDC input signal value.** Press the FIELD button to select the digit to program. The digit will blink when selected.
  - ❖ Press the DIGIT button to change the selected digit.
  - ❖ Repeat until all digits are programmed.
  - ❖ Press the mode button. The **% SPEED** icon will stop blinking and the **Hz** icon will blink indicating the maximum Hz value is ready to be programmed. The currently programmed maximum value is shown on the **3-DIGIT LCD**.
- ❖ **Enter the maximum Hz input signal value (to the nearest 10 Hz).** Note: this value must be greater than the minimum Hz input signal value. Press the FIELD button to select the digit to program. The digit will blink when selected.
  - ❖ Press the DIGIT button to change the selected digit.
  - ❖ Repeat until all digits are programmed.
  - ❖ Press the mode button. Programming is complete.


RUN MODE 4

PROGRAM MODE 4  
% speed at the minimum inputPROGRAM MODE 4  
minimum input valuePROGRAM MODE 4  
% speed at the maximum inputPROGRAM MODE 4  
minimum input value

## MODE 4 PROGRAMMING EXAMPLES


Example 1

0 Hz = 0% OUTPUT  
1000 Hz = 100% OUTPUT




Example 2

0 Hz = 100% OUTPUT  
1000 Hz = 0% OUTPUT



Example 3

0 Hz = 10% OUTPUT  
270 Hz = 75% OUTPUT



## 6.0 ALARMS -

### 6.1 Tube Failure Detection System (TFD)

The pump is equipped with a *Tube Failure Detection System* which is designed to stop the pump and provide a contact closure output in the event the pump tube should rupture and chemical enters the pump head. This patent-pending system is capable of detecting the presence of a large number of chemicals including Sodium Hypochlorite (chlorine), Hydrochloric (muriatic) Acid, Sodium Hydroxide, and many others. The system will not be triggered by water (rain, condensation, etc.) or silicone oil (roller and tubing lubricant).

If the system has detected chemical, the pump tube must be replaced and the pump head and roller assembly must be thoroughly cleaned. Press the **RUN/STAND-BY** and **FIELD** buttons at the same time (prime mode), to remove the pump tube. Thoroughly clean the pump head and roller assembly. Press the **RUN/STAND-BY** button to reset the system.

#### Confirm Chemical Detection -


To determine if your chemical will be detected by the system, remove the pump tube and roller assembly, place a small amount of the chemical in the bottom of the pump head, just enough to cover the sensors, and turn on the pump. If the TFD system detects the chemical, the pump will stop after a five second confirmation period and the **ALARM** icon will light on the display. If the TFD system does not detect the chemical, the pump will continue to run after the confirmation period. Carefully clean the chemical out of the pump head being sure to remove all traces of chemical from the sensor probes. Press the **RUN/STAND-BY** button to clear the alarm condition and restart the pump.

#### To Disable the Chemical Detection -

If the TFD system cannot detect your chemical, no further action is necessary. However, if there is a concern about possible false triggering by chemical contaminants, the system can be disabled by un-plugging the sensor probe wires from the circuit board. See Fig. 4.4, page 7 for the sensor probe's plug location on the internal circuit board.

#### Contact Closure Alarm Output Signal -

A contact closure output is provided with the TFD system. The output can be configured for normally open (factory default) or normally closed operation by properly positioning the connector plug on the circuit board (See fig. 4.4, page 7). The contacts will change states while an alarm condition exists. Two wires (purple), located in the junction box, are provided for connections. 20mA minimum / 1 amp maximum load @ 125V AC /24V DC.



## 7.0 How to Maintain the Pump

### WARNING-RISK OF ELECTRICAL SHOCK

#### 7.1 Routine Inspection and Maintenance

The pump requires very little maintenance. However, the pump and all accessories should be checked weekly. This is especially important when pumping chemicals. Inspect all components for signs of leaking, swelling, cracking, discoloration or corrosion. Replace worn or damaged components immediately.

Cracking, crazing, discoloration and the like during the first week of operation are signs of severe chemical attack. If this occurs, immediately remove the chemical from the pump. Determine which parts are being attacked and replace them with parts that have been manufactured using more suitable materials. The manufacturer does not assume responsibility for damage to the pump that has been caused by chemical attack.

#### 7.2 How to Clean and Lubricate the Pump

The pump will require occasional cleaning and lubricating. The amount will depend on the severity of service.

- ✓ When changing the pump tube assembly, clean the pump head chamber, TFD sensors, roller assembly and pump head cover.
- ✓ The pump head cover bearing may require grease periodically. Apply a small amount of grease (Aeroshell aviation grease #5 or equivalent) when necessary.
- ✓ Silicone oil **ONLY** may be used on the roller assembly and tube assembly.
- ✓ The injection/check valve assembly **must be cleaned** periodically, especially when injecting fluids that calcify such as sodium hypochlorite. These lime deposits and other build ups can clog the fitting increasing the back pressure which can interfere with the check valve operation and possibly damage the fitting and/or the pump. See section 4.3.4. Fig. 4.7.
- ✓ Periodically clean the suction strainer. Fig.4.5.
- ✓ Periodically inspect the air vents located under the motor compartment and on the rear panel. Clean if necessary.

#### 7.3 500 Hour Service Warning Timer

The FPUDVS2000 is equipped with a service warning timer. After 500 hours of accumulated running time, the **SERVICE** icon will light. This is a reminder that the pump tube is nearing its minimum life expectancy and should be replaced. *Your actual tube life will depend on many factors such as the chemical used, back pressure, temperature, viscosity, and motor RPM.*

Simultaneously press the **RUN/STANDBY** and **DIGIT** buttons to reset the service timer to zero. **Note:** Pressing the **FIELD** and **DIGIT** buttons will display the currently accumulated time value.

**CAUTION: PINCHING HAZARD, KEEP YOUR FINGERS OUT OF THE PUMP HEAD WHILE CHANGING THE PUMP TUBE.**



## 7.4 How to Replace the Pump Tube

The pump tube assembly will eventually break if not replaced. The tube has been designed for a minimum service life of 500 hours. However, the life of the tube is affected by many factors such as the type of chemical being pumped, the amount of back pressure, the motor RPM, temperature and others. The pump tube assembly must be inspected and replaced regularly.

**After replacing the pump tube, press the RUN/STANDBY button and the DIGIT button at the same time to reset the service warning timer.**

### 7.4.1 How to Remove the Old Pump Tube

The pump roller assembly spins in a counter clockwise direction. The pump head inlet (suction) side is located at the bottom of the pump and the outlet (discharge) is located at the top of the pump head.

**7.4.1.1** Release any pressure that may be in the discharge tubing.

**7.4.1.2** Disconnect the suction and discharge tubes from the pump tube.

**7.4.1.3** Remove the pump head cover.

**7.4.1.4** With the pump running, pull the inlet fitting out of the pumphead. Guide the tube counter clockwise away from the rollers. Pull the outlet fitting out of the pump head.




FIG. 7.1

### 7.4.2 How to Install a New Pump Tube

Be sure the pump head chamber is clean and free of any debris. Remove and inspect the roller assembly. Be sure the rollers spin freely. If required, apply a small amount of grease to the pump head cover bearing. Silicone oil **only** may be used on the tubing and rollers. See section 7.2.

**6.4.2.1** With the pump running, insert the inlet (suction) side of the Pump Tube fitting into the lower retaining slot in the pump head. Fig. 7.2.

**6.4.2.2** **Carefully** guide the Pump Tube into the pump head. Stretch the tube slightly and insert the outlet (discharge) fitting into the upper retaining slot in the pump head. Fig. 7.3.

**6.4.2.3** Place the clear cover on the pump head and secure with three screws.




FIG. 7.2





FIG. 7.3

# Replacement Parts Drawing



## PARTS LIST

Item	Part No	Description	Qty	Item	Part No	Description	Qty
1	71000-489	Enclosure Back Plate With Gasket, Valox	1	26	A-008-1	Gearbox, 14 Rpm	1
2	90011-094	Washer, Mounting, #10 Stainless	2		A-008-2	Gearbox, 30 Rpm	1
3	90011-091	Mounting Screw, #10 X 1.0" Phillips Steel	4		A-008-3	Gearbox, 45 Rpm	1
4	76001-001	Tubing Spacer FPU2000-14PTA	2		A-008-4	Gearbox, 60 Rpm	1
5	90010-036	Wire Nut, Blue	1		A-008-5	Gearbox, 125 Rpm	1
6	90006-580	Gasket, Enclosure Back Plate	1	27	76001-488	Pumphead, w/TFD sensors	1
7	A-023N-V-115	Circuit board 115V	1	28	C-324N	Screw, Pumphead, 10-32 X .50 Phil Pan Black	4
	A-023N-V-230	Circuit board 220V/230V	1	29	A-031	Spacer, Rotor	1
8	90010-235	Fuse, Circuit Board, 1A 250VAC	1	30	FPU2000-14PTA	Pump Tube, .25 O.D., Compression Barb Type	1
9	71000-175	Power Cord, 115v60hz, Digital Models	1		FPU2000-38PTA	Pump Tube, .37 O.D., Compression Barb Type	1
	71000-176	Power Cord, 220v50hz, Digital Models	1		FPU2000-716PTA	Pump Tube, .43 O.D., Compression Barb Type	1
	71000-177	Power Cord, 230v60hz, Digital Models	1	31	FPU2000-TN	Nut, Tube Compression Type, .37 O.D. Tubing	2
10	70000-589	Cord Inlet Bushing	1	32	A-002N-4Q	Pump Tube, .25 O.D., Quick-connect W/ O-ring	1
11	90003-559	Mounting Feet, Rubber	4		A-002N-6Q	Pump Tube, .37 O.D., Quick-connect W/ O-ring	1
12	76001-000	Slide Clamp, Enclosure Rear	1	33	90003-007	O-ring, Quick-connect Pump Tubes, Viton	2
13	76000-999	Slide Clamp, Enclosure Front	1	34	90008-299	Adapter, Quick-connect Inlet, .37 O.D. Tube	1
14	76001-253	Enclosure	1	35	90008-300	Adapter, Quick-connect Outlet, .37 O.D. Tube	1
15	90006-579	Gasket, Enclosure Front	1	36	C-335-6	Tubing, Outlet, .37 O.D. X 5ft, Polyethylene	1
16	90002-191	Door, Electronic Controls Cover	1	37	C-334-6	Tubing, Inlet, .37 O.D. X 5ft, Clear PVC	1
17	70002-250	Gearmotor, 14 Rpm, 24V DC	1	38	FPU2000-CW	Weight, Inlet Tubing, Ceramic	1
	70002-251	Gearmotor, 30 Rpm, 24V DC	1	39	C-342-2	Strainer, Inlet Tube, Polypropylene	1
	70002-252	Gearmotor, 45 Rpm, 24V DC	1	40	FPU2000-RA	Roller Assembly -4, -6 tubes (white rollers)	1
	70002-253	Gearmotor, 60 Rpm, 24V DC	1		FPU2000-716RA	Roller Assembly -7 tubes (black rollers)	1
18	90010-246	Gearmotor, 125 Rpm, 24V DC	1	41	90012-245	Label, front panel controls	1
19	90010-245	Wire set w/plug, Alarm relay	1	42	90011-074	Washer, #8 splitlock	2
N/s	90010-247	Wire set w/plug, input signals	1	45	FPU2000-PHB	Cover, Pumphead With Sleeve Bearing	1
20	C-1814N-4	Motor Brush kit (2 ea), 24V DC	1	46	76001-003	Bearing, Sleeve, Pumphead Cover	1
21	90011-023	Screw, Motor, 8-32 x .50	2	48	90011-160	Screw, Pumphead Cover, 8-32 X .62 Cap	3
22	90010-244	Motor, 24V DC	1	49	FPU1000IF	Injection Valve Assy, .5-2.5 MPT X .37OD Tube	1
23	90011-024	Screw, Green Ground, 8-32 x .25	1	52	90007-515	Bushing, Junction Box Connector, Alum.	1
24	90011-078	Washer, Ground Screw, #8 Star	1	53	76001-254	Junction Box	1
25	90010-222	Wire, Motor ground, Digital Timers, Green	1	54	90011-129	Screw, Cover, 6-32 X .25 Phil Pan SS Black	2
			1	55	71000-133	Cover, Junction Box with Gasket and Label	1
			1	56	90008-199	Connector Liquid-tight	1



**MADE**

**OMEGA  
WARRANTY/DISCLAIMER**

OMEGA warrants this unit to be free of defects in materials and workmanship and to give satisfactory service for a period of **13 months** from date of purchase. OMEGA Warranty adds an additional one (1) month grace period to the normal one (1) **year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product. If the unit should malfunction, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective it will be repaired or replaced at no charge. However, this WARRANTY is void if the unit shows evidence of having been tampered with or shows evidence of being damaged as a result of excessive corrosion; or current, heat, moisture, or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components which wear or which are damaged by misuse are not warranted. These include contact points, fuses, and triacs.

**OMEGA is glad to offer suggestions on the use of it's various products. Nevertheless, OMEGA only warrants that the parts manufactured by it will be as specified and free of defects.**

**OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED.**

**LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.**

Every precaution for accuracy has been taken in the preparation of this manual; however, OMEGA ENGINEERING, INC. Neither assumes responsibility for any omissions or errors that may appear nor assumes liability for any damages that result from the use of the products in accordance with the information contained in this manual.

**SPECIAL CONDITION:** Should this equipment be used in or with any nuclear installation or activity, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever

---

**RETURN REQUESTS / INQUIRIES**

---

Direct all warranty and repair requests/inquiries to the OMEGA ENGINEERING Customer Service Department. **BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS).** The assigned AR number should then be marked on the outside of the return package and on any correspondence.

**FOR WARRANTY RETURNS,** please have The following information available

1. P.O. Number under which the product was **PURCHASED.**
2. Model and serial number of the product under warranty, and
3. Repair Instructions and/or specific Problems relative to the Product.

**FOR NON WARRANTY REPAIRS OR CALIBRATION,** consult OMEGA for current repair/calbration charges. Have Information before contacting OMEGA.

1. P.O. Number to cover the **COAST** of the repair/ calibration.
2. Model and serial number of product, and
3. Repair instructions and/or specific Problems relative to the product

**OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering. OMEGA is a registered trademark of OMEGA ENGINEERING, INC. ©Copyright 1995 OMEGA ENGINEERING, INC. All rights reserved. This documentation may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without written consent of OMEGA ENGINEERING, INC.**

# Where Do I Find Everything I Need For Process Measurement and Control?

**OMEGA... Of Course!**

*Shop on line at [www.Omega.com](http://www.Omega.com)*

## **TEMPERATURE**

- Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- Wire: Thermocouple, RTD & Thermistor
- Calibrations & Ice Point References
- Recorders, Controllers & Process Monitors
- Infrared Pyrometers

## **PRESSURE / STRAIN FORCE**

- Transducers & Strain Gauges
- Load Cells & Pressure Gauge
- Displacement Transducers
- Instrumentation & Accessories

## **FLOW / LEVEL**

- Rotameters, Gas Mass Flowmeters & Flow Computers
- Air Velocity Indicators
- Turbine / Paddlewheel Systems
- Totalizers & Batch Controllers

## **pH / CONDUCTIVITY**

- pH Electrodes, Testers & Accessories
- Benchtop / Laboratory Meters
- Controllers, Calibrators, Simulators & Pumps
- Industrial pH & Conductivity Equipment

## **DATA ACQUISITION**

- Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- Wire: Thermocouple, RTD & Thermistor
- Calibrations & Ice Point References
- Recorders, Controllers & Process Monitors
- Infrared Pyrometers

## **HEATERS**

- Heating Cable
- Cartridge & Strip Heaters
- Immersion & Band Heaters
- Flexible Heaters
- Laboratory Heaters

## **ENVIRONMENTAL MONITORING AND CONTROL**

- Metering & Control Instrumentation
- Refractometers
- Pumps & Tubing
- Air, Soil & Water Monitors
- Industrial Water & Wastewater Treatment
- pH, Conductivity & Dissolved Oxygen Instruments