



# User's Guide



*Shop online at*

**omega.com<sup>®</sup>**

CEOMEGA<sup>®</sup>

*omega.com*

*e-mail: info@omega.com*

*For latest product manuals:*

*omegamanual.info*

**ISO 9001**  
CERTIFIED  
CORPORATE QUALITY

STAMFORD, CT

**ISO 9002**  
CERTIFIED  
CORPORATE QUALITY

MANCHESTER, UK

**FL-2000-AL**  
**Flowmeter Alarm**



OMEGAnet® Online Service  
omega.com

Internet e-mail  
info@omega.com

### **Servicing North America:**

**U.S.A.:** One Omega Drive, P.O. Box 4047  
ISO 9001 Certified Stamford, CT 06907-0047  
TEL: (203) 359-1660  
FAX: (203) 359-7700  
e-mail: info@omega.com

**Canada:** 976 Bergar  
Laval (Quebec) H7L 5A1, Canada  
TEL: (514) 856-6928  
FAX: (514) 856-6886  
e-mail: info@omega.ca

### **For immediate technical or application assistance:**

**U.S.A. and Canada:** Sales Service: 1-800-826-6342/1-800-TC-OMEGA®  
Customer Service: 1-800-622-2378/1-800-622-BEST®  
Engineering Service: 1-800-872-9436/1-800-USA-WHEN®

**Mexico:** En Español: (001) 203-359-7803  
e-mail: espanol@omega.com  
FAX: (001) 203-359-7807  
info@omega.com.mx

### **Servicing Europe:**

**Czech Republic:** Frystatska 184, 733 01 Karviná, Czech Republic  
TEL: +420 (0)59 6311899  
FAX: +420 (0)59 6311114  
Toll Free: 0800-1-66342  
e-mail: info@omegashop.cz

**Germany/Austria:** Daimlerstrasse 26, D-75392 Deckenpfromn, Germany  
TEL: +49 (0)7056 9398-0  
FAX: +49 (0)7056 9398-29  
Toll Free in Germany: 0800 639 7678  
e-mail: info@omega.de

**United Kingdom:** One Omega Drive, River Bend Technology Centre  
ISO 9002 Certified Northbank, Irlam, Manchester  
M44 5BD United Kingdom  
TEL: +44 (0)161 777 6611  
FAX: +44 (0)161 777 6622  
Toll Free in United Kingdom: 0800-488-488  
e-mail: sales@omega.co.uk

---


It is the policy of OMEGA Engineering, Inc. to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct, but OMEGA accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

**WARNING:** These products are not designed for use in, and should not be used for, human applications.

## SPECIFICATIONS

Body Material:	ABS
Spacer Material:	SBR Rubber
Operating Temperature:	0-70°C; 32-160°F
Supply Voltage:	5VDC Regulated
Supply Current:	250mA
Output Signal: (Requires Advanced Power Supply)	0-5 Volt logic signal
Buzzer Volume:	90dB
Connector:	RJ11
Environmental:	Splash Resistant



## DESCRIPTION


The FL-2000-AL Alarm is a non-contact sensor designed to alert when flow rates exceed defined thresholds. The FL-2000-AL Alarm provides red and green LED's visual status indicators, and a buzzer as an audible indicator of flow rate status.

## FEATURES

- Detects flow rates that exceed user settings.
- Integral red and green LED's and audible buzzer indicate operating state.
- Low-level digital output (on / off) represents operating state (See Output Connector Section for details).
- Latching and Self-resetting modes.
  - Latching mode will alarm continuously after a flow rate error, until the user resets the unit.
  - Self-reset mode will stop alarming when flow returns to desired range, but will light both red and green LED's to indicate that an error had occurred.
- No calibration necessary.
- Rugged, splash resistant enclosure.
- Low power 5V input.
  - Power options include basic supply or supply with battery back up and logic output.
- Multiple units may be installed on a single flow meter to provide multiple thresholds.
- Non-contact sensing system will not be damaged by contaminants in flow stream.
- Field installable while the flow meter is in use.

## INSTALLATION

The FL-2000-AL Alarm is attached to a FL-2000 series acrylic flowmeter by placing the unit flush onto the front of the flow meter and tightening the thumbscrew. Included snap fit spacers (See Diagram 1) allow the unit to fit various FL-2000 series flowmeters. See Table 1 to determine the proper pair of spacers to use for a given flowmeter. The spacers are packed as a pair and are labeled on the end near the sensing holes. The FL-2000-AL Alarm may be installed in an upward or downward orientation. The sensing line is offset to one end to allow two FL-2000-AL Alarms to be installed over a narrow range on the flowmeter.




**DIAGRAM 1, SPACER INSTALLATION**

<b>FL-2000 SERIES</b>	<b>GUIDE ROD</b>	<b>SPACER NUMBER</b>
FL-2071 to FL-2128	Y	NO SPACER REQUIRED
FL-2001 to FL-2025	Y	ESP003
FL-2001 to FL-2025	N	ESP004
FL-2031 to FL-2057	Y	ESP005
FL-2031 to FL-2057	N	ESP006
FL-2060 to FL-2069	Y	ESP007

**TABLE 1, SPACER SELECTION**

The FL-2000-AL Alarm uses an optical based sensing system, it is important that the flowmeter that it is to be installed on is free of dirt, grease, and that no large scratches are present on the sides of the flowmeter. If the flowmeter appears dirty or scratched, prepare the flowmeter for installation of the FL-2000-AL Alarm by following the cleaning instructions included with the flowmeter.

To set the alarm position, adjust the flow rate through the flow meter until the float is at the position that would indicate and alarm. Place the FL-2000-AL Alarm on the flowmeter above or below the float, and slide it towards the float until it alarms. Tighten the setscrew, return the flow to its normal rate, and reset the FL-2000-AL Alarm. (See diagram 2).



**DIAGRAM 2, SETTING ALARM LOCATION**

## OPERATION

The FL-2000-AL Alarm may be operated in standard or self-reset mode. The unit requires no set up, and will begin to operate as soon as it is connected to its power supply, and will operate in standard mode. To operate in self-reset mode, hold the reset button while applying power. When operating without an error, the FL-2000-AL Alarm will have a green LED lit.

**Standard mode:** In this mode, the FL-2000-AL Alarm will alarm when the float crosses the sensing line, and will alarm until the reset button is pressed. While alarming, the red LED will be lit, the buzzer will sound, and the logic output will change state.


**Self-Reset mode:** In this mode, the FL-2000-AL Alarm will alarm when the float crosses the sensing line, and will reset when the float returns to the valid operating range. During normal operation, the green LED will blink to note that the FL-2000-AL Alarm is in self-reset mode. While alarming, the red LED will be lit, the buzzer will sound, and the logic output will change state. Upon returning to the valid range, the green LED will begin to blink, and the red LED will blink to denote violations have occurred since the reset button was pressed.

## OUTPUT CONNECTOR AND PIN-OUT DESCRIPTION

The FL-2000-AL Alarm is provided with a male six pin modular RJ11 connector. This connector provides the power input to the FL-2000-AL Alarm, as well as the logic output. If using the basic power supply, the logic output is not available. This signal is available from a connector on the advanced power supply, or by accessing pin 3 on the connector. The pin configuration for the included cable assembly is as follows:

PIN NUMBER	SIGNAL	WIRE COLOR
1	5VDC	Black
2	N/A	Red
3	LOGIC OUT (0-5V, 10mA)	Green
4	GROUND	Yellow

**TABLE 2. OUTPUT CONNECTOR DEFINITION**



**DIAGRAM 3. OUTPUT CONNECTOR**

## POWER SUPPLY OPTIONS

The FL-2000-AL Alarm may be powered via three different options. These include the basic supply; the advanced supply with universal input and battery backup, or the unit may be powered by the user (See Table 2 for pin definitions).

OPTION	INPUT	PART #
Basic Supply	120V AC (US plug only)	FL-2000-PW
Advanced Supply w/Backup	100-240V AC; 9V Battery (International plugs)	FL-2000-PWA
User Supplied	Regulated 5VDC; 250mA	N/A

**TABLE 3. POWER SUPPLY OPTIONS**

The advanced supply accepts AC power via a universal input adapter, which comes with interchangeable US, European, and Asian style plugs. In addition, a 9V battery is used as battery backup during a power failure. A fully charged 9V battery provides over two (2) hours of backup with the FL-2000-AL Alarm in alarm condition. Backup time is longer if the FL-2000-AL Alarm is operating in a clear state. The supply also has a connector for access to the logic output signal. The signal high (5V) when clear, and low (0V) when alarming. The signal can source up to 25mA.

**TROUBLESHOOTING**

<b><u>Problem</u></b>	<b><u>Solution</u></b>
Unit fails to operate	Ensure that the unit is powered correctly. Power the unit through an UPS to provide reliable power.
Unit does not fit properly on flowmeter	Ensure that proper spacers are being used and are properly installed. Ensure that the unit is tight by checking the thumbscrew.
Unit does not alarm on flow violation	Ensure that proper spacers are being used. Avoid shining bright light on the unit or flowmeter, it may cause false readings. Ensure that the unit is powered correctly.
Unit alarms when placed on unit, will not reset	Ensure that proper spacers are being used. Ensure that the flow tube is free of build up, clean if necessary. Ensure that sides of flowmeter are free of dirt, grease, and major scratches. If used on a liquid meter, ensure that liquid is clear and free of bubbles.
Unit will not stay in Self-Reset mode.	Ensure that the unit is powered correctly. Unit defaults to standard mode at power-up.
Unit alarms without a flow violation	Ensure that unit is tight by checking thumbscrew. If used on a liquid meter, ensure that liquid is clear and free of bubbles.
Spacers will not attach to unit.	Loosen the thumbscrew to facilitate spacer installation.

## WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **13 months** from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal **one (1) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components in which wear is not warranted, include but are not limited to contact points, fuses, and triacs.

**OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by the company will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.**

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

## RETURN REQUESTS/INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of the product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 2005 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.

# Where Do I Find Everything I Need for Process Measurement and Control? **OMEGA...Of Course!** *Shop online at [omega.com](http://omega.com)*

## **TEMPERATURE**

- ☑ Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- ☑ Wire: Thermocouple, RTD & Thermistor
- ☑ Calibrators & Ice Point References
- ☑ Recorders, Controllers & Process Monitors
- ☑ Infrared Pyrometers

## **PRESSURE, STRAIN AND FORCE**

- ☑ Transducers & Strain Gages
- ☑ Load Cells & Pressure Gages
- ☑ Displacement Transducers
- ☑ Instrumentation & Accessories

## **FLOW/LEVEL**

- ☑ Rotameters, Gas Mass Flowmeters & Flow Computers
- ☑ Air Velocity Indicators
- ☑ Turbine/Paddlewheel Systems
- ☑ Totalizers & Batch Controllers

## **pH/CONDUCTIVITY**

- ☑ pH Electrodes, Testers & Accessories
- ☑ Benchtop/Laboratory Meters
- ☑ Controllers, Calibrators, Simulators & Pumps
- ☑ Industrial pH & Conductivity Equipment

## **DATA ACQUISITION**

- ☑ Data Acquisition & Engineering Software
- ☑ Communications-Based Acquisition Systems
- ☑ Plug-in Cards for Apple, IBM & Compatibles
- ☑ Datalogging Systems
- ☑ Recorders, Printers & Plotters

## **HEATERS**

- ☑ Heating Cable
- ☑ Cartridge & Strip Heaters
- ☑ Immersion & Band Heaters
- ☑ Flexible Heaters
- ☑ Laboratory Heaters

## **ENVIRONMENTAL MONITORING AND CONTROL**

- ☑ Metering & Control Instrumentation
- ☑ Refractometers
- ☑ Pumps & Tubing
- ☑ Air, Soil & Water Monitors
- ☑ Industrial Water & Wastewater Treatment
- ☑ pH, Conductivity & Dissolved Oxygen Instruments