

User's Guide



Shop online at

omega.com[®]

Ω OMEGA[®]

omega.com

e-mail: info@omega.com

For latest product manuals:

omegamanual.info

ISO 9001
CERTIFIED
CORPORATE QUALITY

STAMFORD, CT

ISO 9002
CERTIFIED
CORPORATE QUALITY

MANCHESTER, UK

WM7400
M-4376/1006



OMEGAnet® Online Service
www.omega.com

Internet e-mail
info@omega.com

Servicing North America:

USA:
ISO 9001 Certified

One Omega Drive, P.O. Box 4047
Stamford CT 06907-0047
TEL: (203) 359-1660 FAX: (203) 359-7700
e-mail: info@omega.com

Canada:

976 Bergar
Laval (Quebec) H7L 5A1, Canada
TEL: (514) 856-6928 FAX: (514) 856-6886
e-mail: info@omega.ca

For immediate technical or application assistance:

USA and Canada: Sales Service: 1-800-826-6342 / 1-800-TC-OMEGA®
Customer Service: 1-800-622-2378 / 1-800-622-BEST®
Engineering Service: 1-800-872-9436 / 1-800-USA-WHEN®
TELEX: 996404 EASYLINK: 62968934 CABLE: OMEGA

Mexico:

En Español: (001) 203-359-7803 e-mail: espanol@omega.com
FAX: (001) 203-359-7807 info@omega.com.mx

Servicing Europe:

Benelux:

Postbus 8034, 1180 LA Amstelveen, The Netherlands
TEL: +31 (0)20 3472121 FAX: +31 (0)20 6434643
Toll Free in Benelux: 0800 0993344
e-mail: sales@omegaeng.nl

Czech Republic:

Frystatska 184, 733 01 Karviná, Czech Republic
TEL: +420 (0)59 6311899 FAX: +420 (0)59 6311114
Toll Free: 0800-1-66342 e-mail: info@omegashop.cz

France:

11, rue Jacques Cartier, 78280 Guyancourt, France
TEL: +33 (0)1 61 37 2900 FAX: +33 (0)1 30 57 5427
Toll Free in France: 0800 466 342
e-mail: sales@omega.fr

Germany/Austria:

Daimlerstrasse 26, D-75392 Deckenpfronn, Germany
TEL: +49 (0)7056 9398-0 FAX: +49 (0)7056 9398-29
Toll Free in Germany: 0800 639 7678
e-mail: info@omega.de

United Kingdom:

ISO 9002 Certified

One Omega Drive, River Bend Technology Centre
Northbank, Irlam, Manchester
M44 5BD United Kingdom
TEL: +44 (0)161 777 6611 FAX: +44 (0)161 777 6622
Toll Free in United Kingdom: 0800-488-488
e-mail: sales@omega.co.uk

It is the policy of OMEGA to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct, but OMEGA Engineering, Inc. accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

WARNING: These products are not designed for use in, and should not be used for, human applications.

TABLE OF CONTENTS

SPECIFICATIONS.....	3
INSTALLATION.....	4
SETUP ACCESS.....	5
MENU LAYOUT.....	6
CONFIGURATION.....	7
REMOTE SERIAL DISPLAY.....	8
CALIBRATION.....	9
SERIAL PORTS.....	10
SERIAL COMMUNICATIONS.....	11
ANALOG OUTPUT.....	13
DIGITAL INPUT/OUTPUT.....	15
SETPOINTS.....	17
OVER/UNDER.....	17
BATCH MODE.....	18
TIME & DATE.....	19
AC/DC OPERATION.....	19
DISPLAY MESSAGES.....	20
115/220 VAC.....	21

SPECIFICATIONS:

LOAD CELL A/D CONVERTER

TYPE: 24 bit delta sigma
EXCITATION: 5 VDC, 120 mA max.
SIGNAL INPUT: 16 mv
SENSITIVITY: 0.1 uV/grad
UPDATE RATE: 30 update/second

DISPLAY: Six (6) Decades, 0.6 inch LED

CONTROLS: "ZERO","GROSS/NET","TARE", "UNITS", "PRINT"

POWER INPUT: 117/217 VAC, 50-60 HZ, 20 watts, fuse 0.25 A Slo-Blow.

SERIAL PORTS:

Port 1: RS232C or 20ma
Port 2: RS485, RS232C or 20mA.

ENCLOSURE: Stainless Steel, NEMA 4x, Tilt - Stand Base, 7lbs.

CASE: 10"(w) x 6.5"(h) x 4"(d)

OPTIONS:

TIME & DATE: 12/24 hr, battery backed.


ANALOG OUTPUT: 0-10v, 4-20ma (16 bit D/A).

DIO: 4 AC/DC – inputs, 4 AC outputs (SS Relays, 0.5 amp)

INSTALLATION

POWER WIRING:The indicator is designed to be operated from 117/217 VAC, 50-60 Hz. The unit power cord must be plugged into a grounded 3 - wire polarized AC wall socket. All normal wiring and grounding precautions should be observed, including use of a "clean" AC power line.

SCALE WIRING:The unit is equipped with cable gland entry for load cell cable insertion and internal (pluggable) terminal strip for 4 / 6 wire connection. Remove sense jumpers P11-8/7, P11-6/5 for six wire.



Keypad:



SETUP ACCESS

To access instrument configuration, calibration or to enable options, depress the “Zero” key for five seconds.

The Audit Trail counters (“Pxxxx” and “Cxxxx”) are displayed first followed by access code request (“AC?”). The initial factory setting is “0000” which can be entered with four steps of the “Gross/Net” key (“AC0000”) and “Print”. If no entry is made, instrument returns to operate mode.

The access code can be changed to any four digit combination during setup exit when display again shows “AC?”. Use the Tare key to increment a digit and Gross/Net to shift the digit position.

The display check feature is accessed during the initial entry point “AC?”, by a second step of the “Zero” key. The software version “V 1.XX” will be displayed followed by a continuous display test routine. Another step on the “zero” key returns to “AC?”.

Front panel access is inhibited if conventional “sealing” is applied by setting jumper J1-1 in the B position. The board mounted “CAL” button is then used for access.

After entry, use the “Gross/net” key to select a main menu; configuration (“SEL.CFG”), calibration (“SEL.CAL”), or options (“SEL.OPX”).


The “Zero” key enters selected menu and is used to step through sub categories. Individual parameter selection is made with the “Gross/Net” key, which then steps through the parameter choices.

The “Print” key is used at any point to “back” up from categories to menus and to “save?” and “AC?” and exit.

During the exit steps, if changes were made, the display is “save?” with alternate “no”. To save changes, use the “Tare” key to select “yes” and “Print” to exit.

Calibration numeric entries are made with "Tare" key incrementing the flashing digit and the "Gross/Net" key shifting the digit selection.

Menu Layout



CONFIGURATION: “SEL.CFG” Use Zero to enter the menu and step to each category, Gross/Net to select parameters. Print to return to menu selection.

Capacity is the combination of “1”, “2” and “3”.

Example: 1__100, 2__2 and 3__0.0 = 2,000 x 0.2 lb

Step	Parameters	Definition
1	5, 10, 15, 20...100, 120...1000	Number of divisions x100 100 = 10,000 divisions
2	1, 2, 5, 10, 20, 50, and 100.	Count by selection 10,000 divisions, count by 2 = 20,000
3	0, 0.0, 0.00, 0.000, and 0.0000	Decimal point selection
4	105P, 9 d (105% or 9 divisions)	Overrange selection
5	1, 2, 3, 4, 5, 6, 8, 10, 12, 15.....90	Digital filter selection (averaging)
6	off, 0.5, 1, 3, 5, 10 (divisions)	Auto Zero Maintenance (AZM)
7	1.9, 5, 10, 20, FS (% of capacity)	Zero range selection 1.9% of 2,000 x 0.2 = 38.0 lb
7.1	off, on (ISM)	Zero's scale on power-up
8	off, 1, 3, 5,10 (divisions)	Motion Band selection
9	lb, kg, con	Units selection and convert
10	nt, Gtn, n.nt, n.Gtn.	Port 1 serial output selection nt display only, Gtn is Gross Tare Net and n.nt/n.Gtn inhibit neg gross print
11	off, co, de	Off, Continuous, or Demand
12	7o, 7E, 8n	7- odd, 7- even or 8- none
13	12, 24, 48, 96	Baud rate selection
14	off, 1, 2, 3, 5, 10, 15 (seconds)	Delay between lines or continuous output.
19	A, b	A : adds “STX” in continuous b : No “STX” in continuous
20	nt, Gtn, n.nt, n.Gtn	Port 2 serial output selection
21	off, co, de, Ln	Off, Continuous, Demand, Network
22	7o, 7E, 8n	7- odd, 7- even or 8- none
23	12, 24, 48, 96	Baud rate selection
24	off, 1, 2, 3, 5, 10, 15 (seconds)	Delay between lines or continuous output.
25	1 – 16 (RS485/RS422)	Network address selection

30	off, on	DIO Inputs
----	---------	------------

Remote Serial Display (RSD) Option

In RSD mode the instrument can be set to work with another unit as a “remote” either as the main or the slave unit. Communication is pre-set for channel two only on both units.
(RS232, 9600, 8, none)

When in remote mode, re-access to the following selections requires using the internal “cal” switch.

Remote unit can have full or partial control of the main unit. Devices are available to replace the cable for wireless communication.

40	rd.OF, rd.En, rd.re	rd.En : Selects Indicator as Remote Display (RSD) rd.re : Allows indicator to operate w/RSD
41	En.On	Allow remote keypad operation
42	Zr.On	Enable/Disable zero key
43	tr.On	Enable/Disable tare key
44	Un.On	Enable/Disable unit key
45	Pr.On	Enable/Disable print key
46	Fn.On	Enable/Disable all other functions

CALIBRATION: "SEL.CAL" Use Zero to enter the menu indicated by a flashing "C" on the left and live weight is displayed. Scale zero (dead load) or adjusting span (single or multi-point) are independent. Therefore either can be done and repeated as necessary before exiting calibration. If an error has been made, exit without "storing" will return to prior setup.

KEY (FUNCTION)	DISPLAY	Definition
(Live weight 123 lb)	"C"__123	Cal mode scale reading
Zero (acquire dead load)	"-----" to "C__0.0"	acquires new dead load
(live weight 5000 lb)	"C"__4995	Scale reading with load
Gross/Net (adjust span)	004995	freezes display for adjustment
Gross/Net (select digit)	00499"5"	digit flashes
Tare (increments digit)	00499"0"	Increments
Gross/Net (select digit)	0049"9"0	digit flashes
(Adjustment complete)	005000	adjusted value

Then with Print:

(adjust span) "-----" to "C" 5000 displays new span

Repeat as required then use Print to exit CAL.

"Save ?" "No" or "Save ?" "Yes" use Tare to select and Print to store "yes" with changes or "no" to exit without changes.

Continue with Print to "Ent AC" which allows access code change by entering a new four digit code and press again or skip with no entry.

Option 5 Ten point calibration: Allows up to 10 span points (pt1.....pt10). Zeroing the scale clears the existing values. Points are assigned incrementally with error indication if the addition is not above the prior point or exceeding scale capacity. Filter selection included for rolling or box averaging.


5.1	OFF, On	Enable 10 point span
5.2	A, b	A : Rolling average B : Box average

SERIAL PORTS

Port 1: RS232 duplex (Rx,Tx), 20ma (Tx).

Port 2: RS232 duplex (Rx,Tx), 20ma (Rx,Tx), RS485, or RS422.

Note: Position jumper on J2 for Port 2 receive selection.



Serial Communications

Remote Commands

<Z><cr>	Zero Scale	“Gross” mode, no motion, inside zero range.
<N><cr>	Switch to Net	“Gross” mode with Tare stored.
<G><cr>	Switch to Gross	“Net” mode.
<T><cr>	Auto Tare	Switch to Net, no motion, not at “Gross” zero.
<P><cr>	Print	Valid display, No motion

Data Formats

Demand Mode: <stx><pol><DATA><sp><lb/kg><sp><GR/NT><cr/lf>

Continuous Mode: <stx><pol><DATA><L/K><G/N><status><cr/lf>

Brackets “<>” are not sent

stx: “Start of Text” character (ASCII 002) (can be removed in continuous: config 19)

pol: Polarity sign, “SPACE” (ASCII 032) for positive or (-) sign (ASCII 045) for negative

sp: Space character (ASCII 032)

DATA: Seven (7) digit data field including decimal point or fixed (dummy) zero if selected.
“Leading Zero Suppression” with leading zeros transmitted as “space” characters.

lb/kg: Two (2) character field data identification for weight units, in demand (printer) mode.

Weight in lb = “lb” (ASCII 108,098), weight in kg = “kg” (ASCII 107,103)

L/K: One (1) character field data identification for weight units in continuous (computer) mode.

Weight in lb = “L” (ASCII 076), weight in kg = “K” (ASCII 075)

GR/NT: Two (2) character field data identification for weighing mode in demand (printer) mode.

Gross Mode = “GR” (ASCII 071,082), Net Mode = “NT” (ASCII 078,084)

G/N: One (1) character field data identification for weighing mode in continuous (computer) mode.

Gross Mode = "G" (ASCII 071), Net Mode = "N" (ASCII 078)

status: One (1) character data identification used in the continuous (computer) output mode to identify the status of the indicator. Characters are listed below in order of priority.

Calibration/configuration	<D> (ASCII 068)
Over/Under Range	<O> (ASCII 079)
Motion	<M> (ASCII 077)
Center of Zero	<C> (ASCII 067)
None of the above	<sp>(ASCII 032)

cr/lf: Two (2) character field, "Carriage Return" (ASCII 013), "Line Feed" (ASCII 010)

Guidelines for Serial Output:

Demand format will inhibit "print" when scale is in "motion" or with negative "Gross" weight, even in "Net" mode (based on setting "CFG 10").

Local Network Protocol:

Command to the indicator:

<*><DD><00><cmd><data entry><CR>

Response from indicator:


<:><00><DD><cmd echoed><data resp><CR>

Where: (<,> brackets not sent)

*	= Message from master (2AH)
DD	= Indicators address
00	= Master address (fixed at 00)
CR	= Message terminator (ODH)
:	= Response from indicator (3AH)
cmd	= Command to indicator
cmd ech	= Command echoed from indicator
data ent	= Data entered into indicator
data resp	= Data response from indicator

OPTION 1: Analog Output

0 – 10 Vdc or 4 – 20 ma, select with jumpers J1 and J2



Option 1 Analog Output: "SEL.OP1" Use Zero to enter the menu and step to each category, Gross/Net to select parameters. Print to return to menu selection.

DISPLAY	Parameters	Definition
1.1__Gr	Gr, Net, DSP	Analog tracks gross, net or display
"1.5__Zr" "0.00" (flashes current analog starting point)		
Gross/Net (select digit)	00000"0"	digit flashes
Tare (increments digit)	0000"5"	Increments
Gross/Net (select digit)	0000"2"5	digit flashes
(Adjustment complete)	000025	adjusted value

Print to adjust starting point.

"1.5__Zr" "0.25" (flashes current analog starting point)

"1.6__FS" "0.00" (flashes current analog span point)

Gross/Net (select digit)	00"0"000	digit flashes
Tare (increments digit)	00"5"000	Increments
(Adjustment complete)	005000	adjusted value

Print to adjust span point.

1.7__ZrA While monitoring the output, use Unit to decrease, Tare to increase the analog reading (Zero trim digi-pot).


1.8__FSA While monitoring the output, use Unit to decrease, Tare to increase the analog reading (Span Trim digi-pot).

Print to exit OP1.

OPTIONS 2: DIO

AC Inputs; D1, D2 are not installed, J1 = short (underside), J2 = open, R1 – R4 = 18k (3w, 5%, flame proof).

DC Inputs; D1, D2 are installed, J1 = open (cut trace), J2 = short, R1 – R4 = 1.5k (1/2w, 5%, carbon film). AC Outputs; Solid State Relays, 120VAC, 0.5A



Option 2 DIO: “SEL.OP2” First select the operating mode for “Setpoint”, “Over/Under”, “Manual or Auto Batch”. After setup, the parameters for the selection are entered from the weighing mode.

Use Gross/Net to enter the menu and step to each category, Tare Recall to select parameters. ENT to return to menu selection.

Note: external Inputs are enabled in Configuration with “CFG 30”.
DIO Inputs can be configured for 120vac, 5vdc or dry contact.

	Normal	Batch
IN 1	Gross/Net	Stop
IN 2	Tare	Start
IN 3	Zero	Zero
IN 4	Print	Print

DIO Outputs are 120vac (0.5 amp) or optional 24 vdc, based on operating mode:

	Dual	Setpt 1	Setpt 2	Ov/Un	Man B	Auto B
Out 1	Setpt1-A	Main 1	Main 1	Low	Main 1	Main 1
Out 2	Setpt1-B	Fast F1	Fast F1	Accept	Fast F1	Fast F1
Out 3	Setpt2-A	Tol	Main 2	High	Main 2	Main 2
Out 4	Setpt2-B	Zero B	Fast F2	Zero	Zero	Fast F2

Checkweigher “Bar” graph legends:

Ck1-3	Out Low	Low	Accept	High	Out High
-------	---------	-----	--------	------	----------

Setpoint values are entered from “Weighing Mode” by the SET key and direct numeric entry.

Weight errors of any kind (e.g., ol, ul, etc) will de-energize all relay outputs and abort a batch if one is in progress.

Four outputs are available to use as two setpoints with main and fast feed, single setpoint main and fast feed plus tolerance and zero band. Also Pre-Act can be applied to the main, for material in-flight compensation.

Step	Parameter	Definition
2.0	OFF, SP, OU.UN, bAt1, bAt2	Mode select: setpoint, over/under (check weighing), Manual Batch, Auto Batch
2.0	SP	Setpoint
2.2	Off, s1, s1.p, s1.d, s.p.d, Dual	Setpoint. 1 + pre-act, + drib, + both, Set1-A&B.
2.3	Gr, nt, dSP, Count	Setpoint 1 tracks Gross, Net, Display, Count
2.4	POS, ZER	Output on below reading (POS), inverted (ZER)
2.6	Off, s2, s2.p, s2.d, s2.p.d, tOL, Dual	Setpoint. 2 + pre-act, + dribble, + both, Tolerance, Set2-A&B.
2.7	Gr, nt, dSP, Count	Setpoint. 2 + pre-act, + dribble, + both
2.8	POS, ZER	Output on below reading (POS), inverted (ZER)
2.10	ZbO	Zero band output (input weight value)
2.11	Off, On	Hysteresis, provides 3 grads to prevent relay chatter
s.p.d example	SP1.trG (Target) = 1000 SP1.PrE (Pre-act) = 5 SP1.drb (Dribble) = 10	Main and Fast Feed are on until reading reaches 990, then Fast Feed turns off and Main continues until Pre-act at 995

2.0	OU.UN	Over/Under – check weighing
2.2	Off, HL, tGt, Ck1, Ck2, Ck3	High/Low band, Target and +/- band, Check Weigher 1-3.
2.3	Gr, net, dSP	Outputs track Gross, Net, Display
2.4	POS, ZER	Invert low
2.5	POS, ZER	Invert accept
2.6	POS, ZER	Invert high
2.10	ZbO	Zero band output (input weight value)
2.11	Off, On	Hysteresis, provides 3 grads to prevent relay chatter
2.12	Off, On	Enables “Bar” graph legends
HL example	Low = 950 High = 1050	Then low is on until 950, then accept is on until 1050 and high is on above 1050.
tGt example	Target = 1000 Low = 50 High = 50	Outputs match above example for HL

Note:	Batch printouts are from Port 1 only	
2.0	Bat 1	Manual Batch mode, pauses between setpoints
2.1	Prn, tAr, dIn	7400 uses print, tare or external (DIO) for start. Pressing any key other than “start” will pause and a second push will abort. 7600E uses Start/Stop panel switch
2.2	Off, s1, s1.p, s1.d, s.p.d	Setpoint. 1 + pre-act, + dribble, + both
2.3	Gr, nt, dSP, Count	Setpoint 1 tracks Gross, Net, Display, Count
2.4	POS, ZER	Output on below reading (POS), inverted (ZER)
2.6	Off, s2, s2.p, s2.d, s2.p.d	Setpoint. 2 + pre-act, + dribble, + both
2.7	Gr, nt, dSP, Count	Setpoint. 2 + pre-act, + dribble, + both
2.8	POS, ZER	Output on below reading (POS), inverted (ZER)
2.10	ZbO	Zero band output (input weight value), available if S2 dribble not used

2.0	Bat 2	Auto Batch mode, continues without pause
2.1	Prn, tAr, dIn	7400 uses print, tare or external (DIO) for start. Pressing any key other than “start” will pause and a second push will abort. 7600E uses Start/Stop panel switch
2.2	Off, s1, s1.p, s1.d, s.p.d	Setpoint. 1 + pre-act, + dribble, + both
2.3	Gr, nt, dSP, Count	Setpoint 1 tracks Gross, Net, Display, Count
2.4	POS, ZER	Output on below reading (POS), inverted (ZER)
2.5	Off, 1, 2, 3,, 10	Time Delay (settling) before print
2.6	Off, s2, s2.p, s2.d, s2.p.d	Setpoint. 2 + pre-act, + dribble, + both
2.7	Gr, nt, dSP, Count	Setpoint. 2 + pre-act, + dribble, + both
2.8	POS, ZER	Output on below reading (POS), inverted (ZER)
2.9	Off, 1, 2, 3,, 10	Time Delay (settling) before print
2.10	ZbO	Zero band output (input weight value), available if S2 dribble not used

OP3	Time & Date	
3.1	---, 24H, 12A, 12P	Skip time, 24 hour, 12 hour am, 12 hour pm
3.2	T1	Set time: hh mm ss
3.3	dA	Set date: mm dd yy
3.4	S.no, no, Let	Month print selection, short numerical (mm/dd/yy), number 01 thru 12, month spelled out
3.5	Off, Un, Ab, On	Print under, above or on the same line

OP5	10 Point Linearity	On, Off see page 8
OP6	Totalizer	
6.1	Off, On	Enable Totalizer (operates with Batch or Print)
6.2	Off, 1.....50	Totalizer reset band

Option 6 Totalizer: Operates with “print” function in normal mode or batch mode.

In normal mode, current value is added to the totalizer with each “Print” command. The reset band is used to inhibit a double add when not in Batch Mode.

View the Total with the “2” key and during the display (AC..XXXX), the “Print” key is used to print the total, the “Ent” key returns to weigh mode.

The “Clear” key is used to clear the totalizer by first changing the message from “Clr.ACC...no” to “Clr.ACC...yes” with the “Units” key and “Ent” to complete. A “Cleared” message is provided for conformation.

Note: Totalizer works with port 1 only and the “Print” key is disabled when Batch Mode and Totalizer are both enabled.


Option 8: AC/DC operation

8.1	Off, On	Enables battery charger
8.2	Off, 5, 15, 30, 90, 120	Auto shutoff in minutes, timer resets with motion

DISPLAY MESSAGES

MESSAGE	DESCRIPTION
DAC	D/A card detected - Displayed under the check function.
IIC.ERR	IIC short - Power-up hardware failure indication.
RST	EEPROM is reset by EER command - Power-up message
ON	Displayed on power-up when the DC power push-button is pressed.
AUTO	EEPROM is reset - Power-up message
ERR6.x	Key-pad key is stuck.
-232-	Serial calibration/setup is active.
UPDATE	Enhancement calculation in progress.
LO.BATT	Low battery
D BATT	Dead battery
ULULUL	Under-load (-400 graduations under dead-zero)
OLOLOL	Over-load (+9 graduations or 105% from dead-zero reference)
-----	A/D acquisition is in progress.
7x00	Instrument mode selection.
Err 10	Number > 999999
Err 13	Number < -99999
ADC.Err	A/D hardware failure (channel one only).
CHECK	Check mode accessed.
rC.xxxx	Lower four-digits of the ROM check-sum.
Err.80	Serial command data error.
Err.81	Unknown serial command.
-CAL-	Remote calibration
Err.OFF	Hardware failure of the D.C. power on/off circuitry.
RTC.RST	The clock is reset to 01:01:04 12:00:00am.
RST ID	The ID EEPROM has been reset since it was detected as corrupt.
AC OK	Access code entered has been accepted.
E-1234	EEPROM set 1,2,3, and/or 4 have been fixed.
Err 40	Positive or negative signal overload (check sense connections).
Err 31	Bad tare entry
Err 30	Push to Zero out of range
PC Err	Piece Weight Entry is out of range

115 to 220 VAC Conversion : EW1000 Bottom Side



WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **13 months** from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal **one (1) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components which wear are not warranted, including but not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by it will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESS OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

RETURN REQUESTS/INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of the product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 2004 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.

Where Do I Find Everything I Need for Process Measurement and Control? OMEGA...Of Course!

Shop online at www.omega.com

TEMPERATURE

- Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- Wire: Thermocouple, RTD & Thermistor
- Calibrators & Ice Point References
- Recorders, Controllers & Process Monitors
- Infrared Pyrometers

PRESSURE, STRAIN AND FORCE

- Transducers & Strain Gages
- Load Cells & Pressure Gages
- Displacement Transducers
- Instrumentation & Accessories

FLOW/LEVEL

- Rotameters, Gas Mass Flowmeters & Flow Computers
- Air Velocity Indicators
- Turbine/Paddlewheel Systems
- Totalizers & Batch Controllers

pH/CONDUCTIVITY

- pH Electrodes, Testers & Accessories
- Benchtop/Laboratory Meters
- Controllers, Calibrators, Simulators & Pumps
- Industrial pH & Conductivity Equipment

DATA ACQUISITION

- Data Acquisition & Engineering Software
- Communications-Based Acquisition Systems
- Plug-in Cards for Apple, IBM & Compatibles
- Datalogging Systems
- Recorders, Printers & Plotters

HEATERS

- Heating Cable
- Cartridge & Strip Heaters
- Immersion & Band Heaters
- Flexible Heaters
- Laboratory Heaters

ENVIRONMENTAL MONITORING AND CONTROL

- Metering & Control Instrumentation
- Refractometers
- Pumps & Tubing
- Air, Soil & Water Monitors
- Industrial Water & Wastewater Treatment
- pH, Conductivity & Dissolved Oxygen Instruments