


OPERATING INSTRUCTIONS UK MODEL HH801B CA DUAL INPUT J/K/T/E DIGITAL THERMOMETER



FEATURES:

Highly accurate thermometer with 0.1% basic accuracy.
Three displays for easy observations.
Thermocouple offset adjustment.
Four thermocouple types K/J/T/E for common use.
Robust protective holster.
Auto-Power Off and Backlight functions.
MIN/MAX/AVG/REL/HOLD/ functions.

MADE IN TAIWAN

SAFETY INFORMATION

It is recommended that you read the safety and operation instructions before using the thermometer.

WARNING

To avoid electrical shock, do not use this instrument when working voltages at the measurement surface over 24V AC or DC.

WARNING

To avoid damage or burns, do not make temperature measurement in microwave ovens.

CAUTION

Repeated sharp flexing can break the thermocouple leads. To prolong lead life, avoid sharp bends in the leads, especially near the connector.

The symbol on the instrument indicates that the operator must refer to an explanation in this manual.

SPECIFICATIONS

ELECTRICAL

Temperature Scale: Celsius or Fahrenheit user-selectable
Measurement Range:

Thermocouple

K-TYPE(0.1°C) -200°C to 1372°C, -328°F to 1999°F
J-TYPE(0.1°C) -210°C to 1200°C, -346°F to 1999°F
T-TYPE(0.1°C) -200°C to 400°C, -328°F to 752°F
E-TYPE(0.1°C) -220°C to 1000°C, -364°F to 1832°F

Auto range: 0.1°C/1°C, 0.1°F/1°F

Accuracy: Accuracy is specified for operating temperatures over the range of 18°C to 28°C (64°F to 82°F), for 1 year, not including thermocouple error.

±(0.1%rdg+1°C) on -60°C to 1372°C
±(0.1%rdg+2°C) on -60°C to -220°C
±(0.1%rdg+2°F) on -76°F to 1999°F
±(0.1%rdg+4°F) on -76°F to -364°F

ENVIRONMENTAL

Ambient Operating Ranges:

0°C to 50°C (32°F to 122°F) <80% R.H.

Storage Temperature:

-20°C to 60°C (-4°F to 140°F) <70% R.H.

GENERAL

Display: 3-digit liquid crystal display (LCD) with a maximum reading of 1999.

Polarity: Automatic, positive implied, negative polarity indication.

Overrange: "OL" or "-OL" is displayed.

Zero: Automatic.

Low battery indication: The is displayed when the battery voltage drops below the operating level.

Measurement rate: 1 sample/second.

Accuracy: Stated accuracy at 23°C±5°C, <75% R.H.

Dimensions: 160mm (H) x 83mm (W) x 38mm(D).

Weight: approx. 265g including batteries.

OPERATING INSTRUCTIONS

1. Power Button

The key turns the thermometer on or off. In the MAX/MIN record mode the meter cannot be powered

off. With the power off, push and hold this key for more than 4 seconds to disable auto power-off and turn the meter on.

2. "HOLD" Button

Press the "HOLD" key to enter the Data Hold mode, the "HOLD" annunciator is displayed. When HOLD mode is selected, the thermometer holds the present readings and stops all further measurements.

Press the "HOLD" key again to cancel HOLD mode and allow the thermometer to resume taking measurements. In the MAX/MIN recording mode, press the "HOLD" key to stop the recording. Press "HOLD" key again to resume recording. (Previously recorded readings are not erased.)

3. C/F Button

Press button to toggle ON or OFF the backlight. The backlight will switch-off automatically after 30 seconds. Readings are displayed in either degrees Celsius (°C) or degrees Fahrenheit (°F). When the thermometer is turned on, it is set to the temperature scale that was in use when the thermometer was last turned off. To change the temperature scale, press the " C/F" button for more than 2 seconds.

4. "REL" Button

Press the "REL" key to enter the Relative mode, zero the display, and store the displayed reading as a reference value. The annunciator REL will appear on the LCD. Press the "REL" key for more than 2 seconds to exit the relative mode. The relative value can also be entered by the user. (See "SET mode" later in this manual). When the desired Relative value has been entered, press the "SET" key to set Relative value as a reference value. Press "REL" key again to exit the relative mode.

In the Relative mode, the value (can not be greater than ±2,000 counts) shown on the LCD is always the difference between the stored reference and the present reading.

5. "TYPE" Button: K/J/T/E Thermocouple Type

The "TYPE" key selects the thermocouple type to be used as an input. When the thermometer is turned on, it is set to the type that was in use when the thermometer was last turned off.

6. "MAX/MIN" Button: Record mode

Press "MAX/MIN" key to enter the MAX/MIN Recording mode, (displays the Maximum reading, Minimum reading, "MAX-MIN" reading and Average reading stored in record mode). In this mode the automatic power-off feature is disabled and key and all function keys are disabled. The beeper emits a tone when a new maximum or minimum value is recorded.

Push "MAX/MIN" key to cycle through the MAX, MIN, MAX-MIN and AVG readings. If overload is recorded, the averaging function is stopped and average value displays "-OL". In this mode, press the "HOLD" key to stop the recording of readings, all values are held, press again to resume recording. To prevent accidental loss of MAX, MIN, "MAX-MIN" and AVG data, this mode can only be cancelled by pressing and holding the MAX/MIN key for 2 seconds to exit and erase recorded readings.

7. "Hi/Lo" Button: LIMITS mode

Press the "Hi/Lo" key to enter the Hi/Lo LIMITS comparative mode, "LIMIT" is displayed. When the input temperature value is above the Hi value, the beeper emits a continuous tone and "Hi" is displayed. When input temperature value is below the Lo value, the beeper emits a pulsed tone and "Lo" is displayed. Press the "Hi/Lo" LIMIT key again to exit the Hi/Lo LIMIT

mode.

8. "▲" Button

The key increases the value of the selected digit.(See "SET mode" later in this manual.)

9. "TC OFFSET" Button

This button allows the user to adjust the Cold Junction Compensation offset up to ±5.0 counts. This value is used to compensate for thermocouple sensor error. When a value is entered, the readings displayed on the LCD will be automatically adjusted to include this offset. (See "SET mode" later in this manual.)

10. "◀" Button

The key moves to the next digit on the display (See "SET mode" later in this manual.)

11. "▼" Button

The key decreases the value of the selected digit (See "SET mode" later in this manual.)

12. "SET" Button

Allows user to set the Relative value, Hi/Lo Limits value and Cold Junction Compensation value. Press "SET" key to enter SET mode. The LCD displays "SET" and set annunciator is show in the upper right.

Set Relative value:

Press "SET" key to enter SET mode, then Press "REL" button to set relative value. "SET", "REL" and "T1" annunciators are displayed.

Press or to increase or decrease the value of the flashing digit, press to advance to the next digit Use or to set positive or negative for this relative value. Then press the "ENTER" key to set the relative value for T1. Follow the same procedure for T2. In this Relative SET mode, the value can not be greater than ±1999.9 counts. If this value more than ±1999.9 counts, "Err" displayed and a valid offset must be entered.

Set Hi/Lo Limit value:

Press "SET" key to enter SET mode, then Press Hi/Lo button to set Hi/Lo Limit value. "SET", "LIMIT", "Hi" and "T1" annunciator are displayed.

Press or to increase or decrease the value of the flashing digit, press to advance to the next digit Use or to set positive or negative for this Hi/Lo Limit value. Then press the "ENTER" key to store the Hi limit value for T1. Follow the same procedure for T2. In this Hi/Lo Limit SET mode, the value can not be greater than ±1999.9 counts. If this value more than ±1999.9 counts, "Err" displayed and a valid limit must be entered.

Set Cold Junction Compensation (TC OFFSET):

Press SET key to enter SET mode, then Press TC OFFSET button to set TC OFFSET value. First, "CJC" is displayed on LCD. The meter will then enter SET TC OFFSET mode. "SET" and "T1" annunciator are displayed.

Press or to increase or decrease the value of the flashing digit, press to advance to the next digit Press or to set positive or negative for this TC OFFSET value. Then press the "ENTER" key to store the TC OFFSET value for T1, next enter the TC OFFSET value for T2. In this TC OFFSET SET mode, the value can not be greater than ±5.0 counts. If this value more than ±5.0 counts, "Err" displayed and a valid offset must be entered.

OPERATOR MAINTENANCE

WARNING

To avoid possible electrical shock, disconnect the thermocouple connectors from the thermometer before removing the cover.

Battery Replacement

1. Power is supplied by 4pcs 1.5V (AAA SIZE) uM-4 R03.
2. The "—" appears on the LCD display when replacement is needed. To replace battery remove screws from back of meter and lift off the battery cover.
3. Remove the battery from battery contacts and replace.
4. When not in use for long periods the batteries should be removed.
5. Do not store in locations with high temperatures, or high humidity.

Cleaning

Periodically wipe the case with a damp cloth and detergent, do not use abrasives or solvents.



OMEGAnet® Online Service
omega.com

Internet e-mail
info@omega.com

Servicing North America:

U.S.A.:
ISO 9001 Certified

Omega Engineering, Inc., One Omega Drive, P.O. Box 4047
Stamford, CT 06907-0047 USA
Toll Free: 1-800-826-6342 TEL: (203) 359-1660
FAX: (203) 359-7700 e-mail: info@omega.com

Canada:

976 Berger
Laval (Quebec), H7L 5A1 Canada
Toll-Free: 1-800-826-6342 TEL: (514) 856-6928
FAX: (514) 856-6886 e-mail: info@omega.ca

For immediate technical or application assistance:

U.S.A. and Canada: Sales Service: 1-800-826-6342/1-800-TC-OMEGA®
Customer Service: 1-800-622-2378/1-800-622-BEST®
Engineering Service: 1-800-872-9436/1-800-USA-WHEN®

Mexico/
Latin America:

En Español: 001 (203) 359-7803 FAX: 001 (203) 359-7807
info@omega.com.mx e-mail: espanol@omega.com

Servicing Europe:

Benelux:

Managed by the United Kingdom Office
Toll-Free: 0800 099 3344 TEL: +31 20 347 21 21
FAX: +31 20 643 46 43 e-mail: sales@omegaeng.nl

Czech Republic:

Fryštátská 184
733 01 Karviná, Czech Republic
Toll-Free: 0800-1-66342 TEL: +420-59-6311899
FAX: +420-59-6311114 e-mail: info@omegashop.cz

France:

Managed by the United Kingdom Office
Toll-Free: 0800 466 342 TEL: +33 (0) 161 37 29 00
FAX: +33 (0) 130 57 54 27 e-mail: sales@omega.fr

Germany/Austria:

Daimlerstrasse 26
D-75392 Deckenpfronn, Germany
Toll-Free: 0800 6397678 TEL: +49 (0) 7056 9398-0
FAX: +49 (0) 7056 9398-29 e-mail: info@omega.de

United Kingdom:
ISO 9001 Certified

OMEGA Engineering Ltd.
One Omega Drive, River Bend Technology Centre, Northbank
Irlam, Manchester M44 5BD United Kingdom
Toll-Free: 0800-488-488 TEL: +44 (0) 161 777-6611
FAX: +44 (0) 161 777-6622 e-mail: sales@omega.co.uk

WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **13 months** from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal **one (1) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components in which wear is not warranted, include but are not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by the company will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/ DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

RETURN REQUESTS/INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY RETURNS**, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY REPAIRS**, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of the product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC. © Copyright 2010 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.

It is the policy of OMEGA Engineering, Inc. to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification. The information contained in this document is believed to be correct, but OMEGA accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

WARNING: These products are not designed for use in, and should not be used for, human applications

Where Do I Find Everything I Need for Process Measurement and Control? OMEGA...Of Course! Shop online at omega.com

TEMPERATURE

- Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- Wire: Thermocouple, RTD & Thermistor
- Calibrators & Ice Point References
- Recorders, Controllers & Process Monitors
- Infrared Pyrometers

PRESSURE, STRAIN AND FORCE

- Transducers & Strain Gages
- Load Cells & Pressure Gages
- Displacement Transducers
- Instrumentation & Accessories

FLOW/LEVEL

- Rotameters, Gas Mass Flowmeters & Flow Computers
- Air Velocity Indicators
- Turbine/Paddlewheel Systems
- Totalizers & Batch Controllers

pH/CONDUCTIVITY

- pH Electrodes, Testers & Accessories
- Benchtop/Laboratory Meters
- Controllers, Calibrators, Simulators & Pumps
- Industrial pH & Conductivity Equipment

DATA ACQUISITION

- Data Acquisition & Engineering Software
- Communications-Based Acquisition Systems
- Plug-in Cards for Apple, IBM & Compatibles
- Data Logging Systems
- Recorders, Printers & Plotters

HEATERS

- Heating Cable
- Cartridge & Strip Heaters
- Immersion & Band Heaters
- Flexible Heaters
- Laboratory Heaters

ENVIRONMENTAL MONITORING AND CONTROL

- Metering & Control Instrumentation
- Refractometers
- Pumps & Tubing
- Air, Soil & Water Monitors
- Industrial Water & Wastewater Treatment
- pH, Conductivity & Dissolved Oxygen Instruments