
**User's
Manual**

**Models RD-MV2008/RD-MV2010/RD-MV2020/
RD-MV2030/RD-MV2040/RD-MV2048
RD-MV2000
First Step Guide**

Contents

Foreword.....	5
Safety Precautions.....	6
Handling Precautions of the MV	8
CF Card Handling Precautions	8
Protection of Environment	9
Checking the Contents of the Package	11
How to Use This Manual	14
Conventions Used in This Manual	14
Opening the Electronic Manuals	14
Names of Parts:	15
Front View.....	15
Rear Panel.....	15
Basic Operation	16
Panel Keys.....	16
Display	16
Entering Values and Characters	17
RD-MV2000 Workflow.....	19
Installation.....	20
Location	20
Installation Procedure	21
Connecting Input Cables	22
⚠ Wiring to the Signal Input Terminals	22
Wiring Precautions.....	22
Wiring Procedure	23
Connecting a Power Cable	26
⚠ Connecting the Power Cord (if the power supply voltage suffix code is -1).....	26
⚠ Connecting the Power Cord (if the power supply voltage suffix code is -2).....	27
When Using an AC Adapter.....	27
When Using a DC Power Supply.....	28
⚠ Turning the Power ON/OFF	29
Quick Settings:	30
Procedure	30
Measurement	32
⚠ Inserting the CF Card	32
Starting the Memory Sample	33
Stopping the Memory Sample	33
Removing the CF Card	34
Viewing Data with DAQSTANDARD	34
Default RD-MV2000 Settings	36
Setting Mode Settings and Default Values.....	38
Basic Setting Mode Settings and Default Values.....	49

Contents

MV1000/RD-MV2000 User's Manual (Electronic Manual Provided on the Accompanying CD)

- Chapter 1 Overview of Functions
- Chapter 2 Installation and Connection
- Chapter 3 Measurement Channels and Alarms
- Chapter 4 Measurement and Recording
- Chapter 5 Screen Operations
- Chapter 6 Display Configuration
- Chapter 7 Event Action
- Chapter 8 Security Functions
- Chapter 9 Environment Settings
- Chapter 10 Computation and Report Functions (/M1 and /PM1 Options)
- Chapter 11 External Input Channels (/MC1 Option)
- Chapter 12 Troubleshooting and Maintenance
- Chapter 13 Specifications

MV1000/RD-MV2000 Communication Interface User's Manual (Electronic Manual Provided on the Accompanying CD)

- Chapter 1 Overview of Communication Functions
- Chapter 2 Using the Ethernet Interface
- Chapter 3 Using the Serial Interface
- Chapter 4 Commands
- Chapter 5 Responses
- Chapter 6 Status Reports
- Chapter 7 Specifications

Foreword

Thank you for purchasing the MV 2000 (hereafter referred to as the MV). This manual explains the minimum steps required to start measuring quickly. It also contains a list of default RD-MV2000 settings. Please keep it for reference. The following five manuals are provided as RD-MV2000 manuals.

Paper Manual

Manual Title	Manual No.	Description
RD-MV2000 First Step Guide	IM RD-MV2000-02E	This manual. It is also provided in the CD.
Control of Pollution Caused by the Product	IM MV1000-91C	Gives a description of pollution control.

Electronic Manuals Provided on the Accompanying CD

Manual Title	Manual No.	Description
RD-MV2000 First Step Guide	IM RD-MV2000-02E	This is the electronic version of the paper manual.
MV1000/RD-MV2000 User's Manual	IM MV1000-01E	Describes how to use the convenient functions of the RD-MV2000. The communication function is covered in another manual.
MV1000/RD-MV2000 Communication Interface User's Manual	IM MV1000-17E	Describes how to use the communication functions with the Ethernet and serial interfaces.
DAQSTANDARD User's Manual	IM 04L41B01-61E	Describes how to use the accompanying software program, DAQSTANDARD.

Notes

- The contents of this manual are subject to change without prior notice as a result of continuing improvements to the instrument's performance and functions.
- Every effort has been made in the preparation of this manual to ensure the accuracy of its contents. However, should you have any questions or find any errors, please contact your nearest Omega dealer.
- Copying or reproducing all or any part of the contents of this manual without Omega's permission is strictly prohibited.
- The TCP/IP software of this product and the document concerning the TCP/IP software have been developed/created by *OMEGA* based on the BSD Networking Software, Release 1 that has been licensed from the Regents of the University of California.

Trademarks

- Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Adobe and Acrobat are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.
- Company and product names that appear in this manual are registered trademarks or trademarks of their respective holders.
- In this manual, the TM and ® symbols do not accompany trademarks or registered trademarks.

Revisions

December 2007 1st Edition

Safety Precautions

- This instrument conforms to IEC safety class I (provided with terminal for protective grounding), Installation Category II, and EN61326-1 (EMC standard), Measurement Category II (CAT II)*.
 - * Measurement category II (CAT II) applies to measuring circuits connected to low voltage installation, and electrical instruments supplied with power from fixed equipment such as electric switchboards.
- This instrument is an EN61326-1 (EMC standard) class A instrument (for use in commercial, industrial, or business environments).
- The general safety precautions described here must be observed during all phases of operation. If the MV is used in a manner not described in this manual, the MV safety features may be impaired. Omega assumes no liability for the customer's failure to comply with these requirements.
- The MV is designed for indoor use.
- About This Manual
 - Please give this manual to the end user. We also ask you to store this manual in a safe place.
 - Read this manual thoroughly and have a clear understanding of the product before operation.
 - This manual explains the functions of the product. It does not guarantee that the product will suit a particular purpose of the user.
- Precautions Related to the Protection, Safety, and Alteration of the Product

The following safety symbols are used on the product and in this manual.



"Handle with care." To avoid injury and damage to the instrument, the operator must refer to the explanation in the manual.



Protective ground terminal



Functional ground terminal (do not use this terminal as a protective ground terminal.)



Alternating current



Direct current



ON (power)



OFF (power)

- For the protection and safe use of the product and the system in which this product is incorporated, be sure to follow the instructions and precautions on safety that are stated in this manual whenever you handle the product. Take special note that if you handle the product in a manner that violates these instructions, the safety features of the product may be damaged or impaired. In such cases, Omega does not guarantee the quality, performance, function, or safety of the product.
- When installing protection and/or safety circuits such as lightning protection devices and equipment for the product and its control system or designing or installing separate protection and/or safety circuits for fool-proof design and fail-safe design of the processes and lines that use the product and the control system, the user should implement these using additional devices and equipment.
- If you are replacing parts or consumable items of the product, make sure to use parts specified by Omega.
- This product is not designed or manufactured to be used in critical applications that directly affect or threaten human lives. Such applications include nuclear power equipment, devices using radioactivity, railway facilities, aviation equipment, air navigation facilities, aviation facilities, and medical equipment. If so used, it is the user's responsibility to include a system of additional equipment and devices that ensures safety.
- Do not modify this product.

WARNING

- **Use the Correct Power Supply**

Ensure that the source voltage matches the voltage of the power supply before turning the power ON.

- **Use the Correct Power Cord and Plug**

To prevent electric shock or fire, be sure to use the power cord supplied by Omega. The main power plug must be plugged into an outlet with a protective earth terminal. Do not disable this protection by using an extension cord without protective earth grounding.

- **Connect the Protective Grounding Terminal**

Make sure to connect the protective grounding before turning the power ON, to prevent electric shock.

The power cord that comes with the desktop type is a three-pronged power cord. Connect the power cord to a properly grounded three-prong outlet.

- **Do Not Impair the Protective Grounding**

Never cut off the internal or external protective grounding wire or disconnect the wiring of the protective grounding terminal. Doing so invalidates the protective functions of the instrument and poses a potential shock hazard.

- **Do Not Operate with Defective Protective Grounding**

Do not operate the instrument if the protective grounding might be defective. Make sure to check it before operation.

- **Do Not Operate in an Explosive Atmosphere**

Do not operate the instrument in the presence of flammable liquids or vapors. Operation in such an environment constitutes a safety hazard.

Prolonged use in a highly dense corrosive gas (H₂S, SO_x, etc.) will cause a malfunction.

- **Do Not Remove Covers**

The cover should be removed by Omega's qualified personnel only. Opening the cover is dangerous, because some areas inside the instrument have high voltages.

- **Ground the Instrument before Making External Connections**

Connect the protective grounding before connecting to the item under measurement or the control unit.

- **Damage to Safety Features**

Operating the instrument in a manner not described in this manual may damage the instrument's safety features.

CAUTION

This is a class A instrument. Operation of this equipment in a residential area can cause radio interference, in which case users will be required to correct the interference.

- **Exemption from Responsibility**

- Omega makes no warranties regarding the product except those stated in the WARRANTY that is provided separately.
- Omega assumes no liability to any party for any loss or damage, direct or indirect, caused by the user or any unpredictable defect of the product.

-
- **Handling Precautions of the Software**
 - Omega makes no warranties regarding the software accompanying this product except those stated in the WARRANTY that is provided separately.
 - Use the software on a single PC.
 - You must purchase another copy of the software, if you are to use the software on another PC.
 - Copying the software for any purposes other than backup is strictly prohibited.
 - Please store the original media containing the software in a safe place.
 - Reverse engineering, such as decompiling of the software, is strictly prohibited.
 - No portion of the software supplied by Omega may be transferred, exchanged, or sublet or leased for use by any third party without prior permission by Omega.

Handling Precautions of the MV

- Use care when cleaning this instrument, especially its plastic parts. Use a soft dry cloth. Do not use organic solvents, such as benzene or thinner, or other cleansers. They may cause discoloring and deformation.
- The carrying handle should only be used to carry the instrument.
- Keep electrically charged objects away from the signal terminals. If you do not, the MV may malfunction.
- Do not apply volatile chemicals to the display, panel keys, etc. Do not allow rubber and vinyl products to remain in contact with the MV for long periods of time. If you do, the MV may malfunction.
- When not in use, make sure to turn OFF the power switch.
- If there are any symptoms of trouble such as strange odors or smoke coming from the MV, immediately turn OFF the power switch and the power supply source. Then, contact your nearest Omega dealer.

CF Card Handling Precautions

- The CF card is delicate and should be handled with caution.
- Write operations to the CF card may fail if it is operated in a high-temperature or low-temperature environment. If you are operating in a low temperature environment (about 10°C or less), wait for the MV to warm up (30 minutes or more) before using it. If you are operating in a high temperature environment (about 40°C), we recommend that you insert the CF card into the drive when saving data, and remove it after the data has been saved.
- Remove the CF card from the drive when switching the MV ON/OFF.
- Touching the compact flash section when static electricity is built up on the human body can lead to erroneous operation.

CAUTION

- Do not remove the CF card while the access indicator is illuminated. This can damage the data.
 - Do not use the CF card in a place subject to vibrations or shock. The CF card or drive may malfunction.
-

Protection of Environment

Control of Pollution Caused by the Product



For details, see *Control of Pollution Caused by the Product (IM MV1000-91C)*.

Proper Disposal of This Product

This is an explanation of how to dispose of this product based on Waste Electrical and Electronic Equipment (WEEE), Directive 2002/96/EC. This directive is only valid in the EU.

- **Marking**

This product complies with the WEEE Directive (2002/96/EC) marking requirement.

The affixed product label (see below) indicates that you must not discard this electrical/electronic product in domestic household waste.



- **Product Category**

With reference to the equipment types in the WEEE directive Annex 1, this product is classified as a "Monitoring and Control instrumentation" product.

Do not dispose in domestic household waste.

To return unwanted products, contact your local Omega office.


Memo

Checking the Contents of the Package

Unpack the box and check the contents before operating the instrument. If some of the contents are not correct or missing or if there is physical damage, contact the dealer from which you purchased them.

RD-MV200C

There is a name plate on the side panel of the MV. Check that the model name and suffix code given on the name plate match those on your order.



NO. (Instrument Number)

When contacting the dealer that you purchased the instrument from, please give them the instrument number.

MODEL and SUFFIX Code

Model code	Suffix Code	Description
RD-MV2008		8 channels, 125 ms (fast sampling mode: 25 ms)
RD-MV2010		10 channels, 1 s (fast sampling mode: 125 ms)
RD-MV2020		20 channels, 1 s (fast sampling mode: 125 ms)
RD-MV2030		30 channels, 1 s (fast sampling mode: 125 ms)
RD-MV2040		40 channels, 1 s (fast sampling mode: 125 ms)
RD-MV2048		48 channels, 1 s (fast sampling mode: 127 ms)
Internal memory size	-1 -2	Standard Memory Large Memory
External storage medium	-4	CF card (with medium) and USB
Language	-2 -3 -4	English/German/French Chinese Korean
Input terminal	-1 -2	Clamped input terminal (detachable) Screw input terminal (M4)
Power supply	-1 -2	100 VAC, 240 VAC 12 VDC, with AC adapter ¹
Power cord		D AC power: 3-pin inlet, UL/CSA Standard power cord DC power: Screw terminal, UL/CSA cable for AC adapter
		F AC power: 3-pin inlet, VDE Standard power cord DC power: Screw terminal, VDE cable for AC adapter
		R AC power: 3-pin inlet, AS Standard power cord DC power: Screw terminal, AS cable for AC adapter
		Q AC power: 3-pin inlet, BS Standard power cord DC power: Screw terminal, BS cable for AC adapter
		H AC power: 3-pin inlet, GB (CCC) Standard power cord DC power: Screw terminal, GB (CCC) cable for AC adapter
		W Screw terminal, without AC adapter ²

Checking the Contents of the Package


Model code	Suffix Code	Description
Options	/A1	Two alarm output relays ³
	/A2	Four alarm output relays ³
	/A3	Six alarm output relays ³
	/A4	12 alarm output relays ^{3, 4}
	/C2	RS-232 interface ⁵
	/C3	RS-422/RS-485 interface ⁵
	/F1	FAIL/Status output ⁴
	/M1	Mathematical functions ⁷
	/N1	Cu10, Cu25 RTD input/3-wire isolated RTD
	/N2	3-wire isolated RTD ⁶
	/N3	Extended input type (PR40-20, JPt50, etc.)
	/R1	Remote control
	/TPS4	24 VDC transmitter power supply (4 loops) ⁷
	/PM1	Pulse input (including remote control and mathematical functions) ⁸
	/CC1	Calibration correction function
	/MC1	External input function ⁹

- 1 Does not come with an AC adapter if the power cord suffix code is W.
- 2 Can be selected if the supply voltage suffix code is: -2.
- 3 The /A1, /A2, /A3, and A4 options cannot be combined.
- 4 The /A4 and /F1 options cannot be combined.
- 5 The /C2 and /C3 options cannot be combined.


- 6 The /N2 option cannot be selected for the RD-MV2008.
- 7 The /A4 option cannot be combined with the /TPS4 option. If the /TPS4 option is selected, the /A3 and /F1 options cannot be combined with each other.
- 8 The /A4, /M1, and /R1 options cannot be combined with the /PM1 option. If the /PM1 option is selected, the /A2 and /F1 options cannot be combined with each other, and neither can the /A3 and /TPS4 options.
- 9 The /MC1 option cannot be selected for the RD-MV2008.

Standard Accessories

The standard accessories below are supplied with the instrument. Check that all contents are present and undamaged.

No.	Name	Part number/ Model	Qty.	Notes
	Terminal screws	E9655FX	5	M4 (spare)
	Rubber feet	A9088ZM	2	2 (1 pair)
	DAQSTANDARD	DXA120	1	CD-ROM. MV configuration and data display software
	RD-MV2000 First Step Guide (this manual)	IM RD-MV2000-02E	1	Paper size: A4
	Proper disposal	IM MV1000-91C	1	
	User's Manuals for the MV1000/ RD-MV2000	B8806ZZ	1	A CD with a PDF file of the MV1000/RD-MV2000 User's Manual and a PDF file of the Communication Interface User's Manual.
	CF card	B8706NQ	1	128 MB (size and model are subject to change)
	Power cord			When the supply voltage suffix code is -1, one of the following cables is included, depending on the power cable suffix code.
		A1074WD	1	Power cord suffix code D. Maximum rated voltage: 125 V
		A1009WD	1	Power cord suffix code F. Maximum rated voltage: 250 V
		A1024WD	1	Power cord suffix code R. Maximum rated voltage: 250 V
		A1054WD	1	Power cord suffix code Q. Maximum rated voltage: 250 V
		A1064WD	1	Power cord suffix code H. Maximum rated voltage: 250 V

Checking the Contents of the Package

No.	Name	Part number/ Model	Qty.	Notes
	AC adapter and power cord for AC adapter	B8805GV	1	Only included if the supply voltage suffix code is -2 (except for power cord suffix VV). When the supply voltage suffix code is -2, one of the following cables is included, depending on the power cable suffix code.
		B9988YA	1	Power cord suffix code D. Maximum rated voltage: 125 V
		B9988YB	1	Power cord suffix code F. Maximum rated voltage: 250 V
		B9988YC	1	Power cord suffix code R. Maximum rated voltage: 250 V
		A1069WD	1	Power cord suffix code Q. Maximum rated voltage: 250 V
		B9988YJ	1	Power cord suffix code H. Maximum rated voltage: 250 V

Optional Accessories (Sold Separately)

The following optional accessories are available for purchase separately. If you make an order, make sure that all contents are present and undamaged. For information about ordering accessories, contact the dealer from which you purchased the MV.

No.	Name	Model	Minimum Q'ty	Notes
1	CF card	772091	1	128 MB
		772092	1	256 MB
		772093	1	512 MB
		772094	1	1 GB
2	CF card adapter	772090	1	—
3	Shunt resistor (for screw input terminal)	415920	1	250 $\Omega \pm 0.1\%$
		415921	1	100 $\Omega \pm 0.1\%$
		415922	1	10 $\Omega \pm 0.1\%$
4	Shunt resistor (for clamped input terminal)	438920	1	250 $\Omega \pm 0.1\%$
		438921	1	100 $\Omega \pm 0.1\%$
		438922	1	100 $\Omega \pm 0.1\%$
5	Clamp terminal	A1923JT	1	Can be used with models that have an input terminal suffix code of -1.

How to Use This Manual

Conventions Used in This Manual

- This user's manual assumes that the display language is set to English (language suffix code -2).
- For information on setting the display language, see section 9.4, "Changing the Display Language" in the *MV1000/RD-MV2000 User's Manual (IM MV1000-01E)*.

Unit

K stands for 1024. Example: 768 KB (file size)

k stands for 1000.

Markings

The following markings are used in this manual



Improper handling or use can lead to injury to the user or damage to the instrument. This symbol appears on the instrument to indicate that the user must refer to the user's manual for special instructions. The same symbol appears in the corresponding place in the user's manual to identify those instructions. In the manual, the symbol is used in conjunction with the word "WARNING" or "CAUTION."

WARNING

Calls attention to actions or conditions that could cause serious or fatal injury to the user, and precautions that can be taken to prevent such occurrences.

CAUTION

Calls attentions to actions or conditions that could cause light injury to the user or damage to the instrument or user's data, and precautions that can be taken to prevent such occurrences.

Note

Calls attention to information that is important for proper operation of the instrument.



This mark is used to indicate a reference to a related procedure or explanation.

Bold characters

Bold characters are used to indicate text that appears on the screen or operation keys.


Opening the Electronic Manuals

The accompanying CD contains PDF files of the manuals. When you load the CD into the CD-ROM drive on your PC, a startup screen appears. Click the manual title to open the respective manual.


If the startup screen does not appear, double-click MV_manual in My Computer, and open the manuals in the English directory.

Names of Parts

Front View




Rear Panel



Basic Operation


Panel Keys



Terminology

Word	Definition
Memory sampling	Recording measured data.
Memory start	A command to start memory sampling.
Memory stop	A command to stop memory sampling.
Display data	The waveform data displayed on the MV screen. It is essentially measured data that is recorded at the display data sampling rate.
Event data	Measured data that is recorded at a set sampling rate that differs from that of the display data.


Display




Entering Values and Characters

The character/number input keys and DISP/ENTER key are used to set the date/time, set the display span of the input range, set tags, set message strings, enter passwords, etc.

Character/Number input keys



DISP/ENTER key and four arrow keys (up, down, left, and right)



Entering Values

When a window for entering a value appears, enter the value by performing the following key operation.

- **Left and right arrow keys:** Selects the input position.
- **Character/Number input keys:** Enters a value.

The following soft key appears when it can be used.

Space

- **Space soft key:** Enters a space.

Entering Character Strings

Use the following keys when a window for entering a character string appears.

- **Left and right arrow keys:** Select the input position.
- **Character/Number input keys:** Enter a character string.

The character to be entered is determined by the number of times the character type key and the character/number input key is pressed. The character types that can be entered vary depending on the item being set.



Input status of the A/a/1 soft key


Input status of the Ins soft key

- **Space soft key:** Enters a space.
- **Del soft key:** Deletes the character at the cursor.
- **Bs soft key:** Deletes the character before the cursor.
- **Ins soft key:** Selects insert or overwrite.
The Ins soft key switches between insert and overwrite mode. The selected mode is shown on the right side of the soft key display section.
- **A/a/1 soft key:** Selects uppercase alphabet (A), lowercase alphabet (a), or value (1).
The character type that you can enter changes each time you press the A/a/1 soft key. The selected character type is shown on the right side of the soft key display section.

Memo

RD-MV2000 Workflow

To set up the MV for quick use in the field, follow these steps:



Installation

Location

Install the MV indoors in an environment that meets the following conditions:

- **Temperature of 0 to 40°C**

Install the MV in a location where the temperature is 0 to 40°C, and the humidity is 20 to 80% RH (5 to 40°C). Only use the MV when there is no condensation on it.

Note

Condensation may form when moving the MV from a low temperature/humidity environment to a high temperature/humidity environment, or when there is a sudden change in temperature. Temperature/humidity changes may also result in thermocouple measurement errors. In these kinds of circumstances, wait for at least an hour before using the MV, to acclimate it to the surrounding environment.

- **Altitude of 2,000 m or below**

- **Good ventilation**

To prevent overheating, install the MV in a well-ventilated area. We recommend that you leave 50 mm or more of space around the top, left, and right of the MV.

- **Not much mechanical vibration**

Install the MV in a location without much mechanical vibration. Placing the MV in a place that is subject to large levels of mechanical vibration will not only put added stress on its components, it may also impede ordinary measurement.

- **Flat surface**

Install the MV on a flat surface, neither leaning to the left nor to the right. The MV can be tilted if the stand is used.

Do not install the MV in the following places:

- **Outdoors**

- **In an environment with flammable or explosive gases, steam, or dust (dangerous places)**

- **In direct sunlight or near heating devices**

Install the MV in a place that is near room temperature (23°C) and that is not subject to very much temperature fluctuation. Placing the MV in direct sunlight or near heating devices can cause adverse effects on the internal circuitry.

- **In an environment with excessive amounts of soot, steam, moisture, dust, or corrosive gases**

Soot, steam, moisture, dust, and corrosive gases will adversely affect the MV and should be avoided.

- **Near strong magnetic fields**


Install the MV in a place with a magnetic field of less than 400 A/m. Do not bring magnets or instruments that produce electromagnetic fields close to the MV. Operating the MV near strong magnetic fields can cause measurement errors.

- **Where the display is difficult to see**

The MV uses an LCD screen so viewing of the display from an extreme angle is difficult. Install the MV so that the user can view the display directly from the front.

Installation Procedure

Install the MV on a flat surface.




Note

- You cannot put the MV in a stack.
- You can put rubber feet on the bottom of the MV. Please use the ones that come with the MV.

- **Using the stand**

When using the stand, push it out until it locks into place. Push the stand back in when you store the MV.



Connecting Input Cables

Wiring to the Signal Input Terminals



WARNING

- To prevent electric shock, make sure that the power source is turned OFF.

CAUTION

- Exposing the input and output signal cables connected to the MV to high tension may damage the cables and the MV terminals. Do not stretch the cables to their limit, and make sure that the terminals are not being pulled on.
- To prevent fire, only use signal cables with a temperature rating of 70°C or above.
- Do not run a current through any of the input terminals that exceeds the voltages below. Doing so may damage the MV.
 - Maximum input voltage: ± 60 VDC
 - Maximum common mode voltage: ± 60 VDC (under measurement category II conditions)
- The MV is an installation category II product.

Wiring Precautions

Take the following precautions when wiring the input signal cables:

When using a screw terminal, we recommend that you use a crimp-on lug with an insulation sleeve (designed for 4-mm screws).



Crimp-on lug with insulation sleeves (for 4 mm screws)

When using a clamp terminal, we recommend that you use the following kind of cable:

- Conductive cross-sectional area: 0.08 mm² to 1.5 mm² (AWG28 to 16)
- Stripped section: Approx. 7 mm

Take measures to prevent noise from entering the measurement circuit.

- Move the measurement circuit away from the power cable (power circuit) and ground circuit.
- Ideally, the object being measured should not generate noise. However, if this is unavoidable, isolate the measurement circuit from the object. Also, ground the object being measured.
- Shielded wires minimize the noise caused by electrostatic induction. Connect a shield to the ground terminal of the MV as necessary (make sure you are not grounding at two points).
- To minimize noise caused by electromagnetic induction, twist the measurement circuit wires at short, equal intervals.
- Make sure to ground the protective ground terminal through minimum resistance (less than 100 Ω).

When using internal reference junction compensation on a thermocouple input, take measures to stabilize the temperature at the input terminal.

- Always use the terminal cover.
- Do not use thick wires which may cause large heat dissipation (we recommend a cross-sectional area of 0.5 mm² or less).
- Make sure that the ambient temperature remains reasonably stable. Large temperature fluctuations can occur if a nearby fan turns ON or OFF.

Connecting the input wires in parallel with other devices can cause signal degradation, affecting all connected devices. If you have to make a parallel connection, then

- Turn the burnout detection function OFF.
- Ground the instruments to the same point.
- Do not turn other instruments ON or OFF during operation. This can have adverse effects on the other instruments.
- Do not connect RTDs in parallel.

Wiring Procedure


There is a terminal cover screwed onto the signal input terminal block on the rear panel. It has a label indicating the terminal arrangement on it.

1. Turn the MV OFF and remove the terminal cover.
2. Connect the signal wires to the terminals.
3. Replace the terminal cover and fasten it with screws. The appropriate tightening torque for the screws is 0.6N/m.

Note


It may be difficult to firmly secure input signal wires with diameters of 0.3 mm or less to clamp terminals. To secure the wires, try folding the conductive parts over when you connect them to the clamp terminal.

Input Terminal Arrangement




Input terminal block	Channel allocation by model					
	RD-MV2008	RD-MV2010	RD-MV2020	RD-MV2030	RD-MV2040	RD-MV2048
1	1 to 4	1 to 10	1 to 10	1 to 10	1 to 10	1 to 12
2	5 to 8		11 to 20	11 to 20	11 to 20	13 to 24
3				21 to 30	21 to 30	25 to 36
4					31 to 40	37 to 48

Connecting Input Cables




Wiring Screw Terminals


DC voltage input/DI (ON/OFF) input




TC input



RTD input




DC current input




Wiring Clamped Terminals

Remove the terminal block.




Hold both ends of the terminal block and pull straight.

Connect the wires.

**Input signal wire**

First, loosen the screw at the front using a flat-blade screwdriver. Insert the input signal wire into the slit on the left side of the terminal block, and fasten the screw at the front.

Connect the terminal block.



Hold both ends of the terminal block, align it with the connector, and then push it in.

Note

RTD input terminals A and B are isolated on each channel. Terminal b is shorted internally across all channels. However, terminal b is also isolated on each channel on models with the / N1 option (Cu10, Cu25 RTD input/3-wire isolated RTD) and /N2 option (3-wire isolated RTD).

Connecting a Power Cable

Connecting the Power Cord (if the power supply voltage suffix code is -1)

Precautions to Be Taken While Connecting the Power Supply

Make sure to follow the warnings below when connecting the power supply. To prevent electric shock and damage to the MV, observe the following warnings.



WARNING

- Before connecting the power cord, ensure that the source voltage matches the rated supply voltage of the MV and that it is within the maximum rated voltage range of the provided power cord.
- Confirm that the power switch is OFF before connecting the power cord.
- To prevent electric shock or fire, be sure to use the power cord supplied by Omega.
- Make sure to perform protective earth grounding to prevent electric shock. Connect the power cord of the desktop type to a three-prong power outlet with a protective earth terminal.
- Do not use an extension cord without protective earth ground. Otherwise, the protection function will be compromised.

Use a power supply that meets the following conditions:


Item	Specifications
Rated supply voltage	100 to 240 VAC
Allowable power supply voltage range	90 to 132, 180 to 264 VAC
Rated power supply frequency	50/60 Hz
Allowable power supply frequency range	50/60 Hz $\pm$ 2%
Maximum power consumption	65 VA (100 V), 90 VA (240 V)

Note

Do not use a supply voltage in the range 132 to 180 VAC, as this may have adverse effects on measurement accuracy.

Connection Procedure

1. Check that the power switch is OFF.
2. Connect the power cord plug to the power connector on the rear panel. (Use the power cord that comes with the package.)



3. Check that the power outlet meets the conditions given in the table above and that the supply voltage is within the maximum rated voltage range of the power cord that comes with the package. Then, connect the other end of the power cord to the power outlet. You must use a three-prong AC outlet with a protective ground.

Connecting the Power Cord (if the power supply voltage suffix code is -2)

When Using an AC Adapter

Precautions to Be Taken While Connecting the Power Supply

Make sure to follow the warnings below when connecting the power supply. To prevent electric shock and damage to the MV, observe the following warnings.



WARNING


- To prevent electric shock, make sure that the power source is turned OFF.
- Only use the power cord that Omega provides for use with the MV.
- Confirm that the power source voltage matches the specifications of the AC adapter before connecting the power cord.
- When you do not plan on using the MV for a while, remove the power cord from the AC outlet.
- Only use a Omega AC adapter.
- Do not place objects on top of the AC adapter or power cord, and keep them away from heat sources.
- When removing the plug from the power outlet, do not pull on the cord. Pull from the plug. If the power cord is damaged, contact the dealer from whom you purchased the cord.

Use a power supply that meets the following conditions:

Item	Specifications
Rated supply voltage	100 to 240 VAC
Operating supply voltage range	90 to 264 VAC
Rated supply frequency	50/60Hz
Power supply frequency range	48 to 62 Hz
Maximum power consumption	65 VA (100 V), 90 VA (240 V)

Connection Procedure

1. Check that the power switch is OFF.
2. Connect the power cord and the protective ground cord to the power terminal.
Use round crimp-on lugs (designed for 4-mm screws) with insulation sleeves. The appropriate tightening torque for the screws is 1.4 to 1.5 N/m.



3. Attach the power terminal cover (transparent), and fasten it with screws.

When Using a DC Power Supply

Precautions to Be Taken While Connecting the Power Supply

Make sure to follow the warnings below when connecting the power supply. To prevent electric shock and damage to the MV, observe the following warnings.



WARNING

- To prevent electric shock, make sure that the power source is turned OFF.
- To prevent fire, use cables with a cross-sectional area of 0.5 mm² (AWG20) or more.
- Use crimp-on lugs (designed for 4 mm screws) with insulation sleeves to connect both the power cord and the protective ground.
- To prevent electric shock, be sure to attach the electrical wiring cover (transparent).

Use a power supply that meets the following conditions:

Item	Specification
Rated supply voltage	12 or 24 VDC
Operating supply voltage range	10 to 28.8 VDC
Maximum power consumption	35 VA

Connection Procedure

1. Make sure that the power source is OFF. Open the power terminal cover (transparent).
2. Follow the instructions in "When using an AC adapter" and connect the positive and negative cables and the protective ground cable to the power terminal.
3. Attach the power terminal cover (transparent), and fasten it with screws.

Turning the Power ON/OFF

Turning the Power ON




CAUTION

Before turning ON the power switch, check that

- The power cord/wires are connected correctly to the MV.
- The MV is connected to the correct power supply (see page 64).

If the input wires are connected in parallel with other devices, do not turn the power switch of the MV or another device ON or OFF during operation. This can have adverse effects on the measured values.

Turn ON the power switch. After the MV performs a self-test for a few seconds, the operation screen appears.



CAUTION

- If nothing is displayed when the power switch is turned ON, turn the power switch OFF and check the points listed above one more time. After checking the points, turn the power switch ON again. If the MV still does not work, there is probably a malfunction. Contact your nearest Omega dealer for repairs.
- If an error message is displayed on the screen, refer to section 12.2, "Troubleshooting," in the *MV1000/RD-MV2000 User's Manual*, and take the appropriate measures.
- Turn ON the power switch, let the MV warm up for at least 30 minutes, and then start measurement.

Turning the Power OFF



CAUTION

Before turning OFF the power switch, check that the external storage medium is not being accessed.

Turn OFF the power switch.

Quick Settings


Using the quick settings function, you can switch quickly to the measurement channel (measurement range and alarm) and data save configuration screens by pressing **T/DIV**.

Procedure


Operate the MV from the Quick settings screen according to the procedure described below.

- Measurement channels: Set channels 1 through 4 to the following settings:
Mode: Volt, Range: 2V, Span_L: -2V, Span_U: 2V
 - Display-data save settings: Trend/Storage interval: 1min, Save interval: 1h
 - Event data save settings: Sample rate: 1s, Mode: Free (mem. sampling started with START/STOP key), Data length: 1h
- For default RD-MV2000 settings, see page 36.


1 Press MENU.




2 Press the left arrow key.



3 Press T/DIV.




4 Set the measurement range.




1. Select the channel to configure.
Press 1 for the first channel and 4 for the last channel.
2. Select the **Mode**.
Press the **Volt** soft key.
3. Select the **Range**.
Press the **2V** soft key.
4. Enter the **Span Upper** and **Span Lower** limits.
Press the **Input** soft key, and select a value with the character/number input keys and the up and down arrow keys.

5 Press T/DIV.



6 Change the display-data save settings




1. Select the **Trend/Storage interval**.
Press the **1min** soft key.
2. Select the **Save interval**.
Press the **1h** soft key.


Note

This screen does not appear with the default settings.
In A/D, Memory in Basic setting mode, set the data type to E+D

7 Press T/DIV.




8 Change the event data display settings.



1. Select the **Sample rate**.
Press the **1s** soft key.
2. Select the **recording mode**.
Press the **Free** soft key.
3. Select the **Data length**.
Press the **1h** soft key.

9 Press T/DIV.




Return to the **Quick** settings screen.
You have finished configuring the MV.


Measurement

Inserting the CF Card

1. Open the cover.



2. Insert the CF card into the slot.




The CF card icon is displayed.
If the MV does not recognize the CF card, try reinserting it.

3. Close the cover.
Check that the CF card slot eject button is depressed before closing the cover.
- Operation complete.

Starting the Memory Sample


1. Press **START/STOP** once.
Memory sampling starts, and the key blinks green.



Operation complete.

Stopping the Memory Sample

1. Press the **START/STOP** key when it is blinking green.



2. Select **Mem+Math** or **Memory** using the **left and right arrow keys**.
 Memory: Stops memory sampling.
 Mem+Math: Stops memory sampling and computation (option).
 On models without the computation function (option), the confirmation message "Do you want to stop data storage?" appears. Select **Yes**.
3. Press **DISP/ENTER** once.




Recording has stopped.


Operation complete.

Removing the CF Card


1. Press **FUNC** once.
2. Press **Media eject** once.



3. Press the **CF** soft key once. The message, "Media can be removed safely" appears. The CF card icon is blue.



4. Open the cover.
5. Press the CF card eject button. When you eject the CF card, the CF card icon disappears.



6. Close the cover.

Operation complete.

Note

If you remove the CF card without carrying out the media eject procedure, the message "Media was removed compulsorily" appears. Remove the CF card by carrying out the procedure above to prevent damage to the stored data.

Viewing Data with DAQSTANDARD

You can use the DAQSTANDARD software that comes with the RD-MV2000 to view data saved to a CF card. For more information, see the *DAQSTANDARD User's Manual (IM 04L41B01-01E)*.

Memo

Default RD-MV2000 Settings

The setting mode and basic setting mode settings and their default values are listed in this section.

Setting Mode Menu

- Menu

Menu	
Menu channel	Pages 38 to 40
Math channel	Pages 40 to 42*
Ext. channel	Pages 42 and 43*
Data save	Page 43
Display	Page 44
Group set. Trip line	Page 44
Message	Page 44
Timer. Event action	Pages 45 and 46
Menu customize	Pages 47 and 48
Date/Time	Page 48
Basic setting mode	Page 49

* Optional function

Basic Setting Mode Menu

- Environment

Basic Setting Mode	
Environment	
Operating environment	Page 49
View. Message. Input. Alarm	Page 49
Security. Media save. Batch	Page 49
Communication	Page 49
Math. Report	Page 50
End	Page 50

• Menu

Basic Setting Mode		
Menu	Menu	Menu
Alarm		Page 51
A/D Memory		Page 51
Burnout, RJC		Page 51
Keylock		Page 52 ¹
Login		Pages 52 and 53 ¹
Report		Page 53 ²
Time settings		Page 53
Communication (Ethernet)		Pages 53 to 56
Communication (Serial)		Page 57 ²
Status relay		Page 57 ²
End		Page 57

- 1 The function will be displayed if you choose to use it in **Environment**.
2 Optional function

• Initialize

Basic Setting Mode		
Menu	Menu	Menu
Clear settings and data		Page 58
Clear data only		Page 58

Setting Mode Settings and Default Values

Menu Tab

Meas channel > Range, Alarm

Setting	Selectable Range or Choices	Default Value
First-CH, Last-CH	Numeric value (channel number) 1 to 48	001
Range>Mode	Skip/Volt/TC/RTD/Scale/Delta/DI/1-5V/Sqrt	Volt
Mode=Volt		
Range	20mV/60mV/200mV/2V/6V/20V/50V	2V
Span Lower	Numeric value (depends on the range)	-2.0000
Span Upper	Numeric value (depends on the range)	2.0000
Mode=TC		
Range	R/S/B/K/E/J/T/N/W/L/U/WRe	R
Span Lower	Numeric value (depends on the range)	0.0
Span Upper	Numeric value (depends on the range)	1760.0
Mode=RTD		
Range	Pt/JPt	Pt
Span Lower	Numeric value (depends on the range)	-200.0
Span Upper	Numeric value (depends on the range)	600.0
Mode=Scale		
Type	Volt/TC/RTD/DI	Volt
Range	20mV/60mV/200mV/2V/6V/20V/50V (type = Volt) R/S/B/K/E/J/T/N/W/L/U/WRe (type = TC) Pt/JPt (type = RTD) Level/Cont (type = DI)	2V R Pt Level
Span Lower	Numeric value (depends on the range)	-2.0000
Span Upper	Numeric value (depends on the range)	2.0000
Scale Lower	Numeric value (depends on the range)	0.00
Scale Upper	Numeric value (depends on the range)	200.00
Unit	Character string (up to 6 characters)	—
Mode=Delta		
Type	Volt/TC/RTD/DI	Volt
Range	20mV/60mV/200mV/2V/6V/20V/50V (type = Volt) R/S/B/K/E/J/T/N/W/L/U/WRe (type = TC) Pt/JPt (type = RTD) Level/Cont (type = DI)	2V R Pt Level
Span Lower	Numeric value (depends on the range)	-2.0000
Span Upper	Numeric value (depends on the range)	2.0000
Ref. CH	Numeric value (measurement channel number)	001
Mode=DI		
Range	Level/Cont	Level
Span Lower	Numeric value (0, 1)	0
Span Upper	Numeric value (0, 1)	1
Mode=1-5V		
Range	1-5V	1-5V
Span Lower	Numeric value (0.800 to 5.200)	1.000
Span Upper	Numeric value (0.800 to 5.200)	5.000
Scale Lower	Numeric value (-3000 to 3000, decimal place 0 to 4)	0.00
Scale Upper	Numeric value (-3000 to 3000, decimal place 0 to 4)	200.00
Unit	Character string (up to 6 characters)	—
Low-cut	On/Off	Off
Mode=.Sqrt		
Range	20mV/60mV/200mV/2V/6V/20V/50V	2V
Span Lower	Numeric value (depends on the range)	-2.0000
Span Upper	Numeric value (depends on the range)	2.0000
Scale Lower	Numeric value (-3000 to 3000, decimal place 0 to 4)	0.00
Scale Upper	Numeric value (-3000 to 3000, decimal place 0 to 4)	200.00
Unit	Character string (up to 6 characters)	—
Low-cut	On/Off	Off
Low-cut value	0.0 to 5.0 (%)	0.5

Default RD-MV2000 Settings

Setting	Selectable Range or Choices	Default Value
Range > Alarm 1 to 4	On/Off	Off
Type:	H/L/h/l/R/r/T/t	H
Value	Numeric value	0.00
Relay On/Off	On/Off	Off
No.	I01 to I06/I11 to I16/S01 to S30	I01
Detect	On/Off	On

Meas channel > Tag, Memory sample, Alarm delay

Setting	Selectable Range or Choices	Default Value
First-CH, Last-CH	Numeric value (channel number) 1 to 48	001
Tag > Characters	Character string (up to 16 characters)	—
Memory sample > On/Off	On/Off	On
Alarm delay > Time	Numeric value (1 to 3600) s	10

Meas channel > Moving average

Setting	Selectable Range or Choices	Default Value
First-CH, Last-CH	Numeric value (channel number) 1 to 48	001
Moving average > On/Off	On/Off	Off
Count	Numeric value (2 to 400)	2

Meas channel > Color

Setting	Selectable Range or Choices	Default Value
Group of channel	001–010/011–020/021–030/031–040/041–048	001-010
Color	Red, Green Blue, B.violet, Brown, Orange, Y.green, Lightblue, Violet, Gray, Lime, Cyan, Darkblue, Yellow, Lightgray, Purple, Black, Pink, L.brown, L.green, Darkgray, Olive, DarkCyan, S.green	Colors assigned in order to groups Red, Green Blue, B.violet, Brown, Orange, Y.green, Lightblue, Violet, Gray

Meas channel > Zone, Scale, Bar graph

Setting	Selectable Range or Choices	Default Value
First-CH, Last-CH	Numeric value (channel number) 1 to 48	001
Zone	Lower	0
	Upper	100
Scale	Position	1
	Division	10
Bar graph	Base position	Normal
	Division	10

Meas channel > Partial

Setting	Selectable Range or Choices	Default Value
First-CH, Last-CH	Numeric value (channel number) 1 to 48	001
Partial	On/Off	Off
	Expand	50
	Boundary	0.0000

Default RD-MV2000 Settings

Meas channel > Alarm mark, Color scale band

Setting	Selectable Range or Choices		Default Value
First-CH, Last-CH	Numeric value (channel number) 1 to 48		001
Alarm mark	Mark kind	Alarm/Fixed	Alarm
	Indicate on Scale	On/Off	Off
	Alarm mark color > Alarm 1 to 4	Red, Green Blue, B.violet, Brown, Orange, Y.green, Lightblue, Violet, Gray, Lime, Cyan, Darkblue, Yellow, Lightgray, Purple, Black, Pink, L.brown, L.green, Darkgray, Olive, DarkCyan, S.green	Alarm 1: Red Alarm 2: Orange Alarm 3: Orange Alarm 4: Red
Color scale band	Band area	Off/In/Out	Off
	Color	Same as the mark color	Lime
	Display position > Lower	Numeric value (measurement range)	0.0000
	Display position > Upper	Numeric value (measurement range)	0.0100

Meas channel > Calibration correction

Setting	Selectable Range or Choices		Default Value
First-CH, Last-CH	Numeric value (channel number) 1 to 48		001
Calibration correction	Number of set points	Off/2/3/4/5/6/7/8/9/10/11/12/13/14/15/16	Off
	Mes val	Input/Measure	-2.0000
	True val	Numeric value (measurement range)	-2.0000

Meas channel > Calculation expression, Alarm

Setting	Selectable Range or Choices		Default Value
First-CH, Last-CH	Numeric value (computation channel number) 101 to 160		101
Math range	Math On/Off	On/Off	Off
	Calculation expression	Character string (up to 120 characters)	-
	Span Lower	Numeric value (-9999999 to 99999999, decimal place 0 to 4)	-200.00
	Span Upper	Numeric value (-9999999 to 99999999, decimal place 0 to 4)	200.00
	Unit	Character string (up to 6 characters)	-
Alarm	1 to 4	On/Off	Off
	Type	H/L/T/t	H
	Value	Numeric value	0.00
	Relay On/Off	On/Off	Off
	Number	I01 to I06/I11 to I16/S01 to S30	I01
	Detect	On/Off	On

Math channel > Constant

Setting	Selectable Range or Choices	Default Value
Number of constant	K01-K60	K01
Constant > Value	Numeric value (-9.9999E+29 to -1.0000E-30, 0, 1.0000E-30 to -9.9999E+29)	1

Math channel > Tag, Memory sample, Alarm delay

Setting	Selectable Range or Choices	Default Value
First-CH, Last-CH	Numeric value (computation channel number) 101 to 160	101
Tag > Characters	Character string (up to 16 characters)	-
Memory sample > On/Off	On/Off	On
Alarm delay > Time	Numeric value (1 to 3600) s	10

Math channel > TLOG, Rolling average

Setting		Selectable Range or Choices	Default Value
First-CH, Last-CH		Numeric value (computation channel number) 101 to 160	101
TLOG	Timer type	Timer/Match T	Timer
	Timer No.	1/2/3/4	1
	Sum scale	Off, /s, /min, /h	Off
	Reset	On/Off	Off
Rolling average	On/Off	On/Off	Off
	Interval	1s/2s/3s/4s/5s/6s/10s/12s/15s/20s/30s/1min/2min/ 3min/4min/5min/6min/10min/12min/15min/20min/3 0min/1h	10s
	Number of samples	Numeric value (1 to 1500)	1

Math channel > Color

Setting		Selectable Range or Choices	Default Value
Group of channel		101-110/111-120/121-130/131-140/141- 150/151-160	101-110
Color		Red, Green Blue, B.violet, Brown, Orange, Y.green, Lightblue, Violet, Gray, Lime, Cyan, Darkblue, Yellow, Lightgray, Purple, Black, Pink, L.brown, L.green, Darkgray, Olive, DarkCyan, S.green	Colors assigned in order to groups. Red, Green Blue, B.violet, Brown, Orange, Y.green, Lightblue, Violet, Gray

Math channel > Zone, Scale, Bar graph

Setting		Selectable Range or Choices	Default Value
First-CH, Last-CH		Numeric value (computation channel number) 101 to 160	101
Zone	Lower	Numeric value (0 to 95)	0%
	Upper	Numeric value (5 to 100)	100%
Scale	Position	Off/1/2/3/4/5/6/7/8/9/10	1
	Division	4/5/6/7/8/9/10/11/12/C10	10
Bar graph	Base position	Normal/Center/Lower/Upper	Normal
	Division	4/5/6/7/8/9/10/11/12	10

Math channel > Partial

Setting		Selectable Range or Choices	Default Value
First-CH, Last-CH		Numeric value (computation channel number) 101 to 160	101
Partial	On/Off	On/Off	Off
	Expand	Numeric value (1 to 99)%	50
	Boundary	Numeric value (minimum span value + 1 digit to maximum span value - 1 digit)	0.0

Math channel > Alarm mark, Color scale band

Setting		Selectable Range or Choices	Default Value
First-CH, Last-CH		Numeric value (computation channel number) 101 to 160	101
Alarm mark	Mark kind	Alarm/Fixed	Alarm
	Indicate on Scale	On/Off	Off
	Alarm mark color > Alarm 1 to 4	Red, Green Blue, B.violet, Brown, Orange, Y.green, Lightblue, Violet, Gray, Lime, Cyan, Darkblue, Yellow, Lightgray, Purple, Black, Pink, L.brown, L.green, Darkgray, Olive, DarkCyan, S.green	Alarm mark color 1: Red Alarm mark color 2: Orange Alarm mark color 3: Orange Alarm mark color 4: Red
Color scale band	Band area	Off/In/Out	Off
	Color	Red, Green Blue, B.violet, Brown, Orange, Y.green, Lightblue, Violet, Gray, Lime, Cyan, Darkblue, Yellow, Lightgray, Purple, Black, Pink, L.brown, L.green, Darkgray, Olive, DarkCyan, S.green	Lime
	Display position > Lower	Numeric value (measurement range)	0.00
	Display position > Upper	Numeric value (measurement range)	1.00

Math channel > Math start action

Setting	Selectable Range or Choices	Default Value
Math start action > Math start	Off/Start/Rst+St	Start

Ext. channel > Range, Alarm

Setting	Selectable Range or Choices	Default Value
First-CH, Last-CH	Numeric value (external input channel number) 201 to 440	201
Ext. range	On/Off	Off
Span Lower	Numeric value (–30000 to 30000, decimal place 0 to 4)	–200.00
Span Upper	Numeric value (–30000 to 30000, decimal place 0 to 4)	200.00
Unit	Character string (up to 6 characters)	—
Ext. alarm	1 to 4	Off
Type	H/L/T/t	H
Value	Numeric value	0.00
Relay On/Off	On/Off	Off
Number	I01 to I06/I11 to I16/S01 to S30	I01
Detect	On/Off	On

Ext. channel > Tag, Memory sample, Alarm delay

Setting	Selectable Range or Choices	Default Value
First-CH, Last-CH	Numeric value (external input channel number) 201 to 440	201
Tag > Characters	Character string (up to 16 characters)	—
Memory sample	On/Off	Off
Alarm delay > Time	Numeric value (1 to 3600) s	10

Ext. channel > Color

Setting	Selectable Range or Choices	Default Value
Group of channel	201–210/211–220/221–230/.../421–430/431–440	201–210
Color	Red, Green Blue, B.violet, Brown, Orange, Y.green, Lightblue, Violet, Gray, Lime, Cyan, Darkblue, Yellow, Lightgray, Purple, Black, Pink, L.brown, L.green, Darkgray, Olive, DarkCyan, S.green	Colors assigned in order to groups. Red, Green Blue, B.violet, Brown, Orange, Y.green, Lightblue, Violet, Gray

Ext. channel > Zone, Scale, Bar graph

Setting	Selectable Range or Choices	Default Value
First-CH, Last-CH	Numeric value (external input channel number) 201 to 440	201
Zone	Lower	Numeric value (0 to 95) %
	Upper	Numeric value (5 to 100) %
Scale	Position	Off/1/2/3/4/5/6/7/8/9/10
	Division	4/5/6/7/8/9/10/11/12/C10
Bar graph	Base position	Normal/Center/Lower/Upper
	Division	4/5/6/7/8/9/10/11/12

Ext. channel > Partial

Setting	Selectable Range or Choices	Default Value
First-CH, Last-CH	Numeric value (external input channel number) 201 to 440	201
Partial	On/Off	Off
	Expand	Numeric value (1 to 99)%
	Boundary	Numeric value (minimum span value + 1 digit to maximum span value – 1 digit)

Ext. channel > Alarm mark, Color scale band

Setting	Selectable Range or Choices		Default Value
First-CH, Las-CH	Numeric value (external input channel number) 201 to 440		201
Alarm mark	Mark kind	Alarm/Fixed	Alarm
	Indicate on Scale	On/Off	Off
	Alarm mark color > Alarm 1 to 4		
	Red, Green Blue, B.violet, Brown, Orange, Y.green, Lightblue, Violet, Gray, Lime, Cyan, Darkblue, Yellow, Lightgray, Purple, Black, Pink, L.brown, L.green, Darkgray, Olive, DarkCyan, S.green		Alarm 1: Red Alarm 2: Orange Alarm 3: Orange Alarm 4: Red

Data save > File settings

Setting	Selectable Range or Choices		Default Value
Disp/Event File > File format	Binary/Text		Binary
File header > Characters	Character string (up to 50 characters)		—
Data file name	Structure	Date/Serial/Batch	Date
	Identified strings	Character string (up to 16 characters)	—

Data save > Save directory

Setting	Selectable Range or Choices		Default Value
Save directory > Directory name	Character string (up to 20 characters)		DATA0

Data save > Save directory

Setting	Selectable Range or Choices		Default Value
Disp data	Trend/Storage interval	5s/10s/15s/30s/1min/2min/5min/10min/15min/20min/30min/1h/2h/4h/10h (/div)	1min
	Save interval	10min/20min/30min/1h/2h/3h/4h/6h/8h/12h/1day/2day/3day/5day/7day/10day/14day/31day	1h

Data save > Event data

Setting	Selectable Range or Choices		Default Value
Event data	Sample rate	25ms/125ms/250ms/500ms/1s/2s/5s/10s/30s/1min/2min/5min/10min(varies depending on the model)	1s
	Mode	Free/Single/Repeat	Free
	Data length	10min/20min/30min/1h/2h/3h/4h/6h/8h/12h/1day/2day/3day/5day/7day/10day/14day/31day	1h
	Pre-trigger	0/5/25/50/75/95/100 %	0
	Trigger signal > Key	On/Off	On

Data save > Manual sample

Setting	Selectable Range or Choices		Default Value
Manual Sample number	Numeric value (channel number)001 to 120		001
Manual Sample	On/Off	On/Off	On
	Channel	001 to 048, 101 to 160, 201 to 440	001

Data save > Batch text

Setting	Selectable Range or Choices		Default Value
Text field number	1/2/3/4/5/6/7/8		1
Text field	Title of field	Character string (up to 20 characters)	—
	Characters	Character string (up to 30 characters)	—

Default RD-MV2000 Settings

Display > Trend, Bar graph, LCD, Monitor

Setting		Selectable Range or Choices	Default Value
Trend	Direction	Horizon/Vertical/Wide/Split	Wide
	Trend clear	On/Off	On
	Message direction	Horizon/Vertical	Horizon
	Scale > Digit	Normal/Fine	Normal
	Scale > Value indicator	Mark/Bargraph	Mark
	Trend line	1/2/3 dot	2
	Grid	Auto/4/5/.../11/12 div	Auto
	Second interval	5s/10s/30s/1min/2min/5min/10min/15min/20min/30min/1h/2h/4h/10h	1min
Bar graph	Direction	Horizon/Vertical	Vertical
LCD	Brightness	1/2/3/4/5/6	2
	Backlight saver > Mode	Off/Dimmer/Timeoff	Off
	Backlight saver > Saver time	1min/2min/5min/10min/30min/1h	1h
	Backlight saver > Restore	Key/Key+Alm	Key+Alm
Monitor	Background > Display	White/Black	White
	Background > Historical trend	White/Cream/Black/Lightgray	Black
	Scroll time	5s/10s/20s/30s/1min	10s
	Jump default display	Off/1min/2min/5min/10min/20min/30min/1h	Off

Display > HISTORY Key action

Setting		Selectable Range or Choices	Default Value
HISTORY Key action	Action	History/Favorite	History
	Group display	Current/Saved	Saved
	Time axis zoom	Current/Saved	Saved

Group set, Trip line

Setting		Selectable Range or Choices	Default Value
Group number		1/2/3/.../35/36	1
Group set > On/Off	On/Off	On/Off	On (groups 1 to 4 or groups 1 to 5 for 48ch) Off (groups 5 to 36 or 6 to 36 for 48ch)
	Group name	Character string (up to 16 characters)	GROUP 1
	CH set	Character string (channel number designation, up to 39 characters)	001.002.003.004.005.006 .007.008.009.010 (varies depending on the model)
Trip line	1 to 4	On/Off	Off
	Position	Numeric value (0 to 100 %)	50
	Color	Red/Green/Blue/B.violet/Brown/Orange/Y.green/Lightblue/Violet/Gray/Lime/Cyan/Darkblue/Yellow/Lightgray/Purple/Black/Pink/L.brown/L.green/Darkgray/Olive/DarkCyan/S.green	Color 1: Red
			Color 2: Green
			Color 3: Blue
	Line width	1/2/3 dot	Color 4: Yellow 2

Message

Setting	Selectable Range or Choices	Default Value
Message No.	1-10/11-20/21-30/31-40/41-50/51-60/61-70/71-80/81-90/91-100	1-10
Message > Characters	Character string (up to 32 characters)	—

Timer, Event action > Timer

Setting	Selectable Range or Choices	Default Value
Timer No.	1/2/3/4	1
Timer	Mode	Off/Relative/Absolute
	Mode = Relative	
	Interval	Numeric value (00:01 to 24:00)
	Reset at Math Start	On/Off
	Mode = Absolute	
	Interval	1min/2min/3min/4min/5min/6min/10min/12min/15min/20min/30min/1h/2h/3h/4h/6h/8h/12h/24h
	Ref.time	Numeric value (0 to 23)

Timer, Event action > Match time timer

Setting	Selectable Range or Choices	Default Value
Timer number	1/2/3/4	1
Match time timer	Kind	Off, Day, Week, Month, Year
	Kind > Day	
	Day	Numeric value (1 to 28)
	Hour:Minute	Numeric value (00:00 to 23:59)
	Timer action	Single/Repeat
	Kind > Week	
	Day of the week	SUN/MON/TUE/WED/THU/FRY/SAT
	Hour:Minute	Numeric value (00:00 to 23:59)
	Timer action	Single/Repeat
	Kind > Month	
	Day	Numeric value (1 to 28)
	Hour:Minute	Numeric value (00:00 to 23:59)
	Timer action	Single/Repeat
	Kind > Year	
	Month	1/2/3/4/5/6/7/8/9/10/11/12
	Day	Numeric value (1 to 31)
	Hour:Minute	Numeric value (00:00 to 23:59)
	Timer action	Single/Repeat

Timer, Event action > Evnet action

Setting	Selectable Range or Choices	Default Value
Logic box number	1/2/3/4/.../39/40	1
Event-Action		
Event	None/Remote/Relay/Switch/Timer/MatchTimeTimer/Alarm/UserKey	None
Event = Remote		
Remote number	1/2/3/4/5/6/7/8	1
Action	MemoryStart/Stop, MemoryStart, MemoryStop, Trigger, AlarmACK, MathStart/Stop, MathStart, MathStop, MathReset, SaveDisplay, SaveEvent, Message, Snapshot, DisplayRate1/2, ManualSample, TimerReset, DisplayGroupChange, Flag, PanelLoad, TimeAdjust, DisplayFreeze/Active, MemoryClear	DisplayGroupChange
Event = Relay		
Relay number	I01/.../I06, I11/.../I16	I01
Action	MemoryStart/Stop, MemoryStart, MemoryStop, Trigger, MathStart/Stop, MathStart, MathStop, MathReset, SaveDisplay, SaveEvent, Message, Snapshot, DisplayRate1/2, ManualSample, TimerReset, DisplayGroupChange, Flag	DisplayGroupChange
Event = Switch		
Switch No.	S01/S02/S03/.../S29/S30	S01

Default RD-MV2000 Settings

Setting	Selectable Range or Choices	Default Value
Action	MemoryStart/Stop, MemoryStart, MemoryStop, Trigger, MathStart/Stop, MathStart, MathStop, MathReset, SaveDisplay, SaveEvent, Message, Snapshot, DisplayRate1/2, ManualSample, TimerReset, DisplayGroupChange, Flag	DisplayGroupChange
Event = Timer		
Timer No.	1/2/3/4	1
Action	MemoryStart/Stop, MemoryStart, MemoryStop, Trigger, AlarmACK, MathStart/Stop, MathStart, MathStop, MathReset, SaveDisplay, SaveEvent, Message, Snapshot, DisplayRate1/2, ManualSample, DisplayGroupChange, Flag	DisplayGroupChange
Event = MatchTimeTimer		
Timer No.	1/2/3/4	1
Action	MemoryStart/Stop, MemoryStart, MemoryStop, Trigger, AlarmACK, MathStart/Stop, MathStart, MathStop, MathReset, SaveDisplay, SaveEvent, Message, Snapshot, DisplayRate1/2, ManualSample, TimerReset, DisplayGroupChange, Flag	DisplayGroupChange
Event = Alarm		
Action	MemoryStart/Stop, MemoryStart, MemoryStop, Trigger, MathStart/Stop, MathStart, MathStop, MathReset, SaveDisplay, SaveEvent, Message, Snapshot, DisplayRate1/2, ManualSample, TimerReset, DisplayGroupChange, Flag	DisplayGroupChange
Group No.	1/2/3/.../35/36	1
Event = UserKey		
Action	MemoryStart/Stop, MemoryStart, MemoryStop, Trigger, AlarmACK, MathStart/Stop, MathStart, MathStop, MathReset, SaveDisplay, SaveEvent, Message, Snapshot, DisplayRate1/2, ManualSample, TimerReset, DisplayGroupChange, Flag	DisplayGroupChange

Menu customize > Function menu

Setting	Choices
Pause Display	Select/Hide/Transfer
Message	
Free message	
Media eject	
Snapshot	
Manual sample	
Alarm ACK	
LCD Saver	
Trigger	
Save display	
Save event	
Save stop	
Math start	
Math reset	
Math ACK	
Timer reset	
Match T Reset	
Keylock	
Logout	
Password change	
Second speed	
Batch	
Text field	
Favorite regist	
4Panel	
Standard display	
System info	
Network info	
SNTP	
E-Mail start	
E-Mail test	
FTP test	

Menu customize > Display menu

Setting	Submenu	Choices
ESC		Separate/Select/Hide
TREND	GROUP1 to GROUP36 ALL CHANNEL/GROUP CHANNEL AUTO ZONE ON/OFF SCALE ON/OFF FINE GRID ON/OFF DIGITAL ON/OFF MESSAGE DISP 1/2 TREND SPACE ON/OFF AUTO SCROLL ON/OFF EXPAND	
TREND HISTORY	GROUP1 to GROUP36	
DIGITAL	GROUP1 to GROUP36 AUTO SCROLL ON/OFF EXPAND	
BAR	GROUP1 to GROUP36 AUTO SCROLL ON/OFF EXPAND	
OVERVIEW	CURSOR ON/OFF JUMP TO ALM SUM JUMP TO TREND JUMP TO DIGITAL JUMP TO BAR EXPAND	

Default RD-MV2000 Settings

Setting	Submenu	Choices
INFORMATION	ALARM SUMMARY	Select/Hide
	MESSAGE SUMMARY	
	MEMORY SUMMARY	
	MODBUS CLIENT	
	MODBUS MASTER	
	RELAY	
	REPORT DATA	
	COLUMN BAR	
	TO HISTORY	
	TO HISTORY(DISP)	
	TO HISTORY(EV)	
	TO OVERVIEW	
	CHANG SORT KEY	
	ASCENDING ORDER/DESCENDING ORDER	
	DATA SAVE MODE	
	SELECT SAVE	
	M.SAMPLE SAVE	
	REPORT SAVE	
	ALL SAVE	
	CHANGE DISP ITEM	
	CHANGE DATA KIND	
	FILENAME DISPLAY	
	CHANGE REPORT CH	
	DUAL GRAPH/SINGLE GRAPH	
	SELECT COLUMN	
	REPORT GROUP 1 to REPORT GROUP6	
	EXPAND	
LOG	LOGIN	
	ERROR	
	COMMUNICATION	
	FTP	
	MAIL	
	WEB	
	SNTP	
	DHCP	
	MODBUS	
4 PANEL	MIX	
	ALL TREND	
	ALL DIGITAL	
	ALL BAR	
EXPAND	—	

Date/Time > Time settings

Setting	Selectable Range or Choices	Default Value
Time set	—	08/01/01

Date/Time > Daylight Saving Time

Setting	Selectable Range or Choices	Default Value
DST > Use/Not	Use/Not	Use
Start time		
Month	1/2/.../11/12	3
Day order	1st/2nd/3rd/4th/Last	2nd
Day of the week	SUN/MON/TUE/WED/THU/FRI/SAT	SUN
Hour of the day	0 to 23	2
End time		
Month	1/2/.../11/12	11
Day order	1st/2nd/3rd/4th/Last	1st
Day of the week	SUN/MON/TUE/WED/THU/FRI/SAT	SUN
Hour of the day	0 to 23	1

Basic Setting Mode Settings and Default Values

Environment Tab

Operating environment

Setting	Selectable Range or Choices	Default Value
Operating environment		
Tag/Channel	Tag/Channel	Tag
Language	English/Japanese/German/French/Chinese/Korean	English
Temperature	C/F	C
Decimal Point Type	Point/Comma	Point

Environment > View, Message, Input, Alarm

Setting	Selectable Range or Choices	Default Value
View		
Trend type	T-Y	T-Y
Partial	On/Off	Off
Trend rate switching	On/Off	Off
Message		
Write group	Common/Separate	Common
Power-fail message	On/Off	Off
Change message	On/Off	Off
Input		
Value on over-range	Free/Over	Free
Alarm		
No logging	On/Off	Off

Environment > Security, Media save, Batch

Setting	Selectable Range or Choices	Default Value
Security		
Key	Off/Login/Keylock	Off
Communication	Off/Login	Off
Save		
Auto save	On/Off	On
Media FIFO	On/Off	Off
Batch		
On/Off	On/Off	Off
Lot-No. digit	Off/4/6/8	6
Auto increment	On/Off	On

Environment > Communication > Service port

Setting	Selectable Range or Choices	Default Value
Service port		
FTP	Numeric value (1 to 65535)	21
HTTP	Numeric value (1 to 65535)	80
SNTP	Numeric value (1 to 65535)	123
Modbus	Numeric value (1 to 65535)	502

Environment > Communication > POP3 Details

Setting	Selectable Range or Choices	Default Value
POP3 Details		
POP Before SMTP > Send delay [second]	0 to 10 s	2
POP Before SMTP > POP3 Login	PLAIN/APOP	PLAIN

Default RD-MV2000 Settings**Environment > Math, Report**

Setting	Selectable Range or Choices	Default Value
Math		
Value on Error	+Over/-Over	+Over
Value on Overflow > SUM, AVE	Error/Skip/Limit	Skip
Value on Overflow > MAX, MIN, P-P	Over/Skip	Over
Report		
Report select > 1	Max/Min/Ave/Sum/Inst	Ave
Report select > 2	Off/Max/Min/Ave/Sum/Inst	Max
Report select > 3	Off/Max/Min/Ave/Sum/Inst	Min
Report select > 4	Off/Max/Min/Ave/Sum/Inst	Sum
File type	Separate/Combine	Separate

End

Setting	Selectable Range or Choices	Default Value
Do you want to store and make the new settings take effect?	Yes/No/Cancel	☐

Menu Tab

Alarm

Setting	Selectable Range or Choices	Default Value
Basic setting		
Reflash	On/Off	Off
Rate of change > Decrease	1 to 32	1
Rate of change > Increase	1 to 32	1
Indicator	Hold/Nonhold	Nonhold
Switch, Relay		
Internal Switch > AND	None/S01/S01-S02/.../S01-S29/S01-S30	None
Relay > AND	None/I01/I01-I02/.../I01-I15/I01-I16	None
Relay > Action	Energize/De_energize	Energize
Relay > Hold	Hold/Nonhold	Nonhold
Relay > Relay Action on ACK	Normal/Reset	Normal
Hysteresis		
Meas CH > High/Low	Numeric value (0.0 to 5.0)	0.5
Meas CH > Delta High/Low	Numeric value (0.0 to 5.0)	0.0
Math CH > High/Low	Numeric value (0.0 to 5.0)	0.0
Ext. CH > High/Low	Numeric value (0.0 to 5.0)	0.0

A/D, Memory

Setting	Selectable Range or Choices	Default Value
Scan interval > Scan mode	Normal/Fast	Normal
Normal > Scan interval	125ms/250ms (RD-MV2008)	125ms
	1s/2s/5s (RD-MV2010, RD-MV2020, RD-MV2030, RD-MV2040, RD-MV2048)	1s
Normal > A/D integrate	Auto/50Hz/60Hz/100ms	Auto
Fast > Scan interval	25ms (RD-MV2008)	25ms
	125ms (RD-MV2010, RD-MV2020, RD-MV2030, RD-MV2040, RD-MV2048)	125ms
Fast > A/D integrate	600Hz	600Hz
Memory		
Data kind	Display/E+D/Event	Event

Burnout, RJC

Setting	Selectable Range or Choices	Default Value
First-CH, Last-CH	Numeric value (channel number) 001 to 048	001
Burnout		
Mode	Off/Up/Down	Off
RJC		
Mode	Internal/External	Internal
Volt	Numeric value (–20000 to 20000)μV	0

Default RD-MV2000 Settings

Keylock

Setting	Selectable Range or Choices	Default Value
Keylock		
Password	Character string (up to 8 characters)	*****
Key action > START/STOP	Free/Lock	Free
Key action > HISTORY	Free/Lock	Free
Key action > MENU	Free/Lock	Free
Key action > USER	Free/Lock	Free
Key action > DISP/ENTER	Free/Lock	Free
Key action > T/DIV	Free/Lock	Free
Media/USB > External media	Free/Lock	Free
Media/USB > Load settings	Free/Lock	Free
Action of Function > AlarmACK	Free/Lock	Free
Action of Function > Message / Batch	Free/Lock	Free
Action of Function > Math	Free/Lock	Free
Action of Function > Data save	Free/Lock	Free
Action of Function > E-mail / FTP	Free/Lock	Free
Action of Function > Time set	Free/Lock	Free
Action of Function > Display Function	Free/Lock	Free

Login > Basic settings

Setting	Selectable Range or Choices	Default Value
User basic settings		
Auto logout	Off/1min/2min/5min/10min	Off
Operation without Login	Off/Display	Off

Login > Admin settings

Setting	Selectable Range or Choices	Default Value
Admin number	1/2/3/4/5	1
Admin settings		
Mode	Off/Key/Key+Comm	Off
User name	Character string (up to 20 characters)	Admin1, etc.
Password	Character string (up to 8 characters)	????????

Login > User settings

Setting	Selectable Range or Choices	Default Value
User number	1/2/3/.../29/30	1
User settings		
Mode	Off/Key/Comm/Web/Key+Comm	Off
User name	Character string (up to 20 characters)	User1, etc.
Password	Character string (up to 8 characters)	????????
Authority of user	Off/1/2/3/4/5/6/7/8/9/10	Off

Authority of user

Setting	Selectable Range or Choices	Default Value
Authority of user	1/2/3/4/5/6/7/8/9/10	1
Authority of user		
Key action > START/STOP	Free/Lock	Free
Key action > HISTORY	Free/Lock	Free
Key action > MENU	Free/Lock	Free
Key action > USER	Free/Lock	Free
Key action > DISP/ENTER	Free/Lock	Free
Key action > T/DIV	Free/Lock	Free
Media/USB > External media	Free/Lock	Free
Media/USB > Load settings	Free/Lock	Free
Action of Function > AlarmACK	Free/Lock	Free
Action of Function > Message / Batch	Free/Lock	Free
Action of Function > Math	Free/Lock	Free
Action of Function > Data save	Free/Lock	Free
Action of Function > E-mail / FTP	Free/Lock	Free
Action of Function > Time set	Free/Lock	Free
Action of Function > Display Function	Free/Lock	Free

Report > Basic settings

Setting	Selectable Range or Choices	Default Value
Report set		
Report kind	Off/Hour/Day/Hour+Day/Day+Week/Day+Month	Off
Date	Numeric value (1 to 28)	1
Day of the week	SUN/MON/TUE/WED/THU/FRI/SAT	SUN
Time (hour)	Numeric value (0 to 23)	0:00

Report > Report settings

Setting	Selectable Range or Choices	Default Value
Report channel number	R01/R02/R03/.../R59/R60	R01
Report CH		
On/Off	On/Off	Depends on the model
Channel	Numeric value (channel number)	001, etc.
Sum scale	Off, /s, /min, /h, /day	/s

Time settings

Setting	Selectable Range or Choices	Default Value
Time settings		
Time zone(HHMM)	Numeric value (-1300 to 1300)	900
Time deviation limit	Off/10s/20s/30s/1min/2min/3min/4min/5min	30s
Date format	Y/M/D, M/D/Y, D/M/Y, D.M.Y	Y/M/D

Communication (Ethernet) > IP-address, Host settings

Setting	Selectable Range or Choices	Default Value
IP-address		
DHCP	Use/Not	Not
DNS accession (valid when DHCP is USE)	Use/Not	Use
Host-name register (valid when DHCP is USE)	Use/Not	Use
Fixed IP-address > IP-address	Numeric value (0.0.0.0 to 255.255.255.255)	0.0.0.0
Fixed IP-address > Subnet mask	Numeric value (0.0.0.0 to 255.255.255.255)	0.0.0.0
Fixed IP-address > Default gateway	Numeric value (0.0.0.0 to 255.255.255.255)	0.0.0.0
Host settings		
Host name	Character string (up to 64 characters)	☐
Domain name	Character string (up to 64 characters)	☐

Default RD-MV2000 Settings

Communication (Ethernet) > DNS settings

Setting	Selectable Range or Choices	Default Value
Server search order		
Primary	Numeric value (0.0.0.0 to 255.255.255.255)	0.0.0.0
Secondary	Numeric value (0.0.0.0 to 255.255.255.255)	0.0.0.0
Domain suffix search order		
Primary	Character string (up to 64 characters)	☐
Secondary	Character string (up to 64 characters)	☐

Communication (Ethernet) > Keep alive, Application time out

Setting	Selectable Range or Choices	Default Value
Keep alive		
On/Off	On/Off	On
Application time out		
On/Off	On/Off	Off
Time	Numeric value (1 to 120) (min)	1

Communication (Ethernet) > Server

Setting	Selectable Range or Choices	Default Value
Server		
FTP	Use/Not	Not
Web	Use/Not	Use
SMTP	Use/Not	Not
Modbus	Use/Not	Not

Communication (Ethernet) > Web page

Setting	Selectable Range or Choices	Default Value
Page type	Operator/Monitor	Operator
When Page type is Operator		
Web page > On/Off	On/Off	Off
Web page > Access control	Off/Admin	Off
Web page > Command	Use/Not	Not
When Page type is Monitor		
Web page > On/Off	On/Off	Off
Web page > Access control	Off/Admin/User	Off

Communication (Ethernet) > E-mail > Basic setting

Setting	Selectable Range or Choices	Default Value
Basic settings		
SMTP server name	Character string (up to 64 characters)	☐
Port number	Numeric value (0 to 65535)	25
Security	Off/SSL	Off

Communication (Ethernet) > E-mail > Recipients

Setting	Selectable Range or Choices	Default Value
Recipients		
Recipient 1	Character string (up to 150 characters)	☐
Recipient 2	Character string (up to 150 characters)	☐
Sender	Character string (up to 64 characters)	☐

Communication (Ethernet) > E-mail > POP3 settings

Setting	Selectable Range or Choices	Default Value
POP3 Settings		
POP3 Server name	Character string (up to 64 characters)	☐
Port number	Numeric value (0 to 65535)	110
Login name	Character string (up to 32 characters)	☐
Password	Character string (up to 32 characters)	*****...***

Communication (Ethernet) > E-mail > Alarm settings

Setting	Selectable Range or Choices	Default Value
Alarm settings		
E-Mail Recipients > Recipient 1	On/Off	Off
E-Mail Recipients > Recipient 2	On/Off	Off
Active Alarms > Alarm 1	On/Off	Off
Active Alarms > Alarm 2	On/Off	Off
Active Alarms > Alarm 3	On/Off	Off
Active Alarms > Alarm 4	On/Off	Off
E-Mail Contents > Include INST	On/Off	Off
E-Mail Contents > Include source URL	On/Off	Off
E-Mail Contents > Subject	Character string (up to 32 characters)	Alarm_summary
E-Mail Contents > Header 1	Character string (up to 64 characters)	☐
E-Mail Contents > Header 2	Character string (up to 64 characters)	☐

Communication (Ethernet) > E-Mail > Scheduled settings

Setting	Selectable Range or Choices	Default Value
Scheduled settings		
E-Mail Recipients and Transmission time > Recipient 1	On/Off	Off
E-Mail Recipients and Transmission time > Interval	1h/2h/3h/4h/6h/8h/12h/24h	24h
E-Mail Recipients and Transmission time > Ref.time	Numeric value (00: 00 to 23: 59)	00: 00
E-Mail Recipients and Transmission time > Recipient 2	On/Off	Off
E-Mail Recipients and Transmission time > Interval	1h/2h/3h/4h/6h/8h/12h/24h	24h
E-Mail Recipients and Transmission time > Ref.time	Numeric value (00: 00 to 23: 59)	00: 00
E-Mail Contents > Include INST	On/Off	Off
E-Mail Contents > Include source URL	On/Off	Off
E-Mail Contents > Subject	Character string (up to 32 characters)	Periodic_data
E-Mail Contents > Header 1	Character string (up to 64 characters)	☐
E-Mail Contents > Header 2	Character string (up to 64 characters)	☐

Communication (Ethernet) > E-Mail > System settings

Setting	Selectable Range or Choices	Default Value
System settings		
E-Mail Recipients > Recipient 1	On/Off	Off
E-Mail Recipients > Recipient 2	On/Off	Off
E-Mail Contents > Include source URL	On/Off	Off
E-Mail Contents > Subject	Character string (up to 32 characters)	System_warning
E-Mail Contents > Header 1	Character string (up to 64 characters)	☐
E-Mail Contents > Header 2	Character string (up to 64 characters)	☐

Communication (Ethernet) > E-Mail > Report settings

Setting	Selectable Range or Choices	Default Value
Report settings		
E-Mail Recipients > Recipient 1	On/Off	Off
E-Mail Recipients > Recipient 2	On/Off	Off
E-Mail Contents > Include source URL	On/Off	Off
E-Mail Contents > Subject	Character string (up to 32 characters)	Report_data
E-Mail Contents > Header 1	Character string (up to 64 characters)	☐
E-Mail Contents > Header 2	Character string (up to 64 characters)	☐

Default RD-MV2000 Settings

Communication (Ethernet) > FTP client

Setting	Selectable Range or Choices	Default Value
FTP transfer file		Off
Disp&Event data	On/Off	Off
Report	On/Off	Off
Snapshot	On/Off	Off
FTP connection	Primary/Secondary	Primary
FTP server name	Character string (up to 64 characters)	☐
Port number	Numeric value (0 to 65535)	21
Login name	Character string (up to 32 characters)	☐
Password	Character string (up to 32 characters)	***** ...
Account	Character string (up to 32 characters)	☐
PASV mode	On/Off	Off
Initial path	Character string (up to 64 characters)	☐

Communication (Ethernet) > SNTP client

Setting	Selectable Range or Choices	Default Value
SNTP client		Not
Use/Not	Use/Not	☐
Server name	Character string (up to 64 characters)	123
Port number	Numeric value (0 to 65535)	8h
Access interval	Off/1h/8h/12h/24h	00: 00
Access reference time	Numeric value (00: 00 to 23: 59)	30s
Access timeout	10s/30s/90s	Off
Time adjust on Start action	On/Off	

Communication (Ethernet) > Modbus client > Basic settings

Setting	Selectable Range or Choices	Default Value
Modbus client basic settings		
Read cycle	125ms/250ms/500ms/1s/2s/5s/10s	1s
Retry interval	Off/10s/20s/30s/1min/2min/5min/10min/20min/30min/1h	2min

Communication (Ethernet) > Modbus client > Modbus server settings

Setting	Selectable Range or Choices	Default Value
Server number	1-8/9-16	1-8
Modbus server settings		
Port number	Numeric value (0 to 65535)	502
Modbus server name	Character string (up to 64 characters)	☐
Unit	Auto/Fixed	Auto
No.	0 to 255	1

Communication (Ethernet) > Modbus client > Command settings

Setting	Selectable Range or Choices	Default Value
Client command number	1-8/9-16	1-8
1 to 16	Off/R/R-M/W/W-M	Off
Client settings > First	Varies depending on the send command type	☐
Client settings > Last	Varies depending on the send command type	☐
Server settings > Server	1/2/3/.../15/16	1
Server settings > Registers	Numeric value (register number)	R, R-M: 30001 W, W-M: 40001
Server settings > Type	INT16/UINT16/INT32_B/INT32_L/UINT32_B/ UINT32_L/FLOAT_B/FLOAT_L	R, R-M, W: INT16 W-M: INT32_B

Communication (Ethernet) > Modbus client > Auto setting

Setting	Selectable Range or Choices	Default Value
Auto setting of MODBUS client will be executed.	Yes/No	☐
The following settings will be cleared.		
OK?		

Communication (Serial) > Basic settings

Setting	Selectable Range or Choices	Default Value
Serial		
Baud rate	1200/2400/4800/9600/19200/38400	9600
Data length	7/8	8
Parity	Odd/Even/None	Even
Handshaking	Off/Off/XON:XON/XON:RS/CS:RS	Off:Off
Address	Numeric value (1 to 99)	1
Protocol	Normal/Modbus/Modbus-M	Normal

Communication (Serial) > Modbus master > Basic settings

Setting	Selectable Range or Choices	Default Value
Modbus master basic settings		
Read cycle	125ms/250ms/500ms/1s/2s/5s/10s	1s
Timeout	125ms/250ms/500ms/1s/2s/5s/10s/1min	1s
Retrials	Off/1/2/3/4/5/10/20	1
Inter-block delay	Off/5ms/10ms/15ms/45ms/100ms	Off
Auto recovery	Off/1min/2min/5min/10min/20min/30min/1h	2min

Communication (Serial) > Modbus master > Command settings

Setting	Selectable Range or Choices	Default Value
Master command number	1-8/9-16	1-8
1 to 16	Off/R/R-M/W/W-M	Off
Master > First	Varies depending on the send command type	☐
Master > Last	Varies depending on the send command type	☐
Slave > Address	Numeric value (1 to 247)	1
Slave > Registers	Numeric value (register number)	R, R-M: 30001 W, W-M: 40001
Slave > Type	INT16/UINT16/INT32_B/INT32_L/UINT32_B/ UINT32_L/FLOAT_B/FLOAT_L	R, R-M, W: INT16 W-M: INT32_B

Status relay

Setting	Selectable Range or Choices	Default Value
Status relay		
Memory/Media status	On/Off	Off
Measurement error	On/Off	Off
Communication error	On/Off	Off
Memory stop	On/Off	Off

End

Setting	Selectable Range or Choices	Default Value
Do you want to store and make the new settings take effect?	Yes/No/Cancel	☐

Default RD-MV2000 Settings

Initialize Tab

Clear settings and data

Setting	Selectable Range or Choices	Default Value
Are you sure you want to initialize "Settings + Measure&Math data"?	Yes/No	☐

Clear data only

Setting	Selectable Range or Choices	Default Value
Are you sure you want to initialize "Measure&Math data"?	Yes/No	☐