











omega.com e-mail: info@omega.com For latest product manuals: omegamanual.info



# PT-104 RTD Data Acquisition Module



#### OMEGAnet<sup>®</sup> Online Service omega.com

Internet e-mail info@omega.com

### **Servicing North America:**

U.S.A.: ISO 9001 Certified	Omega Engineering, Inc., One Omega I Stamford, CT 06907-0047 USA Toll Free: 1-800-826-6342 FAX: (203) 359-7700	Drive, P.O. Box 4047 TEL: (203) 359-1660 e-mail: info@omega.com
Canada:	976 Bergar Laval (Quebec), Canada H7L 5A1 Toll-Free: 1-800-826-6342 FAX: (514) 856-6886	TEL: (514) 856-6928 e-mail: info@omega.ca
For imme	ediate technical or applicat	tion assistance:
U.S.A. and Canada:	Sales Service: 1-800-826-6342/1-800-TC Customer Service: 1-800-622-2378/1-80 Engineering Service: 1-800-872-9436/1-	-OMEGA® 0-622-BEST® 800-USA-WHEN®
Mexico:	En Español: 001 (203) 359-7803 info@omega.com.mx	FAX: (001) 203-359-7807 e-mail: espanol@omega.com
	Servicing Europe:	
Benelux:	Managed by the United Kingdom Offic Toll-Free: 0800 099 3344 FAX: +31 20 643 46 43	re TEL: +31 20 347 21 21 e-mail: sales@omega.nl
Czech Republic:	Frystatska 184 733 01 Karviná, Czech Republic Toll-Free: 0800-1-66342 FAX: +420-59-6311114	TEL: +420-59-6311899 e-mail: info@omegashop.cz
France:	Managed by the United Kingdom Office         Toll-Free: 0800 466 342       TEL: +33 (0) 161 37 29 00         FAX: +33 (0) 130 57 54 27       e-mail: sales@omega.fr	
Germany/Austria:	Daimlerstrasse 26 D-75392 Deckenpfronn, Germany Toll-Free: 0 800 6397678 FAX: +49 (0) 7056 9398-29	TEL: +49 (0) 7059 9398-0 e-mail: info@omega.de
United Kingdom: ISO 9001 Certified	OMEGA Engineering Ltd. One Omega Drive, River Bend Technol Irlam, Manchester M44 5BD England Toll-Free: 0800-488-488 FAX: +44 (0)161 777-6622	ogy Centre, Northbank TEL: +44 (0)161 777-6611 e-mail: sales@omega.co.uk

It is the policy of OMEGA Engineering, Inc. to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification. The information contained in this document is believed to be correct, but OMEGA accepts no liability for any errors it contains, and reserves the right to alter specifications without notice. **WARNING**: These products are not designed for use in, and should not be used for, human applications.

L

# Contents

1 Introduction		1
1 Overvie	w	1
2 Safety w		2
2 Salety w		
2 Product information		
1 Specifica	ations	3
2 Installing	g the driver	3
3 Connect	- tion	4
4 Backgro	ound on PRTs	7
3 Writing your own progra	ams	9
67 T 6	•	0
1 Driver in	nformation	
	1 Introduction	
	2 pt104_open_unit	10
	3 pt104_close_unit	10
	5 pt104 get cvcle	
	6 pt104 set channel	11
	7 pt104_set_mains	12
	8 pt104_get_value	12
	9 pt104_get_version	13
	10 pt104_get_unit_info	13
	11 pt104_get_driver_version	13
	12 pt104_labview	14
	13 Windows XP (SP2)/Vista	14
	14 Linux	
2 Example	e programs	15
	1 C / C++	
	2 Delphi	
	3 Excel	16
	4 LaDVIEVV	
	6 Agilent VEE	
4 Technical reference		19
1 Serial po	ort settings	18
2 Serial po	ort connections	18
3 Protoco	l information	19
4 Modem	operation	21
5 Lookup	table	22
Index		27

# 1 Introduction

### **1.1** Overview



The PT-104 is a four-channel, high-resolution RTD input data acquisition module for use with PT100 and PT1000 type sensors. It can be used to measure temperature, resistance and voltage.

- In PT100/PT1000/resistance mode, the unit uses a four-wire circuit.
- In voltage mode, the input connector can be treated as a differential input with ground, or as two single-ended inputs. Both inputs must be 0 V or above, though it does not matter which input has the higher voltage. For the 115 mV range, the accuracy is 2% and the temperature coefficient is 100 ppm/° C.

#### **1.2** Safety warning

2

We strongly recommend that you read the general safety information below before using your product for the first time. If the equipment is not used in the manner specified, then the protection provided may be impaired. This could result in damage to your computer and/or injury to yourself or others.

#### Maximum input range

The PT-104 is designed to measure voltages in the range 0 to  $\pm 2.5$  V. Any voltages in excess of  $\pm 30$  V may cause permanent damage to the unit.

#### Mains voltages

The PT-104 is not designed for use with mains voltages. To measure mains we recommend the use of a differential isolating probe specifically designed for such measurements.

#### Safety grounding

The ground of every product is connected directly to the ground of your computer via the interconnecting cable provided. This is done in order to minimise interference. If the PC (especially laptop) is not grounded, reading stability cannot be guaranteed and it may be necessary to manually ground the equipment.

As with most oscilloscopes and data loggers, you should take care to avoid connecting the inputs of the product to anything which may be at a hazardous voltage. If in doubt, use a meter to check that there is no hazardous AC or DC voltage. Failure to check may cause damage to the product and/or computer and could cause injury to yourself or others.

Take great care when measuring temperatures near mains equipment. If a sensor is accidentally connected to mains voltages, you risk damage to the converter or your computer and your computer chassis may become live.

You should assume that the product does not have a protective safety earth. Incorrect configuration or use of the device to measure voltages outside the maximum input range can be hazardous.

#### Repairs

The unit contains no user-serviceable parts. Repair or calibration of the unit requires specialised test equipment and must be performed by Omega Engineering.

# 2 Product information

# 2.1 Specifications

	Temperature	Resistance	Voltage
Sensor	PT100*, PT1000	N/A	N/A
Range	-200 to 800°C	0 to 375 <b>Ω</b> *; 0 to 10 k <b>Ω</b>	0 to 115 mV; 0 to 2.5 V*
Linearity	10 ppm	10 ppm	10 ppm
Accuracy @25°C	0.01°C*	20 ppm*	0.2%*
Temperature coefficient	3 ppm/°C	3 ppm/°C	100 ppm/°C
RMS Noise (using filter)	0.01°C	10 ppm	10 ppm
Resolution	0.001°C	1 mΩ	0.156 mV
Conversion Time Per Channel	720 ms**	720 ms**	180 ms
Number of inputs	4		
Connectors	4-pin mini-DIN		
Input impedance	>> 1 MΩ		
Overvoltage protection	±30 V		
Output	RS-232, DE9 female		
Environmental	20 to 30°C for stated accuracy; 0 to 70°C overall; 20 to 90% RH		
Software	Logging Software; drivers for Windows XP SP2/Vista; examples for C/C++, Delphi, Excel, LabVIEW, Visual Basic, Agilent VEE.		
Quoted accuracy is for options marked *			
For four-wire tempe	rature and resistance me	easurement**	

### **2.2** Installing the driver

The driver is installed automatically when you install the Logging Software. Alternatively, you can download the driver from our website at <u>www.omega.com</u>.

#### 2.3 Connection

To use the PT-104, you should connect its D-connector to your computer's serial port using the cable provided. Next, connect a PT100 or PT1000 PRT to one of the input connectors.

Pin Connections to the PT-104 Mini-DIN socket



Pin	PT100, PT1000	PT100, PT1000	PT100, PT1000	Differential voltage
	4 Wire	3 Wire	2 Wire	
1	Black	Connect to pin 3	Connect to pin 3	Do not connect
2	Red	Red	Red	V -
3	Black	Black	Black	V +
4	Red	Red	Connect to pin 2	Gnd

Single-ended voltage connection

Single-ended mode allows you to double the number of channels from 4 to 8. It is supported by the driver, so you can use it in your own applications. It is not, however, supported by the Logging Software.

Connector	Channel	Pin
1	1	3
	5	2
2	2	3
	6	2
3	3	3
	7	2
4	4	3
	8	2

Note on Differential Voltage Mode

The maximum input voltage range of the PT-104 is 2.5 V. Any voltage in excess of +/-30 V on any input pin may cause permanent damage to the unit.

In Differential Voltage Mode, the input connector should be treated as a differential input with reference to ground. Both inputs (V+ and V-) must be zero volts or above (it does not matter which input has the higher voltage) and must remain within the input range. A ground reference connection is also required for correct operation. The ground connection of each mini-DIN socket consists of a 100  $\Omega$  resistor to mains earth/ground via the serial cable outer braiding and the PC chassis.

#### Setting up

To set up the unit, do the following:

1. From the Logging Recorder File menu, select New settings. The Recording dialog box appears:

Recording	×
Recording method	Real time continuous
Action at end of run	Stop 💌
Restart delay	1 Minutes 💌
🔲 Use multiple conv	erters
ОК	Cancel Help

2. Click OK. The Sampling Rate dialog box appears:

Sampling Rate			×
Sampling interv	al 1	Seconds 💌	ОК
Stop after 💿	500	Samples	Cancel
0	100	Seconds 💌	Help
Readings per sample	As many as po	ssible 💌	

3. Click OK. The Converter details dialog box appears:

Converter details	×
Converter type PT-104	ОК
Port COM1	Cancel
USB Devices           Device         Serial	Help
USB enumeration progress	Status
	Refresh

4. From the Converter type drop-down list, select PT-104.

5. From the Port drop-down list, select the port and click OK. After a short while, the PT-104 channels window appears:

PT-104 channels	×
Port COM1	ОК
Ch1 unused Ch2 unused Ch3 unused	Edit
Ch4 unused	Disable
Mains frequency • 50Hz  • 60Hz	Help

6. In the PT-104 channels window, double-click on Ch1 unused. The Edit PT-104 Channel dialog box appears:

Edit PT104 Channel 🛛 🕺			
Name	Channel 1		
- Admo			
Data type	Pt100	<u> </u>	
Circuit	Four wire	•	
🔲 Filter Ena	ble		
(OK	Cancel	Help	Options

- 7. Type in a name for the channel, if required
- 8. Select the data type required i.e temperature, resistance or voltage
- 9. Select circuit for PT100 and PT1000

10. Now click OK and then OK again. Readings from the PT-104 should appear in the monitor window:

Copying Recorder	
File Settings View	Help
Awaiting data filename Use File   New data	
OChannel 1	24.01 °C

7

#### **2.4** Background on PRTs

PRTs (Platinum Resistance Thermometers) offer excellent accuracy over a wide temperature range (from -200 to 850°C). Sensors are interchangeable between different manufacturers, and are available in various accuracy ratings in packages to suit most applications. Unlike thermocouples, it is not necessary to use special cables to connect to the sensor.

The principle of operation is to measure the resistance of a platinum element. The most common type (PT100) has a resistance of 100  $\Omega$  at 0°C and 138.4  $\Omega$  at 100°C.

The relationship between temperature and resistance is approximately linear over a small temperature range: for example, if you assume that it is linear over the 0 to 100°C range, the error at 50°C is 0.4°C. For precision measurement, it is necessary to linearise the resistance to give an accurate temperature. The most recent definition of the relationship between resistance and temperature is International Temperature Standard 90 (ITS-90). This linearisation is done automatically with software.

The linearisation equation is:

Rt = R0 \* (1 + A\* t + B\*t2 +C\*(t-100)\* t3) A = 3.9083 E-3 B = -5.775 E-7 C = (below 0°C) -4.183 E -12 (Above 0°C) zero

For a PT100 sensor, a 1°C temperature change will cause a 0.384  $\Omega$  change in resistance, so even a small error in measurement of the resistance (for example, the resistance of the wires leading to the sensor) can cause a large error in the measurement of the temperature. For precision work, sensors have four wires - two to carry the sense current, and two to measure the voltage across the sensor element. It is also possible to obtain three-wire sensors, although these operate on the (not necessarily valid) assumption that the resistance of each of the three wires is the same.

The current through the sensor will cause some heating. For example, a sense current of 245  $\mu$ A through a 100  $\Omega$  resistor will generate 6  $\mu$ W of heat. If the sensor element is unable to dissipate this heat, it will report an artificially high temperature. This effect can be reduced by either using a large sensor element, or by making sure that it is in good thermal contact with its environment.

Using a 1 mA sense current will give a signal of only 100 mV. Because the change in resistance for a degree Celsius is very small, even a small error in the measurement of the voltage across the sensor will produce a large error in the temperature measurement. For example, a 100  $\mu$ V voltage measurement error will give a 0.4°C error in the temperature reading. Similarly, a 1  $\mu$ A error in the sense current will give 0.4°C temperature error.

Because of the low signal levels, it is important to keep any cables away from electric cables, motors, switchgear and other devices that may emit electrical noise. Using screened cable, with the screen grounded at one end, may help to reduce interference. When using long cables, it is necessary to check that the measuring equipment is capable of handling the resistance of the cables. Most equipment can cope with up to 100  $\Omega$  per core.

The type of probe and cable should be chosen carefully to suit the application. The main issues are the temperature range and exposure to fluids (corrosive or conductive) or metals. Clearly, normal solder junctions on cables should not be used at temperatures above about 170°C.

Omega Engineering offers a wide range of sensors that comply with BS1904 class B (DIN 43760). These sensors offer an accuracy of  $\pm 0.3^{\circ}$ C at 0°C. For increased accuracy, you can use BS1904 class A ( $\pm 0.15^{\circ}$ C) or tenth-DIN sensors ( $\pm 0.03^{\circ}$ C). Please note that these accuracy specifications relate to the SENSOR ONLY. It is necessary to add on any error in the measuring system as well.

Related standards are IEC751 and JISC1604-1989.

# 3 Writing your own programs

### **3.1** Driver information

#### 3.1.1 Introduction

The PT-104 is supplied with driver routines that you can build into your own programs.

Once you have installed the software, the Drivers directory contains the drivers and a selection of examples of how to use the drivers. It also contains a copy of this manual as a PDF file.

The driver routine is supplied as a Windows DLL.

The Windows DLL can be used with C, C++, Delphi and Visual Basic programs: it can also be used with programs like Microsoft Excel, where the macro language is a form of Visual Basic. More than one application can access the Windows DLL at the same time, as long as the applications do not change the settings for channels that they are not using.

These are the routines in the driver:

<b>)</b>	pt104_open_unit	Open the device on a specified serial port. Close the port (do this each time you finish using the
•	nt104 noll driver 10	device!) Poll the driver (not usually necessary)
0	pt104_get_cycle 11	Find out when the driver has taken a new set of
		readings.
۲	pt104_set_channel	Specify the sensor type and filtering for a channel.
۲	pt104_set_mains 12	Specify the mains setting 50 or 60 Hz. This enables the
		product to reject mains-frequency interference signals.
۲	pt104_get_value 12	Get the most recent data reading from a channel.
۲	pt104_get_version	Get the version number of this PT-104.
١	pt104_get_unit_info	Get the version number, batch number and calibration
	-	number and date of this PT-104.
٢	pt104_get_driver_version	Get the version number of the driver.
_	13	
۲	pt104_labview 14	Easy to use interface for LabVIEW.

The normal calling sequence for these routines is as follows:

- 1. Open driver
- 2. Set Channels
- 3. While you want to read data
- 4. Get data
- 5. End While
- 6. Close Unit
- 7. Close Driver

#### **3.1.2** pt104\_open\_unit

10

short pt104\_open\_unit ( short port );

This routine specifies the serial port number with a PT-104 unit. If you wish to use more than one PT-104, you should call the routine once for each PT-104.

Arguments:	port - the port must be 1 for COM1, 2 for COM2, and so on
Returns:	TRUE - if the driver successfully opens the PT-104

#### **3.1.3** pt104\_close\_unit

```
void pt104_close_unit (
    unsigned short port);
```

This routine disconnects the driver from the specified serial port.

If you successfully open any serial ports, you MUST call pt104\_close\_unit for each port before you exit from your program. If you do not, your computer may misbehave until you next reboot it.

Arguments:	port - the port number. The port must be 1 for COM1, 2 for COM2, and so on
Returns:	none

#### 3.1.4 pt104\_poll\_driver

#### void pt104\_poll\_driver (void);

It is not normally necessary to call this routine, as the driver uses the timer to poll the PT-104. Some programs, like Excel, appear to block the timer, so it is necessary to poll the driver periodically whilst waiting for data.

Arguments:	none
Returns:	none

#### **3.1.5** pt104\_get\_cycle

```
unsigned short pt104_get_cycle(
    unsigned long far * cycle,
    unsigned short port);
```

This routine returns the number of complete cycles of readings taken from a specified PT-104.

When you call <u>pt104\_get\_value</u>, it returns immediately with the most recent reading for the specified channel. If you call it repeatedly, it will return the same reading repeatedly, until the driver takes the next reading from that channel.

If you wish to record values only when the driver has taken a new reading, you can use this routine to find out how many complete cycles of readings the driver has taken, then you can call  $pt104_get_value$  when a cycle has completed.

Note: Each PT-104 is polled independently, so the cycle numbers for multiple PT-104s may not keep in step.

Arguments:	cycle - a pointer to an array where the cycle numbers are stored
	port - the port number. The port must be 1 for COM1, 2 for COM2, and so on
Returns:	a value representing the number of complete cycles of readings taken from a particular PT-104

#### 3.1.6 pt104\_set\_channel

```
short pt104_set_channel (
    unsigned short port,
    unsigned short channel,
    unsigned short data_type
    unsigned short no_of_wires);
```

You should call this routine once for each channel that you would like to take readings from. You can do this any time after calling  $pt104_open_unit$ .

The fewer channels are selected, the more frequently these channels will be updated. It takes about 1 second per active channel.

If a call to pt104\_set\_channel has a data\_type of single ended, then the channel specified's 'sister' channel is also enabled. For example, enabling 3 also enables 7.

Arguments:	channel - specifies which channel you want to set the details for. It should be between 1 and 4 if using single ended inputs in voltage mode.
	data_type - set to the type of reading you require (1 for PT100, 2 for PT1000, 3 for resistance 0 to 500 R, 4 for resistance 0 to 10 k, 5 for differential voltage 0 to 100 mV, 6 for differential voltage 0 to 2.5 V, 7 for single ended voltage 0 to 100 mv and 8 for single-ended voltage 0 to 2.5 V
	no_of_wires - specifies how many wires the PT100 or PT1000 has (set to 2, 3 or 4)
Returns:	TRUE - if the channel was successfully set

#### **3.1.7** pt104\_set\_mains

```
void pt104_set_mains (
    unsigned short sixty_hertz);
```

This routine is used to select the mains frequency of 50 or 60 Hz.

Choosing the wrong frequency may increase susceptibility to electrical noise.

Arguments:	$sixty_hertz$ - for 50 Hz set to 0; for 60 Hz set to 1
Returns:	none

#### **3.1.8** pt104\_get\_value

```
short pt104_get_value (
    long far * data,
    unsigned short port,
    unsigned short channel,
    unsigned short filtered);
```

Once you open the driver and define some channels, the driver begins to take continuous readings from the PT-104. When you call this routine, it immediately sets data to the most recent reading for the specified channel.

Temperatures are returned in thousandths of a degree Celsius, voltages in the 2.5 V range are returned in tens of nanovolts (2.5 V returned as 250 000 000 \* 10 nV), voltages in the 115 mV range are returned in nanovolts and resistances in milliohms.

When measuring single-ended voltages:

connector 1 pin 2 is channel 1 connector 2 pin 2 is channel 2 ... connector 1 pin 3 is channel 5 connector 2 pin 3 is channel 6

Arguments:	data - a pointer to an array where the sample values will be stored
	port - the port number. The port must be 1 for COM1, 2 for COM2, and so on
	channel – 1 - returns a reading from Channel 1 2 - returns a reading from Channel 2 3 - returns a reading from Channel 3 4 - returns a reading from Channel 4
	filtered - if set to TRUE, the driver returns a low-pass filtered value of the temperature. The time constant of the filter depends on the value of filter_factor for this channel, and on how many channels are active
Returns:	TRUE - if a reading is available FALSE - if any of the inputs are out of range. It will normally return FALSE for a few seconds after you open the driver, until the driver has taken a reading from the specified channel

#### 3.1.9 pt104\_get\_version

```
unsigned short pt104_get_version (
    unsigned short far * version,
    unsigned short port);
```

This routine sets version to version number of the specified PT-104.

Arguments:	version - driver version. The upper byte of the version is always 104 for a PT-104; the lower byte is the two hex digits of the version and release. It provides a useful check that the link to the PT-104 is working correctly.
	port - the port number. The port must be 1 for COM1, 2 for COM2, and so on.
Returns:	TRUE - if the parameters are in range

#### 3.1.10 pt104\_get\_unit\_info

```
short pt104_get_unit_info (
    char * str,
    unsigned short line,
    unsigned short port)
```

Call this routine to obtain information on the unit. str is set to the information specified by line.

Arguments:	str - a pointer to a char array that is to receive the information
	line - 0 for version number, 1 for calibration number, 2 for calibration date, 3 for batch number
	port - the port number. The port must be 1 for COM1, 2 for COM2, and so on.
Returns:	the number of bytes written to str

#### 3.1.11 pt104\_get\_driver\_version

short pt104\_get\_driver\_version (void)

Arguments:	none
Returns:	the version number of the current driver

#### 3.1.12 pt104\_labview

```
short pt104_labview (
  float * result,
  unsigned short port,
  unsigned short channel,
  unsigned short data_type,
  unsigned short filtered
  unsigned short no_of_wires)
```

This is an easy-to-use interface for LabVIEW. To gain a thorough understanding of the capabilities of this routine, see the example program supplied with the software.

Arguments:	result - a pointer to a float that is to receive the result
	port - the port number. The port must be 1 for COM1, 2 for COM2, and so on
	channel - 1 for Channel 1, 2 for Channel 2, 3 for Channel 3, and so on
	data_type - set to the type of reading you require (1 for PT100, 2 for PT1000, 3 for resistance 0 to 500 R, 4 for resistance 0 to 10 k, 5 for differential voltage 0 to 100 mV, 6 for differential voltage 0 to 2.5 V, 7 for single ended voltage 0 to 100 mV and 8 for single ended voltage 0 to 2.5 V
	<pre>filtered - if set to TRUE, the driver returns a low-pass filtered value of the temperature. The time constant of the filter depends on the value of filter_factor for this channel, and on how many channels are active</pre>
	no_of_wires - specifies how many wires the PT100 or PT1000 has (set to 2, 3 or 4)
Returns:	<ul><li>1 - if successful</li><li>0 - if unsuccessful</li></ul>

#### 3.1.13 Windows XP (SP2)/Vista

The 32-bit Windows driver is the file pt10432.DLL, which is installed in the drivers\win32 directory. If an application is unable to find the DLL, try moving the DLL to windows\system.

#### 3.1.14 Linux

At the time of release, Linux is not supported. Please check <u>www.omega.com</u> for updates.

#### **3.2** Example programs

#### 3.2.1 C / C++

С

You should find the following files in the directory where your software is installed:

pt104tes.c - Demonstration file. pt10432.dll - Windows 32-bit driver. pt104.h - header file

Producing a library file (.lib)

For Borland and Watcom C, Microsoft Visual C version 1.5 or lower, use the implib program that comes supplied with these compilers.

The command is:

Implib pt10432.lib pt10432.dll

This command is typed in at the command prompt - make sure you are in the correct directory or the pt10432.dll file will not be found. This will create a file called pt10432.lib.

The following steps are then required to use the drivers in your program:

- 1. Include the pt10432.lib in your program
- 2. Include the file pt104.h in the source file(s) of your program.

The ptl04tes.c file can be used to demonstrate using the PT-104 driver program within a Windows application. You will also need to include the resource file ptl04tes. rc.

For Microsoft Visual C versions 2, 4 and 5, Microsoft no longer supply implib. Furthermore, the names used in these versions of C are decorated - there is a prefix which indicates how many bytes are transferred to the routine as parameters. As a result, the C names do not match the names in the DLL. The Microsoft tools to alias decorated to undecorated names do not appear to work, so it is therefore necessary to use ordinal linking- linking by number, rather than name. The file pt104ms.lib (supplied with examples) contains all the neccessary routines. To use this file:

- 1. Include the pt104ms.lib in your project
- 2. Include the file pt104.h in the C source file(s) of your program.

C + +

C++ programs can access all versions of the driver. If pt104.h is included in a C++ program, the PREF1 macro expands to extern "C": this disables name-decoration and enables C++ routines to make calls to the driver routines using C headers.

#### **3.2.2** Delphi

16

The win subdirectory contains a simple program pt104.dpr which opens the drivers and reads temperatures from two channels. You will need the following files to build a complete program:

pt104.dpr	- Project file
pt104fm.dfm	- Delphi form file
pt104fm.pas	- Delphi Pascal unit
pt104.inc	- Procedure prototypes for driver routines

The file pt104.inc contains procedure prototypes for the driver routines: you can include this file in your application.

This example has been tested with Delphi version 2.

#### 3.2.3 Excel

The easiest way to transfer data into Excel is to use the data logging software.

If, however, you need to do something that is not possible using the software, you can write an Excel macro which calls pt104xx.dll to read in a set of data values. The Excel Macro language is similar to Visual Basic.

Excel 7

The example pt10432.XLS reads in 20 values from the unit on channel 1 at one per second, and assigns them to cells A4 to A24.

#### 3.2.4 LabVIEW

The routines described here were tested using LabVIEW under Windows 98 version 4.0.

Although it is possible to access all of the driver routines described earlier, it is easier to use the special LabVIEW access routine. The pt104.11b library in the DRIVERS subdirectory shows how to access this routine.

To use this routine, copy pt104.11b and pt10432.dll to your LabVIEW user.lib directory.

You will then use the PT-104 sub-vi, and an example sub-vi which demonstrates how to use them. You can use one of these sub-vis for each of the channels that you wish to measure. The sub-vi accepts the port (1 for COM1), the channel (1 to 4) the PRT type (1 for PT100, 2 for PT1000). The sub-vi returns a temperature for the PRT.

#### 3.2.5 Visual Basic

The **DRIVERS** subdirectory contains the following files:

pt10432.VBP - Visual basic project file
pt10432.BAS - Contains procedure prototypes for driver routines
pt10432.FRM - Visual basic form

#### 3.2.6 Agilent VEE

The routine described here was tested using Agilent-VEE version 5 under Windows 98.

The DRIVERS subdirectory contains the following files:

pt10432.dll - 32-bit driver file
pt104.vee - Agilent-VEE file
pt104.vh - Procedure prototypes for driver

To use the example, open the file pt104.vee in Agilent-VEE and edit the import library icon so:

File Name path is set to the location of pt10432.dll Definition File path is set to the location of pt104.vh

The example program collects 1000 readings from the PT-104 and displays them on an XY trace.

# 4 Technical reference

### **4.1** Serial port settings

2400 baud, 8 data, 1 stop, no parity.

The following table shows the standard serial port settings for COM ports.

Port	Base address	Interrupt	Standard?
COM1	3F8	4	Yes
COM2	2F8	3	Yes
COM3	3E8	4	De facto
COM4	2E8	3	De facto
COM5		No	No

Note: on most computers, it is not possible to use the same interrupt for two serial ports at the same time. If, for example, you wish to use COM1 and COM3 at the same time, it is necessary to use a serial port card which can be set to an interrupt other than 4.

#### **4.2** Serial port connections

The information presented here is necessary only if you wish to connect the PT-104 to the PC in some unusual way (for example, via a radio modem).

The PT-104 uses the following RS232 data lines (pin connections as on PT-104).

Pin	Name	Usage
3	ТХ	Data from the PC to the PT-104
2	RX	Data from the PT-104 to the PC
7	RTS	Held at a positive voltage (>7V) to power the PT-104
5	GND	0 V line
4	DTR	Held at a negative voltage (<-7V) to power the PT-104

The driver powers up the PT-104 by enabling RTS and disabling DTR to provide the correct polarity power supply. If these are set incorrectly no damage will occur to either PC or PT-104.

When the PT-104 is first powered up, it sends a version response (see Protocol information [19]).

### **4.3** Protocol information

#### Requests

The computer can send the following request to the PT-104.

Command	Data bytes	Function
0x00	-	Get Version
0x01	-	Read EEPROM
0x02	one byte, bit 0 is LSB	Start Converting
	bit 0: enable channel 1	0 = off, 1 = on
	bit 1: enable channel 2	ditto
	bit 2: enable channel 3	ditto
	bit 3: enable channel 4	ditto
	bit 4: channel 1 gain	0 = x1, 1 = x21
	bit 5: channel 2 gain	ditto
	bit 6: channel 3 gain	ditto
	bit 7: channel 4 gain	ditto
0x03	bit 0: select 50/60 Hz mains	0 = 50 Hz, 1 = 60 Hz

#### Responses

At start-up, and on receipt of a version request, the PT-104 sends a version response.

Byte	Value	
1	xFF	
2	хАА	
3	x55	
4	x68	Product type
5	x10	Version

On receipt of a Start Converting request, the PT-104 starts sending conversion responses - approx one every 180 milliseconds. There are four measurement points for each channel, and the PT-104 automatically cycles through each of the measurements for each of the active channels. Each response is as follows:

Byte	Value	
1	bits 0-1: measurement no. (0 to 3)	
	bits 2-3: channel no. (0 to 3)	
	bits 4-7: always zero	
2-5	reading data: byte 2 is MSB	
	0x2000000 = scaled minimum	
	0xE0000000 = scaled maximum	
	The result will always be in the range 0x20000000 to 0xE0000000 inclusive	

On receipt of a Read EEPROM request, the unit returns 64 bytes of EEPROM data. This data contains the following:

Byte	Size
1	Checksum (always 0x55AB)
3	Calibration version (1 = current)
4	Spare
5	Calibration date (ddmmyy followed by NULL char)
13	Batch number
19	Calibration for channel 1 (resistance x 1E6)
23	Calibration for channel 2
27	Calibration for channel 3
31	Calibration for channel 4

#### Examples

```
GAIN = 21
MAXINPUT = 2500000
FSD = 0x10000000
SCALED_MIN = 0x20000000
```

To obtain a single ended voltage reading 0 - 115 mV 0x0A in byte 1 is measurement no 2 on channel 2.

Reading data in bytes 2-5 gives a value of 0x5000000.

Then:

```
result = ((0x5000000 - SCALED_MIN) * MAXINPUT) / (GAIN * FSD)
```

= 357142.857142857142857142857142857

where

```
MAXINPUT = 2,500,000 is the maximum input voltage in microvolts,
GAIN is a fixed gain factor,
FSD = 0x10000000 for a 28-bit ADC
```

To convert the result to mV divide by 10,000.0:

= 35.7142

To obtain a single ended voltage reading 0 - 2.5 V using the same reading.

0x0A in byte 1 is measurement no 2 on channel 2.

Reading data in bytes 2-5 giving a value of 0x50000000.

To convert to voltage:

result = (0x5000000 - SCALED\_MIN ) \* MAXINPUT) / FSD

where MAXINPUT is the maximum input voltage in microvolts.

To convert result to V divide result by 10,000,000.0

21

To obtain a differential reading 0 - 2.5V

Take two measurements on a channel, e.g. measurement 3 and 2 on channel 2.

Then:

((measurement 3 - measurement 2) \* MAXINPUT) / FSD

To convert result to V divide answer by 10,000,000.0

To calculate a resistance

Read the EEPROM to obtain the calibration information for the channels.

Take measurement 0, 1, 2 and 3 on a channel.

Then:

```
result = (channel calibration * (measurement 3 - measurement 2)) / (measurement 1 - measurement 0)
```

To convert to a resistance divide result by 1,000,000.0

To calculate a temperature

Carry out resistance measurement

Use a lookup table 22 to convert the resistance to a temperature.

#### **4.4** Modem operation

The PT-104 is normally connected directly to the computer, but it is also possible to access the PT-104 via a modem using the Windows driver.

It is necessary to provide power to the PT-104, either by instructing the modem to provide power or by connecting a power supply directly to the PT-104. See <u>Serial port</u> connections for information.

Warning: In order to comply with current legislation, use only radio modems which comply with the RTTE directive.

)

# 4.5 Lookup table

Temp (°C)	Resistance (
-30 -49	80.300202
-48	81.100257
-47	81.497036
-46	81.893677
-45	82.290179
-44	82.686545
-43	83.082774
-42	83 874827
-40	84.270652
-39	84.666343
-38	85.061901
-37	85.457327
-36	85.852622
-35	86.247785
-34	87 037721
-32	87.432495
-31	87.827140
-30	88.221657
-29	88.616046
-28	89.010309
-27	89.404445
-20	90 192339
-24	90.586099
-23	90.979734
-22	91.373246
-21	91.766634
-20	92.159898
-19 10	92.55304 I
-17	92.940001
-16	93.731737
-15	94.124394
-14	94.516930
-13	94.909346
-12	95.301643
-11	95.693820
-10	96 477819
-8	96.869641
-7	97.261345
-6	97.652931
-5	98.044401
-4	98.435753
-3	98.820989 00.218100
-2	99.609112
0	100.000000
1	100.390772
2	100.781429
3	101.171970
4	101.562396
J	101.902700

6	102 242001
0	102.342901
/	102.732980
8	103.122944
9	103.512792
10	103 902525
10	103.702323
	104.292142
12	104.681644
13	105.071030
14	105 460301
15	105 940456
15	103.049450
16	106.238496
17	106.627420
18	107.016229
19	107 404922
20	107.101722
20	107.793500
21	108.181962
22	108.570309
23	108.958540
24	109 346656
24	100.724656
25	109./34050
26	110.122541
27	110.510310
28	110.897964
29	111 285502
27	111 47202
30	111.0/2925
31	112.060232
32	112.447424
33	112.834500
31	113 221/61
3 <del>-</del>	112 400204
35	113.008300
36	113.995036
37	114.381650
38	114.768149
30	115 15/532
10	115.154552
40	115.540800
41	115.926952
42	116.312989
43	116.698910
44	117 084716
15	117 470406
40	117.470400
46	117.855981
47	118.241440
48	118.626784
19	110 012012
F0	110 20712
50	119.39/125
51	119./82122
52	120.167004
53	120.551770
54	120 036/21
54	120.750421
55	121.320950
56	121.705376
57	122.089680
58	122,473869
59	122 8570/2
40	122.00/742
00	123.241900
61	123.625742
62	124.009469
63	124.393080

24	Omega PT-104 User's Guide	
	ے ۱24 776576	
65	5 125 159956	
64	6 125.137730	
6	7 125.343221	
69	2 126.300404	
600	0 126.309404	
05	9 I20.092322 0 107.075105	
70	1 107 457010	
/ 7	1 127.457812	
12	2 127.840384	
1:	3 128.222840	
74		
/5	5 128.987406	
/6	6 129.369516	
11	/ 129.751510	
/ 8	8 130.133389	
/ .	9 130.515152	
80	0 130.896800	
81	1 131.278332	
82	2 131.659749	
83	3 132.041050	
84	4 132.422236	
85	5 132.803306	
86	6 133.184261	
87	7 133.565100	
88	8 133.945824	
89	9 134.326432	
90	0 134.706925	
91	1 135.087302	
92	2 135.467564	
93	3 135.847710	
94	4 136.227741	
95	5 136.607656	
96	6 136.987456	
97	7 137.367140	
98	8 137.746709	
99	9 138.126162	
10	00 138.505500	
10	01 138.884722	
10	02 139.263829	
10	03 139.642820	
10	04 140.021696	
10	05 140.400456	
10	06 140.779101	
10	07 141.157630	
10	08 141.536044	
10	09 141.914342	
11	10 142.292525	
11	11 142.670592	
11	12 143.048544	
11	13 143.426380	
11	14 143.804101	
11	15 144.181706	
11	16 144.559196	
11	17 144.936570	
11	18 145.313829	
11	19 145.690972	
12	20 146.068000	
12	21 146.444912	

100	14/ 001700
122	140.821709
123	147.198390
124	147.574956
125	147.951406
126	148.327741
127	148,703960
128	1/9 08006/
120	140 456050
129	149.400002
130	149.831925
131	150.207682
132	150.583324
133	150.958850
134	151.334261
135	151.709556
136	152 084736
137	152 / 59800
107	152.437000
130	102.004749
139	153.209582
140	153.584300
141	153.958902
142	154.333389
143	154.707760
144	155.082016
145	155 456156
146	155 830181
140	154 204000
147	156.204090
148	156.577884
149	156.951562
150	157.325125
151	157.698572
152	158.071904
153	158.445120
154	158.818221
155	159 191206
156	159 564076
150	150 026020
157	160,200460
158	160.309469
159	160.681992
160	161.054400
161	161.426692
162	161.798869
163	162.170930
164	162.542876
165	162.914706
166	163 286421
167	163 658020
167	164 020504
100	104.029304
109	164.400872
170	164.772125
1/1	165.143262
172	165.514284
173	165.885190
174	166.255981
175	166.626656
176	166.997216
177	167 367660
178	167 727020
170	160 100000
1/7	100.100202

26 Omega	a PT-104 User's Guide
180	168.478300
181	168.848282
182	169.218149
183	169.587900
184	169.957536
185	170.327056
186	170.696461
187	171.065750
188	171.434924
189	171.803982
190	172.172925
191	172.541752
192	172.910464
193	173.279060
194	173.647541
195	174.015906
196	174.384156
197	174.752290
198	175.120309
199	175.488212
200	175.856000

27

# Index

# A

Agilent VEE 17

# С

C++ 15 Connecting the PT-104 4 Connections 18

# D

Delphi 16 Driver routines pt104\_close\_unit 10 pt104\_get\_cycle 11 pt104\_get\_driver\_version 13 pt104\_get\_unit\_info 13 pt104\_get\_value 12 pt104\_get\_version 13 pt104\_labview 14 pt104\_open\_unit 10 pt104\_poll\_driver 10 pt104\_set\_channel 11 pt104\_set\_mains 12

# E

Excel 16

# I

Installation 3

# L

LabVIEW 16 Lookup table 22

# Μ

Modem operation 21

# Ρ

Principles of operation 7 Protocol 19 pt104\_close\_unit 10 pt104\_get\_cycle 11 pt104\_get\_driver\_version 13 pt104\_get\_unit\_info 13 pt104\_get\_value12pt104\_get\_version13pt104\_labview14pt104\_open\_unit10pt104\_poll\_driver10pt104\_set\_channel11pt104\_set\_mains12

# S

Safety warning 2 Serial port settings 18 Specifications 3

# V

Visual Basic 16

# W

Windows XP (SP2)/Vista 14

# WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **13 months** from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal **one (1) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components in which wear is not warranted, include but are not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by it will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESS OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

# **RETURN REQUESTS/INQUIRIES**

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting OMEGA:

- 1. Purchase Order number under which the product was PURCHASED,
- 2. Model and serial number of the product under warranty, and
- 3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

- 1. Purchase Order number to cover the COST of the repair,
- 2. Model and serial number of the product, and
- 3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 2009 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.

# Where Do I Find Everything I Need for Process Measurement and Control? OMEGA...Of Course! Shop online at omega.com<sup>sm</sup>

### TEMPERATURE

- Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- ☑ Wire: Thermocouple, RTD & Thermistor
- Calibrators & Ice Point References
- 🗹 Recorders, Controllers & Process Monitors
- Infrared Pyrometers

### **PRESSURE, STRAIN AND FORCE**

- 🗹 Transducers & Strain Gages
- 🗹 Load Cells & Pressure Gages
- Displacement Transducers
- Instrumentation & Accessories

### **FLOW/LEVEL**

- ☑ Rotameters, Gas Mass Flowmeters & Flow Computers
- Air Velocity Indicators
- Turbine/Paddlewheel Systems
- Totalizers & Batch Controllers

### pH/CONDUCTIVITY

- PH Electrodes, Testers & Accessories
- Benchtop/Laboratory Meters
- Controllers, Calibrators, Simulators & Pumps
- Industrial pH & Conductivity Equipment

### DATA ACQUISITION

- ☑ Data Acquisition & Engineering Software
- Communications-Based Acquisition Systems
- Plug-in Cards for Apple, IBM & Compatibles
- Data Logging Systems
- Recorders, Printers & Plotters

### HEATERS

- Heating Cable
- Cartridge & Strip Heaters
- Immersion & Band Heaters
- Flexible Heaters
- Laboratory Heaters

### ENVIRONMENTAL MONITORING AND CONTROL

- Metering & Control Instrumentation
- Refractometers
- Pumps & Tubing
- Air, Soil & Water Monitors
- Industrial Water & Wastewater Treatment
- PH, Conductivity & Dissolved Oxygen Instruments