

User's Guide



Shop online at

omega.com[®]

Ω OMEGA[®]

omega.com

e-mail: info@omega.com

For latest product manuals:

omegamanual.info

ISO 9001
CERTIFIED
CORPORATE QUALITY

STAMFORD, CT

ISO 9002
CERTIFIED
CORPORATE QUALITY

MANCHESTER, UK

DP63100-S **Strain Gage Input Panel** **Meter**



OMEGAnet® Online Service
omega.com

Internet e-mail
info@omega.com

Servicing North America:

U.S.A.: One Omega Drive, P.O. Box 4047
ISO 9001 Certified Stamford, CT 06907-0047
TEL: (203) 359-1660 FAX: (203) 359-7700
e-mail: info@omega.com

Canada: 976 Bergar
Laval (Quebec) H7L 5A1, Canada
TEL: (514) 856-6928 FAX: (514) 856-6886
e-mail: info@omega.ca

For immediate technical or application assistance:

U.S.A. and Canada: Sales Service: 1-800-826-6342/1-800-TC-OMEGA®
Customer Service: 1-800-622-2378/1-800-622-BEST®
Engineering Service: 1-800-872-9436/1-800-USA-WHEN®

Mexico: En Español: (001) 203-359-7803 e-mail: espanol@omega.com
FAX: (001) 203-359-7807 info@omega.com.mx

Servicing Europe:

Czech Republic: Frystatska 184, 733 01 Karviná, Czech Republic
TEL: +420 (0)59 6311899 FAX: +420 (0)59 6311114
Toll Free: 0800-1-66342
e-mail: info@omegashop.cz

Germany/Austria: Daimlerstrasse 26, D-75392 Deckenpfronn, Germany
TEL: +49 (0)7056 9398-0 FAX: +49 (0)7056 9398-29
Toll Free in Germany: 0800 639 7678
e-mail: info@omega.de

United Kingdom: One Omega Drive, River Bend Technology Centre
ISO 9002 Certified Northbank, Irlam, Manchester
M44 5BD United Kingdom
TEL: +44 (0)161 777 6611 FAX: +44 (0)161 777 6622
Toll Free in United Kingdom: 0800-488-488
e-mail: sales@omega.co.uk

It is the policy of OMEGA Engineering, Inc. to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct, but OMEGA accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

WARNING : These products are not designed for use in, and should not be used for, human applications.



- LOAD CELL, PRESSURE AND TORQUE BRIDGE INPUTS
- UNIVERSAL AC/DC POWER SUPPLY
- SELECTABLE 5 VDC OR 10 VDC BRIDGE EXCITATION
- PROGRAMMABLE AUTO-ZERO TRACKING
- 6 / 9 DIGIT DUAL LINE/TRI-COLOR DISPLAY WITH 0.71" & 0.35" DIGITS
- PROGRAMMABLE UNITS DISPLAY
- VARIABLE CONTRAST AND INTENSITY DISPLAY
- UP TO 160 SAMPLES PER SECOND CONVERSION RATE
- BUILT-IN USB PROGRAMMING PORT ENABLING UNIT CONFIGURATION WITH DP6-SOFT PROGRAMMING SOFTWARE
- NEMA 4X/IP65 SEALED FRONT BEZEL

DESCRIPTION

The DP63100-S Strain Gage Panel Meter offers many features and performance capabilities to suit a wide range of industrial applications. The DP63100-S has a strain gage input to handle various types of bridge configurations including load cell, pressure and torque sensors. The optional plug-in output cards allow the opportunity to configure the meter for present applications, while providing easy upgrades for future needs.

Highlighting the DP63100-S is a dual line, display with a large 0.71", tri-color 6 digit top display line and a 0.35", 9 digit green bottom display line. The meter also offers programmable units display, providing capability to tag the display with units of measure. Display color change capability provides machine operators a visual display of changing conditions, even when the operator is not close enough to read the actual display value. In addition, a universal power supply provides the ultimate in flexibility for both AC and DC power.

The meter provides a MAX and MIN reading memory with programmable capture time. The capture time is used to prevent detection of false max or min readings which may occur during start-up or unusual process events. The signal totalizer (integrator) can be used to compute a time-input product. This can be used to provide a readout of totalized weight or calculate service intervals of motors, pumps, etc.

The meter has up to four setpoint outputs, implemented on plug-in option cards. The plug-in cards provide dual FORM-C relays, quad FORM-A, or either quad sinking or quad sourcing open collector logic outputs. The setpoint alarms can be configured to suit a variety of control and alarm requirements.

Communication and bus capabilities are also available as option cards. These include RS232 and RS485. The Meter can be programmed to utilize Modbus protocol. With Modbus, the user has access to all configuration parameters. Readout values and setpoint alarm values can be controlled through the bus. Additionally, the meter has a feature that allows a remote computer to directly control the outputs of the meter.

The DP63100-S includes a built-in USB programming port. With a Windows® based program, made available by Omega, configuration data can be downloaded to the meter without the need of any additional option cards.

A linear DC output signal is available as an optional plug-in card. The card provides either 20 mA or 10 V signals. The output can be scaled independent of the input range and can track either the input, totalizer, max or min readings, or any setpoint value.

After the meter has been initially configured, the parameter programming may be locked out from further modification in its entirety, or allowing selected values accessible for quick entry.

The meter has been specifically designed for harsh industrial environments. With NEMA 4X/IP65 sealed bezel and extensive testing of noise effects with regard to CE requirements, the meter provides a tough reliable application solution.

SAFETY SUMMARY

All safety related regulations, local codes and instructions that appear in this literature or on equipment must be observed to ensure personal safety and to prevent damage to either the instrument or equipment connected to it. If equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired. Do not use this unit to directly command motors, valves, or other actuators not equipped with safeguards. To do so can be potentially harmful to persons or equipment in the event of a fault to the unit.



CAUTION: Risk of Danger.
Read complete instructions prior to installation and operation of the unit.



CAUTION: Risk of electric shock.

DIMENSIONS In inches (mm)

Note: Recommended minimum clearance (behind the panel) for mounting clip installation is 2.1" (53.4) H x 5.5" (140) W.

PANEL CUT-OUT






TABLE OF CONTENTS

General Meter Specifications	4	Programming the DP63100-S	10
Optional Plug-In Output Cards	5	Serial Communications	24
Installing the Meter	6	Frequently Used Modbus Register Table	25
Setting the Jumpers	6	Factory Service Operations	29
Installing Plug-In Cards	7	Troubleshooting Guide	30
Wiring the Meter	7	Parameter Value Chart	31
Front Panel Keys and Display Overview.	9	Programming Overview.	34
Line 2 Display Loops.	9		

GENERAL METER SPECIFICATIONS

1. **DISPLAY:** Positive image LCD
 Top Line - 6 digit, 0.71" (18 mm), with tri-color backlight (red, green or orange), display range: -199,999 to 999,999;
 Bottom Line - 9 digit, 0.35" (8.9 mm), with green backlight, display range: -199,999,999 to 999,999,999

2. **POWER:**
 AC Power: 40 to 250 VAC, 50/60 Hz, 20 VA
 DC Power: 21.6 to 250 VDC, 8 W
 Isolation: 2300 Vrms for 1 min. to all inputs and outputs.

3. **ANNUNCIATORS:** Backlight color: Red
 1 - setpoint alarm 1 3 - setpoint alarm 3
 2 - setpoint alarm 2 4 - setpoint alarm 4
 Line 1 Units Label – programmable 3 digit units annunciator with tri-color backlight (red, green or orange)

4. **KEYPAD:** 2 programmable function keys, 4 keys total

5. **A/D CONVERTER:** 24 bit resolution

6. **UPDATE RATES:**
 A/D conversion rate: programmable 5 to 160 readings/sec.
 Step response:

Input Rate	5	10	20	40	80	160	Readings/Sec
Response Time *	600	400	200	100	50	30	msec response time *

* - max. to within 99% of final readout value (digital filter disabled)

Display update rate: 1 to 20 updates/sec.

Setpoint output on/off delay time: 0 to 3275 sec.

Analog output update rate: 0 to 10 sec

Max./Min. capture delay time: 0 to 3275 sec.

7. **DISPLAY MESSAGES:**

“OLOL” - Appears when measurement exceeds + signal range.

“ULUL” - Appears when measurement exceeds - signal range

“” - Appears when display values exceed + display range.

“ -” - Appears when display values exceed - display range.

8. **INPUT:**

Connection Type: 4-wire bridge (differential); 2-wire (single-ended)

Common Mode Range (with respect to input common): 0 to +5 VDC

Rejection: 80 dB (DC to 120 Hz)

INPUT RANGE	ACCURACY* (18 to 28°C)	ACCURACY* (0 to 50°C)	IMPEDANCE/ COMPLIANCE	MAX CONT. OVERLOAD	** RESOLUTION
± 24 mVDC	0.02% of rdg + 3 µV	0.07% of rdg + 4 µV	100 Mohm	30 V	1 µV
± 240 mVDC	0.02% of rdg + 30 µV	0.07% of rdg + 40 µV	100 Mohm	30 V	10 µV

* After 20 minute warm-up. Accuracy is specified in two ways: Accuracy over an 18 to 28°C and 10 to 75% RH environment; and accuracy over a 0 to 50°C and 0 to 85% RH (non-condensing environment). Accuracy over the 0 to 50°C range includes the temperature coefficient effect of the meter.

** Higher resolution can be achieved via input scaling

9. **EXCITATION POWER:** Jumper selectable

+5 VDC @ 65 mADC max., +/-2%

+10 VDC @ 125 mADC max., +/-2%

Temperature Coefficient (ratio metric): 20 ppm/°C max.

10. **USER INPUTS:** Three programmable user inputs

Max. Continuous Input: 30 VDC

Isolation To Sensor Input Common: Not isolated.

Response Time: 12 msec. max.

Logic State: User programmable (LO/SOURCE) for sink/source (LO/HI) logic

INPUT STATE (LO/SOURCE)	LO/SINK	HI/SOURCE
	20 KΩ pull-up to +3.3 V	20 KΩ pull-down
Active	V _{IN} < 1.1 VDC	V _{IN} > 2.2 VDC
Inactive	V _{IN} > 2.2 VDC	V _{IN} < 1.1 VDC

11. **TOTALIZER:**

Time Base: second, minute, hour, or day

Batch: Can accumulate (gate) input display from a user input

Time Accuracy: 0.01% typical

Decimal Point: 0 to 0.0000

Scale Factor: 0.001 to 65.000

Low Signal Cut-out: -199,999 to 999,999

Total: 6 digits on Line 1; 9 digits on Line 2

12. **CUSTOM LINEARIZATION:**

Data Point Pairs: Selectable from 2 to 16

Display Range: -199,999 to 999,999

Decimal Point: 0 to 0.0000

13. **MEMORY:** Nonvolatile memory retains all programmable parameters and display values.

14. **ENVIRONMENTAL CONDITIONS:**

Operating Temperature Range: 0 to 50 °C

Storage Temperature Range: -40 to 60 °C

Vibration to IEC 68-2-6: Operational 5-150 Hz, 2 g

Shock to IEC 68-2-27: Operational 25 g (10 g relay)

Operating and Storage Humidity: 0 to 85% max. RH non-condensing

Altitude: Up to 2000 meters

15. **CERTIFICATIONS AND COMPLIANCES:**

CE Approved

EN 61326-1 Immunity to Industrial Locations

Emission CISPR 11 Class A

IEC/EN 61010-1

RoHS Compliant

UL Listed: File #E70366

Type 4X Indoor Enclosure rating (Face only)

IP65 Enclosure rating (Face only)

IP20 Enclosure rating (Rear of unit)

Refer to EMC Installation Guidelines section of the bulletin for additional information.

16. **CONNECTIONS:** High compression cage-clamp terminal block

Wire Strip Length: 0.3" (7.5 mm)

Wire Gauge Capacity: One 14 AWG (2.55 mm) solid, two 18 AWG (1.02 mm) or four 20 AWG (0.61 mm)

17. **CONSTRUCTION:** This unit is rated NEMA 4X/IP65 for indoor use only.

IP20 Touch safe. Installation Category II, Pollution Degree 2. One piece bezel/ case. Flame resistant. Synthetic rubber keypad. Panel gasket and mounting clip included.

18. **WEIGHT:** 8 oz. (226.8 g)

OPTIONAL PLUG-IN OUTPUT CARDS



WARNING: Disconnect all power to the unit before installing plug-in cards.

Adding Option Cards

The DP63100-S meters can be fitted with up to three optional plug-in cards. The details for each plug-in card can be reviewed in the specification section below. Only one card from each function type can be installed at a time. The function types include Setpoint Alarms (LDP6-CDS), Communications (LDP6-CDC), and Analog Output (LDP6-CDL). The plug-in cards can be installed initially or at a later date.

COMMUNICATION CARDS (LDP6-CDC)

A variety of communication protocols are available for the DP63100-S meter. Only one LDP6-CDC card can be installed at a time. *Note: For Modbus communications use RS485 Communications Output Card and configure communication (TYPE) parameter for Modbus.*

LDP6-CDC10 - RS485 Serial (Terminal)

LDP6-CDC1C - RS485 Serial (Connector)

LDP6-CDC20 - RS232 Serial (Terminal)

LDP6-CDC2C - RS232 Serial (Connector)

SERIAL COMMUNICATIONS CARD

Type: RS485 or RS232

Communication Type: RLC Protocol (ASCII), Modbus RTU, and Modbus ASCII

Isolation To Sensor & User Input Commons: 500 Vrms for 1 min.

Working Voltage: 50 V. Not Isolated from all other commons.

Data: 7/8 bits

Baud: 1200 to 38,400

Parity: no, odd or even

Bus Address: Selectable 0 to 99 (RLC Protocol), or 1 to 247 (Modbus Protocol), Max. 32 meters per line (RS485)

Transmit Delay: Selectable for 0 to 0.250 sec (+2 msec min)

SETPOINT CARDS (LDP6-CDS)

The DP63100-S meter has 4 available setpoint alarm output plug-in cards. Only one LDP6-CDS card can be installed at a time. (Logic state of the outputs can be reversed in the programming.) These plug-in cards include:

LDP6-CDS10 - Dual Relay, FORM-C, Normally open & closed

LDP6-CDS20 - Quad Relay, FORM-A, Normally open only

LDP6-CDS30 - Isolated quad sinking NPN open collector

LDP6-CDS40 - Isolated quad sourcing PNP open collector

DUAL RELAY CARD

Type: Two FORM-C relays

Isolation To Sensor & User Input Commons: 2000 Vrms for 1 min.

Working Voltage: 240 Vrms

Contact Rating:

One Relay Energized: 5 amps @ 120/240 VAC or 28 VDC (resistive load).

Total current with both relays energized not to exceed 5 amps

Life Expectancy: 100 K cycles min. at full load rating. External RC snubber extends relay life for operation with inductive loads

QUAD RELAY CARD

Type: Four FORM-A relays

Isolation To Sensor & User Input Commons: 2300 Vrms for 1 min.

Working Voltage: 250 Vrms

Contact Rating:

One Relay Energized: 3 amps @ 240 VAC or 30 VDC (resistive load).

Total current with all four relays energized not to exceed 4 amps

Life Expectancy: 100K cycles min. at full load rating. External RC snubber extends relay life for operation with inductive loads

QUAD SINKING OPEN COLLECTOR CARD

Type: Four isolated sinking NPN transistors.

Isolation To Sensor & User Input Commons: 500 Vrms for 1 min.

Working Voltage: 50 V. Not Isolated from all other commons.

Rating: 100 mA max @ $V_{SAT} = 0.7$ V max. $V_{MAX} = 30$ V

QUAD SOURCING OPEN COLLECTOR CARD

Type: Four isolated sourcing PNP transistors.

Isolation To Sensor & User Input Commons: 500 Vrms for 1 min.

Working Voltage: 50 V. Not Isolated from all other commons.

Rating: Internal supply: 18 VDC unregulated, 30 mA max. total
External supply: 30 VDC max., 100 mA max. each output

ALL FOUR SETPOINT CARDS

Response Time: See Update Rates step response specification on page 3; add 6 msec (typical) for relay card

LINEAR DC OUTPUT (LDP6-CDL)

Either a 0(4)-20 mA or 0-10 V retransmitted linear DC output is available from the analog output plug-in card. The programmable output low and high scaling can be based on various display values. Reverse slope output is possible by reversing the scaling point positions.

LDP6-CDL10 - Retransmitted Analog Output Card

ANALOG OUTPUT CARD

Types: 0 to 20 mA, 4 to 20 mA or 0 to 10 VDC

Isolation To Sensor & User Input Commons: 500 Vrms for 1 min.

Working Voltage: 50 V. Not Isolated from all other commons.

Accuracy: 0.17% of FS (18 to 28 °C); 0.4% of FS (0 to 50 °C)

Resolution: 1/3500

Compliance: 10 VDC: 10 K Ω load min., 20 mA: 500 Ω load max.

Powered: Self-powered

Step Response: See Update Rates step response specification on page 3.

Update time: See ADC Conversion Rate and Update Time parameter

PROGRAMMING SOFTWARE


DP6-SOFT is a Windows® based program that allows configuration of the meter from a PC. The software offers standard drop-down menu commands, that make it easy to program the meter. The meter's program can then be saved in a PC file for future use.

1.0 INSTALLING THE METER

Installation

The DP63100-S meets NEMA 4X/IP65 requirements when properly installed. The unit is intended to be mounted into an enclosed panel. Prepare the panel cutout to the dimensions shown. Remove the panel latch from the unit. Slide the panel gasket over the rear of the unit to the back of the bezel. The unit should be installed fully assembled. Insert the unit into the panel cutout.

While holding the unit in place, push the panel latch over the rear of the unit so that the tabs of the panel latch engage in the slots on the case. The panel latch should be engaged in the farthest forward slot possible. To achieve a proper seal, tighten the latch screws evenly until the unit is snug in the panel (Torque to approximately 7 in-lbs [79N-cm]). Do not over-tighten the screws.




Installation Environment

The unit should be installed in a location that does not exceed the operating temperature and provides good air circulation. Placing the unit near devices that generate excessive heat should be avoided.

The bezel should only be cleaned with a soft cloth and neutral soap product. Do NOT use solvents. Continuous exposure to direct sunlight may accelerate the aging process of the bezel.

Do not use tools of any kind (screwdrivers, pens, pencils, etc.) to operate the keypad of the unit.

PANEL CUT-OUT



2.0 SETTING THE JUMPERS


Bridge Excitation

This jumper is used to select bridge excitation voltage level. Use the 5 V excitation with high output (3 mV/V) bridges, so that the higher sensitivity 24 mV range can be used. Using the 5 V excitation also reduces bridge power consumption compared to the 10 V excitation. A maximum of four 350 ohm load cells can be driven by the internal bridge excitation voltage.

JUMPER SELECTIONS
The \surd indicates factory setting.

BRIDGE EXCITATION	INPUT RANGE
5V <input type="checkbox"/>	<input checked="" type="checkbox"/> $\pm 24\text{mV}$
10V <input checked="" type="checkbox"/>	<input type="checkbox"/> $\pm 240\text{mV}$


↓ REAR TERMINALS ↓



3.0 INSTALLING PLUG-IN CARDS


The plug-in cards are separately purchased optional cards that perform specific functions. These cards plug into the main circuit board of the meter. The plug-in cards have many unique functions when used with the DP63100-S.

CAUTION: The plug-in card and main circuit board contain static sensitive components. Before handling the cards, discharge static charges from your body by touching a grounded bare metal object. Ideally, handle the cards at a static controlled clean workstation. Also, only handle the cards by the edges. Dirt, oil or other contaminants that may contact the cards can adversely affect circuit operation.



To Install:

1. With the meter removed from the case, locate the plug-in card connector for the card type to be installed. The types are keyed by position with different main circuit board connector locations. When installing the card, hold the meter by the rear terminals and not by the front display board. If installing the Quad sourcing Plug-in Card (LDP6-CDS40), set the jumper for internal or external supply operation before continuing.



2. Install the plug-in card by aligning the card terminals with the slot bay in the rear cover. Be sure the connector is fully engaged and the tab on the plug-in card rests in the alignment slot on the display board.
3. Slide the meter base back into the case. Be sure the rear cover latches fully into the case.
4. Apply the plug-in card label to the bottom side of the meter in the designated area. Do Not Cover the vents on the top surface of the meter. The surface of the case must be clean for the label to adhere properly.

4.0 WIRING THE METER

WIRING OVERVIEW

Electrical connections are made via screw-clamp terminals located on the back of the meter. All conductors should conform to the meter's voltage and current ratings. All cabling should conform to appropriate standards of good installation, local codes and regulations. It is recommended that the power supplied to the meter (DC or AC) be protected by a fuse or circuit breaker.

When wiring the meter, compare the numbers embossed on the back of the meter case against those shown in wiring drawings for proper wire position. Strip the wire, leaving approximately 0.3" (7.5 mm) bare lead exposed (stranded wires should be tinned with solder). Insert the lead under the correct screw-clamp terminal and tighten until the wire is secure (Pull wire to verify tightness). Each terminal can accept up to one #14 AWG (2.55 mm) wire, two #18 AWG (1.02 mm), or four #20 AWG (0.61 mm).

EMC INSTALLATION GUIDELINES

Although this meter is designed with a high degree of immunity to Electromagnetic Interference (EMI), proper installation and wiring methods must be followed to ensure compatibility in each application. The type of the electrical noise, source or coupling method into a unit may be different for various installations. Cable length, routing, and shield termination are very important and can mean the difference between a successful or troublesome installation. Listed are some EMI guidelines for a successful installation in an industrial environment.

1. A unit should be mounted in a metal enclosure, which is properly connected to protective earth.
2. Use shielded cables for all Signal and Control inputs. The shield connection should be made as short as possible. The connection point for the shield depends somewhat upon the application. Listed below are the recommended methods of connecting the shield, in order of their effectiveness.
 - a. Connect the shield to earth ground (protective earth) at one end where the unit is mounted.
 - b. Connect the shield to earth ground at both ends of the cable, usually when the noise source frequency is over 1 MHz.

3. Never run Signal or Control cables in the same conduit or raceway with AC power lines, conductors, feeding motors, solenoids, SCR controls, and heaters, etc. The cables should be run through metal conduit that is properly grounded. This is especially useful in applications where cable runs are long and portable two-way radios are used in close proximity or if the installation is near a commercial radio transmitter. Also, Signal or Control cables within an enclosure should be routed as far away as possible from contactors, control relays, transformers, and other noisy components.

4. Long cable runs are more susceptible to EMI pickup than short cable runs.
5. In extremely high EMI environments, the use of external EMI suppression devices such as Ferrite Suppression Cores for signal and control cables is effective. The following EMI suppression devices (or equivalent) are recommended:

Fair-Rite part number 0443167251


Line Filters for input power cables:

Schaffner # FN2010-1/07

6. To protect relay contacts that control inductive loads and to minimize radiated and conducted noise (EMI), some type of contact protection network is normally installed across the load, the contacts or both. The most effective location is across the load.
 - a. Using a snubber, which is a resistor-capacitor (RC) network or metal oxide varistor (MOV) across an AC inductive load is very effective at reducing EMI and increasing relay contact life.
 - b. If a DC inductive load (such as a DC relay coil) is controlled by a transistor switch, care must be taken not to exceed the breakdown voltage of the transistor when the load is switched. One of the most effective ways is to place a diode across the inductive load. External diode protection at the load is always a good design practice to limit EMI. Although the use of a snubber or varistor could be used.
7. Care should be taken when connecting input and output devices to the instrument. When a separate input and output common is provided, they should not be mixed. Therefore a sensor common should NOT be connected to an output common. This would cause EMI on the sensitive input common, which could affect the instrument's operation.

4.1 POWER WIRING

AC Power



DC Power




The power supplied to the meter shall employ a 15 Amp UL approved circuit breaker for AC input and a 1 Amp, 250 V UL approved fuse for DC input. It shall be easily accessible and marked as a disconnecting device to the installed unit. This device is not directly intended for connection to the mains without a reliable means to reduce transient over-voltages to 1500 V.


4.2 INPUT SIGNAL WIRING

Before connecting signal wires, the Input Range Jumper and Bridge Excitation Jumper should be verified for proper position.


2-Wire Single Ended Input



4-Wire Bridge Input



6-Wire Bridge Input




4.3 USER INPUT WIRING

If not using User Inputs, then skip this section. User Input terminal does not need to be wired in order to remain in inactive state.


Sinking Logic (USrACt L0)

When the *USrACt* parameter is programmed to *L0*, the user inputs of the meter are internally pulled up to +3.3 V with 20 KΩ resistance. The input is active when it is pulled low (<1.1 V).



Sourcing Logic (USrACt H1)


When the *USrACt* parameter is programmed to *H1*, the user inputs of the meter are internally pulled down to 0 V with 20 KΩ resistance. The input is active when a voltage greater than 2.2 VDC is applied.



- 4.4 SETPOINT (ALARMS) WIRING
- 4.5 SERIAL COMMUNICATION WIRING
- 4.6 ANALOG OUTPUT WIRING

See appropriate plug-in card bulletin for wiring details.

5.0 FRONT PANEL KEYS AND DISPLAY OVERVIEW



KEY DISPLAY MODE OPERATION

D	Index Line 2 through enabled Line 2 display values
P	Enter full programming mode or access the parameter and hidden display loops; Press and hold to skip parameters and go directly to Code or Programming Menu
F1	User programmable Function key 1; hold for 3 seconds for user programmable second function 1*
F2	User programmable Function key 2; hold for 3 seconds for user programmable second function 2*

*Factory setting for F1/F2 and second function F1/F2 is no mode

PROGRAMMING MODE OPERATION

Return to the previous menu level (momentary press) Quick exit to Display Mode (press and hold)
Access the programming parameter menu, store selected parameter and index to next parameter
Increment selected parameter value; Hold F1 and momentarily press F2 key to increment next decade or D key to increment by 1000's
Decrement selected parameter value; Hold F2 and momentarily press F1 key to decrement next decade or D key to decrement by 1000's

DISPLAY LINE 1


Line 1 is the large, 6-digit top line display. Values such as, Input, Gross, Tare, Max(HI), Min(LO), Total and setpoints, can be shown on Line 1. The 3-digit Units mnemonic characters can be used to indicate which Line 1 display value is shown. Standard or custom mnemonics are available for the Line 1 values. See Line 1 parameters in the Display Parameters programming section for configuration details.

DISPLAY LINE 2

Line 2 is the smaller, 9-digit bottom line display. Values such as Input, Gross, Tare, Max(HI), Min(LO), Total, setpoints, and parameter List A/B status can all be shown on the Line 2 display. The display loops described below are used to view, reset and modify the selected display values, based on the Line 2 Value Access setting programmed for each available value. See Line 2 parameters in the Display Parameters programming section for configuration details.

LINE 2 DISPLAY LOOPS

The DP63100-S offers three display loops to allow users quick access to needed information.



Main Display Loop

In the Main display loop, the D key is pressed to sequence through the selected Line 2 values. A left justified 2, 3 or 4-character mnemonic indicates which Line 2 value is currently shown. When in the Main display loop, the Function keys F1 and F2 perform the user functions programmed in the User Input parameter section.

Parameter and Hidden Parameter Display Loops

Display loops provide quick access to selected parameters that can be viewed and modified on Line 2 without having to enter Full Programming mode. These values include Parameter List A/B selection, setpoints, and display (color, intensity and contrast) settings. To utilize the Parameter or Hidden Parameter display loops, a security code (1-250) must be programmed. (See Programming Security Code in the Display Parameters programming section for details.)

The Parameter display loop is accessed by pressing the P key. The selected Parameter display loop values can be viewed and/or changed per the Line 2 Value Access setting programmed for each available value. The Hidden Parameter display loop follows the Parameter display loop, and can only be accessed when the correct security code is entered at the Code prompt. Combining the two parameter loops provides an area for parameters that require general access and/or protected or secure access depending on the application needs.

While in the Parameter and Hidden Parameter loops, pressing the D key will return the meter to the Main display loop. To directly access the Code prompt, press and hold the P key. This can be done from the Main display loop or at any point during the Parameter display loop. Also, to directly access Full Programming mode while in the Hidden Parameter loop, press and hold the P key to bypass any remaining Hidden Parameter loop values.

6.0 PROGRAMMING THE DP63100-S

It is recommended that program settings be recorded as programming is performed. A blank Parameter Value Chart is provided at the end of this bulletin.

PROGRAMMING MODE ENTRY

The Programming Mode is entered by pressing the **P** key. Full Programming Mode will be accessible unless the meter is programmed to use the Parameter loop or Hidden Parameter display loop on the Line 2 display. In this case, programming access will be limited by a security code and/or a hardware program lock. (Refer to the previous section for details on Line 2 display loops and limited programming access.) Full Programming Mode permits all parameters to be viewed and modified. In this mode, the front panel keys change to Programming Mode Operations and certain user input functions are disabled.

MODULE ENTRY

The Programming Menu is organized into five modules. These modules group together parameters that are related in function. The **F1** and **F2** keys are used to select the desired module. The displayed module is entered by pressing the **P** key.

MODULE MENU

Upon entering a module, a parameter selection sub-menu is provided to choose the specific parameter type for programming. For example, this includes analog and user input under the Input Parameter menu. Use the **F1** and **F2** keys to select the desired parameter type, and press the **P** key to enter the parameter menu.

PARAMETER MENU

Upon entering the Parameter Menu, the **P** key is pressed to advance to a specific parameter to be changed. After completing the parameter menu, or upon pressing the **D** key, the display returns to the initial entry point for the parameter menu. For each additional press of the **D** key, the display returns to the previous level within the module until exiting the module entirely.

SELECTION/VALUE ENTRY

For each parameter, the top line display shows the parameter while the bottom line shows the selections/value for that parameter. The **F1** and **F2** keys are used to move through the selections/values for the parameter. Pressing the **P** key, stores and activates the displayed selection/value. This also advances the meter to the next parameter.

Numerical Value Entry

If the parameter is programmed for enter (Enter), the **F1** and **F2** keys are used to change the parameter values in any of the display loops.

The **F1** and **F2** keys will increment or decrement the parameter value. When the **F1** or **F2** key is pressed and held, the value automatically scrolls. The longer the key is held the faster the value scrolls.

For large value changes, press and hold the **F1** or **F2** key. While holding that key, momentarily press the opposite arrow key (**F2** or **F1**) to shift decades (10's 100's, etc), or momentarily press the **D** key and the value scrolls by 1000's as the arrow key is held. Releasing the arrow key removes the decade or 1000's scroll feature. The arrow keys can then be used to make small value changes as described above.

PROGRAMMING MODE EXIT

To exit the Programming Mode, press and hold the **D** key (from anywhere in the Programming Mode) or press the **P** key with **Pro NO** displayed. This will commit any stored parameter changes to memory and return the meter to the Display Mode. If a parameter was just changed, the **P** key must be pressed to store the change before pressing the **D** key. (If power loss occurs before returning to the Display Mode, verify recent parameter changes.)

PROGRAMMING TIPS

It is recommended to start with the Input Parameters and proceed through each module in sequence. If lost or confused while programming, press and hold the **D** key to exit programming mode and start over. It is recommended that program settings be recorded as programming is performed. When programming is complete lock out programming with a user input or lock-out code.


Factory Settings may be completely restored in the Factory Service Operations module. This is useful when encountering programming problems.

In Programming Menu:

* - Top line is green to indicate top level programming modules

** - Top line is orange to indicate module menu or sub-menu selection

*** - Top line is red to indicate a changeable parameter.



INPUT PARAMETERS (INPUT)

INPUT SELECT




ANALOG USER

Select the Input to be programmed.

ANALOG INPUT PARAMETERS (ANALOG)

This section details the programming for the analog input.



INPUT RANGE



0.024u 0.24u

Select the desired input range.

INPUT UPDATE RATE (/SEC)



5 10 20
40 80 160

Select the ADC conversion rate (conversions per second). The selection does not affect the display update rate, however it does affect setpoint and analog output response time. The default factory setting of 5 is recommended for most applications. Selecting a fast update rate may cause the display to appear very unstable.

DECIMAL RESOLUTION (Display Units)



0 0.00 0.0000
0.0 0.000

Select desired display resolution.

ROUNDING INCREMENT



1 2 5
10 20 50 100

Rounding selections other than one, cause the Input Display to 'round' to the nearest rounding increment selected (ie. rounding of '5' causes 122 to round to 120 and 123 to round to 125). Rounding starts at the least significant digit of the Input Display. Remaining parameter entries (scaling point values, setpoint values, etc.) are not automatically adjusted to this display rounding selection.

DISPLAY TARE (Offset) Value



- 19999 to 99999

The Display Tare(offset) Value is the difference between the Gross (absolute) Display value and the Relative (net) Display value for the same input level. The meter will automatically update this value after each Zero Display. The Display Tare Value can be directly keyed-in to intentionally add or remove display offset. See Relative/Gross Display and Zero Display explanations in the Input Parameters - User Input Module.

DIGITAL FILTERING



0.00 to 25.00 seconds

The input filter setting is a time constant expressed in hundredths of a second. The filter settles to 99% of the final display value within approximately 3 time constants. This is an Adaptive Digital Filter which is designed to steady the Input Display reading. A value of '0' disables filtering.

FILTER BAND



0 to 2500 display units

The digital filter will adapt to variations in the input signal. When the variation exceeds the input filter band value, the digital filter disengages. When the variation becomes less than the band value, the filter engages again. This allows for a stable readout, but permits the display to settle rapidly after a large process change. The value of the band is in display units. A band setting of '0' keeps the digital filter permanently engaged.

SCALING POINTS



2 to 16

Linear - Scaling Points (2)

For linear processes, only 2 scaling points are necessary. It is recommended that the 2 scaling points be at opposite ends of the input signal being applied. The points do not have to be the signal limits. Display scaling will be linear between and continue past the entered points up to the limits of the Input Signal Jumper position. Each scaling point has a coordinate-pair of Input Value (INPUT n) and an associated desired Display Value (DISPLAY n).

Nonlinear - Scaling Points (Greater than 2)

For non-linear processes, up to 16 scaling points may be used to provide a piece-wise linear approximation. (The greater the number of scaling points used, the greater the conformity accuracy.) The Input Display will be linear between scaling points that are sequential in program order. Each scaling point has a coordinate-pair of Input Value (INPUT n) and an associated desired Display Value (DISPLAY n). Data from tables or equations, or empirical data can be used to derive the required number of segments and data values for the coordinate pairs. Several linearization equations are available within DP6-SOFT software.

SCALING STYLE



KEY key-in data
APPLY apply signal

If Input Values and corresponding Display Values are known, the Key-in (**KEY**) scaling style can be used. This allows scaling without the presence of the input signal. If Input Values have to be derived from the actual input signal source or simulator, the Apply (**APPLY**) scaling style must be used.

INPUT VALUE FOR SCALING POINT 1



- 199999 to 999999

For Key-in (**KEY**), enter the known first Input Value by using the **F1** or **F2** arrow keys. (The Input Range selection sets up the decimal location for the Input Value). For Apply (**APPLY**), the existing programmed value will appear. If this is acceptable, press the **P** key to save and continue to the next parameter. To update this value, apply the input signal that corresponds to Scaling Point 1, press **F2** key and the actual signal value will be displayed. Then press the **P** key to accept this value and continue to the next parameter.

DISPLAY VALUE FOR SCALING POINT 1



- 199999 to 999999

Enter the first coordinating Display Value by using the arrow keys. This is the same for **KEY** and **APPLY** scaling styles. The decimal point corresponds to the **DECIMAL** selection.

INPUT VALUE FOR SCALING POINT 2



- 199999 to 999999

For Key-in (**KEY**), enter the known second Input Value by using the **F1** or **F2** arrow keys. For Apply (**APPLY**), the existing programmed value will appear. If this is acceptable, press the **P** key to save and continue to the next parameter. To update this value, apply the input signal that corresponds to Scaling Point 2, press **F2** key and the actual signal value will be displayed. Then press the **P** key to accept this value and continue to the next parameter. (Follow the same procedure if using more than 2 scaling points.)

DISPLAY VALUE FOR SCALING POINT 2



- 199999 to 999999

Enter the second coordinating Display Value by using the **F1** or **F2** arrow keys. This is the same for **KEY** and **APPLY** scaling styles. (Follow the same procedure if using more than 2 scaling points.)


USER INPUT / FUNCTION KEY PARAMETERS (USER)

This section details the programming for the rear terminal User Inputs and front panel Function Keys. Three user inputs are individually programmable to perform specific meter control functions. While in the Display Mode, the function is executed when the user input transitions to the active state. (Refer to the user input specifications for response times.) Certain User input functions are disabled in Programming Mode. Two front panel function keys, **F1** and **F2**, are also individually programmable to perform specific meter control functions. While in the Display Mode, the primary function is executed when the key is pressed. Holding the **F1** or **F2** function key for three seconds executes a secondary function. It is possible to program a secondary function without a primary function. The front panel key functions are disabled while in Programming Mode.

In most cases, if more than one user input and/or function key is programmed for the same function, the maintained (level trigger) actions will be performed while at least one of those user inputs or function keys are activated. The momentary (edge trigger) actions are performed every time any of those user inputs or function keys transition to the active state.

The List user function has a value assignment sublist, which appears when the **P** key is pressed and **L15t** is selected. The function will only be performed for the assignment values selected as **YES**. If a user input or function key is configured for a function with a sublist, then that sublist will need to be scrolled through each time to access the remaining user inputs or function keys following the sublist.

Note: In the following explanations, not all selections are available for both user inputs and front panel function keys. Displays are shown with each selection. Those selections showing both displays are available for both. If a display is not shown, it is not available for that selection. In the parameter explanations, **USER-n** represents all user inputs. **Fn** represents both function keys and second function keys.



USER INPUT ACTIVE STATE



L0 HI

Select the desired active state for the User Inputs. Select **L0** for sink input, active low. Select **HI** for source input, active high.

NO FUNCTION



No function is performed if activated. This is the factory setting for all user inputs and function keys.

PROGRAMMING MODE LOCK-OUT

Programming Mode is locked-out, as long as activated (maintained action). A security code can be configured to allow programming access during lock-out.

ZERO (TARE) DISPLAY

The Zero (Tare) Display provides a way to zero the Input Display value at various input levels, causing future relative input display readings to be offset. This function is useful in weighing applications where the container or material on the scale should not be included in the next measurement value. When activated (momentary action), *rESEt* flashes and the Display is set to zero. At the same time, the Display value (that was on the display before the Zero Display) is subtracted from the Display Tare Value and is automatically stored as the new Display Tare Value. If another Zero (tare) Display is performed, the display again changes to zero and the Display Tare Value shifts accordingly.

RESET TARE VALUE

The Reset Tare provides a way to zero the Display Tare (offset) value, eliminating the Tare (offset) from the relative display. When activated (momentary action), *rESEt* flashes and the Display Tare value is set to zero. Following a Reset Tare, the Input display (relative) value will match the Gross (absolute).

RELATIVE/GROSS (ABSOLUTE) VALUE

This function will switch the Input Display between Relative and Gross (Absolute) value. The Relative is a net value that includes the Display Tare (Offset) Value. The Input Display will show the Relative unless switched by this function. The Gross is an absolute value (based on Input (Analog) Module *dSP* and *!AP* entries) without the Display Tare (Offset) Value. The Gross value is selected as long as the user input is activated (maintained action) or at the transition of the function key (momentary action). When the user input is released, or the function key is pressed again, the input display switches back to Relative value. *Gross* (gross) or *rEL* (relative) is momentarily displayed at transition to indicate which value is being displayed.

HOLD DISPLAY

The active display is held but all other meter functions continue as long as activated (maintained action).

HOLD ALL FUNCTIONS

The meter disables processing the input, holds all display contents, and locks the state of all outputs as long as activated (maintained action). The serial port continues data transfer.

SYNCHRONIZE METER READING

The meter suspends all functions as long as activated (maintained action). When the user input is released, the meter synchronizes the restart of the A/D converter input sampling with other processes or timing events.

STORE BATCH READING IN TOTALIZER

The Input Display value is added (batched) to the Totalizer when activated (momentary action) and the display flashes *bAtch*. The Totalizer retains a running sum of each batch operation until the Totalizer is reset. When this function is selected, the normal operation of the Totalizer is overridden and only batched Input Display values accumulate in the Totalizer.

SELECT TOTALIZER DISPLAY

The Totalizer appears on Line 2 as long as activated (maintained action). When the user input is released, the previously selected display is returned. The **D** or **P** keys override and disable the active user input. The Totalizer continues to function including associated outputs independent of the selected display.

RESET TOTALIZER

When activated (momentary action), *rESEt* flashes and the Totalizer resets to zero. The Totalizer then continues to operate as it is configured. This selection functions independent of the selected display.

RESET AND ENABLE TOTALIZER

When activated (momentary action), *rESEt* flashes and the Totalizer resets to zero. The Totalizer continues to operate while active (maintained action). When the user input is released, the Totalizer stops and holds its value. This selection functions independent of the selected display.

ENABLE TOTALIZER

The Totalizer continues to operate while active (maintained action). When the user input is released, the Totalizer stops and holds its value. This selection functions independent of the selected display.

SELECT MAXIMUM DISPLAY

The Maximum display appears on Line 2 as long as activated (maintained). When the user input is released, the previously selected display is returned. The **D** or **P** keys override and disable the active user input. The Maximum continues to function independent of the selected display.

RESET MAXIMUM DISPLAY

When activated (momentary action), *rESEt* flashes and the Maximum resets to the present Input Display value. The Maximum function then continues from that value. This selection functions independent of the selected display.

SELECT MINIMUM DISPLAY

The Minimum display appears on Line 2 as long as activated (maintained). When the user input is released, the previously selected display is returned. The **D** or **P** keys override and disable the active user input. The Minimum continues to function independent of the selected display.

RESET MINIMUM DISPLAY

USER-n FNE
r-L0

Fn FNE
r-L0

When activated (momentary action), *rESEt* flashes and the Minimum resets to the present Input Display value. The Minimum function then continues from that value. This selection functions independent of the selected display.

RESET MAXIMUM AND MINIMUM DISPLAY

USER-n FNE
r-HL

Fn FNE
r-HL

When activated (momentary action), *rESEt* flashes and the Maximum and Minimum readings are set to the present Input Display value. The Maximum and Minimum function then continues from that value. This selection functions independent of the selected display.

SELECT LINE 1 DISPLAY

USER-n FNE
SEL L1

Fn FNE
SEL L1

When activated (momentary action), the display advances to the next Line 1 display that has been made available (in the Display Module, Line 1/Select sub-menu).

SELECT LINE 2 DISPLAY

USER-n FNE
SEL L2

Fn FNE
SEL L2

When activated (momentary action), the display advances to the next Line 2 display that has been made available (in the Display Module, Line 2/Access sub-menu).

ADJUST DISPLAY INTENSITY

USER-n FNE
d-LEU

Fn FNE
d-LEU

When activated (momentary action), the display intensity changes to the next intensity level.

CHANGE DISPLAY COLOR

USER-n FNE
Co lor

When activated (momentary action), Line 1 will change color green to red, red to orange, orange to green.

SELECT PARAMETER LIST

USER-n FNE
L1St

Fn FNE
L1St

Two lists of values are available to allow the user to either switch between two sets of setpoints, or setpoints and scaling parameters and/or Line 1 & 2 mnemonics (if enabled).

The two lists are named *L1St-A* and *L1St-b*. If a user input is used to select the list then *L1St-A* is selected when the user input is not active and *L1St-b* is selected when the user input is active (maintained action). If a front panel key is used to select the list then the list will toggle for each key press (momentary action). The display will indicate which list is active when the list is changed, at power-up, and when entering the Parameter loop (if enabled) or Programming menus.

To program the values for *L1St-A* and *L1St-b*, first complete the programming of all the parameters. Exit programming and switch to the other list. Re-enter programming and enter the desired values for various parameters included in the list.

Two sub-menus are used to select whether scaling parameters and the custom units mnemonics are included in the list function. When the *ScL1St* sub-menu is selected as *YES*, the following parameters are also included in the A/B parameter lists:

Scaling Points 1-16
Input Decimal Point
Input Filter Band
Input Rounding Factor
Totalizer Scale Factor
Totalizer Decimal point

When the list is changed, the Offset (tare) value and internal Auto-zero buffer value (if Number of scaling points = 2) are also converted to the new units.

When the *Units* sub-menu is selected as *YES*, the Custom Units mnemonics are included in A/B parameter list. Using the *L1St* function and enabling *ScL1St* & *Units* provides the ability to use the DP63100-S meter to read-out and display in 2 different engineering units (i.e., pounds and kilograms).

SUB-MENU	DESCRIPTION	FACTORY
<i>ScL1St</i>	Include Scaling Parameters	<i>NO</i>
<i>Units</i>	Include Units mnemonics	<i>NO</i>

SETPOINT SELECTIONS

USER-n FNE
r-n

Fn FNE
r-n

<i>r-1-</i>	Reset Setpoint 1 (Alarm 1)
<i>r-2-</i>	Reset Setpoint 2 (Alarm 2)
<i>r-3-</i>	Reset Setpoint 3 (Alarm 3)
<i>r-4-</i>	Reset Setpoint 4 (Alarm 4)
<i>r-34-</i>	Reset Setpoint 3 & 4 (Alarm 3 & 4)
<i>r-234-</i>	Reset Setpoint 2, 3 & 4 (Alarm 2, 3 & 4)
<i>r-ALL-</i>	Reset All Setpoints (Alarms 1-4)

PRINT REQUEST

USER-n FNE
Pr int

Fn FNE
Pr int

The meter issues a block print through the serial port when activated, and the serial type is set to *rLC*. The data transmitted during a print request and the serial type is programmed in Port (Serial) module. If the user input is still active after the transmission is complete (about 100 msec), an additional transmission occurs. As long as the user input is held active, continuous transmissions occur.

OUTPUT PARAMETERS (OUTPUT)

OUTPUT SELECT




SETPOINT ANALOG

Select the Setpoint or Analog output to be programmed. The Analog output selection only appears if an analog output plug-in card is installed in the meter.

SETPOINT OUTPUT PARAMETERS (SETPOINT)

This section details the programming for the setpoints. To have output capabilities, a setpoint Plug-in card needs to be installed into the DP63100-S. Depending on the card installed, there will be two or four setpoint outputs available. If no output card is installed, programming for the setpoints is still available. An Exchange Parameter Lists feature for setpoint values is explained in User Input programming.

The Setpoint Assignment and Setpoint Output Action determine certain setpoint feature availability. The Setpoint Parameter Availability chart illustrates this.



SETPOINT SELECT



51 52 53 54

Select the Setpoint output to be programmed. The “5n” in the following parameters will reflect the chosen setpoint number. After the chosen setpoint is completely programmed, the display returns to the Setpoint Select menu. Repeat steps for each setpoint to be programmed.

The number of outputs available is setpoint output card dependent (2 or 4). If no output card is installed, programming is still available for all 4 setpoints. This allows the Line 1 color change feature to provide a visual indication when a setpoint value has been reached, even if no setpoint output is being used.

SETPOINT ASSIGNMENT



NONE REL GROSS TOTAL

Selects the meter value to be used to trigger the Setpoint Alarm. The REL setting will cause the setpoint to trigger off of the relative (net) input value. The relative input value is the absolute input value plus the Display Tare (Offset) Value. The GROSS setting will cause the setpoint to trigger off of the gross (absolute) input value. The gross input value is based on the Input (Analog) module dSP and IAP entries.

SETPOINT ACTION



NO AB-HI AB-LO AU-HI
AU-LO DE-HI DE-LO BAND
BANDI LOTO LOTH

Enter the action for the selected setpoint (alarm output). See Setpoint Alarm Figures for a visual detail of each action. The Setpoint Actions that pertain to the total is only active when the Setpoint Assignment is set to TOTAL.

- NO = No Setpoint Action
- AB-HI = Absolute high, with balanced hysteresis
- AB-LO = Absolute low, with balanced hysteresis
- AU-HI = Absolute high, with unbalanced hysteresis
- AU-LO = Absolute low, with unbalanced hysteresis

- DE-HI = deviation high, with unbalanced hysteresis
- DE-LO = deviation low, with unbalanced hysteresis
- BAND = Outside band, with unbalanced hysteresis
- BANDI = Inside band, with unbalanced hysteresis
- LOTO = Lower 6 digits of 9 digit Totalizer, with unbalanced hysteresis
- LOTH = Upper 6 digits of 9 digit Totalizer, with unbalanced hysteresis


SETPOINT VALUE



- 100000 to 999999

Enter desired setpoint alarm value. Setpoint values can also be entered in the Display Mode during Program Lockout when the setpoint is programmed as Enter in the Display (Line 2) Access parameters. The decimal point position is determined by the Setpoint Assignment value.

BAND/DEVIATION VALUE



- 100000 to 999999

This parameter is only available in band and deviation setpoint actions. Enter desired setpoint band or deviation value. When the Setpoint Action is programmed for Band, this value can only be a positive value.

HYSTERESIS VALUE




1 to 65000

Enter desired hysteresis value. See Setpoint Alarm Figures for visual explanation of how setpoint alarm actions (balanced and unbalanced) are affected by the hysteresis. When the setpoint is a control output, usually balanced hysteresis is used. For alarm applications, usually unbalanced hysteresis is used. For unbalanced hysteresis modes, the hysteresis functions on the low side for high acting setpoints and functions on the high side for low acting setpoints. Note: Hysteresis eliminates output chatter at the switch point, while time delay can be used to prevent false triggering during process transient events.

Setpoint Alarm Figures

With reverse output logic rEu , the below alarm states are opposite.



ON TIME DELAY

ON 5n
0.0

0.0 to 3275.0 seconds

Enter the time value in seconds that the alarm is delayed from turning on after the trigger point is reached. A value of 0.0 allows the meter to update the alarm status per the response time listed in the Specifications. When the output logic is rEu , this becomes off time delay. Any time accumulated at power-off resets during power-up.

OFF TIME DELAY

OFF 5n
0.0

0.0 to 3275.0 seconds

Enter the time value in seconds that the alarm is delayed from turning off after the trigger point is reached. A value of 0.0 allows the meter to update the alarm status per the response time listed in the Specifications. When the output logic is rEu , this becomes on time delay. Any time accumulated at power-off resets during power-up.

OUTPUT LOGIC

LOGIC 5n
nor

nor rEu

Enter the output logic of the alarm output. The **nor** logic leaves the output operation as normal. The rEu logic reverses the output logic. In rEu , the alarm states in the Setpoint Alarm Figures are reversed.

RESET ACTION

RESET 5n
Auto

Auto Latch1 Latch2

Enter the reset action of the alarm output.

Auto = Automatic action; This action allows the alarm output to automatically reset at the trigger points per the Setpoint Action shown in Setpoint Alarm Figures. The "on" alarm may be manually reset immediately by a front panel function key or user input. The alarm remains reset until the trigger point is crossed again.

Latch1 = Latch with immediate reset action; This selection latches the alarm output on at the trigger point per the Setpoint Action shown in Setpoint Alarm Figures. Latch means that the alarm output can only be turned off by front panel function key or user input manual reset, serial reset command or meter power cycle. When the user input or function key is activated (momentary or maintained), the corresponding "on" alarm output is reset immediately and remains off until the trigger point is crossed again. (Previously latched alarms will be off if power up Display Value is lower than setpoint value.)

Latch2 = Latch with delay reset action; This selection latches the alarm output on at the trigger point per the Setpoint Action shown in Setpoint Alarm Figures. Latch means that the alarm output can only be turned off by front panel function key or user input manual reset, serial reset command or meter power cycle. When the user input or function key is activated (momentary or maintained), the meter delays the reset event until the corresponding "on" alarm output crosses the trigger off point. (Previously latched alarms are off if power up Display Value is lower than setpoint value. During a power cycle, the meter erases a previous Latch 2 reset if it is not activated at power up.)

SETPOINT STANDBY OPERATION

Standby 5n
no

no YES

When **YES**, the alarm is disabled (at power up) until the trigger point is crossed.

SETPOINT ANNUNCIATOR

Annun ^{Sn}
nor

nor rEu FLASH OFF

The *nor* mode displays the corresponding setpoint annunciators of “on” alarm outputs. The *rEu* mode displays the corresponding setpoint annunciators of “off” alarms outputs. The *FLASH* mode flashes the corresponding setpoint annunciators of “on” alarm outputs. The *OFF* mode disables display setpoint annunciators.

LINE 1 CHANGE COLOR

Color ^{Sn}
no CHG


no CHG GREEN ORANGE red
brnOrb redOrb redbrn LINE 1

This parameter allows the Line 1 Display to change color, or alternate between two colors, when the alarm is activated. When multiple alarms are programmed to change color, the highest numbered active alarm (S4-S1) determines the display color.

The *no CHG* selection will maintain the color displayed prior to the alarm activation. The *LINE 1* selection sets the display to the Display (Line 1) Color (*Color*).

ANALOG OUTPUT PARAMETERS (ANALOG)

This section is only accessible with the optional LDP6-CDL Analog card installed.



ANALOG OUTPUT TYPE

TYPE ^{RnL}
4-20

4-20 0-10 0-20

Enter the analog output type. For 0-20 mA or 4-20 mA use terminals 18 and 19. For 0-10 V use terminals 16 and 17. Only one range can be used at a time.

ANALOG LOW SCALE VALUE

ANALOG ^{LO}
0

- 199999 to 999999

Enter the Display Value that corresponds to 0 mA (0-20 mA) , 4 mA (4-20 mA) or 0 VDC (0-10 VDC).

ANALOG OUTPUT ASSIGNMENT

ASSIGN ^{RnL}
none

none rEL 6r055 t0tAL HI
LO 51 52 53 54

Enter the source for the analog output to retransmit:

none = Manual Mode operation. (See Serial RLC Protocol in the Communications Port module).

rEL = Relative (net) Input Value. The Relative Input Value is the Gross (Absolute) Input Value that includes the Display Tare (Offset) Value.

6r055 = Gross (Absolute) Input Value. The Gross Input Value is based on the Input (Analog) module *d5P* and *i nP* entries.

t0tAL = Totalizer Value

HI = Maximum Display Value

LO = Minimum Display Value

51-54 = Setpoint Values

ANALOG HIGH SCALE VALUE

ANALOG ^{HI}
10000

- 199999 to 999999

Enter the Display Value that corresponds to 20 mA (0-20 mA) , 20 mA (4-20 mA) or 10 VDC (0-10 VDC).

ANALOG UPDATE TIME

UPDATE ^{RnL}
0.0

0.0 to 10.0

Enter the analog output update rate in seconds. A value of 0.0 allows the meter to update the analog output at the ADC Conversion Rate.

DISPLAY PARAMETERS (d SPLY)

DISPLAY SELECT



LINE 1 LINE 2 SEcNdry tOtAL


Select the Display to be programmed.

LINE 1 PARAMETERS (LINE 1)

This section details programming for the Line 1 (Top Line) Display. The Input, Gross, Tare, Total, Maximum (HI) and Minimum (LO) capture values and setpoints can be shown on the Line 1 display. The 3-digit Units mnemonic characters can be used to indicate which Line 1 display value is shown. Standard mnemonics are available for Setpoints 1-4. Standard or custom mnemonics are available for all other Line 1 values.

Main Display Loop

In the Main display loop, the selected values can be consecutively read on Line 1 by activating a user input or function key programmed as SEL L1. Each time the user input/function key is activated, Line 1 display will change to the next enabled Line 1 display value. Line 1 can also be programmed for Scroll, which will cause Line 1 to automatically scroll through all of the selected Line 1 display values.



LINE 1 DISPLAY COLOR



GREEN RED ORANGE

Enter the desired Display Line 1 and programmable Units Display color.

LINE 1 DISPLAY SCROLL ENABLE/TIME



NO 1 to 15 seconds

If Line 1 Display Scrolling is desired, set the scroll time in seconds.

DISPLAY INTENSITY LEVEL



0 to 4

Enter the desired Display Intensity Level (0-4) by using the arrow keys. The display will actively dim or brighten as the levels are changed. This parameter can also be accessed in the Parameter display loop when enabled.

DISPLAY CONTRAST LEVEL



0 to 15

Enter the desired Display Contrast Level (0-15) by using the arrow keys. The display contrast / viewing angle will actively adjust up or down as the levels are changed. This parameter can also be accessed in the Parameter display loop when enabled.

LINE 1 UNITS MNEMONIC(S)



OFF LABEL CUSTOM FACT

Select the mode for Line 1 Units Mnemonic(s). See LINE 1 UNITS MNEMONIC DIAGRAM for programming details.

SELECTION	MODE	DESCRIPTION
OFF	OFF	No Line 1 mnemonic shown.
LAbEL	LABEL	Single programmable mnemonic shown for all Line 1 values.
CUSt	CUSTOM	Custom programmable mnemonics shown for each Line 1 value.
FAcT	FACTORY	Factory default mnemonics shown for each Line 1 value.

The characters available for the programmable modes include:

A B C D E F G H I J K L M N O P Q R S T U V W X Y Z 0 1 2 3 4 5 6 7 8 9 a b c d e f g h i j k l m n o p q r s t u v w x y z . - [] ' " , blank


Two character spaces are required to display this character.

LINE 1 DISPLAY VALUE SELECT/ENABLE



Enter YES to select which values will be shown on the Line 1 display. A sub-menu provides Yes/No selection for each available Line 1 value. Values set to YES in the sub-menu will be displayable on Line 1.

DISPLAY	DESCRIPTION	FACTORY
INPUT	Input	YES
GROSS	Gross (absolute)	NO
TARE	Tare	NO
TOTAL	Total	NO
HI	Max value	NO
LO	Min value	NO
S1	Setpoint 1	NO
S2	Setpoint 2	NO
S3	Setpoint 3	NO
S4	Setpoint 4	NO



LINE 2 PARAMETERS (LINE 2)

This section details programming for the Line 2 (Bottom Line) Display. The Input, Gross, Tare, Total, Max, Min, Setpoint, Band/Deviation values and Parameter List A/B status can be shown on the Line 2 display. The display loops described below are used to view, reset and modify the selected display values, based on the Line 2 Value Access setting programmed for each available value.


Main Display Loop

In the Main display loop, the selected values can be consecutively read on Line 2 by pressing the **D** key. A left justified 2, 3 or 4-character mnemonic indicates which Line 2 value is currently shown. When in the Main display loop, the Function keys **F1** and **F2** perform the User functions programmed in the User Input program section.

Parameter Display Loop and Hidden Parameter Loop

These display loops provide quick access to selected parameters that can be viewed and modified on Line 2 without having to enter Full Programming Mode. These values include Parameter List A/B selection, Setpoints and Display Settings (color, intensity and contrast). To utilize the Parameter or Hidden Parameter display loops, a security code (1-250) must be programmed. (See Programming Security Code at the end of this section.)

The Parameter display loop is accessed by pressing the **P** key. The selected Parameter display loop values can be viewed and/or changed per the Line 2 Value Access setting programmed for each available value. The Hidden Parameter loop follows the Parameter display loop, and can only be accessed when the correct security code is entered at the Code prompt.



LINE 2 VALUE ACCESS



Select **9E5** to program the Value Access setting for each available Line 2 parameter. Line 2 values can be made accessible in either the Main (**D** key), Parameter (**P** key) or Hidden (**P** key following code entry) display loops. When the List parameter is configured for an **Enter** setting, a List assignment sub-menu will follow. Refer to Input module, User sub-menu section for a description of the function.

Each parameter must be configured for one of the following settings. Not all settings are available for each parameter, as shown in the Parameter Value Access table.

SELECTION	DESCRIPTION
L0C	Not viewed on Line 2 Display (Factory Default Setting)
d-rERd	View in Main display loop. Cannot change or reset.
d-rSt	View and reset in Main display loop.
d-Ent r	View and change in Main display loop
P-rERd	View in Parameter display loop. Cannot change or reset.
P-Ent r	View and change in Parameter display loop
H idE	View and change in Hidden Parameter display loop

LINE 2 FUNCTIONS ACCESS



Select **9E5** to display the following list of functions that can be made available at the end of the Parameter (**P-Ent r**) or Hidden (**H idE**) display loops. Each Line 2 Function can be programmed for **L0C**, **P-Ent r**, or **H idE**.

The more critical and frequently used functions should be first assigned to the User Inputs and User Function keys, however if more functions are needed than what can be obtained with user inputs and function keys, these will provide a means to provide that access. Refer to Input module, User sub-menu section for a description of the function.

SELECTION	DESCRIPTION
rEL	Zero (tare) display
r-tArE	Reset Display Tare (offset) value
bAt	Store batch reading in Totalizer
r-tot	Reset Totalizer
r-HI	Reset Maximum value
r-L0	Reset Minimum value
r-HL	Reset Max and Min values
r-i	Reset Setpoint output 1

LINE 2 PARAMETER VALUE ACCESS

DISPLAY	DESCRIPTION	NOT VIEWED	MAIN DISPLAY LOOP (D KEY)			PARAMETER DISPLAY LOOP (P KEY)		HIDDEN LOOP
		L0C	d-rERd	d-rSt	d-Ent r	P-rERd	P-Ent r	H idE
Input	Input	X	X	X				
Gross	Gross (absolute)	X	X					
Tare	Tare Value	X	X		X			
Total	Total	X	X	X				
Max	Max Value	X	X	X				
Min	Min Value	X	X	X				
List	Parameter List A/B	X	X		X	X	X	X
Sn	Setpoint Value (S1-S4) *	X	X		X	X	X	X
band	Band/Deviation	X	X		X	X	X	X
Color	Line 1 Display Color	X				X	X	X
Intensity	Display Intensity Level	X				X	X	X
Contrast	Display Contrast Level	X				X	X	X

* Indicates multiple value entries.

SELECTION	DESCRIPTION
r-2	Reset Setpoint output 2
r-3	Reset Setpoint output 3
r-4	Reset Setpoint output 4
r-34	Reset Setpoint outputs 3 & 4
r-234	Reset Setpoint outputs 2, 3 & 4
r-ALL	Reset all Setpoint outputs
Print	Print Request

LINE 2 DISPLAY SCROLL ENABLE/TIME



NO 1 to 15 seconds

If Line 2 Display Scrolling is desired, set the scroll time in seconds.

LINE 2 UNITS MNEMONIC(S)



OFF LABEL CUST FACT
Lb-FACT L1-FACT Lb-CST Lb Ln1

Select the mode for Line 2 Units Mnemonic(s). See LINE 2 UNITS MNEMONIC DIAGRAM for programming details.

SELECTION	MODE	DESCRIPTION
OFF	OFF	No Line 2 mnemonics shown.
LABEL	LABEL	Single programmable mnemonic shown as a separate item in the Line 2 Display loop. No individual mnemonics are shown with the other Line 2 Display values.
CUST	CUSTOM	Individual Custom programmable mnemonics shown with each value in the Line 2 Display loop.
FACT	FACTORY	Individual Factory default mnemonics shown with each value in the Line 2 Display loop.
Lb-CST	LABEL & CUSTOM	A programmable mnemonic shown as a separate item in the Line 2 Display loop. Also, individual Custom programmable mnemonics shown with each value in the Line 2 Display loop.
Lb-FACT	LABEL & FACTORY	A programmable mnemonic shown as a separate item in the Line 2 Display loop. Also, individual Factory default mnemonics shown with each value in the Line 2 Display loop.
Lb Ln1	LINE 1 INDEXED LABELS	Individual programmable mnemonics, indexed to the Line 1 Display value, are shown as a separate item in the Line 2 Display loop. These same mnemonics are also shown with each value in the Line 2 Display loop.
L1-FACT	LINE 1 INDEXED LABELS & FACTORY	Individual programmable mnemonics, indexed to the Line 1 Display value, are shown as a separate item in the Line 2 Display loop. Also, individual Factory default mnemonics are shown with each value in the Line 2 Display loop.

The characters available for the programmable modes include:

A B C D E F G H I J K L M N O P Q R S T U V W X Y Z 0 1
2 3 4 5 6 7 8 9 a b c d e f g h i j k l m n o p q r s t u v w x y z . blank

Two character spaces are required to display this character.

PROGRAMMING SECURITY CODE



000 to 250

To activate either the Parameter or Hidden Parameter display loops, a security code (1-250) must be entered. If a "0" security code is programmed, pressing the P key takes you directly to the Full Programming Mode.


The Security Code determines the programming mode and the accessibility of programming parameters. This code can be used along with the Program Mode Lock-out (PLDL) in the User Input Function parameter (Input [User] module).

Two programming modes are available. Full Programming Mode allows all parameters to be viewed and modified. Parameter display loop mode provides access to those selected parameters, that can be viewed and/or modified without entering the Full programming mode.


The following chart indicates the levels of access based on various Code and User Input PLDL settings.

SECURITY CODE	USER INPUT CONFIGURED	USER INPUT STATE	WHEN P KEY IS PRESSED	FULL PROGRAMMING MODE ACCESS
0	not PLDL	———	Full Programming	Immediate Access
0	PLDL	Not Active	Full Programming	Immediate Access
0	PLDL	Active	Enter Parameter Display Loop	No Access
>0	not PLDL	———	Enter Parameter Display Loop	After Parameter Display Loop with correct code # at Code prompt.
>0	PLDL	Not Active	Full Programming	Immediate Access
>0	PLDL	Active	Enter Parameter Display Loop	After Parameter Display Loop with correct code # at Code prompt.

LINE 2 UNITS MNEMONIC DIAGRAM (9-DIGITS)



SECONDARY FUNCTION PARAMETERS (Secondary)



MAX (HI) CAPTURE ASSIGNMENT

HI-ASN^{SEC} rEL 6r055

Select the desired input value that will be assigned to the Max Capture.

MAX (HI) CAPTURE DELAY TIME

HI-t^{SEC} 0.0 to 3275.0 seconds

When the Input value is above the present MAX value for the entered delay time, the meter will capture that value as the new MAX reading. A delay time helps to avoid false captures of sudden short spikes.

MIN (LO) CAPTURE ASSIGNMENT

LO-ASN^{SEC} rEL 6r055

Select the desired input value that will be assigned to the Min Capture.

MIN (LO) CAPTURE TIME

LO-t^{SEC} 0.0 to 3275.0 seconds

When the Input value is below the present MIN value for the entered delay time, the meter will capture that value as the new MIN reading. A delay time helps to avoid false captures of sudden short spikes.

DISPLAY UPDATE RATE

dSP-t^{SEC} 1 2 5 10 20 updates/second

This parameter configures the display update rate. It does not affect the response time of the setpoint output or analog output option cards.

AUTO-ZERO TRACKING TIME

At-t^{SEC} 0 to 250 seconds

To disable Auto-zero tracking, set this value to 0.

AUTO-ZERO TRACKING BAND

At-bnd^{SEC} 1 to 4095

The meter can be programmed to automatically compensate for zero drift. Drift may be caused by changes in the transducers or electronics, or accumulation of material on weight systems.

Auto-zero tracking operates when the readout remains within the tracking band for a period of time equal to the auto-zero tracking time. When these conditions are met, the meter re-zeroes the readout. After the re-zero operation, the meter resets and continues to auto-zero track.


The auto-zero tracking band should be set large enough to track normal zero drift, but small enough to not interfere with small process inputs.

For filling operations, the fill rate must exceed the auto-zero tracking rate. This avoids undesirable tracking at the start of the filling operation.

Fill Rate \geq $\frac{\text{tracking band}}{\text{tracking time}}$

Auto-zero tracking is disabled by setting the auto-zero tracking time parameter = 0.

TOTALIZER (INTEGRATOR) PARAMETERS (tOTAL)




The totalizer accumulates (integrates) the Relative Input Display value using one of two modes. The first is using a time base. This can be used to provide an indication of total flow, usage or consumption over time. The second is through a user input or function key programmed for Batch (one time add on demand). This can be used to provide a readout of total weight, useful in weight based filling operations. If the Totalizer is not needed, its display can be locked-out and this module can be skipped during programming.

TOTALIZER DECIMAL POINT



For most applications, this should match the Input Display Decimal Point (diSPLy). If a different location is desired, refer to Totalizer Scale Factor.

TOTALIZER TIME BASE



This is the time base used in Totalizer accumulations. If the Totalizer is being accumulated through a user input programmed for Batch, then this parameter does not apply.

TOTALIZER SCALE FACTOR




For most applications, the Totalizer reflects the same decimal point location and engineering units as the Input Display. In this case, the Totalizer Scale Factor is 1.000. The Totalizer Scale Factor can be used to scale the Totalizer to a value that is different than the Input Display. Common possibilities are:

1. Changing decimal point location (example tenths to whole)
2. Average over a controlled time frame.

Details on calculating the scale factor are shown later.

If the Totalizer is being accumulated through a user input programmed for Batch, then this parameter does not apply.

TOTALIZER LOW CUT VALUE



A low cut value disables Totalizer when the Input Display value falls below the value programmed.

TOTALIZER POWER UP RESET



The Totalizer can be reset to zero on each meter power-up by setting this parameter to 995.

TOTALIZER BATCHING

The Totalizer Time Base is overridden when a user input or function key is programmed for store batch (bAt). In this mode, when the user input or function key is activated, the Input Display reading is multiplied by the totalizer scale factor and then one time added to the Totalizer (batch). The Totalizer retains a running sum of each batch operation until the Totalizer is reset. This is useful in weighing operations, when the value to be added is not based on time but after a filling event.

TOTALIZER USING TIME BASE

Totalizer accumulates as defined by:

$$\text{Totalizer Scale Factor} = \frac{\text{Totalizer Display}^*}{\text{Input Display}^*}$$

*Value indicated with decimal and all display units after the decimal; Prior to calculating, "drop" the decimal leaving all trailing units.

Where:

Input Display = Fixed Input Display value.

Totalizer Display = Totalized value with Input Display constant during a period of time equal to the Totalizer Time Base.

Example: A DP63100-S is monitoring the total weight of material on a 20 ft conveyor. The conveyor operates at a constant rate of 1 ft/sec. The Totalizer will calculate the total weight of material output from the conveyor. Although the DP63100-S Input Display indicates lbs in whole units, the Totalizer will be programmed to display tons in 1/10 units. Note that this application requires a User Input to enable the Totalizer when the conveyor is running. Accuracy is dependent on the amount of material and position of material still on the conveyor. For accurate totalizer reading, the conveyor should be allowed to "empty" before taking a totalizer reading.

There are several factors to consider in this example. First, the material that clears the end of the conveyor in 1 second is only 1/20 of the weight being displayed at any given time (20 ft conveyor @ 1 ft/sec). Second, the Totalizer display is in tenths of tons, while the input is in pounds.

In order to calculate the Totalizer Scale Factor, choose a constant Input Display (100) value and then determine the Totalizer Display value that would result after the period of the Totalizer Time Base (1 hour) selected.

$$\frac{100 \text{ lb}}{20 \text{ sec}} = 5 \text{ lb/sec.} \rightarrow \text{With 100 lb on the conveyor, 5 lbs falls off the end of the conveyor each second.}$$

$$5 \text{ lb/sec} \times 3600 \text{ sec} = 18,000 \text{ lb} \rightarrow 3600 \text{ seconds of material passing the end of the conveyor in an hour.}$$

$$\frac{18,000 \text{ lb}}{2000 \text{ lb}} = 9.0 \text{ tons} \rightarrow \text{Conversion of lbs to tons.}$$

Conclusion: Input Display of 100 results in a Totalizer Display of 9.0 after 1 hour of constant and continuous operation. Place these values in the Totalizer Scale Factor formula as follows:

$$\text{Totalizer Scale Factor} = \text{Totalizer Display}^* / \text{Input Display}^*$$

$$\text{Totalizer Scale Factor} = 9.0/100$$

$$\text{Totalizer Scale Factor} = 90/100 \text{ **}$$

$$\text{Totalizer Scale Factor} = 0.9$$

* This value should include the decimal and all display units after the decimal.

** This step requires that the decimal be "dropped", but all other digits remain.

COMMUNICATIONS PORT PARAMETERS (Port)

To select *SErIAL*, an optional communication card must be installed.

PORT SELECT



USB

SErIAL

Select the Communications Port to be programmed.

USB PORT PARAMETERS (USB)

USB CONFIGURATION



AUTO

SErIAL


AUTO

Meter automatically configures USB port settings to operate with DP6-SOFT configuration software. When a USB cable is attached to DP63100-S and PC, the port is internally set to Modbus RTU protocol, 38400 baud, 8 bits, and Unit Address 247. The Serial Port settings programmed below will not change, or show this.

SErIAL

Configures USB port to utilize the Serial Port settings and protocol programmed below.

SERIAL PORT PARAMETERS (SErIAL)



COMMUNICATIONS TYPE



Modbus - Modbus RTU
Modbus - Modbus ASCII
RLC - RLC Protocol (ASCII)

Select the desired communications protocol. Modbus is preferred as it provides access to all meter values and parameters. Since the Modbus protocol is included within the DP63100-S, the Modbus option card, LDP6-CDC4, should not be used. The LDP6-CDC1 (RS485), or LDP6-CDC2 (RS232) card should be used instead.

PARITY BIT



no EVEN odd

Set the parity bit to match that of the other serial communications equipment on the serial link. The meter ignores the parity when receiving data and sets the parity bit for outgoing data. If no parity is selected with 7 bit word length, an additional stop bit is used to force the frame size to 10 bits. Parity is not available if *data* is set for 8 bit.

BAUD RATE



1200 4800 19200
2400 9600 38400

Set the baud rate to match the other serial communications equipment on the serial link. Normally, the baud rate is set to the highest value that all the serial equipment are capable of transmitting and receiving.


METER UNIT ADDRESS



1 to 247 - Modbus
0 to 99 - RLC Protocol

Select a Unit Address that does not match an address number of any other equipment on the serial link.

DATA BIT



7 8

Select either 7 or 8 bit data word lengths. Set the word length to match the other serial communications equipment on the serial link. For *Modbus* communication type, data bit setting is fixed at 8 bits.

TRANSMIT DELAY



0.000 to 0.250 seconds

Following a Modbus command or RLC Transmit Value command, the DP63100-S will wait this minimum amount of time in seconds before issuing a serial response

The following programming steps are only available when Communications Type (TYPE) is programmed for rLL.

ABBREVIATED PRINTING



NO YES

Select YES for full print or Command T transmissions (meter address, mnemonics and parameter data) or NO for abbreviated print transmissions (parameter data only). This will affect all the parameters selected in the print options. If the meter address is 00, it will not be sent during a full transmission.

PRINT OPTIONS



NO YES

YES - Enters the sub-menu to select the meter parameters to appear during a print request. For each parameter in the sub-menu, select YES for that parameter information to be sent during a print request or NO for that parameter information not to be sent. A print request is sometimes referred to as a block print because more than one parameter information (meter address, mnemonics and parameter data) can be sent to a printer or computer as a block.

DISPLAY	DESCRIPTION	FACTORY SETTING	MNEMONIC
INPUT	Signal Input	YES	INP
GROSS	Gross (absolute) Value	NO	GRS
TARE	Tare Value	NO	TAR
TOTAL	Total Value	NO	TOT
MAX MIN	Max & Min	NO	MAX, MIN
SPNT	Setpoint Values	NO	SP1-SP4

SERIAL COMMUNICATIONS

The DP63100-S supports serial communications using the optional serial communication cards or via the USB programming port located on the side of the unit. When USB is being used (connected), the serial communication card is disabled. When using the standard RS232 and RS485 option cards, the DP63100-S supports both the RLC protocol and Modbus communications. The LDP6-CDC4 Modbus option card should not be used with the DP63100-S, as the DP63100-S internal Modbus protocol supports complete unit configuration, and is much more responsive.

USB

The USB programming port is primarily intended to be used to configure the DP63100-S with the DP6-SOFT programming software. It can also be used as a virtual serial communications port following installation of the DP63100-S USB drivers that are supplied with the DP6-SOFT software. When the USB port is being used, i.e. the USB cable is connected between DP63100-S and PC, all serial communications with the serial option card (if used) is disabled.

USB Cable type required: USB A to Mini-B (not supplied)

DP63100-S CONFIGURATION USING DP6-SOFT AND USB

1. Install DP6-SOFT software.
2. Supply power to DP63100-S
3. Insure USB Configuration “CONF15” in USB Port Parameters is set to “AUT0” (factory default setting).
4. Attach USB cable (USB A to Mini-B) between PC and DP63100-S.
5. Create a new file (File, New) or open an existing DP63100-S database within DP6-SOFT.
6. Configure DP6-SOFT Link options (Link, Options) to the serial port which the USB cable is attached (in Step 4).

SERIAL MODBUS COMMUNICATIONS

Modbus Communications requires that the Serial Communication Type Parameter (TYPE) be set to “RTU” or “RS485”.

DP63100-S CONFIGURATION USING DP6-SOFT AND SERIAL COMMUNICATIONS CARD

1. Install DP6-SOFT software.
2. Install RS232 or RS485 card and connect communications cable from DP63100-S to PC.
3. Supply power to DP63100-S
4. Configure serial parameters (SERIAL) to Modbus RTU “RTU”, 38,400 baud, address 247.
5. Create a new file (File, New) or open an existing DP63100-S database within DP6-SOFT.
6. Configure DP6-SOFT Link options (Link, Options) to the serial port which the communication cable is attached (in step 2).

SUPPORTED FUNCTION CODES

FC03: Read Holding Registers

1. Up to 64 registers can be requested at one time.
2. HEX <8000> is returned for non-used registers.

FC04: Read Input Registers

1. Up to 64 registers can be requested at one time.
2. Block starting point can not exceed register boundaries.
3. HEX <8000> is returned in registers beyond the boundaries.
4. Input registers are a mirror of Holding registers.

FC06: Preset Single Register

1. HEX <8001> is echoed back when attempting to write to a read only register.
2. If the write value exceeds the register limit (see Register Table), then that register value changes to its high or low limit. It is also returned in the response.

FC16: Preset Multiple Registers

1. No response is given with an attempt to write to more than 64 registers at a time.
2. Block starting point cannot exceed the read and write boundaries (40001-41280).
3. If a multiple write includes read only registers, then only the write registers will change.
4. If the write value exceeds the register limit (see Register Table), then that register value changes to its high or low limit.

FC08: Diagnostics

The following is sent upon FC08 request:

Module Address, 08 (FC code), 04 (byte count), “Total Comms” 2 byte count, “Total Good Comms” 2 byte count, checksum of the string

“Total Comms” is the total number of messages received that were addressed to the DP63100-S. “Total Good Comms” is the total messages received by the DP63100-S with good address, parity and checksum. Both counters are reset to 0 upon response to FC08 and at power-up.

SUPPORTED EXCEPTION CODES

01: Illegal Function

Issued whenever the requested function is not implemented in the meter.

02: Illegal Data Address

Issued whenever an attempt is made to access a single register that does not exist (outside the implemented space) or to access a block of registers that falls completely outside the implemented space.

03: Illegal Data Value

Issued when an attempt is made to read or write more registers than the meter can handle in one request.

07: Negative Acknowledge

Issued when a write to a register is attempted with an invalid string length.

FREQUENTLY USED MODBUS REGISTER TABLE

Values less than 65,535 will be in (LO word). Values greater than 65,535 will continue into (Hi word). Negative values are represented by two's complement of the combined (Hi word) and (LO word).

Note 1: The DP63100-S should not be powered down while parameters are being changed. Doing so may corrupt the non-volatile memory resulting in checksum errors.

REGISTER ADDRESS	TABLE INDEX	REGISTER NAME	LOW LIMIT	HIGH LIMIT	FACTORY SETTING	ACCESS	COMMENTS
FREQUENTLY USED REGISTERS							
40001	0	Input Relative Value (Hi word)	-199999	999999	N/A	Read Only	Process value of present input level. This value is affected by Input Type, Resolution, Scaling, & Tare (Offset) Value. (Relative Value = Gross (Absolute) Input Value - Tare Value)
40002	1	Input Relative Value (Lo word)					
40003	2	Maximum Value (Hi word)	-199999	999999	N/A	Read/Write	Maximum Relative Input Capture Value obtained since having been reset.
40004	3	Maximum Value (Lo word)					
40005	4	Minimum Value (Hi word)	-199999	999999	N/A	Read/Write	Minimum Relative Input Capture Value obtained since having been reset.
40006	5	Minimum Value (Lo word)					
40007	6	Total Value (Hi word)	-199999	999999	0	Read/Write	Totalizer value
40008	7	Total Value (Lo word)					
40009	8	Setpoint 1 Value (Hi word)	-199999	999999	100	Read/Write	Active List (A or B)
40010	9	Setpoint 1 Value (Lo word)					
40011	10	Setpoint 2 Value (Hi word)	-199999	999999	200	Read/Write	Active List (A or B)
40012	11	Setpoint 2 Value (Lo word)					
40013	12	Setpoint 3 Value (Hi word)	-199999	999999	300	Read/Write	Active List (A or B)
40014	13	Setpoint 3 Value (Lo word)					
40015	14	Setpoint 4 Value (Hi word)	-199999	999999	400	Read/Write	Active List (A or B)
40016	15	Setpoint 4 Value (Lo word)					
40017	16	Setpoint 1 Band/Dev. Value (Hi word)	-199999	999999	0	Read/Write	Active List (A or B). Applicable only for Band or Deviation Setpoint Action.
40018	17	Setpoint 1 Band/Dev. Value (Lo word)					
40019	18	Setpoint 2 Band/Dev. Value (Hi word)	-199999	999999	0	Read/Write	Active List (A or B). Applicable only for Band or Deviation Setpoint Action.
40020	19	Setpoint 2 Band/Dev. Value (Lo word)					
40021	20	Setpoint 3 Band/Dev. Value (Hi word)	-199999	999999	0	Read/Write	Active List (A or B). Applicable only for Band or Deviation Setpoint Action.
40022	21	Setpoint 3 Band/Dev. Value (Lo word)					
40023	22	Setpoint 4 Band/Dev. Value (Hi word)	-199999	999999	0	Read/Write	Active List (A or B). Applicable only for Band or Deviation Setpoint Action.
40024	23	Setpoint 4 Band/Dev. Value (Lo word)					
40025	24	Setpoint Output Register (SOR)	0	15	0	Read/Write	Status of Setpoint Outputs. Bit State: 0 = Off, 1 = On. Bit 3 = SP1, Bit 2 = SP2, Bit 1 = SP3, Bit 0 = SP4. Outputs can only be activated/reset with this register when the respective bits in the Manual Mode Register (MMR) are set.
40026	25	Manual Mode Register (MMR)	0	31	0	Read/Write	Bit State: 0 = Auto Mode, 1 = Manual Mode Bit 4 = SP1, Bit 3 = SP2, Bit 2 = SP3, Bit 1 = SP4, Bit 0 = Linear Output
40027	26	Reset Output Register	0	15	0	Read/Write	Bit State: 1 = Reset Output, bit is returned to zero following reset processing; Bit 3 = SP1, Bit 2 = SP2, Bit 1 = SP3, Bit 0 = SP4
40028	27	Analog Output Register (AOR)	0	4095	0	Read/Write	Functional only if Linear Output is in Manual Mode. (MMR bit 0 = 1) Linear Output Card written to only if Linear Out (MMR bit 0) is set.
40029	28	Input Gross (Absolute) Value (Hi word)	-199999	999999	N/A	Read Only	Gross (absolute) value of present Input level. This value is affected by Input Type, Resolution, Scaling, but not affected by Offset Value
40030	29	Input Gross (Absolute) Value (Lo word)					
40031	30	Tare Value (Hi word)	-199999	999999	0	Read/Write	Relative Input Value (standard meter value) is the difference between the Gross (absolute) input value and the Tare value, i.e. Relative = Gross - Tare
40032	31	Tare Value (Lo word)					

SERIAL RLC PROTOCOL COMMUNICATIONS

RLC Communications requires the Serial Communications Type Parameter (TYPE) be set to "rLL".

SENDING SERIAL COMMANDS AND DATA TO THE METER

When sending commands to the meter, a string containing at least one command character must be constructed. A command string consists of a command character, a value identifier, numerical data (if writing data to the meter) followed by a command terminator character * or \$. The <CR> is also available as a terminator when Counter C is in the SLAVE mode.

Command Chart

COMMAND	DESCRIPTION	NOTES
N	Node (Meter) Address Specifier	Address a specific meter. Must be followed by a two digit node address. Not required when address = 00.
T	Transmit Value (read)	Read a register from the meter. Must be followed by register ID character
V	Value Change (write)	Write to register of the meter. Must be followed by register ID character and numeric data.
R	Reset	Reset a register or output. Must be followed by register ID character.
P	Block Print Request	Initiates a block print output. Registers are defined in programming.

Command String Construction

The command string must be constructed in a specific sequence. The meter does not respond with an error message to invalid commands. The following procedure details construction of a command string:

1. The first characters consist of the Node Address Specifier (N) followed by a 2 character address number. The address number of the meter is programmable. If the node address is 0, this command and the node address itself may be omitted. This is the only command that may be used in conjunction with other commands.
2. After the optional address specifier, the next character is the command character.
3. The next character is the Register ID. This identifies the register that the command affects. The P command does not require a Register ID character. It prints according to the selections made in print options.
4. If constructing a value change command (writing data), the numeric data is sent next.
5. All command strings must be terminated with the string termination characters *, \$ or when Counter C is set for slave mode <CR>. The meter does not begin processing the command string until this character is received. See Timing Diagram figure for differences between terminating characters.

Register Identification Chart

ID	VALUE DESCRIPTION	MNEMONIC	APPLICABLE COMMANDS/COMMENTS
A	Input (relative value)	INP	T, P, R (Reset command resets input to zero; tares)
B	Total	TOT	T, P, R (Reset command resets total to zero)
C	Max Input	MAX	T, P, R (Reset command resets Max to current reading)
D	Min Input	MIN	T, P, R (Reset command resets Min to current reading)
E	Setpoint 1	SP1	T, P, V, R (Reset command resets the setpoint output)
F	Setpoint 2	SP2	
G	Setpoint 3	SP3	
H	Setpoint 4	SP4	
I	Band/Deviation 1	BD1	T, V
J	Band/Deviation 2	BD2	T, V
K	Band/Deviation 3	BD3	T, V
L	Band/Deviation 4	BD4	T, V
M	Gross (Absolute) Input value	GRS	T, P
O	Tare (Offset) Value	TAR	T, P, R, V
U	Auto/Manual Register	MMR	T, V
W	Analog Output Register	AOR	T, V
X	Setpoint Register	SOR	T, V

Command String Examples:

1. Node address = 17, Write 350 to Setpoint 1.
String: N17VE350\$
2. Node address = 5, Read Input value.
String: N5TA*
3. Node address = 0, Reset Setpoint 4 output.
String: RH*

Sending Numeric Data

Numeric data sent to the meter must be limited to 6 digits (-199999 to 999999). Leading zeros are ignored. Negative numbers must have a minus sign. The meter ignores any decimal point and conforms the number to the scaled resolution. (For example: the meter's scaled decimal point position = 0.0 and 25 is written to a register. The value of the register is now 2.5.

Note: Since the meter does not issue a reply to value change commands, follow with a transmit value command for readback verification.

Analog Output Register (AOR) ID: W

This register stores the present signal value of the analog output. The range of values of this register is 0 to 4095, which corresponds to the analog output range per the following chart:

Register Value	Output Signal*		
	0-20 mA	4-20 mA	0-10 V
0	0.00	4.00	0.000
1	0.005	4.004	0.0025
2047	10.000	12.000	5.000
4094	19.995	19.996	9.9975
4095	20.000	20.000	10.000

**Due to the absolute accuracy rating and resolution of the output card, the actual output signal may differ 0.15% FS from the table values. The output signal corresponds to the range selected (0-20 mA, 4-20 mA or 0-10 V).*

Writing to this register (VW) while the analog output is in the Manual Mode causes the output signal level to update immediately to the value sent. While in the Automatic Mode, this register may be written to, but it has no effect until the analog output is placed in the manual mode. When in the Automatic Mode, the meter controls the analog output signal level. Reading from this register (TW) will show the present value of the analog output signal.

Example: VW2047 will result in an output of 10.000 mA, 12.000 mA or 5.000V depending on the range selected.

Setpoint Output Register (SOR) ID: X

This register stores the states of the setpoint outputs. Reading from this register (TX) will show the present state of all the setpoint outputs. A “0” in the setpoint location means the output is off and a “1” means the output is on.

X abcd

d = SP4
c = SP3
b = SP2
a = SP1

In Automatic Mode, the meter controls the setpoint output state. In Manual Mode, writing to this register (VX) will change the output state. Sending any character besides 0 or 1 in a field or if the corresponding output was not first in manual mode, the corresponding output value will not change. (It is not necessary to send least significant 0s.)

Example: VX10 will result in output 1 on and output 2 off.

- Auto/Manual Mode Register (MMR) ID: U

U abcde

- e = Analog Output
- d = SP4
- c = SP3
- b = SP2
- a = SP1

Example: VU00011 places SP4 and Analog in manual.

COMMAND RESPONSE TIME

The meter can only receive data or transmit data at any one time (half-duplex operation). When sending commands and data to the meter, a delay must be imposed before sending another command. This allows enough time for the meter to process the command and prepare for the next command.

At the start of the time interval t_1 , the computer program prints or writes the string to the com port, thus initiating a transmission. During t_1 , the command characters are under transmission and at the end of this period, the command terminating character (*) is received by the meter. The time duration of t_1 is dependent on the number of characters and baud rate of the channel.

$$t_1 = (10 * \# \text{ of characters}) / \text{baud rate}$$

At the start of time interval t_2 , the meter starts the interpretation of the command and when complete, performs the command function. This time interval t_2 varies from 2 msec to 15 msec. If no response from the meter is expected, the meter is ready to accept another command.

If the meter is to reply with data, the time interval t_2 is controlled by the use of the command terminating character and the Serial Transmit Delay parameter (*dELAY*). The standard command line terminating character is "*". This terminating character results in a response time window of the Serial Transmit Delay time (*dELAY*) plus 15 msec. maximum. The *dELAY* parameter should be programmed to a value that allows sufficient time for the release of the sending driver on the RS485 bus. Terminating the command line with "\$" results in a response time window (t_2) of 2 msec minimum and 15 msec maximum. The response time of this terminating character requires that sending drivers release within 2 msec after the terminating character is received.


At the beginning of time interval t_3 , the meter responds with the first character of the reply. As with t_1 , the time duration of t_3 is dependent on the number of characters and baud rate of the channel.

$$t_3 = (10 * \# \text{ of characters}) / \text{baud rate}$$


At the end of t_3 , the meter is ready to receive the next command. The maximum serial throughput of the meter is limited to the sum of the times t_1 , t_2 and t_3 .

Timing Diagrams

NO REPLY FROM METER



RESPONSE FROM METER



COMMUNICATION FORMAT

Data is transferred from the meter through a serial communication channel. In serial communications, the voltage is switched between a high and low level at a predetermined rate (baud rate) using ASCII encoding. The receiving device reads the voltage levels at the same intervals and then translates the switched levels back to a character.

The voltage level conventions depend on the interface standard. The table lists the voltage levels for each standard.


LOGIC	INTERFACE STATE	RS232*	RS485*
1	mark (idle)	TXD,RXD; -3 to -15 V	a-b < -200 mV
0	space (active)	TXD,RXD; +3 to +15 V	a-b > +200 mV

* Voltage levels at the Receiver

Data is transmitted one byte at a time with a variable idle period between characters (0 to ∞). Each ASCII character is "framed" with a beginning start bit, an optional parity bit and one or more ending stop bits. The data format and baud rate must match that of other equipment in order for communication to take place. The figures list the data formats employed by the meter.

Start bit and Data bits

Data transmission always begins with the start bit. The start bit signals the receiving device to prepare for reception of data. One bit period later, the least significant bit of the ASCII encoded character is transmitted, followed by the remaining data bits. The receiving device then reads each bit position as they are transmitted. Since the sending and receiving devices operate at the same transmission speed (baud rate), the data is read without timing errors.



Character Frame Figure

Parity bit

After the data bits, the parity bit is sent. The transmitter sets the parity bit to a zero or a one, so that the total number of ones contained in the transmission (including the parity bit) is either even or odd. This bit is used by the receiver to detect errors that may occur to an odd number of bits in the transmission. However, a single parity bit cannot detect errors that may occur to an even number of bits. Given this limitation, the parity bit is often ignored by the receiving device. The meter ignores the parity bit of incoming data and sets the parity bit to odd, even or none (mark parity) for outgoing data.

Stop bit

The last character transmitted is the stop bit. The stop bit provides a single bit period pause to allow the receiver to prepare to re-synchronize to the start of a new transmission (start bit of next byte). The receiver then continuously looks for the occurrence of the start bit. If 7 data bits and no parity is selected, then 2 stop bits are sent from the meter.

FACTORY SERVICE OPERATIONS (FACTry)

FACTORY SERVICE CODE

CODE FCS
50

0-250

Enter the Service Code for the desired operation.

RESTORE FACTORY DEFAULTS

CODE FCS [P] rESEt CODE FCS
66 50

Use the $\sqrt{F1}$ and $\sqrt{F2}$ keys to display CODE 66 and press P. The meter will flash rESEt and then return to CODE 50. Press the P key to return to Display Mode. This will overwrite all user settings with the factory settings. The only exception is the User Mnemonics which retain their programmed values (see Code 69).

RESTORE FACTORY DEFAULTS (w/Units Mnemonics)

CODE FCS [P] rESEt CODE FCS
69 50

Same as Code 66, except the User Mnemonics are also returned to the factory default settings (blank).

MODEL AND CODE VERSION

CODE FCS [P] P2-5 FCS CODE FCS
51 UEr x.xx 50

The meter will briefly display the model (P25) on Line 1, and the current firmware version (UEr x.xx) on Line 2, and then return to CODE 50.

METER CALIBRATION

CODE FCS [P] CAL FCS NO INPUT AnLOut
48 NO

The meter has been fully calibrated at the factory. Scaling to convert the input signal to a desired display value is performed in Input Parameters. If the meter appears to be indicating incorrectly or inaccurately, refer to Troubleshooting before attempting to calibrate the meter. When recalibration is required (generally every 2 years), it should only be performed by qualified technicians using appropriate equipment. Calibration does not change any user programmed parameters. However, it will affect the accuracy of the input signal and the values previously stored using the Apply (APPLy) Scaling Style.

Preparation for Voltage Input Calibration



Warning: Input Calibration of this meter requires a signal source capable of producing a signal greater than or equal to the range being calibrated with an accuracy of 0.01% or better.

Before starting, verify that the Input Range Jumper is set for the range to be calibrated. Verify that the precision signal source is connected and ready. Allow a 30 minute warm-up period before calibrating the meter. Selecting $\sqrt{F1}$ at any calibration step, will cause the unit to maintain the existing calibration parameters for that step. Selecting $\sqrt{F2}$ and pressing the P key will cause the unit to store new calibration settings for the range selected. Pressing D at any time will exit programming mode, but any range that has been calibrated will maintain the new settings.

Input Calibration Procedure

1. After entering CODE 48, in Factory Service Operations, select the input (0020u or 020u) to be calibrated.
2. Press the P key until the desired range along with $\sqrt{F1}$ is indicated on Line 1 of the meter.
3. Apply the zero input limit of the range indicated on Line 1 of the meter.
4. Press $\sqrt{F1}$ to select $\sqrt{F2}$.
5. Press P. Display will indicate - - - - on Line 2 as the unit reads and stores the new calibration parameter.
6. Display will indicate the desired range along with Full on Line 1 of the meter.
7. Apply the signal level indicated on Line 1 of the meter.
8. Press $\sqrt{F1}$ to select $\sqrt{F2}$.
9. Press P. Display will indicate - - - - on Line 2 as the unit reads and stores the new calibration parameter.
10. Repeat Preparation and Calibration Procedure for the other Input Range if calibration for the other range is desired.

Analog Output Card Calibration

Before starting, verify that a precision meter with an accuracy of 0.05% or better (voltmeter for voltage output and/or current meter for current output) is connected and ready. Using the chart below, step through the five selections to be calibrated. At each prompt, use the DP63100-S $\sqrt{F1}$ and $\sqrt{F2}$ keys to adjust the output so that the external meter display matches the selection being calibrated. When the external reading matches, or if the range is not being calibrated, press the P key to advance to the next range. When all the desired ranges have been calibrated, exit programming mode and remove the external meters.

DISPLAY	EXTERNAL METER	ACTION
0.000A	0.00 mA	Adjust if necessary, press P
0.004A	4.00 mA	Adjust if necessary, press P
0.020A	20.00 mA	Adjust if necessary, press P
0.0u	0.00 V	Adjust if necessary, press P
10.0u	10.00 V	Adjust if necessary, press P

TROUBLESHOOTING

PROBLEM	REMEDIES
No Display At Power-Up	Check power level and power connections
No Display After Power-Up	Check Display Module: <i>d-LtU</i> , <i>d-Ltnt</i> , and <i>Ltnt</i> program settings.
Program Locked-Out	Check for Active User Input, programmed for <i>PLU</i> . Deactivate User Input. Enter proper access code at <i>Ltnt</i> prompt. (Universal access code = 222)
No Line 1 Display	Check program settings for Line 1 Display Value Select/Enable. Confirm at least one Line 1 Display Value is enabled (<i>YE5</i>).
No Line 2 Display	Check program settings for Line 2 Value Access. Confirm at least one Line 2 Parameter Value is enabled in Main Display Loop (<i>d-rEd</i> , <i>d-rSt</i> , <i>d-Ent</i>).
No Line 1 Units Mnemonic Display	Check program settings for Line 1 Units Mnemonic(s).
Display of <i>0L0L</i> , <i>ULUL</i> , or "..."	See General Meter Specifications, Display Messages.
Incorrect Input Display Value	Check Input Jumper Setting, Input Level, and Input Connections. Verify Input - Analog program settings. Contact factory
Modules or Parameters Not Accessible	Check for corresponding plug-in option card. Verify parameter is valid in regard to previous program settings.
Error Code: <i>ErrKEY</i>	Keypad is active at power up. Check for depressed or stuck keypad. Press any key to clear Error Code.
Error Code: <i>EE PAR</i> Error Code: <i>EE Pdn</i>	Parameter Data Checksum Error. Press any key to clear Error Code, verify all program settings and cycle power. Contact factory if Error Code returns at next power-up.
Error Code: <i>ErrPra</i>	Parameter Data Validation Error. Press any key to clear Error Code, verify all program settings and cycle power. Contact factory if Error Code returns at next power-up.
Error Code: <i>EE CAL</i>	Calibration Data Validation Error. Contact factory.
Error Code: <i>EE Lin</i>	Linear Output Card Data Validation Error. Press any key to clear Error Code and cycle power. If Error Code returns at next power-up, replace Linear Option Card or contact factory.

PARAMETER VALUE CHART DP63100-S

Programmer _____ Date _____
Meter# _____ Security Code _____

INPUT SETUP PARAMETERS

ANALOG Analog Input Parameters

DISPLAY	PARAMETER	USER SETTING
<i>rANGE</i>	INPUT RANGE	_____
<i>rATE</i>	INPUT UPDATE RATE	_____
<i>decPt</i>	DECIMAL RESOLUTION	_____
<i>round</i>	ROUNDING INCREMENT	_____
<i>tArE</i>	DISPLAY TARE (OFFSET)	_____
<i>FILTEr</i>	DIGITAL FILTER	_____
<i>bAND</i>	DIGITAL FILTER BAND	_____
<i>POINTs</i>	SCALING POINTS	_____
<i>StYLE</i>	SCALING STYLE	_____
<i>INPUT 1</i>	INPUT 1 SCALING VALUE	_____
<i>dISPLy 1</i>	DISPLAY 1 VALUE	_____
<i>INPUT 2</i>	INPUT 2 SCALING VALUE	_____
<i>dISPLy 2</i>	DISPLAY 2 VALUE	_____
<i>INPUT 3</i>	INPUT 3 SCALING VALUE	_____
<i>dISPLy 3</i>	DISPLAY 3 VALUE	_____
<i>INPUT 4</i>	INPUT 4 SCALING VALUE	_____
<i>dISPLy 4</i>	DISPLAY 4 VALUE	_____
<i>INPUT 5</i>	INPUT 5 SCALING VALUE	_____
<i>dISPLy 5</i>	DISPLAY 5 VALUE	_____
<i>INPUT 6</i>	INPUT 6 SCALING VALUE	_____
<i>dISPLy 6</i>	DISPLAY 6 VALUE	_____
<i>INPUT 7</i>	INPUT 7 SCALING VALUE	_____
<i>dISPLy 7</i>	DISPLAY 7 VALUE	_____
<i>INPUT 8</i>	INPUT 8 SCALING VALUE	_____
<i>dISPLy 8</i>	DISPLAY 8 VALUE	_____
<i>INPUT 9</i>	INPUT 9 SCALING VALUE	_____

DISPLAY	PARAMETER	USER SETTING
<i>dISPLy 9</i>	DISPLAY 9 VALUE	_____
<i>INPUT 10</i>	INPUT 10 SCALING VALUE	_____
<i>dISPLy 10</i>	DISPLAY 10 VALUE	_____
<i>INPUT 11</i>	INPUT 11 SCALING VALUE	_____
<i>dISPLy 11</i>	DISPLAY 11 VALUE	_____
<i>INPUT 12</i>	INPUT 12 SCALING VALUE	_____
<i>dISPLy 12</i>	DISPLAY 12 VALUE	_____
<i>INPUT 13</i>	INPUT 13 SCALING VALUE	_____
<i>dISPLy 13</i>	DISPLAY 13 VALUE	_____
<i>INPUT 14</i>	INPUT 14 SCALING VALUE	_____
<i>dISPLy 14</i>	DISPLAY 14 VALUE	_____
<i>INPUT 15</i>	INPUT 15 SCALING VALUE	_____
<i>dISPLy 15</i>	DISPLAY 15 VALUE	_____
<i>INPUT 16</i>	INPUT 16 SCALING VALUE	_____
<i>dISPLy 16</i>	DISPLAY 16 VALUE	_____

USER User Input Parameters

DISPLAY	PARAMETER	USER SETTING
<i>USrACT</i>	USER ACTIVE STATE	_____
<i>USER-1</i>	USER INPUT 1	_____
<i>USER-2</i>	USER INPUT 2	_____
<i>USER-3</i>	USER INPUT 3	_____
<i>F1</i>	FUNCTION KEY 1	_____
<i>F2</i>	FUNCTION KEY 2	_____
<i>SEC-F1</i>	2nd FUNCTION KEY 1	_____
<i>SEC-F2</i>	2nd FUNCTION KEY 2	_____

OUTPUT PARAMETERS

SETPOINT Setpoint Output Parameters

DISPLAY	PARAMETER	USER SETTING	USER SETTING	USER SETTING	USER SETTING
<i>SELEct</i>	SETPOINT SELECTION	S1	S2	S3	S4
<i>ASSIGN</i>	SETPOINT SOURCE	_____	_____	_____	_____
<i>ACT: ON</i>	ACTION FOR SETPOINT	_____	_____	_____	_____
<i>SEtPt</i>	SETPOINT VALUE	_____	_____	_____	_____
<i>bn-dEV</i>	SETPOINT BAND/DEVIATION VALUE	_____	_____	_____	_____
<i>HYStEr</i>	HYSTERESIS FOR SETPOINT	_____	_____	_____	_____
<i>t-ON</i>	ON TIME DELAY SETPOINT	_____	_____	_____	_____
<i>t-OFF</i>	OFF TIME DELAY SETPOINT	_____	_____	_____	_____
<i>LOGIC</i>	OUTPUT LOGIC	_____	_____	_____	_____
<i>rESEt</i>	RESET ACTION	_____	_____	_____	_____
<i>Stndby</i>	STANDBY OPERATION	_____	_____	_____	_____
<i>Annun</i>	OUTPUT ANNUNCIATOR LIGHT	_____	_____	_____	_____
<i>Co lor</i>	CHANGE COLOR	_____	_____	_____	_____

ANALOG Analog Output Parameters

DISPLAY	PARAMETER	USER SETTING
<i>TYPE</i>	ANALOG TYPE	_____
<i>ASSIGN</i>	ANALOG ASSIGNMENT	_____
<i>ANALOG LO</i>	ANALOG LOW	_____
<i>ANALOG HI</i>	ANALOG HIGH	_____
<i>UPdATE</i>	ANALOG UPDATE TIME	_____

DISPLAY PARAMETERS

LINE 1 Line 1 Parameters

DISPLAY	PARAMETER	USER SETTING
<i>Co lor</i>	Line 1 Display Color	_____
<i>d-LEV</i>	Display Level	_____
<i>d-Contr</i>	Display Contrast Level	_____
<i>SELEct</i>	Line 1 Display Value Select	_____
<i>INPUT</i>		LO _____
<i>GrOSS</i>		S1 _____
<i>tArE</i>		S2 _____
<i>tOEtAL</i>		S3 _____
<i>HI</i>		S4 _____

DISPLAY	PARAMETER	USER SETTING
Scroll	Line 1 Display Scroll Enable/Time	
Units	Line 1 Units Mnemonic(s)	
	LABEL MNEMONIC	LABEL
		List A List B

Unit 1	Line 1 Units Digit 1 (Left)	
Unit 2	Line 1 Units Digit 2 (Center)	
Unit 3	Line 1 Units Digit 3 (Right)	

LIST A CUSTOM MNEMONICS	Unit 1	Unit 2	Unit 3
Input			
Gross			
Tare			
Total			
Max (HI)			
Min (LO)			

LIST B CUSTOM MNEMONICS	Unit 1	Unit 2	Unit 3
Input			
Gross			
Tare			
Total			
Max (HI)			
Min (LO)			

LINE 2 Line 2 Parameters

ACCESS	LINE 2 VALUE ACCESS	
INPUT		52
GROSS		62-d2
TARE		53
TOTAL		63-d3
HI		54
LO		64-d4
LIST		60 for
SI		d-LEU
bid		d-Cont

FUNCTION	LINE 2 FUNCTIONS ACCESS	
REL		r-2
r-tARE		r-3
bAR		r-4
r-tot		r-34
r-HI		r-234
r-LO		r-ALL
r-HL		Print
r-I		

Scroll	Line 2 Display Scroll Enable/Time	
Units	Line 2 Units Mnemonic(s)	
	LABEL MNEMONIC	LABEL
		List A List B

Unit 1	Line 2 Units Digit 1 (Left)	
Unit 2	Line 2 Units Digit 2	
Unit 3	Line 2 Units Digit 3	
Unit 4	Line 2 Units Digit 4	
Unit 5	Line 2 Units Digit 5	
Unit 6	Line 2 Units Digit 6	
Unit 7	Line 2 Units Digit 7	
Unit 8	Line 2 Units Digit 8	
Unit 9	Line 2 Units Digit 9 (Right)	

LIST A CUSTOM MNEMONICS	1	2	3	4	5	6	7	8	9
Input									
Gross									
Tare									

Total									
HI (Max)									
LO (Min)									

LIST B CUSTOM MNEMONICS

	1	2	3	4	5	6	7	8	9
Input									
Gross									
Tare									
Total									
HI (Max)									
LO (Min)									

Code Security Code

Secondary Function Parameters

DISPLAY	PARAMETER	USER SETTING
HI-ASN	MAX ASSIGNMENT	
HI-t	MAX CAPTURE DELAY TIME	
LO-ASN	MIN ASSIGNMENT	
LO-t	MIN CAPTURE DELAY TIME	
dSP-t	DISPLAY UPDATE TIME	
At-t	AUTO-ZERO TRACKING TIME	
At-bnd	AUTO-ZERO TRACKING BAND	

Totalizer Parameters

DISPLAY	PARAMETER	USER SETTING
dECPnt	TOTALIZER DECIMAL POINT	
t-base	TOTALIZER TIME BASE	
SCALE	TOTALIZER SCALE FACTOR	
LO-cut	TOTALIZER LOW CUT VALUE	
PowerUP	TOTALIZER POWER-UP RESET	

Port COMMS. PORT PARAMETERS


DISPLAY	PARAMETER	USER SETTING
USB	USB Port Parameters	
CONFIG	USB Configuration	


Serial Port Parameters

DISPLAY	PARAMETER	USER SETTING
TYPE	Communications Type	
BAUD	Baud Rate	
DATA	Data Bits	
PARITY	Parity Bit	
Addr	Meter Unit Address	
DELAY	Transmit Delay	
Abbrv	Abbreviated Printing	
OPT	Print Options	
INPUT	Signal Input (relative)	
GROSS	Gross (absolute)	
TARE	Tare Value	
TOTAL	Total Value	
HI	Maximum Value	
LO	Minimum Value	
SETPnt	Setpoint Values	

This page intentionally left blank.

DP63100-S PROGRAMMING QUICK OVERVIEW





DP63100-S Modbus Register Table

REVISED 2/20/12

REGISTER ADDRESS	REGISTER NAME	LOW LIMIT	HIGH LIMIT	FACTORY SETTING	ACCESS	COMMENTS
FREQUENTLY USED REGISTERS						
40001	Input Relative Value (Hi word)	-199999	999999	N/A	Read Only	Process value of present input level. This value is affected by Input Type, Resolution, Scaling, & Tare (Offset) Value. (Relative Value = Gross (Absolute) Input Value - Tare Value)
40002	Input Relative Value (Lo word)					
40003	Maximum Value (Hi word)	-199999	999999	N/A	Read/Write	1 = 1 display unit
40004	Maximum Value (Lo word)					
40005	Minimum Value (Hi word)	-199999	999999	N/A	Read/Write	1 = 1 display unit
40006	Minimum Value (Lo word)					
40007	Total Value (Hi word)	-199999	999999	N/A	Read/Write	1 = 1 display unit
40008	Total Value (Lo word)					
40009	Setpoint 1 Value (Hi word)	-199999	999999	100	Read/Write	Active List (A or B)
40010	Setpoint 1 Value (Lo word)					
40011	Setpoint 2 Value (Hi word)	-199999	999999	200	Read/Write	Active List (A or B)
40012	Setpoint 2 Value (Lo word)					
40013	Setpoint 3 Value (Hi word)	-199999	999999	300	Read/Write	Active List (A or B)
40014	Setpoint 3 Value (Lo word)					
40015	Setpoint 4 Value (Hi word)	-199999	999999	400	Read/Write	Active List (A or B)
40016	Setpoint 4 Value (Lo word)					
40017	Setpoint 1 Band/Dev. Value (Hi word)	-199999	999999	0	Read/Write	Active List (A or B). Applicable only for Band or Deviation Setpoint Action.
40018	Setpoint 1 Band/Dev. Value (Lo word)					
40019	Setpoint 2 Band/Dev. Value (Hi word)	-199999	999999	0	Read/Write	Active List (A or B). Applicable only for Band or Deviation Setpoint Action.
40020	Setpoint 2 Band/Dev. Value (Lo word)					
40021	Setpoint 3 Band/Dev. Value (Hi word)	-199999	999999	0	Read/Write	Active List (A or B). Applicable only for Band or Deviation Setpoint Action.
40022	Setpoint 3 Band/Dev. Value (Lo word)					
40023	Setpoint 4 Band/Dev. Value (Hi word)	-199999	999999	0	Read/Write	Active List (A or B). Applicable only for Band or Deviation Setpoint Action.
40024	Setpoint 4 Band/Dev. Value (Lo word)					
40025	Setpoint Output Register (SOR)	0	15	N/A	Read/Write	Status of Setpoint Outputs. Bit State: 0=Off, 1=On. Bit 3 = SP1, Bit 2 = SP2, Bit 1 = SP3, Bit 0 = SP4. Outputs can only be activated/reset with this register when the respective bits in the Manual Mode Register (MMR) are set.
40026	Manual Mode Register (MMR)	0	31	0	Read/Write	Bit State: 0=Auto Mode, 1=Manual Mode Bit 4 = SP1, Bit 3 = SP2, Bit 2 = SP3, Bit 1 = SP4, Bit 0 = Linear Output
40027	Reset Output Register	0	15	0	Read/Write	Bit State: 1= Reset Output, bit is returned to zero following reset processing; Bit 3 = SP1, Bit 2 = SP2, Bit 1 = SP3, Bit 0 = SP4
40028	Analog Output Register (AOR)	0	4095	0	Read/Write	Functional only if Linear Output is in Manual Mode.(MMR bit 0 = 1) Linear Output Card written to only if Linear Out (MMR bit 0) is set.
40029	Input Gross (Absolute) Value (Hi word)	-199999	999999	N/A	Read Only	Gross (absolute) value of present Input level. This value is affected by Input Type, Resolution, Scaling, but not affected by Offset Value
40030	Input Gross (Absolute) Value (Lo word)					
40031	Tare Value (Hi word)	-199999	999999	0	Read/Write	Relative Input Value (standard meter value) is the difference between the Gross (absolute) input value and the Tare value, i.e. Relative = Gross - Tare
40032	Tare Value (Lo word)					
INPUT PARAMETERS						SEE INPUT MODULE FOR PARAMETER DESCRIPTIONS
Analog Input						
40081	Input Range	0	1	0	Read/Write	0 = +/-24mV, 1 = +/-240mV
40082	ADC Conversion Rate (samples/sec)	0	5	0	Read/Write	0 = 5, 1 = 10, 2 = 20, 3 = 40, 4 = 80, 5 = 160
40083	Decimal Point	0	4	2	Read/Write	0 = 0, 1 = 0.0, 2 = 0.00, 3 = 0.000, 4 = 0.0000
40084	Rounding Factor	0	6	0	Read/Write	0 = 1, 1 = 2, 2 = 5, 3 = 10, 4 = 20, 5 = 50, 6 = 100
40085	Digital Input Filter	0	2500	100	Read/Write	1 = 0.01 Second
40086	Filter Band	0	2500	10	Read/Write	1 = 1 display unit
40087	Input Scaling Points in List Function	0	1	0	Read/Write	0 = No, 1 = Yes

REGISTER ADDRESS		REGISTER NAME	LOW LIMIT	HIGH LIMIT	FACTORY SETTING	ACCESS	COMMENTS
List A	List B	Analog Input Scaling Points Parameters					
40101	40201	Number of Scaling Points	2	16	2	Read/Write	Number of Linearization Scaling Points
40102	40202	Reserved	N/A	N/A	N/A	N/A	
40103	40203	Scaling Pt.1 Input Value (Hi word)	-199999	999999	0	Read/Write	1 = 0.001
40104	40204	Scaling Pt.1 Input Value (Lo word)					
40105	40205	Scaling Pt.1 Display Value (Hi word)	-199999	999999	0	Read/Write	1 = 1 display unit
40106	40206	Scaling Pt.1 Display Value (Lo word)					
thru	thru	Scaling Pts. 2 thru 15 Values	Registers 40107-40162 and 40207-40262 hold values for Scaling Points 2 thru 15, and follow the same ordering as Scaling Point 1.
40163	40263	Scaling Pt.16 Input Value (Hi word)	-199999	999999	0	Read/Write	1 = 1 display unit
40164	40264	Scaling Pt.16 Input Value (Lo word)					
40165	40265	Scaling Pt.16 Display Value (Hi word)	-199999	999999	0	Read/Write	1 = 1 display unit
40166	40266	Scaling Pt.16 Display Value (Lo word)					
List A	List B	Setpoint Values					
40167	40267	Setpoint 1 Value (Hi word)	-199999	999999	100	Read/Write	1 = 1 display unit
40168	40268	Setpoint 1 Value (Lo word)					
40169	40269	Setpoint 2 Value (Hi word)	-199999	999999	200	Read/Write	1 = 1 display unit
40170	40270	Setpoint 2 Value (Lo word)					
40171	40271	Setpoint 3 Value (Hi word)	-199999	999999	300	Read/Write	1 = 1 display unit
40172	40272	Setpoint 3 Value (Lo word)					
40173	40273	Setpoint 4 Value (Hi word)	-199999	999999	400	Read/Write	1 = 1 display unit
40174	40274	Setpoint 4 Value (Lo word)					
40175	40275	Setpoint 1 Band/Dev. Value (Hi word)	-199999	999999	0	Read/Write	Applicable only for Band or Deviation Setpoint Action.
40176	40276	Setpoint 1 Band/Dev. Value (Lo word)					
40177	40277	Setpoint 2 Band/Dev. Value (Hi word)	-199999	999999	0	Read/Write	Applicable only for Band or Deviation Setpoint Action.
40178	40278	Setpoint 2 Band/Dev. Value (Lo word)					
40179	40279	Setpoint 3 Band/Dev. Value (Hi word)	-199999	999999	0	Read/Write	Applicable only for Band or Deviation Setpoint Action.
40180	40280	Setpoint 3 Band/Dev. Value (Lo word)					
40181	40281	Setpoint 4 Band/Dev. Value (Hi word)	-199999	999999	0	Read/Write	Applicable only for Band or Deviation Setpoint Action.
40182	40282	Setpoint 4 Band/Dev. Value (Lo word)					
List A	List B	Scaling Parameters					
40183	40283	Input Decimal Point	0	4	2	Read/Write	0 = 0, 1 = 0.0, 2 = 0.00, 3 = 0.000, 4 = 0.0000
40184	40284	Input Rounding Factor	0	6	0	Read/Write	0 = 1, 1 = 2, 2 = 5, 3 = 10, 4 = 20, 5 = 50, 6 = 100
40185	40285	Input Filter Band	0	2500	10	Read/Write	1 = 1 display unit
40186	40286	Auto-Zero Tracking Band	0	4095	2	Read/Write	0 = OFF, 1 = display unit
40187	40287	Totalizer Decimal Point	0	4	3	Read/Write	0 = 0, 1 = 0.0, 2 = 0.00, 3 = 0.000, 4 = 0.0000
40188	40288	Totalizer Scale Factor	1	65000	1000	Read/Write	1 = 0.001
User Input / Function Keys							
40301		User Input Active State	0	1	0	Read/Write	0 = Active Low, 1 = Active High
40302		User Input 1 Action	0	30	0	Read/Write	0 = NO 9 = d-tot 18 = Sel L1 27 = r-34 1 = PLOC 10 = r-tot1 19 = Sel L2 28 = r-234 2 = rEL 11 = r-tot2 20 = d-LEV 29 = r-ALL 3 = r-TArE 12 = E-tot 21 = Color 30 = Print 4 = d-rEL 13 = d-HI 22 = LISt 5 = d-HLd 14 = r-HI 23 = r-1 6 = A-HLd 15 = d-Lo 24 = r-2 7 = SYNC 16 = r-Lo 25 = r-3 8 = bAt 17 = r-HL 26 = r-4
40303		User Input 2 Action	0	30	0	Read/Write	Same as User Input 1 Action
40304		User Input 3 Action	0	30	0	Read/Write	Same as User Input 1 Action

REGISTER ADDRESS	REGISTER NAME	LOW LIMIT	HIGH LIMIT	FACTORY SETTING	ACCESS	COMMENTS
40305	User F1 Key Action	0	20	0	Read/Write	0 = NO 5 = r-tot 10 = SEL L2 15 = r-3 20 = Print 1 = rEL 6 = r-HI 11 = d-LEV 16 = r-4 2 = r-TArE 7 = r-Lo 12 = LISt 17 = r-34 3 = d-rEL 8 = r-HL 13 = r-1 18 = r-234 4 = bAt 9 = SEL L1 14 = r-2 19 = r-ALL
40306	User F2 Key Action	0	20	0	Read/Write	Same as User F1 Key Action
40307	User F1 Second Action	0	20	0	Read/Write	Same as User F1 Key Action
40308	User F2 Second Action	0	20	0	Read/Write	Same as User F1 Key Action
40309	User List Assign	0	3	0	Read/Write	Set bits to enable items in List A/B parameter list. Bit 0: Scaling (Scaling Points, Input Decimal Point, Input Rounding Factor, Input Filter Band, Auto-Zero Tracking Band, Total Decimal Point, Total Scale Factor; Bit 1: Units Mnemonics
OUTPUT PARAMETERS						SEE OUTPUT MODULE FOR PARAMETER DESCRIPTIONS
Setpoint 1						
40401	Assignment	0	3	0	Read/Write	0 = None, 1 = Rel, 2 = Gross, 3 = Total
40402	Action	0	10	0	Read/Write	0=No, 1=Ab-HI, 2=Ab-LO, 3=AU-HI, 4=AU-LO, 5=dE-HI, 6=dE-LO, 7=bANd, 8=bNdIn, 9=totLo, 10=totHi
40403	Hysteresis Value	1	65000	2	Read/Write	1 = 1 Display Unit
40404	On Time Delay	0	32750	0	Read/Write	1 = 0.1 Second
40405	Off Time Delay	0	32750	0	Read/Write	1 = 0.1 Second
40406	Output Logic	0	1	0	Read/Write	0 = Normal, 1 = Reverse
40407	Reset Action	0	2	0	Read/Write	0 = Auto, 1 = Latch1, 2 = Latch2
40408	Standby Operation	0	1	0	Read/Write	0 = No, 1 = Yes
40409	Annunciator	0	3	1	Read/Write	0 = Off, 1 = Normal, 2 = Reverse, 3 = Flash
40410	Color	0	7	0	Read/Write	0 = No Change, 1 = Green, 2 = Orange, 3 = Red, 4 = Grn/Org, 5 = Red/Org, 6 = Red/Grn, 7 = Line 1 Color
Setpoint 2						
40421	Assignment	0	3	0	Read/Write	0 = None, 1 = Rel, 2 = Gross, 3 = Total
40422	Action	0	10	0	Read/Write	0=No, 1=Ab-HI, 2=Ab-LO, 3=AU-HI, 4=AU-LO, 5=dE-HI, 6=dE-LO, 7=bANd, 8=bNdIn, 9=totLo, 10=totHi
40423	Hysteresis Value	1	65000	2	Read/Write	1 = 1 Display Unit
40424	On Time Delay	0	32750	0	Read/Write	1 = 0.1 Second
40425	Off Time Delay	0	32750	0	Read/Write	1 = 0.1 Second
40426	Output Logic	0	1	0	Read/Write	0 = Normal, 1 = Reverse
40427	Reset Action	0	2	0	Read/Write	0 = Auto, 1 = Latch1, 2 = Latch2
40428	Standby Operation	0	1	0	Read/Write	0 = No, 1 = Yes
40429	Annunciator	0	3	1	Read/Write	0 = Off, 1 = Normal, 2 = Reverse, 3 = Flash
40430	Color	0	7	0	Read/Write	0 = No Change, 1 = Green, 2 = Orange, 3 = Red, 4 = Grn/Org, 5 = Red/Org, 6 = Red/Grn, 7 = Line 1 Color
Setpoint 3						
40441	Assignment	0	3	0	Read/Write	0 = None, 1 = Rel, 2 = Gross, 3 = Total
40442	Action	0	10	0	Read/Write	0=No, 1=Ab-HI, 2=Ab-LO, 3=AU-HI, 4=AU-LO, 5=dE-HI, 6=dE-LO, 7=bANd, 8=bNdIn, 9=totLo, 10=totHi
40443	Hysteresis Value	1	65000	2	Read/Write	1 = 1 Display Unit
40444	On Time Delay	0	32750	0	Read/Write	1 = 0.1 Second
40445	Off Time Delay	0	32750	0	Read/Write	1 = 0.1 Second
40446	Output Logic	0	1	0	Read/Write	0 = Normal, 1 = Reverse
40447	Reset Action	0	2	0	Read/Write	0 = Auto, 1 = Latch1, 2 = Latch2
40448	Standby Operation	0	1	0	Read/Write	0 = No, 1 = Yes
40449	Annunciator	0	3	1	Read/Write	0 = Off, 1 = Normal, 2 = Reverse, 3 = Flash
40450	Color	0	7	0	Read/Write	0 = No Change, 1 = Green, 2 = Orange, 3 = Red, 4 = Grn/Org, 5 = Red/Org, 6 = Red/Grn, 7 = Line 1 Color

REGISTER ADDRESS	REGISTER NAME	LOW LIMIT	HIGH LIMIT	FACTORY SETTING	ACCESS	COMMENTS
Setpoint 4						
40461	Assignment	0	3	0	Read/Write	0 = None, 1 = Rel, 2 = Gross, 3 = Total
40462	Action	0	10	0	Read/Write	0=No, 1=Ab-HI, 2=Ab-LO, 3=AU-HI, 4=AU-LO, 5=dE-HI, 6=dE-LO, 7=bANd, 8=bNdn, 9=totLo, 10=totHi
40463	Hysteresis Value	1	65000	2	Read/Write	1 = 1 Display Unit
40464	On Time Delay	0	32750	0	Read/Write	1 = 0.1 Second
40465	Off Time Delay	0	32750	0	Read/Write	1 = 0.1 Second
40466	Output Logic	0	1	0	Read/Write	0 = Normal, 1 = Reverse
40467	Reset Action	0	2	0	Read/Write	0 = Auto, 1 = Latch1, 2 = Latch2
40468	Standby Operation	0	1	0	Read/Write	0 = No, 1 = Yes
40469	Annunciator	0	3	1	Read/Write	0 = Off, 1 = Normal, 2 = Reverse, 3 = Flash
40470	Color	0	7	0	Read/Write	0 = No Change, 1 = Green, 2 = Orange, 3 = Red, 4 = Grn/Org, 5 = Red/Org, 6 = Red/Grn, 7 = Line 1 Color
Analog Output Parameters						
40491	Type	0	2	1	Read/Write	0 = 0-20 mA, 1 = 4-20 mA, 2 = 0-10 V
40492	Assignment	0	9	0	Read/Write	0=None, 1=Rel, 2=Gross, 3=Total, 4=HI, 5=LO, 6=S1, 7=S2, 8=S3, 9=S4
40493	Analog Low Scale Value (Hi word)	-199999	999999	0	Read/Write	Display value that corresponds with 0 V, 0 mA or 4 mA output
40494	Analog Low Scale Value (Lo word)					
40495	Analog High Scale Value (Hi word)	-199999	999999	10000	Read/Write	Display value that corresponds with 10 V or 20 mA output
40496	Analog High Scale Value (Lo word)					
40497	Update time	0	100	0	Read/Write	0 = Max update rate, 1 = 0.1 Second
DISPLAY PARAMETERS						SEE DISPLAY MODULE FOR PARAMETER DESCRIPTIONS
Line 1 Parameters						
40331	Line 1 Display Color	0	2	0	Read/Write	0 = Green, 1 = Red, 2 = Orange
40332	Display Intensity Level	0	4	4	Read/Write	0 = Min.(off), 4 = Max.
40333	Display Contrast Level	0	15	7	Read/Write	0 = Max downward viewing angle, 15 = Max upward viewing angle
40334	Line 1 Display Value Enable 1	0	255	1	Read/Write	Bit State: 0 = No (Disabled), 1 = Yes (Enabled) Bit 0 = Input, Bit 1 = Gross, Bit 2 = Tare, Bit 3 = Total, Bit 4 = Max, Bit 5 = Min, Bit 6 = Setpoint 1, Bit 7 = Setpoint 2
40335	Line 1 Display Value Enable 2	0	3	1	Read/Write	Bit State: 0 = No (Disabled), 1 = Yes (Enabled) Bit 0 = Setpoint 3, Bit 1 = Setpoint 4
40336	Line 1 Scroll Enable/Time	0	15	0	Read/Write	0 = No Scroll, 1-15 = Scroll Time in Seconds
40337	Line 1 Units Mode	0	3	0	Read/Write	0 = Off, 1 = Label, 2 = Custom, 3 = Factory
40338	Units Digit 1 (Left)	0	57	0	Read/Write	Label Mnemonic Mode only. Active List (A or B). 0 = 9 = I 18 = Q 27 = Z 36 = 8 45 = m(r) 54 =] 1 = A 10 = J 19 = R 28 = 0 37 = 9 46 = o 55 = / 2 = b 11 = K 20 = S 29 = 1 38 = a 47 = q 56 = ° 3 = C 12 = L 21 = t 30 = 2 39 = c 48 = r 57 = _ 4 = d 13 = M(l) 22 = U 31 = 3 40 = e 49 = u 5 = E 14 = M(r) 23 = V 32 = 4 41 = g 50 = w(r) 6 = F 15 = N 24 = W(l) 33 = 5 42 = h 51 = - 7 = G 16 = O 25 = W(r) 34 = 6 43 = i 52 = = 8 = H 17 = P 26 = Y 35 = 7 44 = n 53 = [
40339	Units Digit 2 (Center)					
40340	Units Digit 3 (Right)					
Line 2 Parameters						
40341	Line 2 Input Display Access	0	2	0	Read/Write	0=LOC, 1=d-rEAd, 2=d-rSt
40342	Line 2 Gross (Absolute) Display Access	0	1	0	Read/Write	0=LOC, 1=d-rEAd,
40343	Line 2 Tare (Offset) Display Access	0	2	0	Read/Write	0=LOC, 1=d-rEAd, 2=d-Entr
40344	Line 2 Totalizer Display Access	0	2	0	Read/Write	0=LOC, 1=d-rEAd, 2=d-rSt
40345	Line 2 Maximum (Hi) Value Access	0	2	0	Read/Write	0=LOC, 1=d-rEAd, 2=d-rSt
40346	Line 2 Minimum (Lo) Value Access	0	2	0	Read/Write	0=LOC, 1=d-rEAd, 2=d-rSt
40347	Line 2 List Selection Access	0	5	0	Read/Write	0=LOC, 1=d-rEAd, 2=d-ENtr, 3=P-rEd, 4=P-ENtr, 5=HidE
40348	Line 2 Setpoint 1 Value Access	0	5	0	Read/Write	0=LOC, 1=d-rEAd, 2=d-ENtr, 3=P-rEd, 4=P-ENtr, 5=HidE

REGISTER ADDRESS	REGISTER NAME	LOW LIMIT	HIGH LIMIT	FACTORY SETTING	ACCESS	COMMENTS
40349	Line 2 S1 Band/Dev.Value Access	0	5	0	Read/Write	0=LOC, 1=d-rEAd, 2=d-ENtr, 3=P-rEd, 4=P-ENtr, 5=HidE
40350	Line 2 Setpoint 2 Value Access	0	5	0	Read/Write	0=LOC, 1=d-rEAd, 2=d-ENtr, 3=P-rEd, 4=P-ENtr, 5=HidE
40351	Line 2 S2 Band/Dev.Value Access	0	5	0	Read/Write	0=LOC, 1=d-rEAd, 2=d-ENtr, 3=P-rEd, 4=P-ENtr, 5=HidE
40352	Line 2 Setpoint 3 Value Access	0	5	0	Read/Write	0=LOC, 1=d-rEAd, 2=d-ENtr, 3=P-rEd, 4=P-ENtr, 5=HidE
40353	Line 2 S3 Band/Dev.Value Access	0	5	0	Read/Write	0=LOC, 1=d-rEAd, 2=d-ENtr, 3=P-rEd, 4=P-ENtr, 5=HidE
40354	Line 2 Setpoint 4 Value Access	0	5	0	Read/Write	0=LOC, 1=d-rEAd, 2=d-ENtr, 3=P-rEd, 4=P-ENtr, 5=HidE
40355	Line 2 S4 Band/Dev.Value Access	0	5	0	Read/Write	0=LOC, 1=d-rEAd, 2=d-ENtr, 3=P-rEd, 4=P-ENtr, 5=HidE
40356-40359	Reserved	N/A	N/A	N/A	N/A	Reserved (may be used in future RLC software)
40360	Line 2 Display Color Access	0	3	0	Read/Write	0=LOC, 1=P-rEAd, 2=P-ENtr, 3=HidE
40361	Line 2 Display Intensity Level Access	0	3	0	Read/Write	0=LOC, 1=P-rEAd, 2=P-ENtr, 3=HidE
40362	Line 2 Display Contrast Level Access	0	3	0	Read/Write	0=LOC, 1=P-rEAd, 2=P-ENtr, 3=HidE
40363	Line 2 Zero (Tare) Display Access	0	2	0	Read/Write	0=LOC, 1=P-ENtr, 2=HidE
40364	Line 2 Reset Tare Display Access	0	2	0	Read/Write	0=LOC, 1=P-ENtr, 2=HidE
40365	Line 2 Batch Input to Totalizer Access	0	2	0	Read/Write	0=LOC, 1=P-ENtr, 2=HidE
40366	Line 2 Reset Totalizer Access	0	2	0	Read/Write	0=LOC, 1=P-ENtr, 2=HidE
40367	Line 2 Reset Max (Hi) Display Access	0	2	0	Read/Write	0=LOC, 1=P-ENtr, 2=HidE
40368	Line 2 Reset Min (Lo) Display Access	0	2	0	Read/Write	0=LOC, 1=P-ENtr, 2=HidE
40369	Line 2 Reset Max and Min Access	0	2	0	Read/Write	0=LOC, 1=P-ENtr, 2=HidE
40370	Line 2 Reset Alarm 1 Access	0	2	0	Read/Write	0=LOC, 1=P-ENtr, 2=HidE
40371	Line 2 Reset Alarm 2 Access	0	2	0	Read/Write	0=LOC, 1=P-ENtr, 2=HidE
40372	Line 2 Reset Alarm 3 Access	0	2	0	Read/Write	0=LOC, 1=P-ENtr, 2=HidE
40373	Line 2 Reset Alarm 4 Access	0	2	0	Read/Write	0=LOC, 1=P-ENtr, 2=HidE
40374	Line 2 Reset Alarm 3 and 4 Access	0	2	0	Read/Write	0=LOC, 1=P-ENtr, 2=HidE
40375	Line 2 Reset Alarm 2, 3 and 4 Access	0	2	0	Read/Write	0=LOC, 1=P-ENtr, 2=HidE
40376	Line 2 Reset All Alarms (1-4) Access	0	2	0	Read/Write	0=LOC, 1=P-ENtr, 2=HidE
40377	Line 2 Print Request Access	0	2	0	Read/Write	0=LOC, 1=P-ENtr, 2=HidE
40378	Line 2 Security Code Value	0	250	0	Read/Write	
40379	Line 2 Scroll Enable/Time	0	15	0	Read/Write	0 = No Scroll, 1-15 = Scroll Time in Seconds
40380	Line 2 Units Mode	0	7	3	Read/Write	0 = Off, 1 = Label, 2 = Custom, 3 = Factory, 4 = Label & Custom, 5 = Label & Factory, 6 = Line 1 Indexed Label, 7 = Line 1 Indexed Label & Factory
Secondary Parameters						SEE MODULE 4 FOR PARAMETER DESCRIPTIONS
40381	Max (Hi) Capture Value Assignment	0	1	0	Read/Write	0 = Relative, 1 = Gross (Absolute)
40382	Max (Hi) Capture Delay Time	0	32750	10	Read/Write	0 = Max Update Rate, 1 = 0.1Sec
40383	Min (Lo) Capture Value Assignment	0	1	0	Read/Write	0 = Relative, 1 = Gross (Absolute)
40384	Min (Lo) Capture Delay Time	0	32750	10	Read/Write	0 = Max Update Rate, 1 = 0.1Sec
40385	Display Update (readings per second)	0	4	1	Read/Write	0 = 1, 1 = 2, 2 = 5, 3 = 10, 4 = 20
40386	Auto Zero Tracking Time	0	250	0	Read/Write	0 = Auto Zero Tracking disabled; 1 = 1Sec.
40387	Auto Zero Tracking Band	1	4095	2	Read/Write	1 = display unit
Totalizer Parameters						SEE MODULE 5 FOR PARAMETER DESCRIPTIONS
40391	Totalizer Decimal Point	0	4	3	Read/Write	0 = 0, 1 = 0.0, 2 = 0.00, 3 = 0.000, 4 = 0.0000
40392	Totalizer Time Base	0	3	1	Read/Write	0 = Second, 1 = Minute, 2 = Hour, 3 = Day
40393	Totalizer Scale Factor	1	65000	1000	Read/Write	1 = 0.001
40394	Totalizer Reset at Power Up	0	1	0	Read/Write	0 = No, 1 = Yes
40395	Totalizer Low Cut Value (Hi word)	-199999	999999	-199999	Read/Write	1 = 1 display unit
40396	Totalizer Low Cut Value (Lo word)					

REGISTER ADDRESS		REGISTER NAME	LOW LIMIT	HIGH LIMIT	FACTORY SETTING	ACCESS	COMMENTS
PORT PARAMETERS						SEE MODULE 7 FOR PARAMETER DESCRIPTIONS	
USB							
40481	USB Mode		0	1	0	Read/Write	0 = Automatic (Addr 247, 38400, N, 8, 1) 1 = Serial
Serial							
40482	Type		0	2	2	Read/Write	0 = RLC Protocol (ASCII), 1 = Modbus RTU, 2 = Modbus ASCII
40483	Baud Rate		0	5	5	Read/Write	0=1200, 1=2400, 2=4800, 3=9600, 4=19200, 5=38400
40484	Data Bits		0	1	1	Read/Write	0 = 7 Bits, 1 = 8 Bits
40485	Parity		0	2	0	Read/Write	0 = None, 1 = Even, 2 = Odd
40486	Address	0	99	247	Read/Write	RLC Protocol: 0-99	
		1	247			Modbus: 1-247	
40487	Transmit Delay		0	250	10	Read/Write	1 = 0.001 Second
40488	Abbreviated Transmission (RLC only)		0	1	0	Read/Write	0 = No, 1 = Yes (Not used when communications type is Modbus)
40489	Print Options (RLC only)		0	63	1	Read/Write	0 = No, 1 = Yes (Not used when communications type is Modbus) Bit 0 – Print Input Value, Bit 1 – Print Gross Value, Bit 2 - Print Tare Value, Bit 3 - Print Total Value, Bit 4 – Print Max & Min Values, Bit 5 – Print Setpoint Values
40490	Load Serial Settings		0	1	0	Read/Write	Changing 40481-40487 will not update the PAX2A until this register is written with a 1. After the write, the communicating device must be changed to new PAX2A settings and this register returns to 0.
UNITS MNEMONICS							
List A	List B	Line 1 Units Label Mode (A/B List)				SEE USER LIST FUNCTION IN INPUT MODULE FOR DETAILS	
40601	40801	Line 1 Units Mnemonic Digit 1 (Left)	0	57	0	Read/Write	Label Mnemonic Mode only. 0 = 9 = I 18 = Q 27 = Z 36 = 8 45 = m(r) 54 =] 1 = A 10 = J 19 = R 28 = 0 37 = 9 46 = o 55 = / 2 = b 11 = K 20 = S 29 = 1 38 = a 47 = q 56 = ° 3 = C 12 = L 21 = t 30 = 2 39 = c 48 = r 57 = _ 4 = d 13 = M(l) 22 = U 31 = 3 40 = e 49 = u 5 = E 14 = M(r) 23 = V 32 = 4 41 = g 50 = w(r) 6 = F 15 = N 24 = W(l) 33 = 5 42 = h 51 = - 7 = G 16 = O 25 = W(r) 34 = 6 43 = i 52 = = 8 = H 17 = P 26 = Y 35 = 7 44 = n 53 = [
40602	40802	Line 1 Units Mnemonic Digit 2	0	57	0	Read/Write	
40603	40803	Line 1 Units Mnemonic Digit 3 (Right)	0	57	0	Read/Write	
List A	List B	Line 1 Units Custom Mode (A/B List)					
40604	40804	Input Mnemonic - Digit 1 (Left)	0	57	0	Read/Write	Custom Mnemonic Mode. (See 40601 for list)
40605	40805	Input Mnemonic - Digit 2	0	57	0	Read/Write	
40606	40806	Input Mnemonic - Digit 3 (Right)	0	57	0	Read/Write	
40607	40807	Gross Mnemonic - Digit 1	0	57	0	Read/Write	
40608	40808	Gross Mnemonic - Digit 2	0	57	0	Read/Write	
40609	40809	Gross Mnemonic - Digit 3	0	57	0	Read/Write	
40610	40810	Tare Mnemonic - Digit 1	0	57	0	Read/Write	
40611	40811	Tare Mnemonic - Digit 2	0	57	0	Read/Write	
40612	40812	Tare Mnemonic - Digit 3	0	57	0	Read/Write	
40613	40813	Total Mnemonic - Digit 1	0	57	0	Read/Write	
40614	40814	Total Mnemonic - Digit 2	0	57	0	Read/Write	
40615	40815	Total Mnemonic - Digit 3	0	57	0	Read/Write	
40616	40816	Max (Hi) Mnemonic - Digit 1	0	57	0	Read/Write	
40617	40817	Max (Hi) Mnemonic - Digit 2	0	57	0	Read/Write	
40618	40818	Max (Hi) Mnemonic - Digit 3	0	57	0	Read/Write	
40619	40819	Min (Lo) Mnemonic - Digit 1	0	57	0	Read/Write	
40620	40820	Min (Lo) Mnemonic - Digit 2	0	57	0	Read/Write	
40621	40821	Min (Lo) Mnemonic - Digit 3	0	57	0	Read/Write	

REGISTER ADDRESS		REGISTER NAME	LOW LIMIT	HIGH LIMIT	FACTORY SETTING	ACCESS	COMMENTS
List A	List B	Line 2 Units Label Mode (A/B List)					
40622	40822	Line 2 Units Mnemonic Digit 1 (Left)	0	54	0	Read/Write	Label Mnemonic Mode.
40623	40823	Line 2 Units Mnemonic Digit 2	0	54	0	Read/Write	0 = 9 = I 18 = q 27 = 0 36 = 9 45 = o 54 = _
40624	40824	Line 2 Units Mnemonic Digit 3	0	54	0	Read/Write	1 = A 10 = J 19 = r 28 = 1 37 = a 46 = u
40625	40825	Line 2 Units Mnemonic Digit 4	0	54	0	Read/Write	2 = b 11 = K 20 = S 29 = 2 38 = c 47 = w(r)
40626	40826	Line 2 Units Mnemonic Digit 5	0	54	0	Read/Write	3 = C 12 = L 21 = t 30 = 3 39 = e 48 = -
40627	40827	Line 2 Units Mnemonic Digit 6	0	54	0	Read/Write	4 = d 13 = M(l) 22 = U 31 = 4 40 = g 49 = =
40628	40828	Line 2 Units Mnemonic Digit 7	0	54	0	Read/Write	5 = E 14 = M(r) 23 = W(l) 32 = 5 41 = h 50 = [
40629	40829	Line 2 Units Mnemonic Digit 8	0	54	0	Read/Write	6 = F 15 = N 24 = W(r) 33 = 6 42 = i 51 =]
40630	40830	Line 2 Units Mnemonic Digit 9 (Right)	0	54	0	Read/Write	7 = G 16 = O 25 = Y 34 = 7 43 = n 52 = /
							8 = H 17 = P 26 = Z 35 = 8 44 = m(r) 53 = °
List A	List B	Line 2 Units Custom Mode (A/B List)					
40631	40831	Input Mnemonic - Digit 1	0	54	0	Read/Write	Custom Mnemonic Mode. (See 40622 for list)
40632	40832	Input Mnemonic - Digit 2	0	54	0	Read/Write	
40633	40833	Input Mnemonic - Digit 3	0	54	0	Read/Write	
40634	40834	Input Mnemonic - Digit 4	0	54	0	Read/Write	
40635	40835	Input Mnemonic - Digit 5	0	54	0	Read/Write	
40636	40836	Input Mnemonic - Digit 6	0	54	0	Read/Write	
40637	40837	Input Mnemonic - Digit 7	0	54	0	Read/Write	
40638	40838	Input Mnemonic - Digit 8	0	54	0	Read/Write	
40639	40839	Input Mnemonic - Digit 9	0	54	0	Read/Write	
40640	40840	Gross Mnemonic - Digit 1	0	54	0	Read/Write	
40641	40841	Gross Mnemonic - Digit 2	0	54	0	Read/Write	
40642	40842	Gross Mnemonic - Digit 3	0	54	0	Read/Write	
40643	40843	Gross Mnemonic - Digit 4	0	54	0	Read/Write	
40644	40844	Gross Mnemonic - Digit 5	0	54	0	Read/Write	
40645	40845	Gross Mnemonic - Digit 6	0	54	0	Read/Write	
40646	40846	Gross Mnemonic - Digit 7	0	54	0	Read/Write	
40647	40847	Gross Mnemonic - Digit 8	0	54	0	Read/Write	
40648	40848	Gross Mnemonic - Digit 9	0	54	0	Read/Write	
40649	40849	Tare Mnemonic - Digit 1	0	54	0	Read/Write	
40650	40850	Tare Mnemonic - Digit 2	0	54	0	Read/Write	
40651	40851	Tare Mnemonic - Digit 3	0	54	0	Read/Write	
40652	40852	Tare Mnemonic - Digit 4	0	54	0	Read/Write	
40653	40853	Tare Mnemonic - Digit 5	0	54	0	Read/Write	
40654	40854	Tare Mnemonic - Digit 6	0	54	0	Read/Write	
40655	40855	Tare Mnemonic - Digit 7	0	54	0	Read/Write	
40656	40856	Tare Mnemonic - Digit 8	0	54	0	Read/Write	
40657	40857	Tare Mnemonic - Digit 9	0	54	0	Read/Write	
40658	40858	Total Mnemonic - Digit 1	0	54	0	Read/Write	
40659	40859	Total Mnemonic - Digit 2	0	54	0	Read/Write	
40660	40860	Total Mnemonic - Digit 3	0	54	0	Read/Write	
40661	40861	Total Mnemonic - Digit 4	0	54	0	Read/Write	
40662	40862	Total Mnemonic - Digit 5	0	54	0	Read/Write	
40663	40863	Total Mnemonic - Digit 6	0	54	0	Read/Write	
40664	40864	Total Mnemonic - Digit 7	0	54	0	Read/Write	
40665	40865	Total Mnemonic - Digit 8	0	54	0	Read/Write	
40666	40866	Total Mnemonic - Digit 9	0	54	0	Read/Write	
40667	40867	Max (Hi) Mnemonic - Digit 1	0	54	0	Read/Write	
40668	40868	Max (Hi) Mnemonic - Digit 2	0	54	0	Read/Write	
40669	40869	Max (Hi) Mnemonic - Digit 3	0	54	0	Read/Write	
40670	40870	Max (Hi) Mnemonic - Digit 4	0	54	0	Read/Write	

REGISTER ADDRESS		REGISTER NAME	LOW LIMIT	HIGH LIMIT	FACTORY SETTING	ACCESS	COMMENTS
40671	40871	Max (Hi) Mnemonic - Digit 5	0	54	0	Read/Write	
40672	40872	Max (Hi) Mnemonic - Digit 6	0	54	0	Read/Write	
40673	40873	Max (Hi) Mnemonic - Digit 7	0	54	0	Read/Write	
40674	40874	Max (Hi) Mnemonic - Digit 8	0	54	0	Read/Write	
40675	40875	Max (Hi) Mnemonic - Digit 9	0	54	0	Read/Write	
40676	40876	Min (Lo) Mnemonic - Digit 1	0	54	0	Read/Write	
40677	40877	Min (Lo) Mnemonic - Digit 2	0	54	0	Read/Write	
40678	40878	Min (Lo) Mnemonic - Digit 3	0	54	0	Read/Write	
40679	40879	Min (Lo) Mnemonic - Digit 4	0	54	0	Read/Write	
40680	40880	Min (Lo) Mnemonic - Digit 5	0	54	0	Read/Write	
40681	40881	Min (Lo) Mnemonic - Digit 6	0	54	0	Read/Write	
40682	40882	Min (Lo) Mnemonic - Digit 7	0	54	0	Read/Write	
40683	40883	Min (Lo) Mnemonic - Digit 8	0	54	0	Read/Write	
40684	40884	Min (Lo) Mnemonic - Digit 9	0	54	0	Read/Write	
FACTORY SERVICE							
40501-40506		Factory Service Registers	N/A	N/A	N/A	Read/Write	Factory Use Only - Do Not Modify
41001-41010		Slave ID	N/A	N/A	N/A	Read Only	RLC-PAX2S <a><0100h><0020h><0020h><0010h> <a> = SP Card Status. „0“-No Card, „2“-Dual SP, „4“-Quad SP = Linear Card Status. „0“-Not Installed, „1“-Installed <0100h> = Version Number (1.00 or higher) <0020h><0020h> = 64 Register Writes, 64 Register Reads (Max.) <0010h> = 16 Register GUID/Scratch
41101-41116		GUID/Scratch	N/A	N/A	N/A	Read/Write	Reserved

This page intentionally left blank.

WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **25 months** from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal **two (2) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components in which wear is not warranted, include but are not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by the company will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

RETURN REQUESTS/INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of the product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 2006 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.

Where Do I Find Everything I Need for Process Measurement and Control? OMEGA...Of Course! *Shop online at omega.com*

TEMPERATURE

- ☑ Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- ☑ Wire: Thermocouple, RTD & Thermistor
- ☑ Calibrators & Ice Point References
- ☑ Recorders, Controllers & Process Monitors
- ☑ Infrared Pyrometers

PRESSURE, STRAIN AND FORCE

- ☑ Transducers & Strain Gages
- ☑ Load Cells & Pressure Gages
- ☑ Displacement Transducers
- ☑ Instrumentation & Accessories

FLOW/LEVEL

- ☑ Rotameters, Gas Mass Flowmeters & Flow Computers
- ☑ Air Velocity Indicators
- ☑ Turbine/Paddlewheel Systems
- ☑ Totalizers & Batch Controllers

pH/CONDUCTIVITY

- ☑ pH Electrodes, Testers & Accessories
- ☑ Benchtop/Laboratory Meters
- ☑ Controllers, Calibrators, Simulators & Pumps
- ☑ Industrial pH & Conductivity Equipment

DATA ACQUISITION

- ☑ Data Acquisition & Engineering Software
- ☑ Communications-Based Acquisition Systems
- ☑ Plug-in Cards for Apple, IBM & Compatibles
- ☑ Datalogging Systems
- ☑ Recorders, Printers & Plotters

HEATERS

- ☑ Heating Cable
- ☑ Cartridge & Strip Heaters
- ☑ Immersion & Band Heaters
- ☑ Flexible Heaters
- ☑ Laboratory Heaters

ENVIRONMENTAL MONITORING AND CONTROL

- ☑ Metering & Control Instrumentation
- ☑ Refractometers
- ☑ Pumps & Tubing
- ☑ Air, Soil & Water Monitors
- ☑ Industrial Water & Wastewater Treatment
- ☑ pH, Conductivity & Dissolved Oxygen Instruments