

**5 YEAR**  
WARRANTY



**RoHS**

# **Ω OMEGA™** **User's Guide**

***Shop online at  
omega.com***

***e-mail: [info@omega.com](mailto:info@omega.com)***

***For latest product manuals:  
[www.omegamanual.info](http://www.omegamanual.info)***



## **LDB-T** **Temperature Meters**



omega.com info@omega.com

**Servicing North America:**

**U.S.A.  
Headquarters:**

Omega Engineering, Inc.

Toll-Free: 1-800-826-6342 (USA & Canada only)

Customer Service: 1-800-622-2378 (USA & Canada only)

Engineering Service: 1-800-872-9436 (USA & Canada only)

Tel: (203) 359-1660

Fax: (203) 359-7700

e-mail: info@omega.com

**For Other Locations Visit [omega.com/worldwide](http://omega.com/worldwide)**

# 1. LDB-T Series

## Large format industrial meters for temperature signals

Large format meters for long distance reading, for industrial applications. Different formats available with 4 and 6 digits, with 60 mm and 100 mm digit height. Front keypad to access the configuration menu, and optional remote keypad.

Models to measure temperature signals from Pt100/RTD probes with 2 and 3 wires, and thermocouple types J, K, T, E, S, R, N, C, L and X. Reading configurable in degrees Celsius (°C) or Fahrenheit (°F). Configurable compensation of the thermocouple cold junction (*see section 1.13.2*). Configurable manual offset (*see section 1.13.2*). Configurable behaviour in case of sensor break (*see section 1.13.2*).

Output and control options with 1, 2 and 3 relays, transistor outputs, controls for SSR relays, isolated analog outputs, communications in Modbus RTU, RS485 ASCII and RS232.

Sturdy metal housing with full IP65 protection. Internal connections by plug-in screw clamp terminals, and output through cable glands. Housing prepared for panel, wall and hanging mount.

- Configurable '**Fast access**' to selected functions with key 'UP' (▲) (*see section 1.13.6*)
- '**On power up**' for system protection on 'cold' start-up and/or activation of automatic tare (*see section 1.13.7*)
- alarms with 1 or 2 setpoints, independent activation and deactivation delays, hysteresis, manual unlocking, ... (*see section 1.13.3*)

Display filters, memory of maximum and minimum reading, password protection, 5 brightness levels.

### 1.1 How to use this manual

If this is the first time you are configuring a large format meter, below are the steps to follow to install and configure the instrument.

1. Identify the instrument format (*see section 1.4*)
2. Power and signal connections
  - open the instrument (*see section 1.5*)
  - connect the power (*see section 1.7*)
  - connect the signal (*see section 1.8*)
  - close the instrument (*see section 1.5*)
3. Configure the instrument (*see section 1.13*)
  - configure the sensor connected and configure the temperature parameters (*see section 1.13.2*)
4. Advanced configuration (optional)
  - configure the instrument alarms (*see section 1.13.3*)
  - configure the fast access (*see section 1.13.6*)
  - configure other functions : display filters (1.13.5), 'on power up' (1.13.7), key 'LE' (1.13.8), and password (1.13.11)

Read all the manual sections in order to have a full and clear view of the characteristics of the instrument. Do not forget to read the installation precautions at section 1.17.

5. If the instrument includes analog output (AO) or serial communications (RTU, S4, S2)
  - to include an option to an instrument see section 1.6
  - to configure an installed option, access the option configuration menu (*see section 1.13.15*)
  - see section 2 for information regarding the output and control options available
6. Install the instrument
  - mount on panel, wall or hanging (*see section 1.16*)
  - adjust the brightness level according to your environmental needs (*see section 1.13.14*)

## 1.2 How to order


Format	Model	Power	Color	Option 1	Option 2	Option 3*	Others
LDB-24	T	H					
LDB-24 (60 mm, 4 digits) LDB-26 (60 mm, 6 digits) LDB-44 (100 mm, 4 digits) LDB-46 (100 mm, 6 digits)		-H (85-265 Vac and 120-370 Vdc) -L (11-36 Vdc isolated)	-R (red led) -G (green led)	-R1 (1 relay) -AO (analog output) -RTU (Modbus RTU) -S4 (RS-485) -S2 (RS-232) -T1 (1 transistor) -SSR (1 control SSR) -0 (empty)		*Option 3 available with formats LDB-26 and LDB-46	

## 1.3 Index

1. LDB-T Series . . . . .	2	1.13.14 Brightness configuration . . . . .	16
1.1 How to use this manual . . . . .	2	1.13.15 Access to the options configuration menu . .	16
1.2 How to order . . . . .	3	1.14 Factory configuration . . . . .	17
1.3 Index . . . . .	3	1.15 Full configuration menu. . . . .	18
1.4 Sizes and formats . . . . .	4	1.16 Mounting. . . . .	20
1.4.1 Format LDB-24. . . . .	4	1.17 Installation precautions . . . . .	21
1.4.2 Format LDB-44. . . . .	4	1.18 Warranty . . . . .	21
1.4.3 Format LDB-26. . . . .	5	1.19 CE declaration of conformity . . . . .	21
1.4.4 Format LDB-46. . . . .	5	2. Output and control modules . . . . .	22
1.5 To access the instrument. . . . .	6	2.1 Module R1. . . . .	22
1.6 Modular system . . . . .	6	2.2 Module T1 . . . . .	22
1.7 Power connections and protective earth . . . . .	7	2.3 Module SSR . . . . .	23
1.8 Input signal connections . . . . .	7	2.4 Module AO . . . . .	23
1.9 Connections for remote keypad . . . . .	8	2.5 Module RTU . . . . .	24
1.10 Functions included . . . . .	8	2.6 Module S4 . . . . .	24
1.11 Messages and errors . . . . .	8	2.7 Module S2 . . . . .	25
1.12 Technical specifications . . . . .	8		
1.13 Configuration . . . . .	10		
1.13.1 How to operate the menus . . . . .	10		
1.13.2 Initial set-up . . . . .	11		
1.13.3 Alarms . . . . .	12		
1.13.4 Alarms configuration menu . . . . .	13		
1.13.5 Display filters . . . . .	14		
1.13.6 Fast access . . . . .	14		
1.13.7 'on power up' function . . . . .	14		
1.13.8 'LE' key . . . . .	14		
1.13.9 Display filters configuration menu . . . . .	15		
1.13.10 Tools configuration menu . . . . .	15		
1.13.11 Password configuration . . . . .	16		
1.13.12 Default factory configuration . . . . .	16		
1.13.13 Firmware version . . . . .	16		

# 1.4 Sizes and formats

## 1.4.1 Format LDB-24




Size A	340 mm
Size B	135 mm
Size C	3 mm
Size D	55 mm
Size E	25 mm


Table 1 - Sizes LDB-24

Cut-out G	322 mm (±1)
Cut-out F	117 mm (±1)

Table 2 - Panel cut-out LDB-24



## 1.4.2 Format LDB-44




Size A	542 mm
Size B	166 mm
Size C	3 mm
Size D	55 mm
Size E	25 mm


Table 3 - Sizes LDB-44

Cut-out G	524 mm (±1)
Cut-out F	148 mm (±1)

Table 4 - Panel cut-out LDB-44



1.4.3 Format LDB-26




Size A	436 mm
Size B	135 mm
Size C	3 mm
Size D	55 mm
Size E	25 mm


Table 5 - Sizes LDB-26

Cut-out G	418 mm (±1)
Cut-out F	117 mm (±1)

Table 6 - Panel cut-out LDB-26



1.4.4 Format LDB46




Size A	740 mm
Size B	166 mm
Size C	3 mm
Size D	55 mm
Size E	25 mm

Table 7 - Sizes LDB-46

Cut-out G	722 mm (±1)
Cut-out F	148 mm (±1)

Table 8 - Panel cut-out LDB-46




## 1.5 To access the instrument

To open the housing, remove the screws from the back cover. With each screw there is a metal washer and a plastic washer. Once the screws are out, remove the back cover.

The figure below shows the instrument internal structure for a LDB-26 format. It shows the location of the 3 slots for optional output and control modules, the power terminal and the input signal terminal.

To close the instrument, place the back cover, the screws, the metal washer and the plastic washer. The plastic washer is in contact with the back cover. Confirm that the screws are correctly turning inside the internal female screws.

To ensure a correct IP65 protection tighten the back cover screws with a strength between 30 and 40 Ncm, with the help of a dynamometer screwdriver.




*Risk of electric shock. Removing the back cover will grant access to the internal circuits of the instrument. Operation must be performed by qualified personnel only.*

## 1.6 Modular system

Large format meters are designed with an internal modular architecture. The output and control modules are independent and can be installed by accessing the internal circuits of the instrument, and connecting the module to the connection jumpers of the selected slot.

Each module is provided with a cable tie to fix the module to the tie base. The input signal modules defines the instrument function and are exchangeable, switching a temperature meter to an impulse counter only by replacing the input signal module.


See section 2. for information regarding the output and control options available




- To install an output and control module
- (1) insert the 'module pins' into the 'connection jumpers' in one of the free slots
  - (2) place the 'cable tie' into the 'tie base' and embrace the 'module' firmly, until it is fixed

## 1.7 Power connections and protective earth

1. Unscrew the screws from the back cover and remove the back cover (see section 1.5).
2. Pass the power cable through the power cable gland (see section 1.4).
3. Prepare the power cables so that the earth wire is 20 cm longer than the other cables (see Figure 1).




4. Connect the earth wire to the internal fixed screw 'PE' (see Figure 2) located at the inside of the back cover. The instrument internally connects the back cover metallic



structure with the front metallic structure through an internal green-yellow cable. (dotted cable at Figure 3).




5. Connect phase and neutral (in AC power) or positive and negative (in DC power) to the internal power terminal.
6. The connections label attached to the outside of the instrument has some free space left to write the color or local code for each cable.
7. To comply with security regulation 61010-1, add to the power line a protection fuse acting as a disconnection element, easily accessible to the operator and identified as a protection device.

Power 'H'	500 mA time-lag fuse
Power 'L'	1000 mA time-lag fuse




## 1.8 Input signal connections

1. Unscrew the screws from the back cover and remove the back cover (see section 1.5).
2. Locate the input signal terminal (see section 1.4).
3. Pass the signal cable through the signal cable gland (see section 1.4).
4. Connect the input signal cables
5. The connections label attached to the outside of the instrument has some free space left to write the color or local code for each cable.



## 1.9 Connections for remote keypad

The 4 pin terminal located beside the input signal module allows to replicate a remote version of the front keypad. Connect 4 cables for front keys 'SQ' (■), 'UP' (▲) and 'LE' (◀) and for the common. Pass these cables through the 'remote keypad' cable gland (see section 1.4).



## 1.10 Functions included

Functions included		Section
Fast access menu	yes, configurable	1.13.6
Manual offset	configurable	1.13.2
Thermocouple cold junction	configurable	1.13.2
Probe break detection	configurable	1.13.2
Display filters	'steps'	1.13.5
'On Power Up'	yes	1.13.7
Alarms	simple or double setpoint activation delays deactivation delays hysteresis inverted relays locked alarms	1.13.3
Memory	maximum, minimum	1.13.6
Password	configuration locked	1.13.11
Brightness	configurable, 5 levels	1.13.14

Table 9 - Functions included

## 1.12 Technical specifications

### Digits

number of digits	4
digit	7 segments
view angle	120°
color	red or green
digit height	(see Table 12)

### Reading

max., min.	9999 / -1999
overrange / underrange	flash reading
sensor break	reading to maximum or minimum (see section 1.13.2)

### Input signal

accepted signals	Pt100 / RTD and thermocouples
temperature scale	ITS90
units	°C or °F
wire section	max. 0.5 mm <sup>2</sup>

### Pt100 / RTD signals

resolution	2 or 3 wire, selectable
measuring ranges	1° or 0.1°, selectable
max. error at 25 °C	(see Table 11)
thermal drift	(see Table 11)
cable res. compensation	automatic, up to 14 Ohms
compensation error	<0.02 °C / Ohm
readings	4 / second

### Thermocouples

(*thermocouple X is a lineal 10 uV/°C signal)	
resolution	1°
measuring ranges	(see Table 11)
max. error at 25 °C	(see Table 11)
thermal drift	(see Table 11)
thermocouple CJC	automatic (see section 1.13.2)
CJ accuracy	<1.0 °C
CJ thermal drift	<0.04 °/°C
readings	3 / second

## 1.11 Messages and errors

### Messages and errors.

'h.ovr'	hardware overrange ('h.ovr'). Input signal is higher than 80 mV.
'h.ubr'	hardware underrange ('h.ubr'). Input signal is lower than -30 mV.
'd.ubr'	display underrange ('d.ubr') / overrange ('d.ovr').
'd.ovr'	The display is displaying the maximum/minimum value possible (-1999/9999).

Table 10 - Messages and error codes.

### Messages and errors.

'brk'	instrument displays 'brk' '9999' or '-9999' <ul style="list-style-type: none"> <li>measured Pt100 resistance is higher than 390 Ohms (higher than 850 °C)</li> <li>the Pt100 third wire has a measured impedance higher than 15 Ohms</li> <li>the thermocouple is open circuit</li> </ul>
'Err.1'	incorrect password.
'Err.2'	at 'oPt.X' menu entry, module is not recognized.

Table 10 - Messages and error codes.

<b>Power</b>	
power 'H'	85 to 265 Vac and 120 to 370 Vdc isolated (isolation 2500 Vac)
power 'L'	11 to 36 Vdc isolated (isolation 1500 Vdc)
consumption	(see Table 12)
fuses	(see section 1.7)
wire section	max. 2.5 mm <sup>2</sup>
<b>Configuration</b>	front keypad with 3 keys remote keypad (see section 3.1)
<b>Output and control options</b>	relay output, analog retransmission, Modbus RTU, ... (see section 2)
<b>Mechanical</b>	
IP protection	full IP65 housing
mounting	panel, wall , hanging (see section 1.16)
connections	cable gland outputs internal plug-in screw terminals
housing material	textured iron, black painted methacrylate front filter
weight	(see Table 12)
front sizes	(see section 1.4)
panel cut-out	(see section 1.4)
depth	(see section 1.4)
<b>Temperature</b>	
operation	from 0 to +50 °C
storage	from -20 to +70 °C
warm-up time	15 minutes

	<b>Format LDB-24</b>	<b>Format LDB-44</b>
<i>Number of digits</i>	4	4
<i>Digit height</i>	60 mm	100 mm
<i>Reading distance</i>	25 meters	50 meters
<i>Slots for output and control options</i>	2	2
<i>Consumption (without options installed)</i>	3 W	5.25 W
<i>Consumption (with options installed)</i>	5 W	6.75 W
<i>Weight</i>	2200 gr.	2500 gr.

Table 12 - Technical specifications associated to format


<b>Sensor</b>	<b>Range (en °C)</b>	<b>Error max. a 25 °C</b>	<b>Range (en °F)</b>	<b>Offset thermal drift</b>	<b>Span thermal drift* *includes offset thermal drift</b>
<i>Pt100 / RTD</i>	800/-200 °C	<0.2 °C	1562/-328 °F	0.05 °/°C	0.10 °/°C
<i>Thermocouple J</i>	1200/-200 °C	<2 °C	2192/-328 °F	0.05 °/°C	0.20 °/°C
<i>Thermocouple K</i>	1372/-200 °C	<2 °C	2372/-328 °F	0.05 °/°C	0.20 °/°C
<i>Thermocouple T</i>	400/-200 °C	<2 °C	752/-328 °F	0.02 °/°C	0.02 °/°C
<i>Thermocouple E</i>	1000/-200 °C	<2 °C	1832/-328 °F	0.05 °/°C	0.20 °/°C
<i>Thermocouple S</i>	1768/-50 °C	<4 °C	2282/-58 °F	0.20 °/°C	0.20 °/°C
<i>Thermocouple R</i>	1600/-50 °C	<4 °C	2912/-58 °F	0.20 °/°C	0.20 °/°C
<i>Thermocouple N</i>	1300/-200 °C	<2 °C	2372/-328 °F	0.05 °/°C	0.20 °/°C
<i>Thermocouple C</i>	2320/0 °C	<2 °C	4192/32 °F	0.02 °/°C	0.02 °/°C
<i>Thermocouple L</i>	900/-200 °C	<2 °C	1652/-328 °F	0.05 °/°C	0.20 °/°C
<i>Thermocouple X</i>	4000/-200 °C	<2 °C	7232/-328 °F	0.02 °/°C	0.02 °/°C

Table 11 - Technical specifications associated to sensor



## 1.13.2 Initial set-up

Press 'SQ' (■) for 1 second to access the 'configuration menu'. For a description on how to operate inside the menus see section 1.13.1. For a full vision of the 'configuration menu' structure see section 1.15.



To configure the initial set up of the instrument, select the sensor that is connected to the instrument, and then configure the parameters at the 'temperature configuration' menu.

At the 'Input' ('Inp') parameter, select the sensor that is connected to the instrument. Available options are Pt100/RTD with 2 wires, Pt100/RTD with 3 wires, and thermocouples J, K, T, E, S, R, N, C, L and X. Thermocouple X is a linear 10 uV/°C signal.

At the 'Temperature configuration' ('cnF.t') menu, configure the following parameters:

- at the 'Degrees' ('dEG') parameter select '°C' to read the temperature in degrees celsius or '°F' to read in degrees Fahrenheit.
- at the 'Resolution Pt100' ('P.rES') parameter select '1°' to read the Pt100/RTD with 1 degree resolution, or '0.1°' for tenths of degree resolution.
- at the 'Reading offset' ('oFFS') parameter introduce a number of counts that will be directly added to the reading. This value applies both to the Pt100\RTD and thermocouples. This offset allows to easily compensate for errors due to different types of probes, which can not be corrected by any other means. Values accepted from -100 to 100 counts of display.
- at the 'Thermoc. CJC' ('t.cJc') parameter activate or deactivate the automatic compensation of the thermocouple cold junction. When working with real thermocouples, compensation must be set to 'on'. When working with electronic thermocouple simulators, it may be necessary to deactivate the automatic compensation.
- at the 'on break' ('on.bk') parameter configure the behavior of the instrument (and thus, the alarm behavior) in case of sensor break. Select 'to\_h' to force the reading to go to high level (overrange), or select 'to\_L' to force the reading to low level (underrange).
- at the 'Alpha' ('ALPh') parameter select the alpha for the Pt100/RTD sensor. The two standard industrial values are '385' and '390'.

### 1.13.3 Alarms

The instrument manages 3 independent internal alarms, each one controlling the activation of an optional relay, transistor or control SSR output. Optional modules (see section 2) are installed at the free slots inside the instrument (see section 1.4). LDB-24 and LDB-44 formats have 2 free slots for output and control modules, while LDB-26 and LDB-46 formats have 3 free slots for output and control modules. The instrument has 3 front leds that reflect the state of the 3 internal alarms. These leds are only for local help during installation, as they are not appropriate for long distance reading. Each alarm controls the activation of the relay, transistor or control SSR installed on its associated slot, and the front led.

- **Configurable parameters**

Each alarm has several parameters for configuration, starting with the usual setpoint, hysteresis and maximum (alarm active when reading is higher than setpoint) or minimum (alarm active when reading is lower than minimum) alarm types (see Figure 8).

- **Activation and deactivation delays**

Each alarm can configure independent activation and deactivation delays. These delays affect the alarm as a whole, and the delay will affect the front led and the associated relay.

- **Second setpoint**

Configuring a second setpoint creates ‘windowed alarms’. The windowed alarm controls with a single relay output if the reading is inside or outside the values defined (see Figure 9).

- **Inverted relay**

Activate the ‘inverted relay’ function to invert the activation logic of the associated relay.

- **‘Locked alarms’**

Activate the ‘locked alarms’ function will force the operator to interact with the instrument when an alarm has been activated. Once activated, the alarm will remain locked at active state, even if the reading returns to a value below setpoint, until the operator manually unlocks the alarms pressing the front key ‘LE’ (or the remote key ‘LE’, see section 3.1).




Figure 8 - Examples of alarm with 1 setpoint





Figure 9 - Example of alarm with 2 setpoints

### 1.13.4 Alarms configuration menu



To configure the alarm, access the alarm menu ('ALr1', 'ALr2' or 'ALr3') and configure the following parameters :

- at the '**Active**' ('Act') parameter select '**on**'
- at the '**Type of alarm**' ('Type') parameter select '**MAX**' for maximum alarm (activates when reading is higher than setpoint), or '**Min**' for minimum alarm (activates when reading is lower than setpoint).
- at the '**Setpoint**' ('SEt') parameter configure the alarm activation point. Parameter value is accessible through 'fast access' (see section 1.13.6).
- at the '**Hysteresis**' ('hySt') parameter select the hysteresis value. Hysteresis applies to the alarm deactivation. Alarm deactivates once the reading is beyond the setpoint plus the hysteresis value. Hysteresis prevents relay switching in case of signal fluctuations close to the setpoint value.
- at the '**Activation delay**' ('dEL.0') parameter configure the delay to apply before the alarm is activated. Delay starts to count once the setpoint is reached. Value from 0.0 to 99.9 seconds.
- at the '**Deactivation delay**' ('dEL.1') parameter configure the delay to apply before the alarm is deactivated. Delay starts to count once the setpoint is reached plus the hysteresis value. Value from 0.0 to 99.9 seconds.
- to work with 'windowed alarms' (see Figure 9) activate '**Setpoint 2**' ('SEt2') to '**on**' and then configure the desired second setpoint value. Second setpoint must always be higher in value than the first setpoint.
- at the '**Inverted relay**' ('r.Inv') parameter select '**on**' to invert the activation logic of the relay. Relay is inactive when alarm is active, and relay is active when alarm is inactive.
- at the '**Locked alarm**' ('A.Lck') parameter select '**on**' to block the automatic alarm deactivation. Alarm deactivation must be performed manually, by pressing the 'LE' front button (see section 1.13.8).

### 1.13.5 Display filters

The available functions are:

- the **'Steps' ('StEP')** function defines the reading to be done in steps of 1, 2, 5, 10, 20 or 50 counts.

*Example - selecting a step of 20 configures the reading to change in steps of 20 counts ('1420', '1440', '1460', ...).*

- the **'Memory of maximum' ('MAX')** function displays the maximum reading value stored in memory and allows to reset this value. This parameter is directly accessible using key 'UP' (▲) (see section 1.13.6).

- the **'Memory of minimum' ('MIn')** function displays the minimum reading value stored in memory and allows to reset this value. This parameter is directly accessible using key 'UP' (▲) (see section 1.13.6).

### 1.13.6 Fast access

The *'fast access'* is an operator configurable menu. The operator can access this menu with a single press of the front key 'UP' (▲). The configured menu entries will be accessible. Eligible parameters to be accessed by this menu are:

- access to the alarm setpoints through the 'UP' (▲) key allows to read and modify the values.
- access to the maximum and minimum alarms through the 'UP' (▲) key allows to read and reset the values. To reset the memory values: visualize the value on display, press the 'UP' (▲) key, when the 'rSt' message appears, press 'SQ' (■). The instrument will return to the memory visualization. Press the 'LE' (◀) key to exit his menu.

The *'fast access'* menu is not affected by the password function. This means that the configuration menu can be password blocked, while some configured functions or arameters can still be accessible to the operator through the *'fast access'* menu.

- **Super fast access**

If only a single function is selected for the *'fast access'* menu, pressing the the 'UP' (▲) key will shortly display the function name and then automatically jump to the function value.

### 1.13.7 'on power up' function

The **'On Power Up' ('on.Pu')** functions allows to define a series of actions to activate when the instrument restarts after a power loss. Functions available are a delay so the instrument waits a defined time before starting to measure and control, and the state of the alarms at power up. The functions will apply only after a restart due to power-loss, they will not apply after a restart due to changes in configuration.


Delaying the measure and control functions gives additional time to elements of the system who are slower, so they can start completely before the instrument begins to acquire signal and control the outputs.

While on delay mode, the instrument shows all decimal points lightened and flashing, all alarms are deactivated, and there is no signal acquisition or communications control. When the delay time is over, the instrument starts its normal functioning.

### 1.13.8 'LE' key

The 'LE' (◀) key at the front of the instrument can be configured to activate several functions. Only one function can be assigned to the 'LE' (◀) key. Eligible functions are the alarm unlock function (see section 1.13.3).


### 1.13.9 Display filters configuration menu



All display functions are grouped under the **'Display'** menu. For more information relating the functions listed below see section 1.13.5.

- at the **'Steps'** (**'StEP'**) parameter configure the value for the steps reading changes.
- the **'Memory of maximum'** (**'MAX'**) and **'Memory of minimum'** (**'MIN'**) are access to the memory values. To reset the value, select the **'rSt'** entry and press **'SQ'** (■).

### 1.13.10 Tools configuration menu



Inside the **'Tools'** (**'tool'**) menu several different functions are grouped.

At the **'Key UP ('fast access)'** (**'K.uP'**) menu configure which functions and parameters will be accessible through the 'fast access' menu. Select **'on'** to activate each function. For more information see section 1.13.6.

- the **'Setpoint 1'** (**'ALr1'**) function allows to visualize and modify the alarm1 setpoint through the 'fast access' menu.
- the **'Setpoint 2'** (**'ALr2'**) function allows to visualize and modify the alarm2 setpoint through the 'fast access' menu.
- the **'Setpoint 3'** (**'ALr3'**) function allows to visualize and modify the alarm3 setpoint through the 'fast access' menu.

- the **'Memory of maximum'** (**'MAX'**) or **'Memory of minimum'** (**'MIN'**) functions allow to visualize the maximum or minimum reading value stored in memory.


The **'On Power Up'** (**'on.Pu'**) menu assigns functions to be applied when the instrument starts after a power loss. For more information see section 1.13.7.

- at the **'Delay'** (**'dLAY'**) parameter configure the time the instrument will wait before starting normal functionality. Time between 0 and 200 seconds.
- at the **'Alarm 1'** (**'ALr1'**), **Alarm 2** (**'ALr2'**) and **Alarm 3** (**'ALr3'**) select **'on'** for the alarm to be active during the start up after a power loss.

The **'LE'** (◀) key at the front of the instrument can be configured to activate several functions. For more information see section 1.13.8.

- the **'No function'** (**'nonE'**) parameter assigns no function.
- the **'Alarm unlock'** (**'A.Lck'**) parameter assigns the manual alarm unlocking, when the **'Locked alarms'** (**'A.Lck'**) is active (see section 1.13.3).


### 1.13.11 Password configuration



The password function blocks access to the configuration menu. The ‘fast access’ menu is not affected by the password function. This means that the configuration menu can be password blocked, while some configured functions or parameters can still be accessible to the operator through the ‘fast access’ menu.


To active the ‘**Password**’ function select ‘on’ and introduce the 6 digits code. The code will be requested when trying to access the ‘configuration menu’ (front key ‘SQ’ (■)).

### 1.13.12 Default factory configuration




At the ‘**Factory configuration**’ (‘FAcT’) menu select ‘yes’ to activate the default factory configuration. See section 1.14 for a list of default parameters.

### 1.13.13 Firmware version




The ‘**Version**’ (‘VEr’) menu informs about the firmware version installed on the instrument.

### 1.13.14 Brightness configuration



At the ‘**Brightness**’ (‘LIGH’) menu select the intensity level for the display . Use this function to adapt the brightness to match other instruments in the vicinity or to the darkness or clarity of your environment.

### 1.13.15 Access to the options configuration menu



The output and control options are optional modules that can be installed at the instrument. Formats LDB-24 and LDB-44 have 2 free slots for output and control options, while formats LDB-26 and LDB-46 have 3 free slots (see section 1.4).

Several of these optional modules have their own configuration menu embedded. The ‘OPT.1’, ‘OPT.2’ and ‘OPT.3’ menu entries give access to the configuration menu of the option installed.



See section 2 for a list of available output and control modules



## 1.14 Factory configuration

Sensor	Pt100 2 wires
Temperature configuration	
Degrees	°C
Pt100 resolution	0.1°
Offset	0 counts
Thermocouple CJC	on
'on break'	'to_h'
Alpha	385
Alarms 1,2 and 3	
Active	off (disabled)
Type	as maximum
Setpoint	1000
Hysteresis	0 counts
Activation delay	0.0 seconds
Deactivation delay	0.0 seconds
Setpoint 2	off
Inverted relay	off
Locked alarms	off
Display	
'Steps'	off
Maximum memory	-1999
Minimum memory	9999
Tools	
Fast access	off
'On Power Up'	
Delay	0 seconds
Alarm 1	off
Alarm 2	off
Alarm 3	off
Ley 'LE'	no function
Password	off
Brightness	3

## 1.15 Full configuration menu

Press 'SQ' (■) for 1 second to access the 'Configuration menu'.





## 1.16 Mounting

The instrument fixations are designed to allow panel mount, wall mount, or hanging mount. For each type of mounting,

- Panel mount. Apply the cut-out to the panel as seen on section 1.4. Remove the side fixations. Introduce the instrument into the panel cut-out. Mount the side fixations as shown (see Figure 10). Slightly loosen the fixation screw of one side and press the instrument against the panel. Tighten the fixation screw so it presses the panel and maintains the fixation. Repeat with the opposite side fixation. For IP65 protection at the panel junction, see the IPB accessories at section 3.




Figure 10 - Panel mount

see the position of the fixations at the images below.

- Wall mount. Mount the side fixations against the wall, as shown (see Figure 12). Each fixation has 2 holes with 4.5 mm diameter and a separation between hole centers of 30 mm. Once the side fixations are secured against the wall, place the instrument and press the fixation screws slightly. Tilt the instrument to the desired viewing angle and firmly screw the fixation screws.




Figure 12 - Wall mount

- Hanging mount. Mount the side fixations as shown (see Figure 11). Each fixation has 2 holes with 4.5 mm diameter and a separation between hole centers of 30 mm. Instrument can be hanged using cable, threaded rod, ....




Figure 11 - Hanging mount

1.17 Installation precautions



Risk of electrical shock. Instrument terminals can be connected to dangerous voltage.



Instrument conforms to CE rules and regulations.

This instrument has been designed and verified conforming to the 61010-1 CE security regulation, for industrial applications. Installation of this instrument must be performed by qualified personnel only. This manual contains the appropriate information for the installation. Using the instrument in ways not specified by the manufacturer may lead to a reduction of the specified protection level. Disconnect the instrument from power before starting any maintenance and / or installation action.

The instrument does not have a general switch and will start operation as soon as power is connected. The instrument does not have protection fuse, the fuse must be added during installation.

An appropriate ventilation of the instrument must be assured. Do not expose the instrument to excess of humidity. Maintain clean by using a humid rag and do NOT use abrasive products such as alcohols, solvents, etc.

General recommendations for electrical installations apply, and for proper functionality we recommend : if possible, install the instrument far from electrical noise or magnetic field generators such as power relays, electrical motors, speed variators, ... If possible, do not install along the same conduits power cables (power, motor controllers, electrovalves, ...) together with signal and/or control cables.

Before proceeding to the power connection, verify that the voltage level available matches the power levels indicated in the label on the instrument.

In case of fire, disconnect the instrument from the power line, fire alarm according to local rules, disconnect the air conditioning, attack fire with carbonic snow, never with water.

1.18 Warranty

Please see the last page for Omega’s warranty disclaimer

1.19 CE declaration of conformity

Supplier      Omega Engineering  
Products      LDB-T

The manufacturer declares that the instruments indicated comply with the directives and rules indicated below.

Electromagnetic compatibility directive 2014/30/EU  
Low voltage directive 2014/65/EU  
Directive ROHS 2011/65/EU  
Directive WEEE 2012/19/EU

Security rules EN-61010-1

Instrument      Fixed, Permanently connected  
Pollution degree 1 and 2 (without condensation)  
Isolation      Basic + Protective union  
Category      CAT-II

Electromagnetic compatibility rules EN-61326-1

EM environment      Industrial

Immunity levels

EN-61000-4-2	By contact ±4 KV	Criteria B
	By air ±8 KV	Criteria B
EN-61000-4-3		Criteria A
EN-61000-4-4	On AC power lines: ±2 KV	Criteria B
	On DC power lines: ±2 KV	Criteria B
	On signal lines : ±1 KV	Criteria B
EN-61000-4-5	Between AC power lines ±1 KV	Criteria B
	Between AC power lines and earth ±2 KV	Criteria B
	Between DC power lines ±1 KV	Criteria B
	Between DC power lines and earth ±2 KV	Criteria B
	Between signal lines and earth ±1 KV	Criteria B
EN-61000-4-6		Criteria A
EN-61000-4-8	30 A/m at 50/60 Hz	Criteria A
EN-61000-4-11	0 % 1 cycle	Criteria A
	40 % 10 cycles	Criteria A
	70 % 25 cycles	Criteria B
	0 % 250 cycles	Criteria B

Emission levels

CISPR 11      Instrument Class A, Group 1      Criteria A



According to directive 2012/19/EU, electronic equipment must be recycled in a selective and controlled way at the end of its useful life.


# 2. Output and control modules

## 2.1 Module R1


The R1 module provides 1 relay output to install in large format industrial meters from LDB series. Formats LDB-26 and LDB-46 accept up to 3 relays, and formats LDB-24 and LDB-44 accept up to 2 relays.

Configuration is performed from the front keypad of the instrument, by setting the alarm parameters. Check the alarm menu parameters at the instrument user's manual for full information.

Modules R1 can be provided factory installed into an instrument, or standalone for delayed installation. No soldering or special configuration is required. See section 1.6 on how to install output and control modules.



Type of relay	3 contacts (Com, NO, NC)
Max. current	3 A (resistive load)
Voltage	250 Vac continuous
Isolation	3500 Veff
Terminal	plug-in screw clamp, pitch 5.08 mm
Installation allowed at	slot 1, slot 2, slot 3




## 2.2 Module T1


The T1 module provides 1 transistor output to install in large format industrial meters from LDB series. Formats LDB-26 and LDB-46 accept up to 3 transistor outputs, and formats LDB-24 and LDB-44 accept up to 2 transistor outputs.

Configuration is performed from the front keypad of the instrument, by setting the alarm parameters. Check the alarm menu parameters at the instrument user's manual for full information.

Modules T1 can be provided factory installed into an instrument, or standalone for delayed installation. No soldering or special configuration is required. See section 1.6 on how to install output and control modules.



Type of output	transistor
Max. voltage	35 Vdc
Max. current	50 mA
Isolation	3500 Veff, optoisolated
Terminal	plug-in screw clamp, pitch 5.08 mm
Installation allowed at	slot 1, slot 2, slot 3



## 2.3 Module SSR

The SSR module provides 1 output for SSR relay control, to install in large format industrial meters from LDB series. Formats LDB-26 and LDB-46 accept up to 3 SSR control outputs, and formats LDB-24 and LDB-44 accept up to 2 SSR control outputs.

Configuration is performed from the front keypad of the instrument, by setting the alarm parameters. Check the alarm menu parameters at the instrument user's manual for full information.

Modules SSR can be provided factory installed into an instrument, or standalone for delayed installation. No soldering or special configuration is required. See section 1.6 on how to install output and control modules.




Figure 17 - Module 'SSR' and internal schematic

Type of output	for SSR relay control
Output voltage	+15 Vdc
Max. current	45 mA
Isolation	1000 Vdc
Terminal	plug-in screw clamp, pitch 5.08 mm
Installation allowed at	slot 1, slot 2, slot 3




Figure 18 - Connections for 'SSR' control module

## 2.4 Module AO

The AO module provides 1 analog output, configurable for 4/20 mA or 0/10 Vdc signal, to install in large format industrial meters from LDB series. Formats LDB-26 and LDB-46 accept up to 3 analog outputs, and formats LDB-24 and LDB-44 accept up to 2 analog outputs.

Output signal is fully scalable, both with positive and negative slopes, and is proportional to the reading. The mA output can be configured for active loops (the instrument provides the power to the mA loop) or passive loops (the loop power is external to the instrument).

Configuration is performed from the front keypad of the instrument, by accessing the menu entries 'Opt.1', 'Opt.2' or 'Opt.3', according to the slot where the module is installed.

AO modules can be provided factory installed into an instrument, or standalone for delayed installation. No soldering or special configuration is required. See section 1.6 on how to install output and control modules.





Figure 19 - Module 'AO'

Signal output	4/20mA, 0/10Vdc (active and passive)
Accuracy	0.1% FS
Isolation	1000 Vdc
Terminal	plug-in screw clamp, pitch 5.08 mm
Installation allowed at	slot 1, slot 2, slot 3



A	Excitation voltage
B	Signal in mA or Vdc
C	Common
Jumper M	Jumper closed for mA output
Jumper V	Jumper closed for Vdc output

Figure 20 - Connections for 'AO' analog output module

## 2.5 Module RTU

The RTU module provides an isolated Modbus RTU communications port, to install in large format industrial meters from LDB series.

The RTU module implements function '4' ('Read Input Registers') of the Modbus RTU protocol, to access the instrument registers (reading value, alarm status, memory of maximum and minimum, ...).


Configuration is performed from the front keypad of the instrument, by accessing the menu entries 'Opt.1', 'Opt.2' or 'Opt.3', according to the slot where the module is installed.

Modules RTU can be provided factory installed into a LDB series instrument, or standalone for delayed installation. No soldering or special configuration is required. See section 1.6 on how to install output and control modules.



Figure 21 - Communications module 'RTU'

Protocol	Modbus RTU
Bus	RS485, up to 57.6 Kbps
Isolation	1000 Vdc
Terminal	plug-in screw clamp, pitch 5.08 mm
Installation allowed at	slot 1, slot 2, slot 3



A	Bus signal A
B	Bus signal B
G	GND

Figure 22 - Connections for Modbus 'RTU' communications module

## 2.6 Module S4

The S4 module provides an isolated RS-485 ASCII communications port, to install in large format industrial meters from LDB series.

The S4 module implements a MASTER / SLAVE protocol, with up to 31 addressable slaves. In SLAVE mode allows access to reading values, alarm status, memory of maximum and minimum, ...


Configuration is performed from the front keypad of the instrument, by accessing the menu entries 'Opt.1', 'Opt.2' or 'Opt.3', according to the slot where the module is installed.

Modules S4 can be provided factory installed into a LDB series instrument, or standalone for delayed installation. No soldering or special configuration is required. See section 1.6 on how to install output and control modules.



Figure 23 - Communications module 'S4'

Protocol	ASCII
Bus	RS485, up to 57.6 Kbps
Isolation	1000 Vdc
Terminal	plug-in screw clamp, pitch 5.08 mm
Installation allowed at	slot 1, slot 2, slot 3



A	Bus signal A
B	Bus signal B
G	GND

Figure 24 - Connections for RS485 'S4' communications module

## 2.7 Module S2

The S2 module provides an isolated RS232 ASCII communications port, to install in large format industrial meters from LDB series.

The S2 module implements a MASTER / SLAVE protocol, with up to 31 addressable slaves, with 'daisy-chain' connection. In SLAVE mode allows access to reading values, alarm status, memory of maximum and minimum, ...

Configuration is performed from the front keypad of the instrument, by accessing the menu entries 'Opt.1', 'Opt.2' or 'Opt.3', according to the slot where the module is installed.

Modules S2 can be provided factory installed into a LDB series instrument, or standalone for delayed installation. No soldering or special configuration is required. See section 1.6 on how to install output and control modules.





Figure 25 - Communications module Module 'S2'

Protocol	ASCII
Bus	RS232, up to 57.6 Kbps
Isolation	1000 Vdc
Terminal	plug-in screw clamp, pitch 5.08 mm
Installation allowed at	slot 1, slot 2, slot 3



A	'Daisy chain' Tx data transmission
B	'Daisy chain' Rx data reception
C	Tx data transmission
D	Rx data reception
E	GND

Figure 26 - Connections for RS232 'S2' communications module

# Options and Accessories

## Index

1.1 Read this first . . . . .	2	3.3 Exception codes . . . . .	9
1.2 Modular architecture . . . . .	2	3.4 Compatible versions . . . . .	9
1.3 Installation and start-up . . . . .	2	3.5 Description and example of registers . . . . .	10
1.4 To access the instrument . . . . .	3	4. Option S4 . . . . .	11
1.5 Modular system . . . . .	3	4.1 Accessible registers . . . . .	11
1. Options R1, T1 and SSR . . . . .	4	4.2 Configuration menu . . . . .	12
1.1 Module R1 . . . . .	4	4.3 Compatible versions . . . . .	12
1.2 Module T1 . . . . .	4	4.4 Frame types . . . . .	13
1.3 Module SSR . . . . .	5	4.5 Frame structure . . . . .	13
2. Option AO . . . . .	6	4.6 Error codes . . . . .	13
2.1 Connection examples . . . . .	6	4.8 Frame examples . . . . .	14
2.2 Configuration menu . . . . .	7	4.8.1 Frames 'RD' (36) and 'ANS' (37) . . . . .	14
2.3 Error codes . . . . .	7	4.8.2 Frames 'ERR' (38) . . . . .	14
3. Option RTU . . . . .	8	4.7.1 Frames 'PING' (32) and 'PONG' (33) . . . . .	14
3.1 Registers accessible through Modbus RTU . . . . .	8	4.7 CRC calculation . . . . .	14
3.2 Configuration menu . . . . .	9	5. Option S2 . . . . .	15

### 1.1 Read this first

All modules mentioned in this document are compatible with large format meters from LDB series has 4 formats, and each format differ in the number of digits, the digit height and the number of output and control options they can accept. This document assumes the following :

Format	Digits	Digit height	Options
LDB-24	4	60 mm	2
LDB-44	4	100 mm	2
LDB-26	6	60 mm	3
LDB-46	6	100 mm	3

- inside the programming menus, when a 6 digits value is shown, it is assumed that only 4 digits apply to formats LDB-24 and LDB-44
- when this document explains that a maximum of 3 output and control modules are installable, it is assumed that the maximum is 2 modules for formats LDB-24 and LDB-44

The output and control modules mentioned in this document, are covered by the warranty of the instrument where they are installed. Check the user's manual of the instrument for more information related to warranty.

The user's manual of the instrument where the module is installed, has important information related to installation that applies also to the output and control modules mentioned in this document. Check the user's manual of the instrument for more information related to installation precautions.

The output and control modules mentioned in this document are covered by the 'CE declaration of conformity' of the instrument where they are installed. Check the user's manual of the instrument for more information related to the CE declaration of conformity.

### 1.2 Modular architecture

Large displays from the LDB series are designed following a modular architecture that allows the operator to install any of the output and control modules mentioned in this document. Each module is supplied with 1 cable tie, 1 square self adhesive tie base and 1 female connector.

### 1.3 Installation and start-up

To install an optional output and control module into a large display:

1. remove the rear cover of the instrument (*see section 1.4*)
2. install the module at one of the free slots (*see section 1.5*)
3. place the squared tie base at the free slot selected. Location to place the tie base is clearly indicated on the PCB (*see section 1.5*).
4. pass the cable tie through the tie base (*see section 1.5*)
5. place the output and control module at the slot connection jumpers (*see section 1.5*)
6. use the cable tie to firmly fix the module (*see section 1.5*)
7. if needed, configure the appropriate jumpers at the output and control module
8. pass the connection wires through the housing cable gland
9. connect the signal wires to the terminals of the output and control module
10. place and close the rear cover of the instrument (*see section 1.4*)
11. configure the parameters at the 'Configuration menu'.
  - modules R1, T1 and SSR are configured from the alarms menu of the instrument
  - other modules are configured from menu entries 'Opt.1', 'Opt.2' or 'Opt.3', depending on the slot where the module has been installed.


## 1.4 To access the instrument

To open the housing, remove the screws from the back cover. With each screw there is a metal washer and a plastic washer. Once the screws are out, remove the back cover.

The figure below shows the instrument internal structure for a LDB-26 format. It shows the location of the 3 slots for optional output and control modules, the power terminal and the input signal terminal.

To close the instrument, place the back cover, the screws, the metal washer and the plastic washer. The plastic washer is in contact with the back cover. Confirm that the screws are correctly turning inside the internal female screws.

To ensure a correct IP65 protection tighten the back cover screws with a strength between 30 and 40 Ncm, with the help of a dynamometer screwdriver.




*Risk of electric shock. Removing the back cover will grant access to the internal circuits of the instrument. Operation must be performed by qualified personnel only.*

## 1.5 Modular system

Large format meters are designed with an internal modular architecture. The output and control modules are independent and can be installed by accessing the internal circuits of the instrument, and connecting

the module to the connection jumpers of the selected slot. Each module is provided with a cable tie to fix the module to the tie base. A cable gland to install at the back cover is also provided, in order to enable an output for the connection wires.



- To install an output and control module
- (1) insert the 'module pins' into the 'connection jumpers' in one of the free slots
  - (2) place the 'cable tie' into the 'tie base' and embrace the 'module' firmly, until it is fixed
  - (3) an additional white cable tie is provided to fix as indicated below. Only needed in case of vibrations or heavy transportation.



# 1. Options R1, T1 and SSR

The R1, T1 and SSR modules provide 1 digital ‘on/off’ output. The output is configured from the instrument alarms menu (‘ALr.1’, ‘ALr.2’ o ‘ALr.3’).

The menu allows to configure the setpoint, hysteresis,

independent activation and deactivation delays, and a second setpoint to create windowed alarms.

The R1, T1 and SSR output modules are isolated between them and between all other circuits of the instrument.

## 1.1 Module R1




Figure 1 - Detail for the ‘R1’ module and internal schematic

Option	R1
Type of output	relay
Type of relay	3 contacts (Com, NO, NC)
Max. current	3 A (resistive load)
Voltage	250 Vac continuous <i>(max. 150 Vac if switching power network with Overvoltage category III)</i>
Isolation	3500 Veff
Type of terminal	plug-in screw clamp pitch 5.08 mm
Installation allowed atslot 1, slot 2, slot 3	




Figure 2 - Connections for the ‘R1’ relay output module

## 1.2 Module T1




Figure 3 - Detail for the ‘T1’ module and internal schematic

Option	T1
Type of output	transistor
Max voltage	35 Vdc
Max. current	50 mA
Isolation	3500 Veff, optoisolated
Type of terminal	plug-in screw clamp pitch 5.08 mm
Installation allowed atslot 1, slot 2, slot 3	






Figure 4 - Connections for the ‘T1’ transistor output module

# 1.3 Module SSR



Option	SSR
Type of output	to control SSR relay
Output voltage	+15 Vdc
Max. current	45 mA
Isolation	1000 Vdc
Type of terminal	plug-in screw clamp pitch 5.08 mm
Installation allowed at slot 1, slot 2, slot 3	



# 2. Option AO

The AO modules provide 1 analog output, configurable for 4/20 mA or 0/10 Vdc signal. The analog output is configured from the options menu entry ('Opt.1', 'Opt.2' or 'Opt.3') of the instrument.


<b>Option</b>	<b>AO</b>
Type of output	analog output
Signal output	4/20 mA active 4/20 mA passive 0/10 Vdc
Max. signal	22 mA, 10.5 Vdc
Min. signal	0 mA, -50 mVdc
Scaling	proportional to the reading positive or negative slopes
Vexc (terminal A)	+13.8 Vdc $\pm$ 0.4 Vdc (max. 25 mA) protection against shortcircuit
Load impedances	$\leq$ 350 Ohm (for 4/20 mA active) $\leq$ 800 Ohm (for 4/20 mA passive) (for 24 Vdc external Vexc) (maximum voltage 27 Vdc between 'B' and 'C') $\geq$ 10 KOhm (en 0/10 Vdc)
Accuracy (at 25 °C)	<0.1 % FS
Thermal stability	60 ppm/°C in mA 50 ppm/°C in Vdc
Step response (0% to 99% of the signal)	<75 mSeconds + step response of the reading
Isolation	1000 Vdc
Warm up	15 minutes
Type of terminal	plug-in screw clamp pitch 5.08 mm
Factory configuration	'Mode mA' 'Scaling 0/9999 = 4/20 mA' 'On error 'to_h'
Installation allowed at	slot 1, slot 2, slot 3

The output signal is proportional to the reading, and it is scalable both in positive or negative slopes. The mA output can be configured for active loops (the instrument provides the power to the mA loop) or passive loops (the loop power is external to the instrument).

The AO analog output modules are isolated between them and between all other circuits of the instrument.




Figure 7 - Detail for the 'AO' module



A	Excitation voltage
B	Signal in mA or Vdc
C	Common
Jumper M	Jumper closed for mA output
Jumper V	Jumper closed for Vdc output


Figure 8 - Connections for 'AO' analog output module

## 2.1 Connection examples



Jumper M	Jumper closed
Jumper V	Jumper open

Figure 9 - Connections for active 4/20 mA. The current loop is internally powered from the 'AO' module



Jumper M	Jumper closed
Jumper V	Jumper open

Figure 10 - Connections for passive 4/20 mA. The current loop is externally powered.



2.2 Configuration menu

At the 'Mode' ('ModE') menu configure the type of output '4/20 mA' ('mA') or '0/10 Vdc' ('Vdc'). Position for jumpers 'V' and 'M' must be according to the range selected.

At the 'Scaling' ('ScAL') menu enter the values that define the two points of the slope:

- the lower point, defined by the 'Low Display' ('d.Lo') and 'Low Output' ('Ao.Lo')
- the upper point, defined by the 'High Display' ('d.hi') and 'High Output' ('Ao.hi')


Analog output values are shown with 'XX.XX' format. acceptable values are '0.00' to '10.00' Vdc for voltage, and '0.00' to '20.00' mA for current.



2.3 Error codes

'Er.34' output signal configured to value lower than 0 Vdc or 0 mA  
'Er.35' output signal configured to a value higher than 10 Vdc or 20 mA

'Er.36' configured slope points are not acceptable, such as :  
'd.Hi'='d.Lo'  
'Ao.Hi'='Ao.Lo'  
( 'Ao.Hi'-'Ao.Lo' ) > ( 'd.Hi'-'d.Lo' )



# 3. Option RTU

The RTU modules provide 1 port for communications in Modbus RTU protocol. Use function '4' ('Read Input Registers') of the Modbus RTU protocol, to access the instrument registers (reading value, alarm status, memory of maximum and minimum, setpoint values, ...).

Option	RTU
Type of output	Modbus RTU communication
Function implemented	4 (Read_Input_Registers)
Addresses	01 to 247
Exception codes	see section 3.3
Registers*	see section 3.1
<i>*available registers can vary for different instruments</i>	
Bus	RS-485
Speed	57.6 Kbps to 600 bps
Data format	8e1 (standard), 8o1, 8n2
Bus terminator	not included
Isolation	1000 Vdc
Temperature	operation from 0 to 50 °C storage from -20 to +70 °C
Factory configuration	'Address 1'
	'Speed 19.2 Kbps'
	'Format 8e1'
	'Decimal point Auto'
Installation allowed at	slot 1, slot 2, slot 3

The communication parameters are configured from the options menu entry ('Opt.1', 'Opt.2' or 'Opt.3') of the instrument.

The RTU modules are isolated between them and between all other circuits of the instrument.




Figure 12 - Detail for the 'RTU' module





Figure 13 - Connections for Modbus 'RTU' module

## 3.1 Registers accessible through Modbus RTU

Register	Name	Description	Size	Refresh	6 Digit Models (LDB-26 y LDB-46)	4 Digit Models (LDB-24 y LDB-44)
0	DISPLAY1_L	Display value	16 bits	same as display	999999 to -199999	9999 to -1999
1	DISPLAY1_H		16 bits			
2	DECIMALES1	Decimals on display	16 bits		0 to 6	0 to 4
3	MAXMEM_L	Memory of maximum	16 bits	every 30 seconds	999999 to -199999	9999 to -1999
4	MAXMEM_H		16 bits			
5	MINMEM_L	Memory of minimum	16 bits		999999 to -199999	9999 to -1999
6	MINMEM_H		16 bits			
7	SETPOINT1_L	Setpoint 1 value	16 bits	every 2 seconds	999999 to -199999	9999 to -1999
8	SETPOINT1_H		16 bits			
9	SETPOINT2_L	Setpoint 2 value	16 bits		999999 to -199999	9999 to -1999
10	SETPOINT2_H		16 bits			
11	SETPOINT3_L	Setpoint 3 value	16 bits		999999 to -199999	9999 to -1999*
12	SETPOINT3_H		16 bits			
13	STATUS	Alarm status Instrument status	16 bits	same as display	bit 0...7 alarm status bit 8...16 instrument status	
14 a 16	Reserved	Reserved	16 x 3 bits		Not accessible	Not accessible

Table 1 - Registers accessible through MODBUS-RTU. Registers codified as binary numbers. Negative values codified in two's complement. Available registers can vary for different instruments. Register 11 is not accessible for instruments with formats LDB-24 and LDB-44 ( slot 3 is not available).

## 3.2 Configuration menu



At the 'Configuration' ('rtu') menu, configure the 'Address' ('Addr') parameter with the address value between '1' and '247', at the 'Speed' ('bAud') parameter select the bus speed (in Kbps) and at the 'Format' ('bltS') parameters select the data format.

Inside the 'Tools' ('Tool') menu, special tools and functions are grouped.

- the 'Decimal point' ('dP') menu is provided for compatibility with ancient hardware that does not support decimal point retransmission. By default, select 'Automatic' ('Auto'). If your instrument does not transmit the decimal point position, select 'Manual' ('MANL') and fix the position of the decimal point manually.
- at the 'Factory reset' ('FAct') menu, select 'yes' to load the default factory configuration for the instrument.

the 'Version' ('VEr') menu informs of the current firmware version installed in the module.

## 3.3 Exception codes

The Modbus RTU protocol defines the following scenarios when a 'Master' is sending a frame to a 'Slave':

- the 'Slave' device receives the frame correctly and replies with the requested data
- the 'Slave' device detects a CRC error, parity error, or other, and discards the frame without generating a reply frame. The 'Master' will detect a 'TIMEOUT' condition due to the absence of reply.
- the 'Slave' device receives the frame correctly, but replies with an 'EXCEPTION\_CODE' as it can not process the function or register requested.

The 'EXCEPTION\_CODES' configured in the RTU module are :

Exception code	Name	Description
0	ILLEGAL_FUNCTION	Requested function is not supported
1	ILLEGAL_DATA_ADDRESS	Requested register is not supported

Table 2 - Exception codes

## 3.4 Compatible versions

Formats LDB-26, LDB-46	Firmware version	Formats LDB-24, LDB-44	Firmware version
---	---	LDB24-P, LDB44-P	41.57
LDB26-P, LDB46-P	50.00	---	---
---	---	LDB24-T, LDB44-T	44.05
---	---	LDB24-R, LDB44-R	45.05
LDB26-C1, LDB46-C1	27.08	LDB24-C1, LDB44-C1	47.07
LDB26-CR, LDB46-CR	28.02	LDB24-C1, LDB44-C1	48.05

Table 3 - Firmware versions compatible with the indicated registers

## 3.5 Description and example of registers

### Registers R0 and R1 (DISPLAY1\_L y DISPLAY1\_H)

Contains the display value of the instrument, codified in two registers of 16 bits each. Possible values are from 999999 to -199999. Decimal point position is codified at register R2.

*Example R0=FBF1 (hex) and R1=0009 (hex)*

*Register value = 0009 FBF1 (hex)*

*Reading value = 654321*

### Register R2 (DECIMALS1)

Contains the number of decimals of the display, codified in a single register of 16 bits. Possible values are from 0 to 6.

*Example R2=0002 (hex)*

*Number of decimals = 2 = 6543.21*

### Register R3 and R4 (MAXMEM\_L and MAXMEM\_H)

Contains the memory of maximum reading of the instrument, codified in two registers of 16 bits each. Possible values are from 999999 to -199999. Decimal point position is codified on register R2.

*Example - same example as in R0 and R1 but accessing to R3 and R4.*

### Registers R5 and R6 (MINMEM\_L and MINMEM\_H)

Contains the memory of minimum reading of the instrument, codified in two registers of 16 bits each. Possible values are from 999999 to -199999. Decimal point position is codified on register R2.

*Example - same example as in R0 and R1 but accessing to R5 and R6.*

### Registers R7 and R8 (SETPOINT1\_L and SETPOINT1\_H)

Contains the setpoint value of alarm 1, codified in two registers of 16 bits each. Possible values are from 999999 to -199999. Decimal point position is codified on register R2.

*Example - same example as in R0 and R1 but accessing to R7 and R8.*

### Registers R9 and R10 (SETPOINT2\_L and SETPOINT2\_H)

Contains the setpoint value of alarm 2, codified in two registers of 16 bits each. Possible values are from 999999 to -199999. Decimal point position is codified on register R2.

*Example - same example as in R0 and R1 but accessing to R9 and R10.*

### Registers R11 and R12 (SETPOINT3\_L and SETPOINT3\_H)

Contains the setpoint value of alarm 3, codified in two registers of 16 bits each. Possible values are from 999999 to -199999. Decimal point position is codified on register R2.

*Example - same example as in R0 and R1 but accessing to R11 and R12.*

### Register R13 (STATUS)

Information bit-by-bit, for the alarm status (on / off) and instrument status. See below for a description.

- Bit 0 Alarm 1 status (0 = inactive, 1 = active)
- Bit 1 Alarm 2 status (0 = inactive, 1 = active)
- Bit 2 Alarm 3 status (0 = inactive, 1 = active)
- Bit 3 to 7 Reserved
- Bit 8 Display overrange
- Bit 9 Display underrange
- Bit 10 Lost communication with the main processor
- Bit 11 to 15 Reserved

### Registers R14, R15 and R16

Reserved

# 4. Option S4

The S4 modules provide 1 port for communications RS485 ASCII protocol. Protocol with 'master' - 'slave' architecture, addressable up to 31 modules. Frames codified in representable ASCII characters (codes 32 to 255), which are visible using 'hyperterminal' or similar programs. Instrument

<b>Option</b>	<b>S4</b>
Type of output	RS-485 ASCII communication
Bus	RS-485
Speed	57.6 Kbps to 600 bps
Data format	8n1 (standard), 8o1, 8n2, 8e1
Bus terminator	not included
Protocol	ASCII
Architecture	'master - slave'
Addresses	01 to 31
'Broadcast' address	128
Registers*	see section 4.1
<i>*available registers can vary for different instruments</i>	
Isolation	1000 Vdc
Temperature	operation from 0 to 50 °C storage from -20 to +70 °C
Factory configuration	'Mode                      Slave'
	'Address                 1'
	'Speed                   19.2 Kbps'
	'Format                  8n1'
	'Decimal point          Auto'
Configuration 'Master'	'Destination address   31'
	'Frequency               0.5 sec.'
	'Decimial point          Auto'
Tools	'Legacy                   Off'
	'Answer delay           0 mSec.'
Installation allowed at	'Opt.1', 'Opt.2', 'Opt.3'

registers are accessible through the RS-485 ASCII port (reading value, alarm status, memory of maximum and minimum, setpoint values, ...). The communication parameters are configured from the options menu entry ('Opt.1', 'Opt.2' or 'Opt.3') of the instrument. The S4 modules are isolated between them and between all other circuits of the instrument.




Figure 14 - Detail for the 'S4' module




Figure 15 - Connections for 'S4' module

## 4.1 Accessible registers

Display values (DISPLAY1, MAXMEM, MINMEM, AL1, AL2, AL3) are codified with a minimum of 6 digits (left zeros are added if necessary), polarity and decimal point.

Register	Name	Description
0	DISPLAY1	Display1 value
1	MAXMEM	Memory of maximum
2	MINMEM	Memory of minimum
3	AL1	Setpoint 1 value
4	AL2	Setpoint 2 value
5	AL3	Setpoint 3 value
6	STATUS	Alarm status

Table 4 - Accessible registers for ASCII protocol.

### Register 0 - DISPLAY1

Contains the display value of the instrument, in ASCII code, including polarity (positive / negative) and decimal point.

Example 1 - R0='+' '0' '6' '5' '4' '3' '.' '2' Display value = 6543.2

Example 2 - R0='-' '0' '0' '0' '4' '.' '5' '2' Display value = -4.52

### Register 1 - MAXMEM

Contains the value for memory of maximum, in ASCII code,

including polarity (positive / negative) and decimal point.

### Register 2 - MINMEM

Contains the value for memory of minimum, in ASCII code, including polarity (positive / negative) and decimal point.

### Register 3 - AL1

Contains the value for alarm 1 setpoint, in ASCII code, including polarity (positive / negative) and decimal point.

### Register 4 - AL2

Contains the value for alarm 2 setpoint, in ASCII code, including polarity (positive / negative) and decimal point.

### Register 5 - AL3


Contains the value for alarm 3 setpoint, in ASCII code, including polarity (positive / negative) and decimal point.

### Register 6 - STATUS

Contains the alarm status (on/off).

Bit 0	Alarm 1 status (0 = inactive, 1 = active)
Bit 1	Alarm 2 status (0 = inactive, 1 = active)
Bit 2	Alarm 3 status (0 = inactive, 1 = active)
Bit 3 to 15	Reserved

4.2 Configuration menu



At the ‘Configuration ASCII’ (‘AScl’) menu, configure the ‘Mode’ (‘ModE’) parameter to select the ‘slave’ or the ‘master’ mode, at the ‘Address’ (‘Addr’) parameter configure the local port address between ‘1’ and ‘31’, at the ‘Speed’ (‘bAud’) parameter select the bus speed (in Kbps) and at the ‘Format’ (‘bltS’) parameter select the data format.

When working as ‘master’, the instrument continuously transmits the display value data frame. The local module address is ‘0’. Configure at menu ‘Configuration Master’ (‘cnF.M’) the ‘Destination address’ (‘d.Add’) parameter from ‘1’ to ‘31’ or use value ‘128’ for a broadcast message. At parameter ‘Frequency’ (‘FrEq’) select the how often the frame with the reading value will be transmitted.

Special tools are grouped inside the ‘Tools’ (‘Tool’) menu.

- the ‘Decimal point’ (‘dP’) menu is provided for compatibility with ancient hardware that does not support decimal point retransmission. By default, select ‘Automatic’ (‘Auto’). If your instrument does not transmit the decimal point position, select ‘Manual’ (‘MANL’) and fix the position of the decimal point manually.
- the ‘Legacy mode’ (‘LEG’) parameter is provided to maintain compatibility with instruments with older communication protocols. Select ‘on’ to activate this mode.
- the ‘Answer delay’ (‘Ans.d’) parameter applies only to ‘Slave’ mode. The local module delays the answer frame. Configure for applications where the ‘Master’ needs additional time to switch between ‘transmit’ and ‘receive’ modes. Enter a numeric value between ‘0’ and ‘1000’ mSeconds.
- at the ‘Factory reset’ (‘FAct’) menu, select ‘yes’ to load the default factory configuration for the instrument.

the ‘Version’ (‘VEr’) menu informs of the current firmware version installed in the module.

4.3 Compatible versions

Formats LDB-26, LDB-46	Version firmware	Formats LDB-24, LDB-44	Version firmware
Instruments with access to registers 0, 1, 2, 6			
		LDB24-P, LDB44-P	41.57
LDB26-P, LDB46-P	50.00	---	---
		LDB24-T, LDB44-T	44.05
		LDB24-R, LDB44-R	45.05
LDB26-C1, LDB46-C1	27.08	LDB24-C1, LDB44-C1	47.07
LDB26-CR, LDB46-CR	28.02	LDB24-CR, LDB44-CR	48.05

Table 5 - Firmware versions compatible with the indicated registers

## 4.4 Frame types

The ASCII protocol defines the following frames:

- Frame ‘read’ (**‘RD’**). Id code 36. Request data frame. The requested register is indicated into the ‘REG’ byte (‘Header’ section).
- Frame ‘answer’ (**‘ANS’**). Id code 37. Response frame to a request data frame. The requested register is indicated into the ‘REG’ byte (‘Header’ section). Data of the requested register is indicated into data bytes ‘D0’ to ‘Dn’ (‘Data’ section).
- Frame ‘error’ (**‘ERR’**). Id code 38. Response frame to a request data frame. Indicates that an error has occurred. Error code is codified into the ‘REG’ byte (‘Header’ section).
- Frame ‘ping’ (**‘PING’**). Id code 32. Used to confirm the existence of the remote instrument.
- Frame ‘pong’ (**‘PONG’**). Id code 33. Response to a ‘ping’ frame. It confirms the existence of the remote instrument.

## 4.5 Frame structure

Header								Data				Trail	
STX	ID	RSV	FROM	TO	REG	RSV	LONG	D0	D1	...	Dn	CRC	ETX
2	x	32	x	x	x	32	n+1	[data]				x	3
0	1	2	3	4	5	6	7	8	9	...	n+7	n+8	n+9

Protocol frames have a structure made of ‘Header’, ‘Data’ and ‘Trail’.

### Section ‘Header’

Contains the start byte (‘STX’), the frame identifier (‘ID’), the origin address (‘FROM’) and the destination address (‘TO’), the register id (‘REG’) and the length (‘LONG’) of the ‘Data’ section.

### Section ‘Data’

Contains data for the requested register (‘REG’).

### Section ‘Trail’

Contains the ‘CRC’ code and the end of frame byte (‘ETX’).

### ‘Real value’ and ‘Frame value’

To use representable ASCII values, the real values are codified before being sent into the frame. The following definitions apply :

- ‘real value’ is the value of the field without codification
- ‘frame value’ is the value of the field, codified

Field	Description	Size	Position	Real value	Frame value
STX	Start of frame	1 byte	0	does not apply	2
ID	Frame type	1 byte	1	(see section 4.4)	real_value
RSV	Reserved	1 byte	2	0	32
FROM	Origin address	1 byte	3	0 (‘Master’) / 1 to 31 (‘Slave’)	32 + real_value
TO	Destination address	1 byte	4	0 (‘Master’) / 1 to 31 (‘Slave’) 128 (‘broadcast’)	32 + real_value
REG	Register identification	1 byte	5	(see section 4.1)	32 + real_value
RSV	Reserved	1 byte	6	0	32
LONG	Length of ‘Data’ section	1 byte	7	n (between 0 and 32)	32 + real_value
D0 ... Dn	Data	n bytes	8 to n+7	number 0 to 9 decimal point polarity (+/-)	ASCII code of the number (48 to 57) ASCII code of decimal point (46) ASCII code of ‘+’ (43) ASCII code of ‘-’ (45)
CRC	CRC calculation	1 byte	n+8	does not apply	(see section 4.7)
ETX	End of frame	1 byte	n+9	does not apply	3

Table 6 - Description of the bytes for the ASCII frame

## 4.6 Error codes

Frames ‘ERR’ contain within the ‘REG’ field, the error code.

Available error codes are :

error 1                      unknown register

error 2                      display overrange  
error 3                      display underrange  
error 4                      CRC error  
error 5                      internal error

## 4.8 Frame examples

### 4.8.1 Frames 'RD' (36) and 'ANS' (37)

Example - 'Master' (address '0') requests the value of register '0' (display value) to the 'Slave' at address '28' ('RD' frame) and the 'Slave' replies to the 'Master' with a reply frame ('ANS'

frame) containing the requested data (765.43).

\*Instruments with 4 digits also send reading values formatted with 6 digits : value -321.5 is transmitted as -00321.5

Header								Trail	
STX	ID	RSV	FROM	TO	REG	RSV	LONG	CRC	ETX
2	36	32	32	60	32	32	32	58	3
Start	RD	---	0	28	0	---	0	CRC	Stop

Header								Data								Trail	
STX	ID	RSV	FROM	TO	REG	RSV	LONG	D0	D1	D2	D3	D4	D5	D6	D7	CRC	ETX
2	37	32	60	32	32	32	40	43	48	55	54	53	46	52	51	15	3
Start	ANS	---	28	0	0	---	8	+0765.43								CRC	Stop

### 4.8.2 Frames 'ERR' (38)

Example - 'Slave' at address '11' replies to the 'Master' (address '0') with an error frame ('ERR' frame) indicating that the requested register number is unknown

('UNKNOWN\_REGISTER', error code '1'). The error code is codified into the 'REG' byte. For a list of error code see section 4.6.

Header								Trail	
STX	ID	RSV	FROM	TO	REG	RSV	LONG	CRC	ETX
2	38	32	43	32	33	32	32	46	3
Start	ERR	---	11	0	1	---	0	CRC	Stop

### 4.7.1 Frames 'PING' (32) and 'PONG' (33)

Example - 'Master' (address '0') requests confirmation of existence to the 'Slave' at address '22' ('PING' frame) and the 'Slave' replies to the 'Master' with a 'PONG' frame.

Header								Trail	
STX	ID	RSV	FROM	TO	REG	RSV	LONG	CRC	ETX
2	32	32	32	54	32	32	32	52	3
Start	Ping	---	0	22	0	---	0	CRC	Stop

Header								Trail	
STX	ID	RSV	FROM	TO	REG	RSV	LONG	CRC	ETX
2	33	32	54	32	32	32	32	53	3
Start	Pong	---	22	0	0	---	0	CRC	Stop

## 4.7 CRC calculation

The 'frame value' for the CRC byte is calculated applying a XOR function to the 'frame value' (see section 4.5) of all bytes in sections 'Header' and 'Data', from byte '0' ('STX') to the last data byte ('Dn').

- if the calculated CRC value is lower than '32', it is normalized by applying the 'one's complement' function .

$$CRC0 = STX \wedge ID \wedge RSV \wedge FROM \wedge TO \wedge REG \wedge RSV \wedge LONG \wedge D0 \wedge \dots \wedge Dn$$

- if (CRC0<32) -> CRC=!CRC0 (one's complement function)
- if (CRC0>31) -> CRC=CRC0

```
//example of CRC calculation in C language
int8 Calculate_CRC(int8 CRC_Position)
{
    int8 i,CRC=0;
    for(i=0;i<CRC_Position;i++)
    {
        CRC=CRC ^ frame[i];
    }
    if(CRC<32) CRC=~CRC;
    return(CRC);
}
```



# 5. Option S2

The S2 modules provide 1 port for communications RS232 ASCII protocol. The S2 modules use the same protocol as the S4 modules (see section 4), the only difference is the physical layer of the bus, that is RS232 for the S2.

S2 modules allow for point-to-point communication over RS232 and also allow for multinode communication over

Option	S2
Type of output	RS-232 ASCII communication
Bus	RS-232
Speed	57.6 Kbps a 600 bps
Data format	8n1 (standard), 8o1, 8n2, 8e1
Protocol	ASCII
Architecture	'master - slave'
Address	01 to 31
'Broadcast' address	128
Registers*	see section for S4 module
*available registers can vary for different instruments	
Isolation	1000 Vdc
Temperature	operation from 0 to 50 °C storage from -20 to +70 °C
Installation allowed at	'Opt.1', 'Opt.2', 'Opt.3'

RS232 using a 'Daisy-Chain' type of connection. Terminals RX1 and TX1 are for the main communication with the RS232 bus. Terminals RX2 and TX2 are for the multinode connection, so all frames received at RX1 with destination address different from the local address, will be retransmitted through TX2. On the same way, frames received at RX2 with destination address different from the local address, will be retransmitted through TX1.



A	GND
B	Rx data reception
C	Tx data transmission
D	'Daisy chain' Rx data reception
E	'Daisy chain' Tx data transmission

Figure 17 - Connections for 'S2' module

# 1. Remote keypad LDB-RKB

Industrial keypad with 3 push buttons to connect to large format meters from LDB series. It allows to replicate the front keypad of the instrument to a remote location.

A RKB remote keypad allows the operator to access the advanced control functions from the large format meters, such as fast access to alarm setpoints, preset value modification, access to maximum and minimum reading values, signal tare for load applications, front reset, manual alarm unlock, ...



All these features are accessible while maintaining the main feature of these instruments, which is the installation in heights for long distance reading.

The RKB remote keypad is provided with an industrial IP65 protected housing, with cable gland output, aligned with the technical specifications of the LDB series. The RKB remote keypad can be easily installed against wall. The push buttons are 25 mm size for easy use even with protection gloves.



The RKB remote keypad is provided with labeled push buttons and does not included cable.



Normal button state	open
Recommended wire	0.25 mm2
Protection	IP65
Output	by cable gland
Mounting	accepts wall mount
Color	grey
Material	plastic
Weight	200 gr



Connect the wire to the 4 pole terminal located close to the input signal module. Connect 4 wires for keys 'SQ' (■), 'UP' (▲), 'LE' (◀) and common. Pass the wires through the cable gland identified as 'remote keypad' (see Figure 2) and connect the other end to the internal RKB push buttons.



## WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **61 months** from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal **five (5) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components in which wear is not warranted, include but are not limited to contact points, fuses, and triacs.

**OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by the company will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.**

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

## RETURN REQUESTS/INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of the product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a trademark of OMEGA ENGINEERING, INC.

© Copyright 2018 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.

# **Where Do I Find Everything I Need for Process Measurement and Control? OMEGA...Of Course! *Shop online at omega.com***

## **TEMPERATURE**

- ☑ Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- ☑ Wire: Thermocouple, RTD & Thermistor
- ☑ Calibrators & Ice Point References
- ☑ Recorders, Controllers & Process Monitors
- ☑ Infrared Pyrometers

## **PRESSURE, STRAIN AND FORCE**

- ☑ Transducers & Strain Gages
- ☑ Load Cells & Pressure Gages
- ☑ Displacement Transducers
- ☑ Instrumentation & Accessories

## **FLOW/LEVEL**

- ☑ Rotameters, Gas Mass Flowmeters & Flow Computers
- ☑ Air Velocity Indicators
- ☑ Turbine/Paddlewheel Systems
- ☑ Totalizers & Batch Controllers

## **pH/CONDUCTIVITY**

- ☑ pH Electrodes, Testers & Accessories
- ☑ Benchtop/Laboratory Meters
- ☑ Controllers, Calibrators, Simulators & Pumps
- ☑ Industrial pH & Conductivity Equipment

## **DATA ACQUISITION**

- ☑ Communications-Based Acquisition Systems
- ☑ Data Logging Systems
- ☑ Wireless Sensors, Transmitters, & Receivers
- ☑ Signal Conditioners
- ☑ Data Acquisition Software

## **HEATERS**

- ☑ Heating Cable
- ☑ Cartridge & Strip Heaters
- ☑ Immersion & Band Heaters
- ☑ Flexible Heaters
- ☑ Laboratory Heaters

## **ENVIRONMENTAL MONITORING AND CONTROL**

- ☑ Metering & Control Instrumentation
- ☑ Refractometers
- ☑ Pumps & Tubing
- ☑ Air, Soil & Water Monitors
- ☑ Industrial Water & Wastewater Treatment
- ☑ pH, Conductivity & Dissolved Oxygen Instruments