


**FLOW CHART**

Below is a flowchart showing how to navigate through all top level menus by pressing the **↶** and **↷** buttons.




**Note** It is required that you put the controller in Standby Mode for any configuration changes other than Setpoints and Alarms.

†Where: CALC/VALUE = Calculated input based on the transducer specification [Without Known Loads (DSBL)]  
 ACT/VALUE = Actual signal being received [Known Loads (ENBL)]


**READING CONFIGURATION SETUP (operation example)**

Below is a flowchart showing how to navigate through the submenus of the Reading Configuration menu item by pressing the front buttons.




**DISPLAY COLOR SETUP (examples)**

**Example 1:**  
 Output 1 & Output 2: SSR  
 Alarm setup: Absolute, Above, Alarm 2 HI Value  
 "ALR.H" =200, Alarm 1 HI Value "ALR.H"=400  
 Color Display setup: Normal Color "N.CLR"=Green, Alarm 1 Color "1.CLR"=Amber, Alarm 2 Color "2.CLR"=Red



**Example 2:**  
 Output 1: Relay, Set Point 1 = 200,  
 Output 2: Relay, Set Point 2 = 200  
 Alarm 1 setup: Deviation, Band, "ALR.H" = 20  
 Alarm 2 setup: Deviation, Hi/Low, "ALR.H" = 10, "ALR.L" = 5"  
 Color Display setup: "N.CLR"=Green, "1.CLR"=Amber, "2.CLR"=Red



**SPECIFICATION**

**Accuracy:** 0.03% rdg.  
**Resolution:** 10 / 1 µV process  
**Linearization Points:** 10 points  
**Temperature Stability:** 50 ppm/°C process  
**Display iDRP Option:** 4-digit, 9-segment LED 21 mm (0.83"), 48H x 96W x 39D (1.89 x 3.78 x 1.55"), Red, green, and amber programmable colors for process variable, set point and temperature units.  
**Input Types:** Analog Voltage and Current  
**Voltage:** 0 to 100 mV, 0 to 1 V (±100 mV), 0 to 10 Vdc  
**Input Impedance:** 10 MΩ for 100 mV, 1 MΩ for 1 or 10 Vdc  
**Current:** 0 to 20 mA (5 Ω load)  
**Output 1:** Relay 250 Vac @ 3 A Resistive Load, SSR, Pulse, Analog Voltage and Current  
**Output 2:** Relay 250 Vac @ 3 A Resistive Load, SSR, Pulse  
**Options: Communication** RS-232 / RS-485 or 10BaseT or **Excitation:** 5 Vdc @ 40 mA, 10 Vdc @ 60 mA. *Exc. not available for Low Power Option*  
**Line Voltage/Power:** 90 - 240 Vac ±10%, 50 - 400 Hz\*, or 110-375 Vdc, **4W**  
*\* No CE compliance above 60 Hz*  
**Low Voltage Power Option:** 12 - 36 Vdc, **3 W\*\***  
*\*\* Units can be powered safely with 24 Vac but No Certification for CE/UL are claimed.*  
**Dimensions:** Standard Unit iSDR: 92.5H x 125.2D x 24.9mm W (3.64 x 4.93 x 0.98")  
 Ethernet Unit iSDR-EI/C4EI: 92.5H x 125.2D x 39.8mm W (3.64 x 4.93 x 1.55")  
**Weight:** \_\_\_\_\_g (0.\_\_\_\_lb)  
**Approvals:** UL, C-UL, CE per EN61010-1:2001

**WARNING:** These products are not designed for use in, and should not be used for, patient-connected applications.

This device is marked with the international caution symbol. It is important to read the Setup Guide before installing or commissioning this device, as the guide contains important information relating to safety and EMC.

It is the policy of OMEGA to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct, but OMEGA Engineering, Inc. accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

**TRADEMARK NOTICE:** , *omega.com*, OMEGA, and are Trademarks of OMEGA ENGINEERING, INC.

**WARRANTY/DISCLAIMER**

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **one (1) year** from the date of purchase. In addition to OMEGA's standard warranty period, OMEGA Engineering will extend the warranty period for **four (4) additional years** if the warranty card enclosed with each instrument is returned to OMEGA.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components which wear are not warranted, including but not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by it will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESS OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

**RETURN REQUESTS/INQUIRIES**

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT. (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR WARRANTY RETURNS, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED.
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.


FOR NON-WARRANTY REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.  
 © Copyright 2005 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.

PATENT AND TRADEMARK NOTICE: This product is covered by one or more of the following patents: U.S. Pat. No. Des. 336,895; 5,774,577; 6,243,021 / CANADA 2052599; 2052600; IT/74 1249450; GERMANY DE 41 34388 C2 / SPAIN 2039150; 2048066 / UK Patent No. GB2 249 837; GB2 248 954 / FRANCE BREVET NO. 91 12756. The "Meter Bezel Design" is a trademark of Newport Electronics, Inc. USED UNDER LICENSE. Other U.S. and International Patents pending or applied for.



**iSDR Series** DIN Rail Strain & Process Controller



<b>OMEGAnet® On-Line Service</b> www.omega.com	<b>Internet e-mail</b> info@omega.com
---	--

**Servicing North America:**

<b>USA:</b> ISO 9001 Certified	One Omega Drive, P.O. Box 4047 Stamford CT 06907-0047 TEL: (203) 359-1660 e-mail: info@omega.com	FAX: (203) 359-7700
<b>Canada:</b>	976 Bergar Laval (Quebec) H7L 5A1 TEL: (514) 856-6928 e-mail: info@omega.ca	FAX: (514) 856-6886

**For immediate technical or application assistance:**

**USA and Canada:** Sales Service: 1-800-826-6342 / 1-800-TC-OMEGA®  
 Customer Service: 1-800-622-2378 / 1-800-622-BEST®  
 Engineering Service: 1-800-872-9436 / 1-800-USA-WHEN®

**Mexico and Latin American:** TEL: (001)800-TC-OMEGA® FAX: (001) 203-359-7807  
 En Español: (001) 203-359-7803  
 e-mail: espanol@omega.com

**Servicing Europe:**

<b>Benelux:</b>	Postbus 8034, 1180 LA Amstelveen, The Netherlands TEL: +31 20 3472121 Toll Free in Benelux: 0800 0993344 e-mail: sales@omegaeng.nl	FAX: +31 20 6434643
<b>Czech Republic:</b>	Frystatska 184, 733 01 Karviná TEL: +420 59 6311899 e-mail: info@omegashop.cz	FAX: +420 59 6311114
<b>France:</b>	11, rue Jacques Cartier, 78280 Guyancourt TEL: +33 1 61 37 29 00 Toll Free in France: 0800 466 342 e-mail: sales@omega.fr	FAX: +33 1 30 57 54 27
<b>Germany/Austria:</b>	Daimlerstrasse 26, D-75392 Deckenpfronn, Germany TEL: +49 7056 9398-0 Toll Free in Germany: 0800 639 7678 e-mail: info@omega.de	FAX: +49 7056 9398-29
<b>United Kingdom:</b> ISO 9002 Certified	One Omega Drive River Bend Technology Centre Northbank, Irlam Manchester M44 5BD United Kingdom TEL: +44 161 777 6611 Toll Free in England: 0800 488 488 e-mail: sales@omega.co.uk	FAX: +44 161 777 6622



This Quick Start Reference provides information on setting up your instrument for basic operation. The latest complete Communication and Operational Manual as well as free Software and ActiveX Controls are available at [www.omega.com/specs/iseries](http://www.omega.com/specs/iseries) or on the CD-ROM enclosed with your shipment.

### SAFETY CONSIDERATION



This device is marked with the international Caution symbol.

The instrument is protected in accordance with EN 61010-1:2001, electrical safety requirements for electrical equipment for measurement, control and laboratory. Remember that the unit has no power-on switch. Building installation should include a switch or circuit-breaker that must be compliant to IEC 947-1 and 947-3.


### SAFETY:

- Do not exceed voltage rating on the label located on the side of the instrument housing.
- Always disconnect power before changing signal and power connections.
- Do not use this instrument on a work bench without its case for safety reasons.
- Do not operate this instrument in flammable or explosive atmospheres.
- Do not expose this instrument to rain or moisture.

### EMC:


- Whenever EMC is an issue, always use shielded cables.
- Never run signal and power wires in the same conduit.
- Use signal wire connections with twisted-pair cables.
- Install Ferrite Bead(s) on signal wire close to the instrument if EMC problems persist.

### MOUNTING



To install unit onto DIN Rail:

- Tilt unit, position mounting slot onto DIN Rail, as shown.
- Push unit towards DIN Rail and it will snap into place.



To remove unit from DIN Rail:


- Insert flat screw-driver into tab and push downwards.
- Unit will detach from DIN Rail.

### WIRING


Wire the instrument according to the figure shown below.



**Warning: Do not connect ac power to your device until you have completed all input and output connections. This device must only be installed by a specially trained electrician with corresponding qualifications. Failure to follow all instructions and warnings may result in injury!**



Connect the main power connections as shown in the figure below.




FUSE	Connector	Output Type	For 115Vac	For 230Vac	DC
FUSE 1	Output 1	Relay	3 A(T)	3 A(T)	-
FUSE 2	Output 2	Relay	3 A(T)	3 A(T)	-
FUSE 3	Power	N/A	100 mA(T)	100 mA(T)	100 mA(T)
FUSE 4	Power	N/A	N/A	N/A	400 mA(T)



If instrument has the communication option, the internal excitation is not available. Use external excitation to power your transducer.

### DIMENSIONS



### CONFIGURATION



The following steps for configuring your device are explained by using the optional Remote Programmer Display (iDRP), you may also configure your device through the Networking or Communication option (-C24, -C4EI or -EI).

### Button Functions in Configuration Mode

	<ul style="list-style-type: none"> <li>To enter the Menu, the user must first press .</li> <li>Use this button to advance/navigate to the next menu item. The user can navigate through all the top level menus by pressing .</li> <li>While a parameter is being modified, press  to escape without saving the parameter.</li> </ul>
	<ul style="list-style-type: none"> <li>Press the up  button to scroll through "flashing" selections. When a numerical value is displayed press this key to increase value of a parameter that is currently being modified.</li> <li>Holding the  button down for approximately 3 seconds will speed up the rate at which the setpoint value is incremented.</li> <li>In the Run Mode pressing  causes the display to flash the PEAK or GROSS value – press again to return to the Run Mode.</li> </ul>
	<ul style="list-style-type: none"> <li>Press the down  button to go back to a previous Top Level Menu item.</li> <li>Press this button twice to reset the controller to the Run Mode.</li> <li>When a numerical value is flashing (except setpoint value) press  to scroll digits from left to right allowing the user to select the desired digit to modify.</li> <li>When a setpoint value is displayed press  to decrease value of a setpoint that is currently being modified. Holding the  button down for approximately 3 seconds will speed up the rate at which the setpoint value is decremented.</li> <li>In the Run Mode pressing  causes the display to flash TARE value to tare your reading (zeroing).</li> </ul>
	<ul style="list-style-type: none"> <li>Press the enter  button to access the submenus from a Top Level Menu item.</li> <li>Press  to store a submenu selection or after entering a value — the display will flash a <b>SEt</b> message to confirm your selection.</li> <li>To reset flashing PEAK or GROSS press .</li> <li>In the Run Mode, press  twice to enable Standby Mode with flashing <b>StBy</b>.</li> </ul>



Reset: Except for Alarms, modifying any settings of the menu configuration will reset the controller prior to resuming Run Mode.

### DISPLAY ABBREVIATIONS

<b>SP1</b>	Set Point 1 Value	<b>SP2</b>	Set Point 2 Value
<b>CNFG</b>	Configuration Menu	<b>INPt</b>	Input Type (Range)
<b>INPt</b>	Input Type (range)	<b>0 - 0.1</b>	100 mV Input Voltage
<b>0 - 1.0</b>	1 V Input Voltage	<b>0 - 10</b>	10 V Input Voltage
<b>0 - 20</b>	20 mA Input Current	<b>RESO</b>	Display Resolution
<b>Rtio</b>	Ratiometric Operation	<b>PEAK</b>	Peak Value
<b>bUtN</b>	Button Peak/Gross		
<b>GROS</b>	Gross Value		
<b>RdG</b>	Reading Configuration		
<b>dEC</b>	Decimal Point	<b>F.FFF</b>	Decimal Point Position
		<b>..FFFF</b>	
<b>LOAd</b>	Input Load	<b>EnbL</b>	Scaling with Known Loads (Actual Value)
<b>DSbL</b>	Scaling without Known Loads (Calculated Value)	<b>L.Pnt</b>	Linearization Points
<b>0002..</b>	Number of Linearization Points	<b>FLtR</b>	Filter Constant
<b>..0010</b>			
<b>0001..</b>	Filter Constant Value	<b>IN.Rd</b>	Input/Reading Scale and Offset Menu
<b>..0128</b>			
<b>IN 1</b>	Input 1	<b>Rd 1</b>	Reading 1
<b>IN 2</b>	Input 2	<b>Rd 2</b>	Reading 2
.....		.....	
<b>IN 10</b>	Input 10	<b>Rd 10</b>	Reading 10
<b>ANLG</b>	Analog Output	<b>CURR</b>	Current Output
<b>VoLt</b>	Voltage Output	<b>Rd 1</b>	Reading 1
<b>Out.1</b>	Output 1	<b>Rd 2</b>	Reading 2
<b>Out.2</b>	Output 2		
<b>ALR1</b>	Alarm 1 Menu	<b>AbSo</b>	Absolute Mode
<b>dEV</b>	Deviation Mode	<b>Ltch</b>	Latched Mode
<b>UNLt</b>	Unlatched Mode	<b>Ct.CL</b>	Contact Closure
<b>N.o.</b>	Normally Open	<b>N.c.</b>	Normally Closed
<b>ActV</b>	Active Type	<b>AboV</b>	Active Above
<b>bELo</b>	Active Below	<b>Hi.Lo</b>	Above High/Below Low
<b>bANd</b>	Above or Below Band	<b>A.P.oN</b>	Alarm Enable/Disable at Power On
<b>ALR.L</b>	Alarm Low Value	<b>ALR.H</b>	Alarm High Value
<b>ALR.2</b>	Alarm 2 Menu		
<b>LOOP</b>	Loop Break Menu	<b>b.tiM</b>	Loop Break Time
<b>R.AdJ</b>	Reading Adjust	<b>SP.dN</b>	Set Point Deviation
<b>OUt1</b>	Output 1 Menu	<b>SELF</b>	Manual Control
<b>o°LO</b>	Percent Low	<b>o°HI</b>	Percent High
<b>CtRL</b>	Control Type	<b>ON.OF</b>	On/Off Control
<b>4 -20</b>	Amplitude Control	<b>PId</b>	PID Control
<b>ActN</b>	Action Type	<b>RVRS</b>	Reverse Action
<b>dRct</b>	Direct Action	<b>ANt1</b>	Anti Integral
<b>AUto</b>	Auto PID	<b>A.tUN</b>	Auto Tune PID
<b>StRt</b>	Start Auto Tune PID	<b>PRoP</b>	Proportional Band
<b>RESt</b>	Reset Setup	<b>RAtE</b>	Rate Setup
<b>CYCL</b>	Cycle Time	<b>dPNG</b>	Damping Factor
<b>dEAd</b>	Dead Band		
<b>OUt2</b>	Output 2 Menu		
<b>RAMP</b>	Ramp Time	<b>SOak</b>	Soak Time
<b>Id</b>	ID Code Menu	<b>CH.Id</b>	Change ID Code
<b>FULL</b>	Full ID	<b>SP.Id</b>	Set Point ID
<b>COMM</b>	Communication Option*	<b>NONE</b>	Communication is Not Installed
<b>COLR</b>	Display Color Selection	<b>N.CLR</b>	Normal Color Display
<b>1.CLR</b>	Alarm 1 Color Display	<b>2.CLR</b>	Alarm 2 Color Display
<b>REd</b>	Display Color is Red	<b>AMbR</b>	Display Color is Amber
<b>GRN</b>	Display Color is Green		
<b>dSbL</b>	Disable	<b>ENbL</b>	Enable
<b>ERRO</b>	Error	<b>+ OL</b>	Input (+) Overload

\* For abbreviations of Communication Option see Communication Manual.