

3 YEAR
WARRANTY

MADE IN
USA



User's Guide



Shop online at

omega.com[®]

Ω OMEGA[®]

omega.com

e-mail: info@omega.com

For latest product manuals:

omegamanual.info

ISO 9001
CERTIFIED
CORPORATE QUALITY
STAMFORD, CT

ISO 9002
CERTIFIED
CORPORATE QUALITY
MANCHESTER, UK

CL535 Frequency Calibrator with Totalizer



OMEGAnet® Online Service omega.com	Internet e-mail info@omega.com
---	---

Servicing North America:

U.S.A.: One Omega Drive, Box 4047
ISO 9001 Certified Stamford, CT 06907-0047
Tel: (203) 359-1660 FAX: (203) 359-7700
e-mail: info@omega.com

Canada: 976 Bergar
Laval (Quebec) H7L 5A1, Canada
Tel: (514) 856-6928 FAX: (514) 856-6886
e-mail: info@omega.ca

For immediate technical or application assistance:

U.S.A. and Canada: Sales Service: 1-800-826-6342 / 1-800-TC-OMEGA®
Customer Service: 1-800-622-2378 / 1-800-622-BEST®
Engineering Service: 1-800-872-9436 / 1-800-USA-WHEN®

Mexico: En Español: (001) 203-359-7803 e-mail: espanol@omega.com
FAX: (001) 203-359-7807 info@omega.com.mx

Servicing Europe:

Benelux: Postbus 8034, 1180 LA Amstelveen, The Netherlands
Tel: +31 (0)20 3472121 FAX: +31 (0)20 6434643
Toll Free in Benelux: 0800 0993344
e-mail: sales@omegaeng.nl

Czech Republic: Frystatska 184, 733 01 Karviná, Czech Republic
Tel: +420 (0)59 6311899 FAX: +420 (0)59 6311114
Toll Free: 0800-1-66342 e-mail: info@omegashop.cz

France: 11, rue Jacques Cartier, 78280 Guyancourt, France
Tel: +33 (0)1 61 37 2900 FAX: +33 (0)1 30 57 5427
Toll Free in France: 0800 466 342
e-mail: sales@omega.fr

Germany/Austria: Daimlerstrasse 26, D-75392 Deckenpfronn, Germany
Tel: +49 (0)7056 9398-0 FAX: +49 (0)7056 9398-29
Toll Free in Germany: 0800 639 7678
e-mail: info@omega.de

United Kingdom: One Omega Drive, River Bend Technology Centre
ISO 9002 Certified Northbank, Irlam, Manchester
M44 5BD United Kingdom
Tel: +44 (0)161 777 6611 FAX: +44 (0)161 777 6622
Toll Free in United Kingdom: 0800-488-488
e-mail: sales@omega.co.uk


It is the policy of OMEGA Engineering, Inc. to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct, but OMEGA accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

WARNING: These products are not designed for use in, and should not be used for, human applications.

A. Basic Keypad Operations

- 1 EZ-Check™ Switch/EZ-Step™ Pushbutton**
Slide the switch to select the user stored values for calibration points.
Push the EZ-Step™ pushbutton like a stop Watch to Run or Stop Totalizing.



- 2 SOURCE/AMPLITUDE Button**
Press and release **SOURCE/AMPLITUDE** to change source modes. These are:
- Source CPH 1 - 20000
 - Source CPM 0.1 - 2000.0
 - Source HZ 0.01 - 200.00
 - Source HZ 0.1 - 2000.0
 - Source KHZ 0.001 - 20.000
 - Totalizer

Press and hold **SOURCE/AMPLITUDE** to change amplitude voltage from 0.1-12Vp.

Then press the SOURCE/AMPLITUDE or STORE/CLEAR button to save selections and to exit.

- 3 ON/OFF Button**
Press **ON/OFF** to turn the CL535 on or off.

- 4 MENU Button**
Press and release the menu button and a mode of operation menu will appear with all the selections for operation mode.

REFER TO SECTION B.

- 5 READ/GATE TIME Button**
Press and release **READ/GATE TIME** to change read modes. These are:
- Read Source CPH 1 - 20000
 - Read CPM 0.1 - 2000.0
 - Read HZ 0.01 - 200.00
 - Read HZ 0.1 - 2000.0
 - Read KHZ 0.001 - 20.000
 - Totalizer

Press and hold **READ/GATE TIME** to select gate time adjustment for Source & Read Totalize mode.

Then press the SOURCE/AMPLITUDE or STORE/CLEAR button to save selections and to exit.

- 6 STORE/CLEAR Button**
In source mode press the **STORE/CLEAR** to save the calibration values. The display will flash "STORED" to confirm.

In read mode press **STORE/CLEAR** to clear the values saved in the EZ-Check™ HI and LO positions. The display will flash "CLEARED" to confirm.

- 7 EZ-Dial™ Knob**
Source mode -Turn the EZ-Dial™ knob to adjust the output level. Press and turn to adjust 100X faster.

Read mode - Turn the EZ-Dial™ knob to adjust the trigger level.

B.**CL535 Configuration**

Press the MENU BUTTON on the CL535 after you turn the unit on to access the configuration mode. Turn the EZ-Dial™ Knob to select configuration items. Press the EZ-Dial™ Knob to change configuration items. Then press the Menu or STORE/CLEAR button to save selections and to exit.

→AUTO OFF	ON
X1/X10	X10
0 XING/BASED	XING
EZ-CHECK	ON
SINE/SQ	SQ
BASIC CONFIGURATION	

Auto Off - ON (default)/OFF

Auto Off is ON, by default, to save battery life by turning the unit off after 30 minutes of inactivity. Turn Auto Off to OFF to prevent automatic shutdown. This is typically useful for manual loading or continuous use.

X1/X10 - X1 (default)

This selection is for attenuation of input signals factored by X1 or by X10, X1 for voltage between 1 - 12Vpk or X10 for voltages between 1 - 120Vp.

0 XING/BASED Based (default)

This selection gives the users the ability to change output signals between Zero Based and Zero Crossing. This gives the user the ability to select 0 XING for Zero Crossing Square or Sine waves to be able to output signals that go from positive to negative. Zero Based Square Wave to output only positive signals.

NOTE: FOR SIMULATING NEGATIVE ONLY SIGNALS, SWAP THE BLACK AND RED LEAD WIRES IN ZERO BASED MODE.

EZ-Check™ HI/LO Readings ON (default)

If the EZ-Check™ HI/LO Readings option is ON, the highest and lowest readings will automatically be saved in the HI and LO EZ-Check™ positions.

If this option is OFF the HI and LO positions will show the current reading.

SINE/SQ SQ (default)

This selection gives the users two choices to choose from for an output signal:
Sign Wave Signal or Square Wave Signal

BASIC CONFIGURATION

If Basic Configuration is selected, the unit will restore all factory defaults. This will reset any changes made in the CL535 Configuration options, returning the unit to its simplest factory configuration. Which means Auto Off is on, range at x1, Zero Based Square Wave, EZ-Check is on and Square wave is selected.

C. EZ-Dial™ Knob

Source mode - Adjust the output up and down with the EZ-Dial™ knob. The increment is the far right digit (XXXX1). Press while turning to adjust 100X faster (XX1XX)

Read mode - Trigger level adjustment. Adjust knob until LED Blinks and Reading is displayed.

D. EZ-Check™ Switch

The EZ-Check™ switch has three positions -- high, set, and low. Its position is shown at the left edge of the LCD display with "HI" and "LO" indicators. Use of the EZ-Check™ switch depends on mode:

Source Modes:

Slide the EZ-Check™ switch to the HI and LO positions to recall the settings stored in those positions. While in the HI and LO positions, dial the EZ-Dial™ knob to change the display. Press **STORE/CLEAR** to save new settings in the HI and LO positions. The display will flash "STORED" to confirm.

Hint: For faster calibrations, the position of the switch can be felt. This feature allows continuous monitoring of the device being calibrated without looking back at the CL541 display. This is also useful in poor lighting or under difficult operating conditions.

Read Modes:

In read modes, with the EZ-Check™ switch in the middle position, the CL535 calibrator records the maximum and minimum readings observed in each mode. Slide the EZ-Check™ switch to the HI and LO positions to display the readings. Press **STORE/CLEAR** to clear the readings. The display will flash "CLEARED" to confirm.

E. TOTALIZE Pushbutton

The EZ-Step™ Switch pushbutton is a feature for read and source modes.

Push the EZ-Step™ like a stop watch to run or stop Totalizing.

F. FREQUENCY OUTPUT (SOURCE MODE)

Press the SOURCE button to select the Frequency output mode, the word Source will appear on the LCD Display. Press the SOURCE button to select the desired frequency range. Press and hold the Source/Amplitude button to enter the Amplitude adjustment screen. Then turn the EZ-Dial™ knob to select the desired Level (amplitude) this will be indicated on the LCD. Levels are indicated in Vp and Vpp with respect to the black lead (-). Then press the SOURCE/AMPLITUDE or STORE/CLEAR button to save selections and to exit.

You are able to setup three desired set points for quick calibration. Use the **EZ-Check™** slide switch. Slide the EZ-Check™ switch to the HI and dial the EZ-Dial™ to the desired set point. Press the STORE/CLEAR button to save settings. Do the same in the LO positions. For the mid range just dial it to the set point. It will stay at that point unless you move the EZ-Dial™. This is so you may test linearity in the mid range while maintaining the 0% and 100% end points.

Connect the CL535 to the output of the equipment or sensor to being calibrated then slide the EZ-Check™ switch to the HI, MIDDLE and LO positions to recall the settings stored in those positions.

If you need to change set points, while in the HI and LO positions, dial the EZ-Dial™ knob to change the display. Press **STORE/CLEAR** to save new settings in the HI and LO positions. The display will flash "STORED" to confirm.

G. FREQUENCY COUNTER (READ MODE)

Press the READ button to select the READ mode, the word READ will appear on the LCD Display. Press the READ button to select the desired frequency range. Press the Menu button and select the Level (amplitude) X1 for signals 0.1 to 12Vp or X10 for signals from 1 to 120Vp. Then press the READ/GATE TIME or STORE/CLEAR button to save selections and to exit.

In read modes, the CL535 calibrator records the maximum and minimum readings observed in each mode. Connect the CL535 to the equipment or sensor being measured and use the **EZ-Check™** slide switch in the center position to monitor the frequency. Slide the EZ-Check™ switch to the HI and LO positions to display the min. & max. readings. Press **STORE/CLEAR** to clear the readings. The display will flash "CLEARED" to confirm.

H. FUNCTION OF THE GREEN LED

The CL535 is equipped with a GREEN LED light. It is being used in the Read mode to let the user know that their signal is being detected by the calibrator when the LED is flashing. If the LED is not lit, the user must adjust the trigger level. NOTE: Led will appear solid above Frequency of 60Hz.

I. TOTALIZE (READ MODE)

The CL535 will count pulses with-in the users defined period. Press the Menu button and select the Level (amplitude) X1 for signals 0.1 - 12Vp or X10 for signals from 1V to 140Vp. Then press the Menu or STORE/CLEAR button to save selections and to exit. Press the READ/GATE TIME button and select the TOTALIZER mode. Press and hold the READ/GATE TIME button and adjust the number of minutes (1-100) that you want the CL535 to count pulses. Then press the READ/GATE TIME or STORE/CLEAR button to save selections and to exit. Then turn the EZ-Dial™ knob to adjust the trigger time. This will be indicated on the LCD.

Connect the CL535 to the output of the equipment or sensor being measured and push the EZ-Step™ push button on the side of the unit, similar to a Stop Watch, to run or stop Totalizing. The words RUN or STOP will appear on the LCD display.

See Totalizer Connections on next page.

J. CALIBRATE TOTALIZE RS (SOURCE MODE)


The CL535 will count pulses with-in a selected time frame. Press the SOURCE/AMPLITUDE button and select the TOTALIZER mode. Press and hold the READ/GATE TIME button and adjust the number of minutes (1-100) that you want the CL535 to output pulses. Then press the SOURCE/AMPLITUDE or STORE/CLEAR button to save selections and to exit. Then turn the EZ-Dial™ knob to adjust the number of pulses required during the time period defined. This will be indicated on the LCD.

Connect the CL535 to the output of the equipment or sensor to be calibrated then Press the Slide the EZ-Check™ Switch to start.


See Calibrate Totalizers Connection diagram on next page.

TOTALIZE CONNECTIONS

Connect the CL535 to the output of the equipment or sensor to be measured and push the EZ-Step™ pushbutton like a stop watch to run or stop Totalizing. The words RUN or STOP will appear on the LCD display.



CALIBRATE TOTALIZERS



Connect the CL535 to the input of the equipment or sensor to be calibrated. Slide the EZ-Check™ switch to the HI and LO positions to recall the settings stored in those positions.

K. Specifications

General Specifications:(Unless otherwise indicated all specifications are rated from a nominal 23 °C, 70 % RH for 1 year from calibration)

Operating Temperature Range	-20 to 60 °C (-5 to 140 °F)
Storage Temperature Range	-30 to 60 °C (-22 to 140 °F)
Relative Humidity Range	10 % ≤RH ≤90 % (0 to 35 °C), Non-condensing 10 % ≤RH ≤ 70 % (35 to 60 °C), Non-condensing
Size	7.00 X 3.30 X 2.21 inches (177.8 x 83.8 x 56.1mm)
Weight	12.0 oz (340 grams)
Battery	9V Alkaline
Miscellaneous	Low battery indication with nominal 1 hour of operation left Over-voltage protection to 120 Vrms (rated for 30 seconds) or 240 Vrms (rated for 15 seconds) High contrast graphic liquid crystal display with 0.45" (11.4 mm) high digits

Common Specifications for all Frequency Modes:

Frequency Ranges	1CPH to 20.000KHz
Accuracy	± 0.005% of range
Temperature Effect	≤ 10ppm/°C of range

Frequency Ranges Specifications:

1	1 CPH < CPH Range < 20000 CPH
2	0.1 CPM (0.0167Hz) < CPM Range < 2000.0 CPM (33.33Hz)
3	0.01Hz < Hz < 200.00Hz
4	0.1Hz < Hz Range < 2000.0Hz
5	0.001KHz < KHz Range < 20.000KHz
6	Totalize inputs/outputs from 1 to 99999 counts in 1 minutes to 100.0 minutes

Read Inputs Specifications:

Read	x1 attenuation range: 0.1Vpk to 12Vpk x10 attenuation range: 1Vpk to 120V peak – Limit of attenuation is 120Vpk
Input Impedance	> 1 Meg Ω + 100pF
Adjustable Signal Attenuation	Adjustable trigger level with X1 and X10 attenuation ranges
Miscellaneous	Battery life ≥ 24 hour typical
Fuse-less protection	240Vrms

Waveforms Source Specifications:

Output current	>6mA _{pp} at 12V _{pp} output, 20KHz
Output Impedance	< 25Ω
Square Wave:	
Zero Crossing, Zero Based	Selectable
Rise/Fall Time	< 0.0001% of output Vpk per Second
Frequency Jitter	< 0.5LSB of frequency range
Duty cycle	50% ± 2%
Sine Wave:	
Offset and Zero Crossing	<± 10% of Vpk Output amplitude setting
Symmetry	
Amplitude Adjustment	100mV < Nominal Output < 12V _{pp} ± 10% of setting

Calibration Certificate:

Option:	NIST Traceable Certificate provided
	Test data available upon request at additional charge.

Available Options:

Option:	Part Number:
CL535-BNC	With a BNC connector ADDED CHARGE OF \$50.00 to the list of the CL535
Carrying Case	SC-530

CL535 Field Test Procedure

Equipment Needed:

1. Universal Counter Timer with an accuracy of ± 10 PPM RDG.
2. Digitizing Oscilloscope.
3. Frequency Source with an accuracy of ± 10 PPM RDG.

CALIBRATION:

No Calibration is required.

Final Test:

Source Mode:

Connect the CL535 to the Universal Counter Timer. Press the SOURCE Button to switch to different source modes. Set the CL535 to the settings below and verify the CL535 is properly functioning within specification.

UUT Setting	Counter Timer Reading
20000 CPH	5.5555 Hz \pm 0.0003 Hz
2000.0 CPM	33.3333 Hz \pm 0.0017 Hz
200.00 Hz	200.00 Hz \pm 0.01 Hz
2000.0 Hz	2000.0 Hz \pm 0.1 Hz
20.000 kHz	20.000 kHz \pm 1.000 kHz

Read Mode:

Connect the CL535 to a Frequency Source. Press the READ Button to switch to the different read modes. Set the frequency calibrator to the settings in the table below and verify the UUT is reading within specification.

Frequency Calibrator Setting	UUT Reading
5.5556 Hz	2000.0 CPH \pm 0.1 CPH
33.3333 Hz	2000.0 CPM \pm 0.1 CPM
200.00 Hz	200.00 Hz \pm 0.01 Hz
2000.0 Hz	2000.0 Hz \pm 0.1 Hz
20.000 kHz	20.000 kHz \pm 1.000 kHz

Source Mode:

1. Check that the Output impedance is $< 25\Omega$.
2. Check that the Duty cycle is $50\% \pm 2\%$.
3. Check that the Amplitude Adjustment is $\pm 10\%$ of setting.
4. Check the Zero crossing Symmetry is $< \pm 10\%$ of Vpk Output amplitude setting.

Completion of Field Test:




FIGURE 1 (Source Modes)




FIGURE 2 (Read Modes)

NOTES



WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **37 months** from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal **three (3) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components in which wear is not warranted, include but are not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by the company will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

RETURN REQUESTS/INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of the product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 2005 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.

Where Do I Find Everything I Need for Process Measurement and Control? **OMEGA...Of Course!** *Shop online at omega.com*

TEMPERATURE

- ☑ Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- ☑ Wire: Thermocouple, RTD & Thermistor
- ☑ Calibrators & Ice Point References
- ☑ Recorders, Controllers & Process Monitors
- ☑ Infrared Pyrometers

PRESSURE, STRAIN AND FORCE

- ☑ Transducers & Strain Gages
- ☑ Load Cells & Pressure Gages
- ☑ Displacement Transducers
- ☑ Instrumentation & Accessories

FLOW/LEVEL

- ☑ Rotameters, Gas Mass Flowmeters & Flow Computers
- ☑ Air Velocity Indicators
- ☑ Turbine/Paddlewheel Systems
- ☑ Totalizers & Batch Controllers

pH/CONDUCTIVITY

- ☑ pH Electrodes, Testers & Accessories
- ☑ Benchtop/Laboratory Meters
- ☑ Controllers, Calibrators, Simulators & Pumps
- ☑ Industrial pH & Conductivity Equipment

DATA ACQUISITION

- ☑ Data Acquisition & Engineering Software
- ☑ Communications-Based Acquisition Systems
- ☑ Plug-in Cards for Apple, IBM & Compatibles
- ☑ Datalogging Systems
- ☑ Recorders, Printers & Plotters

HEATERS

- ☑ Heating Cable
- ☑ Cartridge & Strip Heaters
- ☑ Immersion & Band Heaters
- ☑ Flexible Heaters
- ☑ Laboratory Heaters

ENVIRONMENTAL MONITORING AND CONTROL

- ☑ Metering & Control Instrumentation
- ☑ Refractometers
- ☑ Pumps & Tubing
- ☑ Air, Soil & Water Monitors
- ☑ Industrial Water & Wastewater Treatment
- ☑ pH, Conductivity & Dissolved Oxygen Instruments