

# EWSE Series

## Rugged, Weatherproof Temperature Sensors and Transmitters

INSTRUCTION  
SHEET

MUK001/0311

Shop online at: [omega.co.uk](http://omega.co.uk) e-mail: [sales@omega.co.uk](mailto:sales@omega.co.uk)  
For latest product manuals: [omega.co.uk](http://omega.co.uk)

### 1.0 Description

The EWSE air temperature sensors are designed for wall or pipe mounting in harsh indoor or outdoor environments.

A rugged 6mm diameter sheathed RTD probe is housed in the centre of a 14mm dia. outer protection tube. The RTD sensor terminal block or optional transmitter are housed in a tough aluminium alloy enclosure, rated to IP65.

An IP68 cable gland is fitted to the left hand side of the enclosure, suitable for cables from 2.5 to 6.5mm diameter.



### 2.0 Receiving and Unpacking

Please inspect the packaging and sensor thoroughly for any signs of transit damage. Please notify Omega customer service if any damage is found.

### 3.0 Specifications

**Dimensions:**

Box: 80 W x75 H x 58 mm D

Sensors: 75 mm long x 14 mm O.D

Cable Entry: IP68 gland for 2.5 to 6.5 O.D cable

**EWSE-Pt100 Sensor Only Model:**

**Sensor Type:**

- Pt100 class A 4-wire standard

- Pt1000 on request

**Ambient Temperature Range:**

-50 to +100°C

**Electrical Connection:**

Screw terminal block

**EWSE-Pt100-TX:**

**Ambient Temperature Range:**

-40 to +85°C at 10 to 90% RH non condensing

**Standard Transmitter Scaling:**

4 mA at -25 C, 20 mA at +75°C

**Electrical Connection:**

Screw terminals, 2-wire

**Power Supply:**

10 to 30Vdc, loop powered

**Power Supply:**

$[(V \text{ supply}-10)/20]$  K $\Omega$ . eg. 700 $\Omega$  @ 24V

### 4.0 Mechanical Installation


The EWSE has been designed for wall or pipe mounting.

For wall fixing a drilling template is provided in **Annex A** of this manual.

An optional bracket, part number EWSE-MB is available for pipe mounting. See **Annex B** for details.

### 5.0 Electrical Installation

For the EWSE-Pt100-TX temperature sensor with transmitter please refer to the transmitter manual M4561 for wiring and scaling information. The standard EWSE-Pt100 model features a 4 way screw terminal block for connection to the 4-wire Pt100 sensor.





Online Service omega.co.uk	Internet e-mail slaes@omega.co.uk
-------------------------------	--------------------------------------

### Servicing Europe:

**United Kingdom:** OMEGA Engineering Ltd.  
ISO 9001 Certified  
 One Omega Drive, River Bend Technology Centre, Northbank  
 Irlam, Manchester M44 5BD United Kingdom  
 Free Phone: 0800-488-488      TEL: +44 (0) 161 777-6611  
 FAX: +44 (0) 161 777-6622      e-mail: sales@omega.co.uk

**France:** Managed by the United Kingdom Office  
 Toll-Free: 0800 466 342      TEL: +33 (0) 161 37 29 00  
 FAX: +33 (0) 130 57 54 27      e-mail: sales@omega.fr

**Benelux:** Managed by the United Kingdom Office  
 Toll-Free: 0800 099 3344      TEL: +31 20 347 21 21  
 FAX: +31 20 643 46 43      e-mail: sales@omegaeng.nl

**Germany/Austria:** Daimlerstrasse 26, D-75392 Deckenpfronn, Germany  
 Toll-Free: 0800 6397678      TEL: +49 (0) 7056 9398-0  
 FAX: +49 (0) 7056 9398-29      e-mail: info@omega.de

### Servicing North America:

**U.S.A.:** Omega Engineering, Inc., One Omega Drive, P.O. Box 4047  
ISO 9001 Certified  
 Stamford, CT 06907-0047  
 Toll-Free: 1-800-826-6342      Tel: (203) 359-1660  
 FAX: (203) 359-7700      e-mail: info@omega.com

**Canada:** 976 Bergar  
 Laval (Quebec), H7L 5A1 Canada  
 Toll-Free: 1-800-826-6342      TEL: (514) 856-6928  
 FAX: (514) 856-6886      e-mail: info@omega.ca

### For immediate technical or application assistance:

**United Kingdom:** Sales Service Free Phone: 0800-488-488 (UK ONLY)  
 Sales Service International: +44(0)-161-777-2225  
 Engineering Service Direct +44(0) -161-777-2232

**U.S.A. and Canada:** Sales Service: 1-800-826-6342/1-800-TC-OMEGA®  
 Customer Service: 1-800-622-2378/1-800-622-BEST®  
 Engineering Service: 1-800-872-9436/1-800-USA-WHEN®

It is the policy of OMEGA Engineering, Ltd. to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct, but OMEGA accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.  
**WARNING:** These products are not designed for use in, and should not be used for, human applications.



## WARRANTY/DISCLAIMER

OMEGA ENGINEERING, LTD. warrants this unit to be free of defects in materials and workmanship for a period of **13 months** from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal **one (1) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components in which wear is not warranted, include but are not limited to contact points, fuses, and triacs.

**OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by the company will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.**

**CONDITIONS:** Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

## RETURN REQUESTS / INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of the product, and
3. Repair instructions and/or specific problems relative to the product.


OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering. OMEGA is a registered trademark of OMEGA ENGINEERING, LTD.

© Copyright 2011 OMEGA ENGINEERING, LTD. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, LTD.

# EWSE MOUNTING BRACKET

SUITABLE FOR USE WITH PIPES BETWEEN Ø30mm TO Ø60mm

ORDERING PART NUMBER: EWSE - MB



## FIXING KIT

The following fasteners are supplied with each bracket assembly:

- 2 x M6 x 75 long BZP Hexagon headed set screws
- 2 x M6 x 40 long BZP Hexagon headed set screws
- 2 x M6 flat washers BZP
- 2 x M4 x 20 long BZP Cap screws

MUK001 / 0311 - Annex B.



# TX12 PUSH BUTTON PT100 TX

MADE IN UNITED KINGDOM



## INSTRUCTION SHEET

M4561/0807

Shop online at: [omega.co.uk](http://omega.co.uk) e-mail: [sales@omega.co.uk](mailto:sales@omega.co.uk)  
For latest product manuals: [omega.co.uk](http://omega.co.uk)

### 1.0 DESCRIPTION

The TX12 head mounted temperature transmitter connects to any standard Pt100 resistance sensor and converts the linearised temperature to a (4 to 20) mA signal. The transmitter is a two wire device and is fully configurable by the user, over a wide temperature range, with the aid of a simple push button. This new TX12 design incorporates additional configuration menus, allowing the user to push button trim the transmitter output at both zero and span, ideal for trimming out sensor errors. The transmitter's advanced circuitry guarantees high stability over the wide operating ambient temperature ranges experienced by head mounted devices.

One of the transmitter's features is the program LED, which provides visual indication of sensor fault when in normal operation and is also used to guide the operator through the simple menus during configuration.

### 2.0 RECEIVING AND UNPACKING

Please inspect the packaging and instrument thoroughly for any signs of transit damage. If the instrument has been damaged, please notify your supplier immediately.

### 3.0 SPECIFICATION @ 20 °C

<b>INPUT</b>	
Sensor Type	PT100 100 R @ 0°C 2 or 3 Wire
Sensor Range	(-200 to +850) °C (18 to 390) °F
Sensor Connection	Screw terminal
Minimum span (see note 1)	25 °C
Linearity	BS EN 60751(IEC 751) standard / JISC1604
Accuracy (see note 2)	±0.1 °C ±0.05% of Reading
Thermal Drift	0.0025 % / °C
Excitation current	< 200 uA
Lead Resistance Effect	0.002 °C / °C
Maximum lead Resistance	20 Ω per leg

Note 1 Any span may be selected, full accuracy is only guaranteed for spans greater than the minimum recommended span. Basic measurement accuracy includes the effects of calibration, linearity and repeatability.

Note 2

<b>OUTPUT</b>	
Type	Two wire (4 to 20) mA sink
Limits	Low 3.8 mA ; High 21.5 mA
Accuracy	±(mA out / 2000) or ±5 uA which ever greater
Loop Effect	± 0.2 uA / V measured @ 50 Hz 1 V (peak to peak)
Thermal Drift	± 1 uA / °C typical ; ±1.5 uA Max
Max Load	[V(supply) - 10] / 20 [kΩ]

### GENERAL

Update Time	0.5 Seconds
Response Time	1 Second to reach 90% of final value
Start up time	From power up typically 5 Seconds
Filter Factor	Adaptive
Ambient Temperature	(-40 to 85) °C
Connection	Screw Terminal
Approvals	BS EN 61326 ; 1998 – Electrical equipment for measurement and control ANNEX A ; ANNEX F

Factory Default

(0 to 100) °C upscale burnout (0.0 °C user trim)

### 4.0 INSTALLATION AND WIRING

#### SIDE VIEW





Figure 1

#### BASE VIEW



Mounting holes : two holes 5.5 mm diameter, 33 mm centres  
Centre Hole sensor wire entry : 4 mm

#### 4.1 Mechanical

The TX12 transmitter has been specifically designed to fit inside a DIN standard probe head enclosure (such as the Omega NB series), which provides adequate protection from moisture, dust, corrosive atmosphere etc. All cable entries must be sealed using the correct size gland. Likewise any probe assembly fitted must be sealed.

Care must be taken when locating the transmitter to ensure the working ambient temperature range of (-40 to 85) °C is not exceeded. The TX12 enclosure has a centre hole allowing the sensor wired to enter screw terminals from the transmitter centre, this is applicable when the sensor is mounted directly below the transmitter.


#### 4.2 Electrical

Electrical connections to the transmitter are made to the screw terminal provided on the top face. The sensor wires must be equal length and type for the lead compensation to work correctly. The screw terminals allow for wires to enter either inner or outer direction. The transmitter is protected against reverse connection and over voltage. If no sensor (input) connection is made the transmitter will go into either up or down scale output current, depending on configuration.

Figure 2 gives connection details, the output is shown connected to a 24 V supply. The load symbol represent any other device connected in the loop, such as Monitoring equipment, panel indicators and loop isolators. The load value can range from 0 ohms to the max loop load for given supply, refer to section 3 "Max load" for more information. The transmitter conforms with EC directive BS EN 61326 : 1998 when correctly installed in a termination head providing at least IP20 protection and with sensor wires less than 3 metres. Screened or twisted pair wires are recommended for output wires. Always ensure the (4 to 20) mA loop is grounded at one point, this would normally be at the monitoring equipment or loop power supply.

In normal operation the program LED acts as over-range LED.

Figure 2



### 5.0 USER CONFIGURATION

**IMPORTANT**  
READ COMPLETE SECTION BEFORE ATTEMPTING CONFIGURATION  
PARTICULAR CARE SHOULD BE TAKEN REGARDING TIMEOUTS IN MENU 2 & 3




Figure 3 Configuration circuit

#### User Configuration

User configuration uses three menus, each menu sets a different parameter:-

- Menu 1 Set range
- Menu 2 Set direction of output on sensor burnout
- Menu 3 User trim at 4 mA and 20 mA.

The configuration menus are navigated using the push button and program LED. The push button is located under the hole in the keyhole shaped wiring label. To press the button use a 3 mm screw driver (flat blade) inserted into the hole. The button has a slight click action.

Three types of button press are used:-

- Single button press = Advance
- Double press within 0.5 seconds = Escape or change direction
- Press and hold button > two seconds = Enter

When a menu is selected the Program LED will flash in bursts of one to three flashes, the number of flashes represents the menu number.

#### Navigating the menus

- To access menus, press and hold button > 2 second, then program LED will start to flash, one flash every burst. This indicates "menu 1" is selected.
- Use single button press to advance selection to "menu 2", the program LED will now show two flashes per burst. The Next single presses will advance the selected menu to menu 3 and the next single press will advance selected menu back to menu 1. Repeated single presses will cycle the selected menu back around menus 1 to 3, in the above sequence.
- Double press button to escape from menus, and return to normal. Normal operation can also be selected by turning transmitter power off and on. Note the transmitter will not time out and automatically escape from menus.

#### Menu 1 Range configuration (No Timeout)

Configuration will require the following tools and equipment:-

- DC Supply (12 to 30 V @ 30 mA
- Precision resistance decade box to simulate PT100 sensor.
- Screw driver flat blade 3mm wide
- PT100 resistance tables
- Current meter (user trim)



## 5.0 USER CONFIGURATION

### IMPORTANT

## READ COMPLETE SECTION BEFORE ATTEMPTING CONFIGURATION PARTICULAR CARE SHOULD BE TAKEN REGARDING TIMEOUTS IN MENU 2 & 3




Figure 3 Configuration circuit

### User Configuration

User configuration uses three menus, each menu sets a different parameter:-

- Menu 1 Set range
- Menu 2 Set direction of output on sensor burnout
- Menu 3 User trim at 4 mA and 20 mA.

The configuration menus are navigated using the push button and program LED. The push button is located under the hole in the keyhole shaped wiring label. To press the button use a 3 mm screw driver (flat blade) inserted into the hole. The button has a slight click action.

Three types of button press are used:-

- Single button press = Advance
- Double press within 0.5 seconds = Escape or change direction
- Press and hold button > two seconds = Enter

When a menu is selected the Program LED will flash in bursts of one to three flashes, the number of flashes represents the menu number.

### Navigating the menus

To access menus, press and hold button > 2 second, then program LED will start to flash, one flash every burst. This indicates 'menu 1' is selected.

- Use single button press to advance selection to 'menu 2', the program LED will now show two flashes per burst. The Next single presses, will advance the selected menu to menu 3 and the next single press will advance selected menu back to menu 1. Repeated single presses will cycle the selected menu back around menus 1 to 3, in the above sequence.
- Double press button to escape from menus, and return to normal. Normal operation can also be selected by turning transmitter power off and on. Note the transmitter will not time out and automatically escape from menus.

### Menu 1 Range configuration (No Timeout)

Configuration will require the following tools and equipment:-

- DC Supply (12 to 30) V @ 30 mA
- Precision resistance decade box to simulate PT100 sensor.
- Screw driver flat blade 3mm wide
- PT100 resistance tables
- Current meter (user trim)

### Using Menus

To re-range the temperature scale follow the following instructions:-

- Refer to figure 3, connect resistance box to TX12 input terminals using three wire connection. Connect output to a DC supply, observe polarity. Turn power on and allow 1 minute warm up period.
- Set calibrator to the equivalent resistance of the PT100 sensor, at required low range temperature. If the program LED is on at this stage the input is out of range, check resistance and connection.
- Press and hold button > 2 seconds to enter menus, menu 1 will then be selected, indicated by one flash every burst.
- Whilst menu 1 is selected, press and hold button > 2 seconds to enter menu 1, at which stage the program LED toggle on and off at a slow rate.
- Allow ten seconds then single press button to store low range setting, the program LED will now flash at a fast rate.
- Set calibrator to the equivalent resistance of the pt100 sensor, at required high range temperature and allow ten seconds.
- Press button to store high range setting, the program LED will flicker for one second before the transmitter returns to normal operation. The transmitter is now re-ranged.

### Menu 2 Burnout Selection (Timeout is 3 Seconds)

- Refer to figure 3, Connect output to a DC supply, observe polarity. For this menu the input can be connected or open circuit. Turn power on.
- Press and hold button > 2 seconds to enter menus, menu 1 will then be selected, indicated by one flash every burst.
- Single press button to advance selection to menu 2, indicated by two flashes of the program LED every burst.
- Whilst menu 2 is selected, press and hold button > 2 seconds to enter menu 2, at which stage the program LED will either toggle on and off at a slow indicating low scale burnout or fast rate indicating upscale burnout.
- To change burnout direction single press button. The Program LED toggle rate will change to the other setting. Repeated single presses will toggle between up and down scale.
- To store setting allow 3 seconds with no button action, the program will then timeout, store new setting then return to normal operation.

### Menu 3 User trim (Timeout is 20 Seconds)

This menu allows the user to trim the output current at 4 mA and 20 mA points, (similar function to trim potentiometers) and is very useful for trimming out sensor errors.

The input of the transmitter must be connected to either a calibrator or temperature sensor held at a known temperature. The (4 to 20) mA loop current also need to be monitored with a current meter.

- Refer to figure 3, connect sensor or resistance box to TX12 input terminals using three wire connection. Connect output to a DC supply, observe polarity, connect current meter in series with loop. Turn power on and allow 1 minute warm period. Set calibrator to the equivalent resistance of the PT100 sensor, at required point. Alternatively ensure sensor temperature is at the required calibration point.
- The transmitter will automatically trim the 4 mA end if the output is within the active band of (3.8 to 6) mA, and trim the 20 mA end if the output is within the active band of (18 to 21.5) mA. No setting adjustment is performed if the output current not within these two bands. Ensure your calibration points are within these bands. Press and hold button > 2 seconds to enter menus, menu 1 will then be selected, indicated by one flash every burst.
- Single press button to advance selection to menu 2, and single press again select menu 3 indicated by three flashes of the program LED every burst.
- Whilst menu 3 is selected, press and hold button > 2 seconds to enter menu 3, which stage the program LED toggle on and off at either a slow rate indicating downward trim direction or fast rate indicating upwards trim direction.
- To change trim direction double press button. The Program LED toggle rate toggle to the opposite direction. Repeated double presses will toggle between And trim direction.
- To trim output current, single press button to advance current 2 uA in set direction, or press and hold button to auto advance in set direction release button to stop advance. Note after approximately 20 seconds of continuous button press, auto trim rate will speed up. Monitor the current change on the current meter.
- To store new setting allow 20 seconds with no button action, the program will then timeout, store new setting then return to normal operation.

### Reset to factory default settings

If required the TX12 can be reset to factory default settings, this procedure also removes any user trim adjustment. Factory default settings are :

- Range Burnout up-scale
- User trim All user adjustment cleared

To reset to factory setting, hold the button down whilst the TX12 is powered up.

### RETURN REQUESTS/INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department BEFORE RETURNING ANY PRODUCTS TO OMEGA. PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (ARI) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence. The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

**FOR WARRANTY RETURNS**, please have the following information available BEFORE contacting OMEGA:

- Purchase Order number under which the product was purchased.
- Model and serial number of the product under warranty, and
- Repair instructions and/or specific problems relative to the product.

**FOR NON-WARRANTY REPAIRS**, consult OMEGA for repair information before the following information is available BEFORE contacting OMEGA:

- Purchase Order number to cover the COST of the repair.
- Model and serial number of the product and
- Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.

### WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **13 months** from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal **one (1) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (ARI) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion, or current, heat, moisture or vibration, improper specification/misapplication, in which wear is not warranted, include but are not limited to contact points, fuses, and traces.

**OMEGA is pleased to offer suggestions on the use of its various products.** However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by the company will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this product, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Products be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility, as set forth in our basic WARRANTY/DISCLAIMER (language and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Products) in such a manner.

It is the policy of OMEGA Engineering, Inc. to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct, but OMEGA accepts no liability for any errors it contains, and reserves the right to alter specifications without notice. **WARNING:** These products are not designed for use in, and should not be used for, human applications.

## Where Do I Find Everything I Need for Process Measurement and Control? OMEGA...Of Course!

### Shop online at [omega.com](http://omega.com)

#### TEMPERATURE

- Thermocouple, RTD & Thermistor Probes, Connectors, Fans & Assemblies
- Wire: Thermocouple, RTD & Thermistor
- Calibrators & Ice Point References
- Recorders, Controllers & Process Monitors

#### PRESSURE, STRAIN AND FORCE

- Intrinsically Safe Transducers
- Load Cells & Pressure Gages
- Displacement Transducers
- Instrumentation & Accessories

#### FLOW/LEVEL

- Rotameters, Gas Mass Flowmeters & Flow Computers
- Air Velocity Indicators
- Turbine/Paddlewheel Systems
- Totalizers & Batch Controllers

#### pH/CONDUCTIVITY

- pH Electrodes, Testers & Accessories
- Benchtop/Laboratory Meters
- Controllers, Calibrators, Simulators & Pumps
- Industrial pH & Conductivity Equipment

#### DATA ACQUISITION

- Data Acquisition & Engineering Software
- Communications-Based Acquisition Systems
- Plug-in Cards for Apple, IBM & Compatibles
- Datalogging Systems
- Recorders, Printers & Plotters

#### HEATERS

- Heating Cable
- Cartridge & Strip Heaters
- Immersion & Band Heaters
- Flexible Heaters
- Laboratory Heaters

#### ENVIRONMENTAL MONITORING AND CONTROL

- Metering & Control Instrumentation
- Retardometers
- Pumps & Tubing
- Air, Soil & Water Monitors
- Industrial Water & Wastewater Treatment
- pH Conductivity & Dissolved Oxygen Instruments