


**1 YEAR**  
WARRANTY



# User's Guide



**Shop online at**

**omega.com<sup>®</sup>**

Ω OMEGA<sup>®</sup>

*omega.com*

*e-mail: info@omega.com*

**For latest product manuals:  
*omegamanual.info***

**ISO 9001**  
CERTIFIED  
CORPORATE QUALITY  
STAMFORD, CT

**ISO 9002**  
CERTIFIED  
CORPORATE QUALITY  
MANCHESTER, UK

## **DPG 1200 SERIES Digital Pressure Gauge**

# Model 1200, 1202, 1203 and 1205

## DIGITAL PRESSURE GAUGE OPERATING INSTRUCTION

---

### Operating / Mounting Instructions

1. Mount the gauge on a suitable \_” (or appropriately sized) NPT female fittings. Use Teflon tape or pipe dope to seal threads. Do not over tighten.
2. Depress **ON/OFF** button to power up unit (no pressure applied). If there is a reading other than zero, press the **ZERO** button to zero-out the display.
3. **Apply pressure** to the gauge – the display should now indicate that pressure is being applied.  
**Note:** If the ZERO Button is pressed when the pressure is changing, the display will not indicate “0” until the pressure has stabilized or by reducing the system pressure back to “0” (no pressure applied). Press the ZERO button to zero-out the display once pressure has been stabilized.
4. Press the **ON/OFF** button to shut off display.  
**Note:** The display will automatically turn off after approximately 3 minutes.
5. **Battery Replacement:** The battery is located on the inside of the rear cover. Remove one screw to remove the rear cover. Using a small screwdriver to slide the battery out, un-snap the old 9V battery and replace with the new battery. Replace the rear cover and the screw when complete.

**Caution:** Do not hold down the ON/OFF button for more than 5 seconds. This could affect the calibration of the gauge.

## Model 1200, 1202, 1203 & 1205

### Operation Settings

<u>Display</u>	<u>Option Display</u>	<u>Function</u>
123.4		At normal display, <u>Press &amp; Hold</u> "ZERO" for more than 5 sec.
Cont. Holding	Release - 1 -	Cont
		<b>Continuous Reading (Cont) &amp; Peak and Hold (hold)</b> As display switches between "Cont" and "hold" <u>Press</u> "ZERO" to select.
Cont. Holding	Release - 2 -	Aon
		<b>Always On (Aon) &amp; Auto Shut-Off (Aoff)</b> As display switches between "Cont" and "hold", <u>Press</u> "ZERO" to select.
Cont. Holding	Release - 2 -	Aoff
		<b>Always On (Aon) &amp; Auto Shut-Off (Aoff)</b> As display switches between "Cont" and "hold", <u>Press</u> "ZERO" to select.
	Release - 3 -	180
		If "Aoff" is selected, display will show shut-off time in seconds. <u>Press</u> "ON/OFF" or "ZERO" to increase or decrease seconds.
	Release - 3 -	PSI
		<b>Pressure Unit Setting</b> <u>Press</u> "ZERO" to select.
	Release - 3 -	Bar
Cont. Holding	Release - 3 -	Kgf/cm <sup>2</sup>
		<b>Pressure Unit Setting</b> <u>Press</u> "ZERO" to select.
	Release - 4 -	330.0
		<b>Maximum Over Pressure Limit</b> <u>Press</u> "ON/OFF" or "ZERO" to increase or decrease.
Cont. Holding	Release - 5 -	-30.0
		<b>Minimum Under Pressure Limit</b> <u>Press</u> "ON/OFF" or "ZERO" to increase or decrease.
Cont. Holding	Release - 5 -	END
		If hold key continuously, the LCD will display "END". It won't go back to normal display mode until the key is released.
Release	Release - 5 -	123.4
		Normal display

#### **Settings Glossary:**

Continuous reading: the gauge display constantly shows the current reading

Peak and Hold: the gauge displays the maximum recorded pressure during a specified time period or session

Aon: the gauge will be set to stay on for a maximum of 15 minutes

Aoff: the gauge will be set to stay on for only 3 minutes

Maximum Over Pressure Limit: the maximum amount of pressure the gauge will display beyond the gauge's specified range

Minimum under pressure Limit: the lower limit that the gauge will display beyond zero



Ω OMEGA®

OMEGAnet® Online Service  
omega.com

Internet e-mail  
info@omega.com

**Servicing North America:**

**U.S.A.:**  
ISO 9001 Certified

One Omega Drive, Box 4047  
Stamford, CT 06907-0047  
Tel: (203) 359-1660 FAX: (203) 359-7700  
e-mail: info@omega.com

**Canada:**

976 Bergar  
Laval (Quebec) H7L 5A1, Canada  
Tel: (514) 856-6928 FAX: (514) 856-6886  
e-mail: info@omega.ca

**For immediate technical or application assistance:**

**U.S.A. and Canada:** Sales Service: 1-800-826-6342 / 1-800-TC-OMEGA®  
Customer Service: 1-800-622-2378 / 1-800-622-BEST®  
Engineering Service: 1-800-872-9436 / 1-800-USA-WHEN®A

**Mexico:** En Español: (001) 203-359-7803 e-mail: espanol@omega.com  
FAX: (001) 203-359-7807 info@omega.com.mx

**Servicing Europe:**

**Benelux:**

Postbus 8034, 1180 LA Amstelveen, The Netherlands  
Tel: +31 (0)20 3472121 FAX: +31 (0)20 6434643  
Toll Free in Benelux: 0800 0993344  
e-mail: sales@omegashop.nl

**Czech Republic:**

Frystatska 184, 733 01 Karviná, Czech Republic  
Tel: +420 (0)59 6311899 FAX: +420 (0)59 6311114  
Toll Free: 0800-1-66342 e-mail: info@omegashop.cz

**France:**

11, rue Jacques Cartier, 78280 Guyancourt, France  
Tel: +33 (0)1 61 37 2900 FAX: +33 (0)1 30 57 5427  
Toll Free in France: 0800 466 342  
e-mail: sales@omega.fr

**Germany/Austria:**

Daimlerstrasse 26, D-75392 Deckenpfronn, Germany  
Tel: +49 (0)7056 9398-0 FAX: +49 (0)7056 9398-29  
Toll Free in Germany: 0800 639 7678  
e-mail: info@omega.de

**United Kingdom:**

ISO 9002 Certified  
One Omega Drive, River Bend Technology Centre  
Northbank, Irlam, Manchester  
M44 5BD United Kingdom  
Tel: +44 (0)161 777 6611 FAX: +44 (0)161 777 6622  
Toll Free in United Kingdom: 0800-488-488  
e-mail: sales@omega.co.uk

It is the policy of OMEGA Engineering, Inc. to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct, but OMEGA accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

**WARNING:** These products are not designed for use in, and should not be used for, human applications.



**WARRANTY/DISCLAIMER**

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **13 months** from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal **one (1) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components in which wear is not warranted, include but are not limited to contact points, fuses, and triacs.

**OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by the company will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.**

**CONDITIONS:** Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

**RETURN REQUESTS / INQUIRIES**

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting OMEGA:

- 1. Purchase Order number under which the product was PURCHASED,
- 2. Model and serial number of the product under warranty, and
- 3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

- 1. Purchase Order number to cover the COST of the repair,
- 2. Model and serial number of the product, and
- 3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 2005 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.