

HX98

Relative Humidity Transmitter



M3499/0899

The Omega HX98 Relative Humidity Transmitter is a waterproof RH sensing element and package which is ideally suited for monitoring relative humidity in high RH/harsh environment applications or where washdowns are required. The unit is designed for continuous monitoring of relative humidity and temperature.

Both sensor and electronics are contained in an epoxy-hardened enclosure designed for continuous service. A water-tight membrane filter is installed over the RH sensor for increased protection against high RH, contaminants and washdowns. The unit is designed to withstand 100% saturation.

The sensor incorporates a bulk polymer resistance element. The polymer is impervious to most contaminants and, since it is a bulk resistance device, surface contamination such as dust will not alter the accuracy of the readings.

The unit is provided with continuous temperature compensation which adjusts for temperature-induced change in the RH sensor output. The compensation provides high accuracy over the entire operating range of the instrument. Features:

- Waterproof Sensing Element and Housing
- Compact Transmitter with Built-In Sensor
- Bulk Polymer Resistance RH Sensor
- Resistant to Contamination
- Thermistor Temperature Measurement
- Temperature Compensation

Specifications

Humidity

Sensing Element: Resistance change of bulk polymer sensor

Performance

Accuracy: at 25°C (75°F) ±2% RH. 30-95% RH including hysteresis, linearity and repeatability

Temperature Effect: Less than 0.11% per °C (0.06% per °F)

Sensitivity: 0.1% RH Repeatability: 0.5% RH Linearity: See Accuracy Hystereiss: Less than 1%

Operating Range:

Sensor and Electronics: 0% to 100% RH, -20 to 54°C (-4 to 129°F)

Max. Air Velocity: 10,000 ft/min

Output Ranges

4-20 mA current, 2-wire, loop-powered for 0-100% RH (standard) into 0-900 Ω

0-5 volt for 0-100% RH 0-10 volt for 0-100% RH

Adjustment

Zero: ±20%, non-interactive Span: ±10%, non-interactive

Long Term Stability: Less than 2% drift per year typical

Power

Supply Voltage: 12-36 Vdc Max. Lead: $\Omega = \frac{\text{Supply-}10 \text{ Vdc}}{\text{Max.}}$

Note: Minimum supply voltage of 15 Vdc is required for 10 volt output units.

Wiring Connections

HX98-1: Deutsch 4-position waterproof connector (for front wiring only)

HX98-2: Flying Leads (for back wiring)


Storage

Temperature: -65 to 70°C (-85 to 158°F)

Temperature

Sensor Element: Thermistor, 10K ohm at 25°C, 2-wire measurement

Accuracy: at 25°C (77°F) - ±0.3°C (±0.5°F)



* Dimensions are in inches



OMEGAnet® On-Line Service www.omega.com

Internet e-mail info@omega.com

Servicing North America:

USA: One Omega Drive, Box 4047

ISO 9001 Certified Stamford CT 06907-0047

Tel: (203) 359-1660

e-mail: info@omega.com

Canada: 976 Bergar

Laval (Quebec) H7L 5A1

Tel: (514) 856-6928

e-mail: info@omega.ca

Omega Drive, box 404/

FAX: (203) 359-7700

FAX: (514) 856-6886

For immediate technical or application assistance:

USA and Canada: Sales Service: 1-800-826-6342 / 1-800-TC-OMEGA®

Customer Service: 1-800-622-2378 / 1-800-622-BEST*
Engineering Service: 1-800-872-9436 / 1-800-USA-WHEN*
TELEX: 996404 EASYLINK: 62968934 CABLE: OMEGA

Mexico: Tel: (001) 800-826-6342

En Español: (001) 203-359-7803

FAX: (001) 203-359-7807

e-mail: espanol@omega.com info@omega.com.mx

Servicing Europe:

Benelux: Postbus 8034, 1180 LA Amstelveen, The Netherlands

Tel: +31 (0)20 6418405 FAX: +31 (0)20 6434643

Toll Free in Benelux: 0800 0993344

e-mail: nl@omega.com

Czech Republic: Rudé armády 1868, 733 01 Karviná 8

Tel: +420 (0)69 6311899 FAX: +420 (0)69 6311114
Toll Free: 0800-1-66342 e-mail: czech@omega.com

9, rue Denis Papin, 78190 Trappes

Tel: +33 (0)130 621 400 FAX: +33 (0)130 699 120

Toll Free in France: 0800-4-06342 e-mail: france@omega.com

Germany/Austria: Daimlerstrasse 26, D-75392 Deckenpfronn, Germany

Tel: +49 (0)7056 3017 FAX: +49 (0)7056 8540

Toll Free in Germany: 0800 TC-OMEGASM

e-mail: germany@omega.com

United Kingdom: One Omega Drive, River Bend Technology Centre

ISO 9002 Certified Northbank, Irlam, Manchester

M44 5EX United Kingdom

Tel: +44 (0)161 777 6611 FAX: +44 (0)161 777 6622

Toll Free in United Kingdom: 0800-488-488

e-mail: sales@omega.co.uk

It is the policy of OMEGA to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

France:

The information contained in this document is believed to be correct, but OMEGA Engineering, inc. accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

WARNING: These products are not designed for use in, and should not be used for, patient-connected applications.



WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of 13 months from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal one (1) year product warranty to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components which wear are not warranted, including but not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by it will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESS OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

RETURN REQUESTS / INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR <u>WARRANTY</u> RETURNS, please have the following information available BEFORE contacting OMEGA:

- Purchase Order number under which the product was PURCHASED,
- Model and serial number of the product under warranty, and
- Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

- 1. Purchase Order number to cover the COST of the repair,
- 2. Model and serial number of the product, and
- Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 1999 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.