



# OMEGABOND® OB-TL THINNING LIQUID



INSTRUCTION  
SHEET

M1243-0913

Shop online at: [www.omega.com](http://www.omega.com) e-mail: [info@omega.com](mailto:info@omega.com)  
For latest product manuals: [www.omegamanual.info](http://www.omegamanual.info)

## GENERAL DESCRIPTION

The OMEGABOND® OB-TL Thinning Liquid is a soluble sodium silicate solution used to dampen porous substrates before application of mixed OMEGABOND 300, 400, 600 or 700 cements. Thinning Liquid has many exceptional characteristics including:

- Quick-drying
- Odorless
- Fire-resistant
- Adhesive
- Conducts heat
- Oil-resistant
- High resistance to acids (except hydrofluoric)
- Seals porous surfaces
- Nonflammable

OMEGABOND® Thinning Liquid is subject to freezing. If frozen, the material cannot be restored and should not be used. Avoid storing OMEGABOND® Thinning Liquid in areas exposed to freezing temperatures.

## SHELF LIFE

OMEGABOND® Thinning Liquid has a shelf life of (6) months when stored in unopened, tightly sealed containers in a dry location at 70°F.

## DIRECTIONS FOR USE

OMEGABOND® Thinning Liquid may be applied by brushing, spraying or dipping.

## HANDLING INFORMATION

### CAUTION

- Avoid prolonged breathing of vapors - work in well-ventilated area
- Protect skin against contamination
- Protect eyes against contamination
- Do not take internally

OMEGABOND® Thinning Liquid is an alkaline material and may irritate eyes and skin. Avoid contact with eyes or skin by wearing gloves and goggles or a face shield. Wash thoroughly with soap and water after handling and before eating and smoking. Keep containers closed.

## NOTE

The Material Safety Data Sheet (MSDS) for the OMEGA® OB-TL is available at [omega.com](http://omega.com).

## NOTES



omega.com info@omega.com

### Servicing North America:

**U.S.A.:** Omega Engineering, Inc., One Omega Drive, P.O. Box 4047, Stamford, CT 06907-0047 U.S.A.  
Toll-Free: 1-800-826-6342 (USA & Canada only)  
Customer Service: 1-800-622-2378 (USA & Canada only)  
Engineering Service: 1-800-872-9436 (USA & Canada only)  
Tel: (203) 359-1660 Fax: (203) 359-7700  
e-mail: info@omega.com

**Canada:** Toll-Free: 1-800-826-6342 (USA & Canada only)  
Tel: (514) 856-6928 Fax: (514) 856-6886  
e-mail: generalinfo@omega.ca  
Web: www.omega.ca

### Servicing Mexico and Latin America:

**Mexico/  
Latin America:** Tel: 001-800-099-0420 (Mexico only)  
Tel: 001-203-359-7577 (Outside Mexico)  
Fax: 001-203-968-7290  
e-mail: ventas@mx.omega.com  
Web: mx.omega.com

### Servicing Asia:

**China:** Hotline: (+86) 800 819 0559, (+86)400 819 0559  
e-mail: info@cn.omega.com Web: cn.omega.com

**France:** Freephone: 0805 541 038 (France only)  
Tel: 01 57 32 48 17 Fax: 01 57 32 48 18  
e-mail: esales@omega.fr Web: www.omega.fr

**Germany/Austria:** Freephone: 0800 826 6342 (Germany only)  
Tel: +49 (0)7056-9398-0 Fax: +49 (0)7056-9398-29  
e-mail: info@omega.de Web: www.omega.de

**Italy:** Freephone: 800 906 907 (Italy only)  
Tel: +39 022 333 1521 Fax: +39 022 333 1522  
e-mail: commerciale@it.omega.com  
Web: it.omega.com

**Netherlands:  
Benelux** Freephone: 0800 099 3344 (Netherlands only)  
Tel: +31 070 770 3815 Fax: +31 070 770 3816  
e-mail: esales@omega.nl Web: www.omega.nl

**Spain:** Freephone: 800 900 532 (Spain only)  
Tel: +34 911 776 121 Fax: +34 911 776 122  
e-mail: ventas@es.omega.com  
Web: es.omega.com

**United Kingdom:** Freephone: 0800 488 488 (United Kingdom only)  
Tel: +44 (0)161 777 6611 Fax: +44 (0)161 777 6622  
e-mail: sales@omega.co.uk Web: www.omega.co.uk



## WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **13 months** from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal **one (1) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components in which wear is not warranted, include but are not limited to contact points, fuses, and triacs.

**OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by the company will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.**

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

## RETURN REQUESTS / INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of the product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering. OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 2013 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.