

User's Guide



<http://www.omega.com>
e-mail: info@omega.com

CL550
Portable Temperature Calibrator



OMEGAnetSM On-Line Service http://www.omega.com	Internet e-mail info@omega.com
---	--

Servicing North America:

USA: One Omega Drive, Box 4047
ISO 9001 Certified Stamford, CT 06907-0047
Tel: (203) 359-1660 FAX: (203) 359-7700
e-mail: info@omega.com

Canada: 976 Bergar
Laval (Quebec) H7L 5A1
Tel: (514) 856-6928 FAX: (514) 856-6886
e-mail: info@omega.ca

For immediate technical or application assistance:

Usa and Canada: Sales Service: 1-800-826-6342 / 1-800-TC-OMEGASM
Customer Service: 1-800-622-2378 / 1-800-622-BESTSM
Engineering Service: 1-800-872-9436 / 1-800-USA-WHENSM
TELEX: 996404 EASYLINK: 62968934 CABLE: OMEGA

Mexico and Latin America: Tel: (95) 800-826-6342 FAX: (95) 203-359-7807
En Español: (95) 203-359-7803
e-mail: espanol@omega.com

Servicing Europe:

Benelux: Postbus 8034, 1180 LA Amstelveen, The Netherlands
Tel: (31) 20 6418405 FAX: (31) 20 6434643
Toll Free in Benelux: 0800 0993344
e-mail: nl@omega.com

Czech Republic: ul. Rude armady 1868, 733 01 Karvina-Hranice, Czech Republic
Tel: 420 (69) 6311899 FAX: 420 (69) 6311114
Toll free: 0800-1-66342
e-mail: czech@omega.com

France: 9, rue Denis Papin, 78190 Trappes
Tel: (33) 130-621-400 FAX: (33) 130-699-120
Toll Free in France: 0800-4-06342
e-mail: france@omega.com

Germany/Austria: Daimlerstrasse 26, D-75392 Deckenpfronn, Germany
Tel: 49 (07056) 3017 FAX: 49 (07056) 8540
Toll Free in Germany: 0130 11 21 66
e-mail: info@omega.de

United Kingdom: One Omega Drive, River Bend Technology Centre
ISO 9002 Certified Northbank, Irlam, Manchester
M44 5EX, England
Tel: 44 (161) 777-6611 FAX: 44 (161) 777-6622
Toll Free in United Kingdom: 0800-488-488
e-mail: info@omega.co.uk

It is the policy of OMEGA to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be corrected but OMEGA Engineering Inc. accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

WARNING: These products are not designed for use in, and should not be used for, patient connected applications.

INTRODUCTORY NOTE

ATTENTION : THIS MANUAL MUST BE REFERRED TO INSTRUMENTS WITH SERIAL N. 006880 ONWARDS.

*This publication contains operating instructions, as well as a description of the principles of operation, of the **CL550** portable temperature calibrator. The information covers all models of the instrument, including the basic equipment and its options and accessories.*

The instructions reported in this manual, for the above mentioned equipment, are those relevant to:

- *Start-up preparation*
- *Operation description*
- *Start-up instructions*
- *Shut-down instructions*
- *Typical faults and their remedies*

OMEGA has used the best care and efforts in preparing this book and believes the information in this publication are accurate. The **OMEGA** Products are subjected to continuous improvement, in order to pursue the technological leadership; these improvements could require changes to the information of this book. **OMEGA** reserves the right to change such information without notice.

OMEGA makes no warranty of any kind, expressed or implied, with regard to the documentation contained in this book. **OMEGA** shall not be liable in any event - technical and publishing error or omissions - for any incidental and consequential damages, in connection with, or arising out of the use of this book.

*The instrument uses sophisticated analog and digital technologies. Repair and service require highly qualified personnel. **OMEGA Engineering, inc** will supply, on request, all pertinent instructions and procedures for service and calibration. **OMEGA Engineering, inc** specialists will be glad to give any technical support you may require.*

*No part of this document may be stored in a retrieval system, or transmitted in any form, electronic or mechanical, without prior written permission of **OMEGA**.*

TABLE OF CONTENTS

1	GENERAL PERFORMANCE	5
1.1	Specifications	6
2	GENERAL FEATURES	7
2.1	Temperature stability	7
2.2	Application flexibility	7
2.3	Internal digital indicator	7
2.4	External digital indicator	7
2.5	Digital interface	7
3	PHYSICAL DESCRIPTION	8
4	FUNCTIONAL DESCRIPTION	9
5	PRE-OPERATIONAL CHECK.....	10
5.1	Unpacking	10
5.2	Preparation for the start-up	10
5.3	Wiring practice.....	10
5.4	Thermocouple wires	11
6	SAFETY RECOMMENDATIONS	12
7	OPERATION & APPLICATION.....	13
7.1	Calibration by comparison	13
7.1.1	Calibration with the internal Pt100 sensor	13
7.1.2	Calibration with an external standard Pt100 sensor	14
7.2	Power ON.....	15
7.2.1	Display resolution	15
7.2.2	High temperature option	16
7.2.3	Temperature switch test	16
7.3	Set-up procedure - 1st level	17
7.4	Set-up procedure - 2nd level	18
7.5	P.I.D. tuning	19
8	MAINTENANCE.....	20
8.1	Defects and faults.....	20
8.2	Spare parts.....	20
8.3	Storage.....	21
9	COMMUNICATION	22
9.1	Communication Protocol	22
9.2	Reading a variable	22
9.3	Setting a variable.....	23

1 GENERAL PERFORMANCE

A highly accurate and powerful system to test and calibrate temperature sensors built into a single compact instrument.

The temperature parameter represents the most important factor to fulfill quality, operational safety and reliability of industrial processes.

Thermocouples, resistance thermometers and any other temperature sensor, when installed in an industrial process, are subjected to mechanical, thermal and chemical stresses which accelerate their aging.

Therefore it is a recommended procedure to inspect, check and calibrate each sensor during the commissioning phase and at regular and programmed time intervals.

The temperature calibrator **OMEGA** series **CL550** is a transportable unit designed to obtain a controlled temperature with high stability, high uniformity in a range from ambient temperature within -30°C and $+125^{\circ}\text{C}$.

The internal metal block, designed with a self lock feature to avoid dangerous undesired block drop, is interchangeable and equipped with a six holes insert and with an immersion depth of 125 mm.

The portable temperature calibrator **CL550** is a multifunction instrument designed to meet the needs of instrumentation engineers, both in laboratory and in field work.

Accurate, compact, rugged, easy to use; the ideal solution to test and calibrate:

- thermocouples
- resistance thermometers
- thermostats
- gas filled thermometers
- mercury thermometers
- material thermal test

CL550 has been designed using the most advanced thermal and electronic technologies to provide high stability and accuracy with easy operations combined with a powerful operating flexibility.

1.1 Specifications

- **Range**
from -30 to +125 °C Std
from -20 to +150 °C with 150°C option
- **Stability:** ± 0.03 °C
- **Stabilizing time:** typical 6 min.
- **Radial uniformity:** ± 0.1 °C at 100 °C
- **Axial uniformity:** ± 0.2 °C at 80mm
- **Heating rate**
15 °C/min Std
20 °C/min with 150°C option
- **Cooling rate**
from 12 °C/min Std
from 15 °C/min with 150°C option
- **Switch test function:** with 12 Vdc power supply
- **Display:** Alphanumeric high contrast dot matrix LCD display 2 line of 16 characters backlight device
- **Display resolution:** 0.1 or 0.01 °C
- **Measuring accuracy:** ± 0.15 °C at 100°C
- **Real time clock:** with internal battery back up
- **A/D converter:** 15 bit resolution plus polarity
- **Display response time:** 10 readings a second
- **Digital interface:** RS232
- **Internal cryostat:** Peltier Cells
- **Internal metal block:** standard aluminium with n. 6 holes \varnothing 3.175 / 4.75 / 6.5 / 8 / 9.5 / 19 mm.
- **Electronic section:** in a separate metal shell
- **Internal temperature sensor:** Pt100 Class A sensor (control and indication)
- **External temperature sensor:** An auxiliary input connectors for Pt100 sensor is available on the back panel
- **Temperature control:** PID with optimized tuning constants
- **Heat/cool control:** full automatic switch-over
- **Protection grid:** removable
- **Mains line connection:** socket for mains line cable equipped with a protection fuse
- **Power supply:** 110 or 220 Vac (to be specified) 50/60 Hz
- **Power:** 300 VA
- **Chassis:** separate shell for thermal and electronic sections with carrying handle
- **Size:** 370 x 300 x 140mm
- **Weights:** Net 10 kg Gross 17 kg
- **Aluminium case dimensions:** 410 x 350 x 250 mm
- **Packing dimensions:** 450 x 450 x 350 mm

ATTENTION :

THE MINIMUM RELEVANT TEMPERATURE IS RELATED TO AMBIENT TEMPERATURE.

2 GENERAL FEATURES

2.1 Temperature stability

The internal microcontroller system handles, through the keyboard, the man-machine communications, the internal logic and grants a stability of the internal thermal equalizing metal block of ± 0.05 °C.

The temperature control uses a sophisticated PID algorithm with memory stored optimized tuning constants.

For special tests the operator could, through a security code, load different tuning constants.

2.2 Application flexibility

The operative set-up mode is made simple and easy with a sequence of menu pages that only requires <F> (Function), <E> (Enter), <▲> (Increase) and <▼> (Decrease) instructions.

The panel lamp and keys have the following features:

"HEATING"	LED	indicates power applied to the oven
"COOLING"	LED	indicates cooling action through the modulated fan
"SWITCH TEST"	LED	indicates thermostat switch-over
<F>		key for function selection
<▲> and <▼>		parameter adjustment
<E>		Enter key for new instruction acknowledgement

The instrument will also provide some acoustic signals as it follows:

single "beep"	operator instruction acknowledgment when the <E> key is pressed
multiple "beep" (five times)	the temperature is stabilized on the set-point value and the instrument is ready for sensor calibration.

2.3 Internal digital indicator

The internal digital indicator is a dot matrix LCD display with 2 lines of 16 characters equipped with a backlight device for easy reading also in poor light condition.

The operator could select the required operative function, the set-point value and read the temperature value of the internal thermal equalizing block.

The temperature is obtained with a class A Pt100 resistance thermometer Pt100. The measurement accuracy is ± 0.15 °C at 100°C using the internal Pt100 sensor.

The overall limit of error can be improved using an external high accuracy calibrated resistance thermometer that can be supplied on request.

2.4 External digital indicator

When an high accuracy is required, the portable temperature calibrator **CL550** can be used in combination with a high accuracy indicator and an external high accuracy calibrated resistance thermometer (ask for the pertinent literature).

2.5 Digital interface

The calibrator is standard equipped with a full bi-directional RS232 digital interface for any communication with a Personal Computer.

The Portable Temperature Calibrator can be part of an automatic calibration system with a programmable cycle and the acquisition of all data required to generate a full calibration report.

OMEGA engineers are ready to support you with components, accessories and software that fulfil your application requirements.

3 PHYSICAL DESCRIPTION

The **CL550** portable temperature calibrator consists of two modules mechanically and electrically interconnected.


The module on the left incorporates the cryostat, the thermal equalizing metal block, the Peltier cells and a modulated air blower.

The module on the right present the alphanumeric dot matrix LCD display with a backlight device, a microcontroller mother board with all base functions, an operator keyboard, a power package.

The portable temperature calibrator is supplied in an aluminum case with cover and carrying handle to assure easy transportation and better protection of the instrument against mechanical knocks or scratches.

4 FUNCTIONAL DESCRIPTION

The **CL550** portable temperature calibrator functional block diagram is shown below.



The instrument functional blocks of the instrument are as it follows:

- power supply
- microcontroller (central unit + memory)
- A/D converter
- power driver
- keyboard
- switch test
- digital interface
- digital display
- Peltier cells

5 PRE-OPERATIONAL CHECK

5.1 Unpacking

Remove the instrument from its packing case and remove any shipping ties, clamps, or packing materials.

Carefully follow any instructions given on any attached tags.

Inspect the instrument from scratches, dents, damages to case corners etc. which may have occurred during shipment. If any mechanical damage is noted, report the damage to the shipping carrier and then notify **OMEGA** directly or its nearest agent, and retain the damaged packaging for inspection.

A label, on the back of the instrument case, indicates the serial number of the instrument.

Refer to this number for any inquiry for service, spare parts supply or application and technical support requirements.

OMEGA keeps updated a data base with all information regarding your instrument.

5.2 Preparation for the start-up

Remove the calibrator from the carrying case and place it on a flat surface.

Connect the instrument to a mains supply with the nominal voltage specified on the back label (115 or 230 Vac).

Remember that the instrument requires a power of approximately 300 VA.

For safe operations the equipment must be correctly connected to the ground.

5.3 Wiring practice

Although most temperature indicators are designed to be insensitive to transient or noise, the following recommendations should be carried out to reduce pick up in the signal leads and to ensure a good general performance. The signal leads should not be run near ac line wiring, transformer and heating elements.

Connection leads should, if possible, be twisted and shielded with the shield grounded at the end of the cable.

When shielded cables are used the shield must be connected to the positive terminal.

Appropriate extension wires should be used for thermocouples unless the thermocouple leads permit direct connection.

Make sure that both thermocouple and compensating cable are connected with the correct polarity.

If in doubt, the polarity of the compensating leads can be checked by connecting a length of lead to the indicator, shortening the free ends of the wires together and noting that the indicator reading increases when the wires connection is heated.

Color codes of compensating cables change in different countries. Check the appropriate table (A).

For the Resistance Temperature Detector connection use cable of adequate gauge to lower the overall input resistance.

The use of a cable with a good resistance balance between conductors is also necessary.

Table A
Colour code & polarity for extension wires

	Thermocouple		Wires	Color code
E	Chromel	(+)	Chromel	Purple
	Constantan	(-)	Constantan	Red
J	Iron	(+)	Iron	White
	Constantan	(-)	Constantan	Red
K	Chromel	(+)	Chromel	Yellow
	Alumel	(-)	Alumel	Red
R	Pt 13% Rh	(+)	Copper	Black
	Platinum	(-)	Alloy 11	Red
S	Pt 10% Rh	(+)	Copper	Black
	Platinum	(-)	Alloy 11	Red
T	Copper	(+)	Copper	Blue
	Constantan	(-)	Constantan	Red
B	Pt 6% Rh	(+)	Copper	
	Pt 30% Rh	(-)	Copper	
N	Nicrosil	(+)	Nicrosil	Orange
	Nisil	(-)	Nisil	Red

5.4 Thermocouple wires

When making measurements where additional wires have to be connected to the thermocouple leads, care must be exercised in selecting these wire types, not only when they are claimed to be of the same composition as the thermocouple involved, but, also, of the same "quality".

Performance results where high precision is required and in circumstances where some types of thermocouple wire leads are added to the original installation should be reviewed carefully for the impact of the choice of the additional wire leads. The quality of the thermocouple wire is established by the limit of error to be expected with its use.

There are three recognized levels of quality:

- Special or Premium grade
- Standard grade
- Extension wire grade

The error limits determining the grade of the quality differ from thermocouple type to thermocouple type, reflecting the degree of difficulty in maintaining the precise levels of purity of the metal used.

The table below summarizes the error limits for Premium and Standard grades, while the Extension grade wire is characterized by limits of error exceeding those in the table.

Errors up to $\pm 4^{\circ}\text{C}$ may be experienced when using the Extension grade thermocouple wire for J and K thermocouples.

Limit of Error of the thermocouple

The range indicated is the temperature limit for the indicated errors. Cold junction at 0°C .

Tc	Class 1	Class 2	Class 3
type T	0.5°C (-40 to +125°C) 0.004 . T (T >125°C)	1°C (-40 to 133°C) 0.0075 . T (T >133 °C)	1°C (-67 to 40°C) 0.015. T (T <-67°C)
T range	-40 to +350°C	-40 to +350°C	-200 to 40°C
type E	1.5°C (-40 to 375°C) 0.004.T (T >375°C)	2.5°C (-40 to 333 °C) 0.0075.T (T >333°C)	2.5°C (-167 to +40°C) 0.015.T (T <-167°C)
T range	-40 to 800°C	-40 to 900°C	-200°C to 40°C
type J	1.5°C (-40 to 375°C) 0.004.T (T >375°C)	2.5°C (-40 to 333 °C) 0.0075.T (T >333°C)	2.5°C (-167 to +40°C) 0.015.T (T <-167°C)
T range	-40 to 750°C	-40 to 750°C	----
type K & N	1.5°C (-40 to 375°C) 0.004.T (T >375°C)	2.5°C (-40 to 333 °C) 0.0075.T (T >333°C)	2.5°C (-167 to +40°C) 0.015.T (T <-167°C)
T range	-40 to 1000°C	-40 to 1200°C	-200°C to 40°C
type R & S	1°C (0 to 1100°C) 1 + 0.003 (T-100) (T >1100°C)	1.5°C (-40 to 600 °C) 0.0075.T (T >600°C)	4°C (600 to +800°C) 0.005.T (T>800°C)
T range	0 to 1600°C	0 to 1600°C	----
type B	1°C (0 to 1100°C) 1 + 0.003 (T-100) (T >1100°C)	1.5°C (-40 to 600 °C) 0.0075.T (T >600°C)	4°C (600 to +800°C) 0.005.T (T>800°C)
T range	-----	600 to 1700°C	600 to 1700°C

NOTE : Specially selected "premium grade" wire are available on request

6 SAFETY RECOMMENDATIONS

Since the **CL550** temperature calibrator is a transportable instrument designed also for a field use, make sure that the mains line socket is correctly grounded.

During maintenance and repair operations make sure that the equipment has cooled down and has been disconnected from the mains line supply.

During long term tests at high temperatures the upper protection grill may become hot; handle the oven to avoid thermal hazards and make sure that it has cooled down before putting it into its case.

Do not fill the thermal equalizer block holes with any type of fluid.

Do not insert the sensor to be tested in the oven at a high temperature.

Do not use the temperature calibrator near flammable compounds.

ATTENTION

THE EQUIPMENT HAS BEEN DESIGNED TO PROTECT THE OPERATOR FROM ELECTRICAL AND HIGH TEMPERATURE HAZARDS.

HOWEVER, THE FOLLOWING CAUTIONS SHOULD BE TAKEN:

WEAR PROTECTIVE GLOVES.

DO NOT PLACE ANY COMPONENT ON THE TOP OF THE OVEN.

DO NOT OPERATE THE UNIT CLOSE TO FLAMMABLE COMPOUNDS.


7 OPERATION & APPLICATION

7.1 Calibration by comparison

To verify or calibrate a temperature sensor by comparison with the internal or the external Pt100 standard follow the procedure indicated below.

For correct operations strictly follow these recommendations:

- Measure the outside diameter of the sensor to be tested.
- Insert the sensor to be tested in one hole of the thermal equalizing block.
- For a correct calibration the outside diameter of the sensor under test should be approximately 0.3 mm less than the inside diameter of the hole;
- If required use the appropriate well adapter (see the figure below).
- Do not force the sensor to be tested into the thermal equalizing block (see the figure below).



ATTENTION

**DO NOT INSERT THE SENSOR UNDER TEST IN THE THERMAL EQUALIZING BLOCK WHEN THE OVEN IS AT A HIGH TEMPERATURE.
THERMAL SHOCK COULD DAMAGE THE SENSING ELEMENT OF THE PROBE.**

AT THE END OF THE TEST DO NOT REMOVE IMMEDIATELY THE PROBE/S FROM THE THERMAL EQUALIZING BLOCK.

WAIT FIRST FOR THE TEMPERATURE CALIBRATOR TO COOL.

AT THE END OF THE OPERATION.

WAIT FOR THE THERMAL EQUALIZING BLOCK TO BE COMPLETELY COOLED BEFORE PLACING THE CALIBRATOR INTO THE CARRYING CASE.


7.1.1 Calibration with the internal Pt100 sensor

- Start the calibration only at ambient temperature.
- Insert the sensor under test in to the correct hole with the sensing element into the recommended calibration zone as indicated in the following figure.
- The errors of temperature, due to the differences in depths, remain within $\pm 0.3^{\circ}\text{C}$.

Note: Do not insert the sensor to be tested inside the hot block. Thermal shock can break the element.


- Switch the instrument on with the main switch on the rear panel.
- With <▲> key increase the set-point values.
- With <▼> key decrease the set-point values.

- To confirm values, press the <E> key.
- Verify the reading temperature on the display with the values reported on the Certificate of Conformity and make the related modifications.
- Calibrate the value read on the sensor under test to the correct value on the indicator.
- The check can be made with several temperature values. In order to follow our instructions just set up the set-point to the relevant temperature value and wait for stabilization.




7.1.2 Calibration with an external standard Pt100 sensor

- Start the calibration procedure only at ambient temperature.
- Insert both the sensor under test and the external standard Pt100 in the relevant holes of the thermal equalizing block and keep the sensing elements of the probes at the same depth as indicated in the figure below.
- The errors of temperature, due to the differences in depths, remain within ± 0.2 °C.
- Switch -ON- the instrument
- Verify the reading temperature from the standard reference with the values reported on the Certificate of Conformity and make related variations.
- Calibrate the value read on the sensor under test to the correct value reported on official Certificate of Conformity.
- The check can be made for several temperature values. In order to follow our instructions just set up the set-point to the relevant temperature value and wait for stabilization.



- The external standard Pt100 must be connected to the back panel connector using the component supplied as a standard accessory.
- The new configuration must be selected through the set-up procedure.



7.2 Power ON

- To power the instrument press the back panel switch **-ON-**. The indication of the following running figure will appear for few seconds where a diagnostic routine checks critical circuits and components.

CL550

- Once the diagnostic routine is ended, the heater is forced to continuous cooling by means of a ventilation fan at its maximum speed. A green Led is lit on until the the set-point is confirmed or a new set-point value is entered. The display shows the current heater temperature and the last set-point value entered.

T : 23.5 °C
SP : 50.0

- In the example above, the display shows a blinking message (**SP: 50.0**) until the operator validates the value of **50.0** as relevant set-point by pressing the **<E>** key. Using the **<▲>** / **<▼>** keys a new set-point value can be selected to become the relevant set-point value, when the operator validates it by pressing the **<E>** key. An acoustic beep, together with a temporary indication (■) right on the screen, will indicate that the value has been correctly stored in memory.

7.2.1 Display resolution

The **CL550** provides two resolutions of the display: 0.1 °C and 0.01 °C.

- To select the correct resolution press several times the **<F>** key until you obtain the following display:

T : 23.5 °C
Res.: 0.1

- Press **<▲>** key to have 0.01 °C resolution.

T : 23.56 °C
Res.: 0.01

- Press the **<F>** key to return to the normal operative conditions. The indication will return to the following indication:

T : 23.56 °C
SP : 50.0

Note : If no further indication is supplied by the operator, the instrument automatically resumes the initial conditions.

7.2.2 High temperature option

If High temperature option is included in **CL550**, the calibrator can operate at temperature up to 150°C. The operation procedure up to 130°C are the same of the standard version. To set higher temperature, it is necessary operate on the switch on the rear of the calibrator. This operation switch the fan off. To reduce the temperature, set the new set-point and switch the fan on.

7.2.3 Temperature switch test

CL550 is designed for the set-point control of thermostats. For this purpose, two terminals for the electrical connection to the thermostat under test are installed on the rear part of the instrument, while on the front side of it, a red LED indicates:

- close contact **<ON>** (light on)
- open contact **<OFF>** (light off)

The thermostats test is carried out varying constantly the heater temperature. In order to accomplish this procedure, use SP-2 and Ramp functions, verify the right switching of the thermostat contact on the Test LED and contemporaneously check the temperature value on the display.

The difference between the set value supplied and the temperature, high light the **Dt** of the thermostat.

To verify the right functioning of the thermostat proceed as it follows:

- Insert the sensing elements of the thermostat into the relevant hole of the thermal equalizing block.
- Electrically connect the output connecting the terminals of the thermostat with the two terminals located on the upper part of the instrument.
- Regulate the set-point of the thermostat to the test value (e.g.: 100 °C - see diagram).
- Energize the **CL550**.
- Wait for the control routine to be done and regulate the SP to 95° C using the **<▲>** key.
Press the **<E>** key to confirm the value.
Within a few seconds the heater temperature will settle to 95°C.
When the temperature is settled, press the **<F>** key. The display will show:

```
T : 95.0 °C
SP-2: 40.0 °C
```

- Press the **<▲>** key to set the SP-2: value to 105.0:

```
T : 95.0 °C
SP-2: 105.0 °C
```

- Press the **<E>** key to confirm.
- Then press the **<F>** key until you obtain:

```
T : 95.0 °C
grad: 0.4 °C/m
```

- Press the **<▲>** or **<▼>** key to determine a speed variation of the heater set-point temperature similar to the acknowledgement time of the thermostat (e.g.: 1 ° / min.):

```
T : 95.0 °C
grad: 1.0 °C/m
```

- Press the **<E>** key to confirm.
- Press the **<F>** key to obtain:

```
T : 95.0 °C
ramp: OFF
```

- Press **<▲>** to obtain:

```
T : 95.0 °C
ramp: ON
```


- Press the <E> key to confirm.

From now on the heater temperature will vary from 95.0 to 105.0 °C with increments of 1 °C per minute.

- Press the <F> key five times

```
T : 95.0 °C
SW/ON : 94.8
```

```
T : 95.0 °C
SW/OFF : 23.5
```

7.3 Set-up procedure - 1st level

The 1st level set-up procedure allows the operator to modify , if required, the configuration of the following parameters:

- the tuning constant of the PID algorithm
- internal/externalPt100 reference sensor
- cooling rate
- °C/°F selection
- default parameters
- security code (n. 2 as standard)

- To enter this procedure start from the normal operating function and from the following indication:

```
T : 23.5 °C
SP : 50.0
```

- press simultaneously the <▲> + <F> keys to enter the 1st level set-up procedure and to obtain the following indication relevant to the Proportional Band constant:

```
T : 23.5 °C
P.B. : 1.6 %
```

- The PID constants are experimentally defined and memory loaded for tuning optimization. The operator can eventually change the value for special application only. It is recommended for routine application to use the "default" stored values. To adjust a new value use the <▲> and <▼> cursors and memory store with the <E> key.

- Press the <F> key to obtain the following indication relevant to the Integral constant:

```
T : 23.5 °C
Ti : 100 sec.
```

- Press the <F> key to obtain the following indication relevant to the Derivative constant:

```
T : 23.5 °C
Td : 10 sec.
```

- Press the <F> key to select the Internal or External reference resistance thermometer (Pt100):

```
T : 23.5 °C
Pt100: INT.
```

```
T : 23.5 °C
Pt100: EXT.
```

- Press the <F> key to select the required temperature unit:

```
T : 23.5 °C
units °C
```

```
T : 23.5 °C
units °F
```

- Press the <F> key to enable or disable the Default parameter:

```
T : 23.5 °C
Def.Par.: OFF
```

```
T : 23.5 °C
Def.Par.: ON
```

- Press the <F> key to select access key number for the 2nd level set-up procedure:

```
T : 23.5 °C
Key : 0
```

- To enter the 2nd level set-up procedure adjust the key number to n. 2
- Press the <F> key to return to the normal operative condition with the following indication:

```
T : 23.5 °C
SP : 50.0
```

7.4 Set-up procedure - 2nd level

The 2nd level set-up procedure allows the operator to modify , if required, the configuration of the following parameters:

- security or access code
- baud rate
- address code
- serial number

- The 2nd level set-up procedure starts from the following indication at the end of the 1st level set-up procedure.

```
T : 23.5 °C
Key : 0
```

- To enter this procedure select the access key n. 2 as it follows:

```
T : 23.5 °C
Key : 2
```

then press simultaneously the <F> + <▲> keys to obtain the following indication:

```
T : 23.5 °C
Access key : 2
```

- The operator can, if required, change the access key number to be memory stored with the <E> key. The new number must be remembered for following operations.
- Press the <F> key to enter the Baud rate adjustment step with the following indication:

```
T : 23.5 °C
Baud rate: 9600
```

The Baud Rate can be adjusted for your required value among 19200, 9600, 4800, 2400, 1200, 600, 300.

- Press the <F> key to enter the machine code selection:

```
T : 23.5 °C
Address : 1
```

The machine code can be adjusted from 1 to 99.

- Press the <F> key to select the page indicating the serial number of the instrument:

```
T : 23.5 °C
S/N: B363594
```

- Press the <F> key to review the type of sensor selected:

```
T : 23.5 °C
PTCh selected
```

- Press the <F> key to set the max. temperature limit:

```
T : 23.5 °C
MAX. set 550.0
```

- Press simultaneously the <▲> + <F> keys to exit the procedure and to return to the normal operative mode with the following indication:

```
T : 23.5 °C
SP : 50.0
```

7.5 P.I.D. tuning

The P.I.D. tuning parameters have been settled at works and they are stored as "Default Parameters".

The normal values are the following ones:

Prop. band	10%
Integral Time	240 s
Derivative Time	2 s

Please note that on instruments with serial number up to 0009476 the above default parameters were respectively 4% - 60 s - 3 s.

In case it should be necessary to change that parameter for special applications proceed as it is shown at paragraph 7.3.

8 MAINTENANCE

The **CL550** portable temperature calibrator has been factory tested and calibrated before shipment.

The calibration should be verified and re-adjusted if the instrument shows an error exceeding the declared specifications or when a critical active or passive component has been replaced (either at the component level or at the board level).

OMEGA will supply, on request, a technical reference manual, with all instructions and recommendations for service and calibration.


OMEGA engineers will give prompt support for any assistance request.

8.1 Defects and faults

N°	FAULT DESCRIPTION	FAULTY COMPONENT OR FUNCTION	METHOD FOR REMOVAL
1	The control panel is working normally but doesn't rise in temperature.	The heater element is cut off. The triac is cut off.	Replace the heater element or the triac after checking if they are damaged.
2	On pushing the main switch the fuse blows	Short circuit on the heater element or on another part of the circuit.	Replace (after check) the heater element or the part of the circuit which has been damaged.
3	The temperature doesn't stop at the set point value.	Short circuit on the triac.	Replace the triac.
4	The set point value isn't the engaged value, or the temperature shown on the display is different from the actual temperature of the block.	The internal Pt100 or the Microcontroller is damaged.	Check and replace the damaged part.
5	The temperature doesn't fall to the right temperature.	The fan is damaged; The connection is cut off. The fan triac is cut off.	Check if there is tension at the fan ; if the circuit is active replace the fan. Otherwise, replace the fan triac.
6	The display shows -760°C and the calibrator doesn't heat.	The Pt100 is open Short circuit on the internal Pt100.	Replace the Pt100.
7	The display shows 3 lines and the calibrator doesn't heat.	Short circuit on the Pt100.	Replace the Pt100.
8	On connecting the electrical cable and pushing the main switch the calibrator doesn't work.	The fuse blows. The electrical cable is cut off. The main switch is damaged.	Check and replace the damaged part.

8.2 Spare parts

POS.	DESCRIPTION
1	Socket
3	Fuse
4	Switch Test Plug
5	Fan
5.1	Fan
6	Equalizing Block
10	MicroController
11	Controller driver
12	Pt100 internal sensor
13	Peltier cells
14	Well
15	Tweezers



8.3 Storage

Store the instrument in the original package, at a temperature from -30°C to +60°C, with R.H. less than 90%.

9 COMMUNICATION

9.1 Communication Protocol

CL550 is equipped with a RS232 bi-directional , half-duplex interface as standard.

Baud rate is set at 9600 baud as default. You can modify it through keyboard selecting following rate : 300, 600, 1200, 2400, 4800, 9600 and 19200 baud. Transmission parameters are 8 bit length, no parity and 1 bit stop. Address can be modified through keyboard and it is set 1 as default. RS232 interface connector is a 9 pin DB9 male connector.

Cable connection to a standard personal computer as follows :

9 pin CL550 9 pin PC connector 25 pin PC connector

2 -----> 3 -----> 2
3 -----> 2 -----> 3
5 -----> 5 -----> 7

Communication protocol is based on Answer to Request system.
CL550 will answer only if you sent a Request to it.

There are two kind of request :

RVAR to read a variable.

WVAR to set a variable.

9.2 Reading a variable

The instruction to read a variable has to be an ASCII code composed as follows :

\$ character

Instrument Address

RVAR request string

Variable Index

Blank space

Carriage Return

For example, if the set point has to be read (Variable index = 0), supposing the instrument address to be 1:
\$1RVAR0 \r

ASCII code	\$	1	R	V	A	R	0		\r
HEX \$ code	24	31	52	56	41	52	30	20	0D

The answer of the CL550 will be as follows:

* character

Carriage return

* character

Instrument Address

Answer string

Carriage Return

For example if set point is 50.5 °C , supposing the instrument address to be 1:

ASCII code	*	\r	*	1		S	P			:		0	0	5	0	.	5	\r
HEX \$ code	2A	0D	2A	31	20	53	50	20	20	3A	20	30	30	35	30	2E	33	0D

List of Variable Index available

Variable	Index
Actual Setpoint	0
Ramp : ON /OFF	1
Second Setpoint	2
Ramp gradient	3
Resolution : 0.01° / 0.1°	4

Proportional band	5
Integral time	6
Derivative time	7
Pt100 : Internal / External	8
Engineering unit °C / °F	10
Default Parameters : ON/OFF	11
Key	12
Access Key	13
Baud Rate	14
Address	15
Switch ON value	22
Switch OFF value	23
Memory release	24
Actual temperature	100

9.3 Setting a variable

The instruction to write a variable has to be an ASCII code composed as follows :

\$ character
Instrument Address
WVAR request string
Variable Index
Blank space
Value to be written
Carriage Return

For example, if the set point has to be set (Variable index = 0) to 123 °C , supposing the instrument address to be 1:
\$1WVAR0 123\r

ASCII code	\$	1	W	V	A	R	0		1	2	3	\r
HEX \$ code	24	31	57	56	41	52	30	20	31	32	33	0D

The answer of the CL550 will be as follows :

* character
Carriage return
* character
Instrument Address
Answer string
Carriage Return

ASCII code	*	\r	W	V	A	R	0		1	2	3	\r
HEX \$ code	2A	0D	57	56	41	52	30	20	31	32	33	0D

For example, if the resolution has to be changed to 0.01° (Variable index = 4) , supposing the instrument address to be 1:
\$1WVAR4 1\r

ASCII code	\$	1	W	V	A	R	4		1	\r
HEX \$ code	24	31	57	56	41	52	34	20	31	0D

The answer of the **CL550** will be as follows :

* character
Carriage return
* character
Instrument Address
Answer string
Carriage Return

ASCII code	*	\r	W	V	A	R	4		1	\r
HEX \$ code	2A	0D	57	56	41	52	34	20	31	0D

List of Variable Index available

Variable	Index	Correct Value
Actual Setpoint	0	decimal value
Ramp : ON /OFF	1	1 for ON, 0 for OFF
Second Setpoint	2	decimal value
Ramp gradient	3	decimal value
Resolution : 0.01° / 0.1°	4	1 for 0.01°, 0 for 0.1°
Proportional band	5	decimal value
Integral time	6	decimal value
Derivative time	7	decimal value
Pt100 : Internal / External	8	1 for Internal, 0 for External
Engineering unit °C / °F	10	1 for °F, 0 for °C
Default Parameters : ON/OFF	11	1 for OFF, 0 for ON
Key	12	decimal value
Access Key	13	decimal value
Baud Rate	14	decimal value
Address	15	decimal value

WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **13 months** from date of purchase. OMEGA Warranty adds an additional one (1) month grace period to the normal **one (1) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit should malfunction, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of being damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components which wear are not warranted, including but not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by it will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

RETURN REQUESTS / INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting OMEGA:

1. P.O. number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. P.O. number to cover the COST of the repair,
2. Model and serial number of product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

(C) Copyright 1999 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without prior written consent of OMEGA ENGINEERING, INC.

Where Do I Find Everything I Need for Process Measurement and Control? **OMEGA...Of Course!**

TEMPERATURE

- ☒ Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- ☒ Wire: Thermocouple, RTD & Thermistor
- ☒ Calibrators & Ice Point References
- ☒ Recorders, Controllers & Process Monitors
- ☒ Infrared Pyrometers

PRESSURE, STRAIN AND FORCE

- ☒ Transducers & Strain Gauges
- ☒ Load Cells & Pressure Gauges
- ☒ Displacement Transducers
- ☒ Instrumentation & Accessories

FLOW/LEVEL

- ☒ Rotameters, Gas Mass Flowmeters & Flow Computers
- ☒ Air Velocity Indicators
- ☒ Turbine/Paddlewheel Systems
- ☒ Totalizers & Batch Controllers

pH/CONDUCTIVITY

- ☒ pH Electrodes, Testers & Accessories
- ☒ Benchtop/Laboratory Meters
- ☒ Controllers, Calibrators, Simulators & Pumps
- ☒ Industrial pH & Conductivity Equipment

DATA ACQUISITION

- ☒ Data Acquisition & Engineering Software
- ☒ Communications-Based Acquisition Systems
- ☒ Plug-in Cards for Apple, IBM & Compatibles
- ☒ Datalogging Systems
- ☒ Recorders, Printers & Plotters

HEATERS

- ☒ Heating Cable
- ☒ Cartridge & Strip Heaters
- ☒ Immersion & Band Heaters
- ☒ Flexible Heaters
- ☒ Laboratory Heaters

ENVIRONMENTAL MONITORING AND CONTROL

- ☒ Metering & Control Instrumentation
- ☒ Refractometers
- ☒ Pumps & Tubing
- ☒ Air, Soil & Water Monitors
- ☒ Industrial Water & Wastewater Treatment
- ☒ pH, Conductivity & Dissolved Oxygen Instruments