


MADE
IN U.S.A.

1 YEAR
WARRANTY



User's Guide

Shop online at

omega.com[®]
Ω OMEGA[®]

omega.com

e-mail: info@omega.com

*For latest product manuals:
omegamanual.info*

ISO 9001
CERTIFIED
CORPORATE QUALITY

STAMFORD, CT

ISO 9001
CERTIFIED
CORPORATE QUALITY

MANCHESTER, UK



Series FDT-81 Portable Transit Time Ultrasonic Flow Meter



OMEGAnet® Online Service
omega.com

Internet e-mail
info@omega.com

Servicing North America:

U.S.A.:
ISO 9001 Certified

One Omega Drive, P.O. Box 4047
Stamford, CT 06907-0047
TEL: (203) 359-1660
FAX: (203) 359-7700
e-mail: info@omega.com

Canada:

976 Bergar
Laval (Quebec) H7L 5A1, Canada
TEL: (514) 856-6928
FAX: (514) 856-6886
e-mail: info@omega.ca

For immediate technical or application assistance:

U.S.A. and Canada: Sales Service: 1-800-826-6342/1-800-TC-OMEGA®
Customer Service: 1-800-622-2378/1-800-622-BEST®
Engineering Service: 1-800-872-9436/1-800-USA-WHEN®

Mexico:

En Español: (001) 203-359-7803
e-mail: espanol@omega.com
FAX: (001) 203-359-7807
info@omega.com.mx

Servicing Europe:

Czech Republic:

Frystatska 184, 733 01 Karviná, Czech Republic
TEL: +420 (0)59 6311899
FAX: +420 (0)59 6311114
Toll Free: 0800-1-66342
e-mail: info@omegashop.cz

Germany/Austria:

Daimlerstrasse 26, D-75392 Deckenpfronn, Germany
TEL: +49 (0)7056 9398-0
FAX: +49 (0)7056 9398-29
Toll Free in Germany: 0800 639 7678
e-mail: info@omega.de

United Kingdom:

ISO 9001 Certified

One Omega Drive, River Bend Technology Centre
Northbank, Irlam, Manchester
M44 5BD United Kingdom
TEL: +44 (0)161 777 6611
FAX: +44 (0)161 777 6622
Toll Free in United Kingdom: 0800-488-488
e-mail: sales@omega.co.uk

It is the policy of OMEGA Engineering, Inc. to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct, but OMEGA accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

WARNING: These products are not designed for use in, and should not be used for, human applications.

BEFORE OPERATING THE FDT-81

Important Notice!




Figure 1.1

The FDT-81 flow meter is equipped with a Lead Acid Gel Cell battery. This battery will require charging before initial operation.

Apply power, utilizing the enclosed 12 Volt DC output line power converter or cigarette-style power cord, to the FDT-81 for a period of 16-24 hours prior to using the product for the first time. The power converter connects to the **DC IN +12V** socket connection located on the side of the enclosure. See **Figure 1.1**. A fully charged battery will provide up to 24 hours of continuous operation before recharging will be necessary.

When the battery level has decreased to a point where recharging is required, the LOW BATTERY indicator will illuminate on the front panel. At that point, the meter will only operate a short time more until it automatically turns itself off—preventing excessive battery discharge that can damage the Gel Cell battery. The FDT-81 has an integral charging circuit that prevents overcharging. The instrument can be permanently connected to AC line power without damaging the flow meter or the battery. Page 1.10 of this manual contains additional recommendations to preserve and maximize the power in the FDT-81 battery.

If the FDT-81 is to be used for extended periods of operation, the AC power converter or the 12 volt cigarette converter can remain connected indefinitely.

TABLE OF CONTENTS

	Pages
	Quick-Start Operating Instructions 1.6
Part 1 - Introduction	Introduction General 1.8 Applications 1.8 Product Identification 1.9 Product Specifications 1.10
Connections	Transmitter Connections 1.11 Battery Charging and Maintenance 1.12
Inputs and Outputs	Input/Output Connections and Options 4-20 mA Output 1.15 Optional ISO-Mods 1.16
Part 2 - Transducer Installation	Transducer Mounting Location 2.1 Transducer Spacing Mounting Modes 2.4 Keypad Entry 2.5 Transducer Mounting Pipe Preparation 2.14 V-Mount and W-Mount Installation 2.15 Z-Mount Installation 2.16 Mounting Track Installation 2.19 Small Pipe Transducer Installation 2.20

TABLE OF CONTENTS

	Pages
Part 3 - Operation	
Instrument Startup and Configuration	3.1
Keypad Operation	3.2
Menu Structure	
BASIC MENU	3.4
OUT2 MENU 4-20 mA	3.13
Optional Input/Output	3.15
SENSOR MENU	3.19
SECURITY MENU	3.19
SERVICE MENU	3.20
Signal Strength	3.21
Setting ZERO Flow	3.23
DISPLAY MENU	3.24
Appendix	
Appendix	
Error Codes	
Fluid Characteristic Table	
Digital Communications Protocol	
Pipe Dimension Chart: Cast Iron	
Pipe Dimension Chart: Ductile Iron	
Pipe Dimension Chart: ST, SS, PVC	
Velocity to Volumetric Conversion	
Addendum - Heat Flow	
Statement of Warranty	

QUICK-START OPERATING INSTRUCTIONS

Transducer Location

This manual contains detailed operating instructions for all aspects of the FDT-81 instrument. The following condensed instructions are provided to assist the operator in getting the instrument configured and measuring as quickly as possible. This pertains to basic operation only. If specific instrument features are to be used or if the installer is unfamiliar with this type of instrument, refer to the appropriate section in the manual for complete details.

1. TRANSDUCER LOCATION

- A. In general, select a mounting location on the piping system with a minimum of 10 pipe diameters (10 times the pipe inside diameter) of straight pipe upstream and 5 straight diameters downstream. See **Table 2.1** for detailed piping configurations and recommended lengths of straight pipe.
- B. Select a mounting method for the transducers based on pipe size and liquid characteristics. See **Figure 1.2**. Select **W-Mount** for plastic pipes flowing clean, non-aerated liquids in the 2-3 inch [50-75 mm] internal diameter range. Select **V-Mount** for pipes of all materials and most liquids in pipe sizes from 2-10 inches [50-250 mm]. Select **Z-Mount** for pipes 10-100 inches [250-2540 mm] inches.




Figure 1.2

QUICK-START OPERATING INSTRUCTIONS

*Nominal values for these parameters are included within the FDT-81 operating system. The nominal values may be used as they appear or may be modified if exact system values are known.




Figure 1.3

Connections

Startup

C. Enter the following data into the FDT-81 transmitter via the integral keypad.

- | | |
|--------------------------------------|-----------------------------|
| 1. Transducer mounting method | 9. Fluid type |
| 2. Pipe O.D. (Outside Diameter) | 10. Fluid sound speed* |
| 3. Pipe wall thickness | 11. Fluid viscosity* |
| 4. Pipe material | 12. Fluid specific gravity* |
| 5. Pipe sound speed* | |
| 6. Pipe relative roughness* | |
| 7. Pipe liner thickness (if present) | |
| 8. Pipe liner material (if present) | |

D. Record the value calculated and displayed as Transducer Spacing/XDCR SPC.

2. PIPE PREPARATION AND TRANSDUCER MOUNTING

- The piping surface, where the transducers are to be mounted, needs to be clean and dry. Remove loose scale, rust and paint to ensure satisfactory acoustical bonds.
- Apply a liberal amount of couplant grease onto the transducer faces.
- Attach the transducers to the pipe at the location(s) determined in Step 1. Refer to **Figure 1.2** for proper orientation.

3. TRANSDUCER/POWER CONNECTIONS

- If additional transducer cable is required, utilize RG59 coaxial wire with 75 Ohm terminations.
- Refer to the WIRING DIAGRAM located on the inner door of the FDT-81 transmitter and **Figure 1.3** for proper power and transducer connections.

4. INITIAL SETTINGS AND POWER UP

- Press the ON button on the flow meter keypad.
- From the Service Menu, verify that signal strength is greater than 2.0%.
- Input proper units of measure and I/O data.


PART 1 - INTRODUCTION

General

The FDT-81 ultrasonic flow meter is designed to measure the fluid velocity of liquid within closed conduit (pipe). The transducers are a non-contacting, clamp-on type, which will provide benefits of non-fouling operation and ease of installation.

FDT-81 transit time flow meters utilize two transducers that function as both ultrasonic transmitters and receivers. The transducers are clamped on the outside of a closed pipe at a specific distance from each other. The

transducers can be mounted in V-mode where the sound transverses the pipe two times, W-mode where the sound transverses the pipe four times, or in Z-mode where the transducers are mounted on opposite sides of the pipe and the sound crosses the pipe once. This selection is based on pipe and liquid characteristics. The flowmeter operates by alternately transmitting and receiving a frequency modulated burst of sound energy between the two transducers and measuring the time interval that it takes for sound to travel between the two transducers. The difference in the time interval measured is directly related to the velocity of the liquid in the pipe.



Application Versatility

The FDT-81 flow meter can be successfully applied on a wide range of metering applications. The simple to program transmitter allows the standard product to be used on pipe sizes ranging from 2 - 100 inch [50 - 2540 mm] internal diameters. A variety of liquid applications can be accommodated: ultrapure liquids, potable water, chemicals, raw sewage, reclaimed water, cooling water, river water, plant effluent, etc. Because the transducers are non-contacting and have no moving parts, the flow meter is not affected by system pressure, fouling or wear. Standard transducers are rated to 300 °F [150 °C]. Higher temperatures can be accommodated. Please consult the factory for assistance.

PART 1 - INTRODUCTION

User Safety

The FDT-81 employs modular construction and provides electrical safety for the operator. The display face contains voltages no greater than 10 Vdc. All user connections are made through sealed bulk-head plugs located on the side of the FDT-81 enclosure.

Data Integrity

Non-volatile flash memory retains all user-entered configuration values in memory for several years, even if power is lost or the unit is turned off. Password protection is provided as part of the Security menu and prevents inadvertent configuration changes or totalizer resets.

Product Identification

The serial number and complete model number of the FDT-81 is located on the inside of the transmitter's front cover. Should technical assistance be required, please provide the Omega Customer Service Department with this information.

PART 1 - SPECIFICATIONS

TRANSMITTER

Power Requirements	Internal 12 V lead-acid Gel Cell battery provides 24 hrs of continuous operation @ 20 °C. Charging: Wall mount power converter. 115 or 230 VAC 50/60 Hz ±15% VA max; 12-15 VDC @ 2.5 VA max
Velocity Range	-40 to +40 FPS (-12 to +12 MPS)
Inputs/Outputs	All output modules are optically isolated from earth and system grounds. One module and one data logger may be installed.
Standard	
4-20 mA	800 Ohm max; 12-bit resolution, passive or active
Options	
Rate Pulse	MOSFET, 0.21 Ohms, 100 V max, 0 to 2,500 Hz max
Dual Relay	2 separate Form C relays, 200 VAC max at 0.5 A (resistive)
RS232C	Data rate to 57.6k
RS485	Supports up to 119 drops
Heat Flow (RTD)	Supports two 1000 Ohm RTDs, multiplexed, 12-bit resolution
Display	128 × 64 pixel graphics LCD, LED backlit. Two user selectable font sizes 0.35" (8.9 mm) or 0.2" (5 mm) 8 digit rate, 8 digit totalizer (resettable)
Units	User configured
Rate	Gal, liters, million gal, ft³, m³, acre-ft, oil barrels (42 gal), liquid barrels (31.5 gal), ft, m, lb, kg, BTU, MBTU, MMBTU, ton
Time	Seconds, minutes, hours, days
Totalizer	Gal, liters, million gal, ft³, m³, acre-ft, oil barrels (42 gal), liquid barrels (31.5 gal), lb, kg, BTU, MBTU, MMBTU, ton
Mode	Forward, reverse, net, batch
Ambient Conditions	-40 °F to +185 °F (-40 °C to +85 °C), 0 to 95% relative humidity (non-condensing)
Enclosure	NEMA 4X (IP-66) while open, NEMA 6 (IP-68) while closed, ABS with SS hardware
Size	14.00" H × 6.06" W × 10.56" D (355.6 mm H × 153.9 mm W × 268.2 mm D); 14.8 lbs (6.7 Kg)
Flow Rate Accuracy	FDT-81-STD / FDT-81-HT: ±1% of reading at rates >1 FPS (0.3 MPS), ±0.01 FPS (±0.003 MPS) at rates lower than 1 FPS FDT-81-SML: 1" and larger units ±1% of reading from 10-100% of measuring range, ±0.01 FPS (±0.003 MPS) at rates lower than 10% of measuring range; ½" and ¾" units ±1% FS
Flow Sensitivity	0.001 FPS (0.0003 MPS)
Repeatability	±0.01% of reading
Response Time (Flow)	0.3 to 30 seconds, user configured, to 100% of value, step change in flow
Security	Keypad lockout, user selected 4 digit access code

TRANSDUCERS

Liquid Types	Most non-aerated, clean liquids
Cable Length	Up to 990 ft (300 meters); standard lengths 20, 50, 100 ft (6, 15, 30 meters)
Pipe Sizes	FDT-81-STD / FDT-81-HT: 2 inch and larger FDT-81-SML: 1/2", 3/4", 1", 1-1/4", 1-1/2", 2" (ANSI pipe, copper tube, tubing)
Environment	NEMA 6
Pipe Surface Temperature	FDT-81-STD: -40 °F to +250 °F (-40 °C to +121 °C) FDT-81-SML: -40 °F to +185 °F (-40 °C to +85 °C) FDT-81-HT: -40 °F to +350 °F (-40 °C to +177 °C)
Ambient Conditions	-40 °F to +185 °F (-40 °C to +85 °C)
Housing Material	FDT-81-STD: CPVC, Ultem®, and nylon FDT-81-SML: PVC, Ultem®, and nylon FDT-81-HT: PTFE, Vespel®, and nickel-plated brass

PART 1 - FDT-81 TRANSMITTER CONNECTIONS

Transmitter Location Considerations

After unpacking, it is recommended to save the shipping carton and packing materials in case the instrument is stored or re-shipped. Inspect the equipment and carton for damage. If there is evidence of shipping damage, notify the carrier immediately.

When the FDT-81 is to be utilized for extended periods of time in one location, the enclosure should be placed in an area that is convenient for servicing, calibration or for observation of the LCD readout.

1. Locate the transmitter within the length of transducer cable that was supplied with the FDT-81 system. If this is not possible, additional cable should be RG59 coaxial cable and terminations should be 75 Ohm. Longer cables are also available by contacting the factory.
2. Place the FDT-81 transmitter in a location that is:
 - ◆ Where little vibration exists.
 - ◆ Protected from falling corrosive fluids.
 - ◆ Within ambient temperature limits -40 to +185 °F [-40 to +85 °C]
 - ◆ Out of direct sunlight. Direct sunlight may increase transmitter temperatures above maximum limit.
3. If the transmitter will be subjected to a wet environment, it is recommended that the cover remain closed and the latches secured after configuration is completed. The faceplate/keypad of the FDT-81 is watertight, but avoid letting water collect on the keypad area.

It is highly recommended that the internal battery in the FDT-81 be fully charged before using the meter for the first time. Details covering this procedure are located on Page 1.1 of this manual.

PART 1 - FDT-81 TRANSMITTER CONNECTIONS

Electrical Connections




Figure 1.4

Battery Charging and External Power Sources

1. The connectors located on the side of the FDT-81 consist of three 1/4 turn BNC-type and one 5.5mm power plug. These connectors are environmentally sealed, but it is recommended not to allow water or other liquids to collect in the electrical connections pocket.
2. Connect the appropriate wires to the corresponding connections on the transmitter. The transducer cable has markings of UPSTREAM and DOWNSTREAM to assist in the installation process. The UPSTREAM transducer is the one located closer to the direction from which fluid flow normally comes from (The fluid normally passes the UPSTREAM transducer before passing the DOWNSTREAM transducer.) If the transducer wires are connected backwards, a negative flow indication will be observed on the flow meter display. See **Figure 1.4** or the Wiring Diagram located on the inner door of the transmitter.

NOTE: The transducer cables carry low level signals. If additional cable is required, it must be RG59 coaxial cable with 75 Ohm terminations. Longer cables are also available from the factory.

The 12 volt DC power converter and 12 volt cigarette-style power cord connect to the socket connection located on the side of the enclosure. See **Figure 1.4**. A fully charged battery will provide up to 24 hours of continuous operation before recharging will be necessary. When the battery level has decreased to a point where recharging is required, the LOW BATTERY indicator will illuminate on the front panel. At that point, the meter will only operate a short time more until it automatically turns itself off—preventing excessive battery discharge that can damage the Gel Cell battery.

PART 1 - FDT-81 TRANSMITTER CONNECTIONS

If the FDT-81 is to be used for extended periods of operation, the 12 Vdc line power converter or the 12 V cigarette-style converter can remain connected indefinitely.

To charge the internal Gel Cell battery, apply power, utilizing the enclosed 12 Vdc line power converter or cigarette-style power cord, to the FDT-81 for a period of 16-24 hours. The FDT-81 has an integral charging circuit that prevents overcharging. The instrument can be permanently connected to AC line power without damaging the flow meter or the battery.

The Gel Cell battery is “maintenance free”, but it still requires a certain amount of attention to prolong its useful life. To obtain the greatest capacity and longevity from the battery, the following practices are recommended:

- Do not allow the battery to completely discharge. (Discharging the battery to the point where the LOW BATTERY indicator illuminates will not damage the battery. Allowing the battery to remain discharged for long periods of time can degrade the storage capacity of the battery.) When not in use, continually charge the battery by keeping the 12 Vdc line power converter plugged in and connected to the flow meter. The FDT-81 battery management circuitry will not allow the battery to become “over-charged”.

NOTE: The FDT-81 will automatically enter a low power consumption mode approximately 1-1/2 minutes after the LOW BATTERY indicator illuminates. This circuit prevents excessive discharge of the internal battery.

- If the FDT-81 is stored for prolonged periods of time, monthly charging is recommended.
- If the FDT-81 is stored for prolonged periods of time, store at a temperature below 70 °F [21 °C].

Use wiring practices that conform to local codes (National Electric Code Handbook in the USA). Use only the power converters that have been supplied with the FDT-81 flow meter. The ground terminal, if present on the converter, is mandatory for safe operation.

PART 1 - FDT-81 TRANSMITTER CONNECTIONS

CAUTION: Any other wiring method may be unsafe or cause improper operation of the instrument.

It is recommended not to run line power with other signal wires within the same wiring tray or conduit.

NOTE: This instrument requires clean electrical line power. Do not operate this unit on circuits with noisy components (i.e. Fluorescent lights, relays, compressors, variable frequency drives, etc.).

The FDT-81 can be operated from a 11-15 Vdc source, using the included auto-style power cord, as long as it is capable of supplying at least 3 Watts—observe proper polarity.

PART 1 - FDT-81 TRANSMITTER CONNECTIONS

General Information Regarding Input/ Output: ISO-MODs

The FDT-81 flow meter may contain two *Isolated Input/output Modules* (ISO-MODs); one located inside of the flow meter enclosure and one that is user accessible, located under the access door on the keyboard. The standard configuration of these modules is to have the internal module configured as an actively powered 4-20 mA.

ISO-MODs are epoxy encapsulated electronic input/output modules that are simple to install and replace in the field. All modules are 2,500 volt optically isolated from FDT-81 power and earth grounds -- eliminating the potential for ground loops and reducing the chance of severe damage in the event of an electrical surge.

The standard 4-20mA output may be replaced with one of the following four ISO-MODs: dual-relay, rate pulse, RS232C, and RS485. FDT-81 supports one ISO-MOD input/output module. All modules are field configurable by utilizing the keyboard. Field wiring connections to ISO-MODs are quick and easy using pluggable terminals.

Standard 4-20 mA Output

The 4-20 mA Output Module interfaces with virtually all recording and logging systems by transmitting an analog current signal that is proportional to system flow rate. Independent 4 mA and 20 mA span settings are established in software using the FL 4MA and FL 20MA settings in the OUTPUT2 configuration menu. These entries can be set anywhere in the -40 to +40 fps [-12 to +12 mps] measuring range of the instrument. Output resolution of the module is 12-bits (4,096 discrete points). The module can drive more than 800 ohms of load with its internally generated 24 volt power source.




Figure 1.5

A 4-20 mA output interface cable has been included with the FDT-81 package. Connect the 1/4-turn BNC connection to the jack located on the side of the flow meter. See **Figure 1.5**. The red clip on the cable provides the positive leg of the output and the black clip provides the negative side. Verify that the sum of the resistances in the loop do not exceed 800 Ohms. The FDT-81 output is configured to source current.

Refer to Section 3 of this manual for detailed information regarding the configuration, calibration and testing of the 4-20 mA output.

PART 1 - FDT-81 TRANSMITTER CONNECTIONS

Other *Optional* ISO-Mods

There are four additional optional ISO-Mods available in replacement of the standard 4-20mA output. If interested in one of these optional ISO-Mods, please contact Omega.

PART 2 - TRANSDUCER POSITIONING

General

The transducers that are utilized by the Series FDT-81 contain piezoelectric crystals for transmitting and receiving ultrasound signals through walls of liquid piping systems. The transducers are relatively simple and straight-forward to install, but spacing and alignment of the transducers is critical to the system's accuracy and performance. Extra care should be taken to ensure that these instructions are carefully executed.

Mounting of the clamp-on ultrasonic transit time transducers is comprised of three steps:

1. Selection of the optimum location on a piping system.
2. Entering the pipe and liquid parameters by keying the parameters into the FDT-81 keypad. The software embedded in the FDT-81 will calculate proper transducer spacing based on these entries.
3. Pipe preparation and transducer mounting.

1. Mounting Location

The first step in the installation process is the selection of an optimum location for the flow measurement to be made. For this to be done effectively, a basic knowledge of the piping system and its plumbing are required.

An optimum location would be defined as a piping system that is completely full of liquid when measurements are being taken and has lengths of straight pipe such as those described in **Table 2.1**. The optimum straight pipe diameter recommendations apply to pipes in both horizontal and vertical orientation.

PART 2 - TRANSDUCER POSITIONING







Piping Configuration and Transducer Position	Upstream Pipe Diameters	Downstream Pipe Diameters
	*	**
	24	4
	14	3
	9	3
	8	3
	8	3
	24	4

Table 2.1¹

¹ The FDT-81 system will provide repeatable measurements on piping systems that do not meet these requirements, but the accuracy of these readings may be influenced to various degrees.

PART 2 - TRANSDUCER POSITIONING

2. Transducer Spacing

FDT-81 transit time flow meters utilize two transducers that function as both ultrasonic transmitters and receivers. The transducers are clamped on the outside of a closed pipe at a specific distance from each other. The transducers can be mounted in V-mode where the sound transverses the pipe two times, W-mode where the sound transverses the pipe four times, or in Z-mode where the transducers are mounted on opposite sides of the pipe and the sound crosses the pipe once. For further details, reference pictures located under **Table 2.2**. The appropriate mounting configuration is based on pipe and liquid characteristics. Selection of the proper transducer mounting method is not entirely predictable and many times is an iterative process. **Table 2.2** contains recommended mounting configurations for common applications. These recommended configurations may need to be modified for specific applications if such things as aeration, suspended solids or poor piping conditions are present. W-mode provides the longest sound path length between the transducers—but the weakest signal strength. Z-mode provides the strongest signal strength—but has the shortest sound path length. On pipes smaller than 3 inches [75 mm], it is desirable to have a longer sound path length, so that the differential time can be measured more accurately. Use of the FDT-81 diagnostics in determining the optimum transducer mounting is covered later in this section.

IMPORTANT: Since the time interval being measured is influenced by the transducer spacing, it is critical that the transducer spacing be measured on the pipe accurately to assure optimum performance from the FDT-81 system.


PART 2 - TRANSDUCER POSITIONING

Table 2.2
Transducer Mounting Modes


Transducer Mount Mode	Pipe Material	Pipe Size	Liquid Composition
W-Mode	Plastic (all types) Carbon Steel Stainless Steel Copper Ductile Iron Cast Iron	1-6 in. (25-150 mm) 1-4 in. (25-100 mm) 1-6 in. (25-150 mm) 1-6 in. (25-150 mm) Not recommended Not recommended	Low TSS; non-aerated Low TSS; non-aerated Low TSS; non-aerated Low TSS; non-aerated Low TSS; non-aerated
V-Mode	Plastic (all types) Carbon Steel Stainless Steel Copper Ductile Iron Cast Iron	6-30 in. (150-750 mm) 4-24 in. (100-600 mm) 6-30 in. (150-750 mm) 6-30 in. (150-750 mm) 3-12 in. (75-300 mm) 3-12 in. (75-300 mm)	Low TSS; non-aerated Low TSS; non-aerated Low TSS; non-aerated Low TSS; non-aerated Low TSS; non-aerated Low TSS; non-aerated
Z-Mode	Plastic (all types) Carbon Steel Stainless Steel Copper Ductile Iron Cast Iron	> 30 in. (> 750 mm) > 24 in. (> 600 mm) > 30 in. (> 750 mm) > 30 in. (> 750 mm) > 12 in. (> 300 mm) > 12 in. (> 300 mm)	Low TSS; non-aerated Low TSS; non-aerated Low TSS; non-aerated Low TSS; non-aerated Low TSS; non-aerated Low TSS; non-aerated

TSS = Total Suspended Solids


Transducer Mounting Modes



**W-Mount
Configuration**



**V-Mount
Configuration**



**Z-Mount
Configuration**

PART 2 - TRANSDUCER POSITIONING

Entering the Pipe and Liquid Data

The FDT-81 system calculates proper transducer spacing by utilizing piping and liquid information entered by the user. This information can be entered via the keypad.

In addition, the following information is required before mounting the transducers on the pipe. Note that much of the data relating to material sound speed, viscosity and specific gravity are preprogrammed into the meter. This data only needs to be modified if it is known that a particular liquid data varies from the reference value.

1. Transducer mounting configuration (Table 2.2)
2. Pipe O.D. (Outside Diameter)
3. Pipe wall thickness
4. Pipe material
5. Pipe sound speed¹
6. Pipe relative roughness¹
7. Pipe liner thickness (if present)
8. Pipe liner material (if present)
9. Fluid type
10. Fluid sound speed¹
11. Fluid viscosity¹
12. Fluid specific gravity¹


¹Nominal values for these parameters are included within the FDT-81 operating system. The nominal values may be used as they appear or may be modified if exact system values are known.

After entering the data listed above, the FDT-81 will calculate proper transducer spacing for the particular data set. This distance will be in inches if the FDT-81 is configured in English units, or millimeters if configured in metric units.

PART 2 - TRANSDUCER POSITIONING

Keypad Entry

The FDT-81 contains a tactile feedback keypad interface that allows the user to configure parameters used by the FDT-81 operating system.



Graphics Display Configuration

The following “Soft Key” menu items will be displayed immediately above the two keys located in the lower corners of the Graphics Display.

1. The (soft)MENU key is pressed from RUN mode to enter PROGRAM mode. The (soft)EXIT key is pressed in PROGRAM mode to exit configuration parameters and menus. If any configuration changes are made, the user will be prompted with a SAVE? (soft)YES or (soft)NO when returning to RUN mode. If no changes are made, the user will not be prompted for to SAVE.
2. The UP/DOWN ARROW keys are used to scroll through menus and configuration parameters. The ARROW keys can also be used to adjust parameter numerical values. In RUN mode the UP/DOWN ARROW keys are used to adjust the display contrast level.
3. The Numerical Keypad is used for entering numerical values.
4. The (soft)EDIT key is used to
 - access the configuration parameters in the various menus.
 - initiate changes in configuration parameters.
5. The (soft)ACCEPT key is used to
 - accept configuration parameter changes.

PART 2 - TRANSDUCER POSITIONING

6. The (soft)SELECT key is used to

- Configure the engineering units on the graphics display—Press the (soft)SELECT key from RUN mode to highlight the engineering unit presently being displayed on the graphics display (pressing the SELECT key multiple times will toggle the highlighted unit from line to line). Use the UP/DOWN ARROW keys to select display units of:
 - RATE
 - TOTALizer
 - VELOCITY
 - SIGNAL STRENGTH
- From Menu 7, Display Menu, the number of graphics display lines can be toggled between two and four lines.

Menu 1, the **BASIC** menu contains all of the configuration parameters necessary to make the transducer spacing calculation.

UNITS Entry

UNITS

ENGLISH

METRIC

Installs a global measurement standard into the operation of the instrument. The choices are either English or Metric measurements.

- Select ENGLISH if all configurations (pipe sizes, etc.) are to be made in inches. Select METRIC if the meter is to be configured in millimeters.
- The ENGLISH/METRIC selection will also configure the FDT-81 to display sound speeds in pipe materials and liquids as either feet per second or meters per second respectively.

PART 2 - TRANSDUCER POSITIONING

Transducer Mount Configuration

XDCR MNT -- Transducer Mounting Method

Selects the mounting orientation for the transducers. The selection of an appropriate mounting orientation is based on pipe and liquid characteristics. Refer to **Table 2.2** in this manual.

V -- Mount. A reflective type (transducers mounted on one side of the pipe) of installation used primarily on pipe sizes in the 3-10 inch [75-250 mm] internal diameter range.

W -- Mount. A reflective type (transducers mounted on one side of the pipe) of installation used primarily on pipe sizes in the 2-3 inch [50-75 mm] internal diameter range.

Z -- Mount. A direct type (transducers mounted on opposite sides of the pipe) of installation used primarily on pipe sizes in the 10-100 inch [250-2540 mm] internal diameter range.

Pipe O.D. Entry

PIPE OD -- Pipe Outside Diameter Entry

ENGLISH (Inches)

METRIC (Millimeters)

Enter the pipe outside diameter in inches if ENGLISH was selected as UNITS; in millimeters if METRIC was selected.

Pipe Wall Entry

PIPE WT -- Pipe Wall Thickness Entry

ENGLISH (Inches)

METRIC (Millimeters)

Enter the pipe wall thickness in inches if ENGLISH was selected as UNITS; in millimeters if METRIC was selected.

PART 2 - TRANSDUCER POSITIONING

Pipe Material Entry

PIPE MAT -- Pipe Material Selection

CARBON S - Carbon Steel

STAINLES - Stainless Steel

CAST IRO - Cast Iron

DUCTILE - Ductile Iron

COPPER - Copper

PVC - Polyvinylchloride

PVDF LOW - Low Density Polyvinylidene Flouride

PVDF HI - High Density Polyvinylidene Flouride

ALUMINUM - Aluminum

ASBESTOS - Asbestos Cement

FIBERGLA - Fiberglass

OTHER

This list is provided as an example. Additional materials are being added continuously. Select the appropriate pipe material from the list or select OTHER if the material is not listed.

Pipe Sound Speed Entry

PIPE SS -- Speed of Sound in the Pipe Material

ENGLISH (Feet per Second)

METRIC (Meters per Second)

Allows adjustments to be made to the speed of sound in the pipe wall. If the UNITS value was set to ENGLISH, the entry is in FPS (feet per second). METRIC entries are made in MPS (meters per second).

If a pipe material was chosen from the PIPE MAT list, a nominal value for speed of sound in that material will be automatically loaded. If the actual sound speed rate is known for the application piping system and that value varies from the automatically loaded value, the value can be revised.

If OTHER was chosen as PIPE MAT, a PIPE SS will need to be entered.

PART 2 - TRANSDUCER POSITIONING

Pipe Roughness Entry

PIPE R -- Pipe Material Relative Roughness *UNITLESS VALUE*

The FDT-81 provides Reynolds Number compensation in its flow measurement calculation. The ratio of average surface imperfection as it relates to the pipe internal diameter is used in this compensation.

$$\text{PIPE R} = \frac{\text{Linear RMS measurement of the pipe internal wall surface}}{\text{Internal Diameter of the pipe}}$$

If a pipe material was chosen from the PIPE MAT list, a nominal value relative roughness in that material will be automatically loaded. If the actual roughness is known for the application piping system and that value varies from the automatically loaded value, the value can be revised.

If OTHER was chosen as PIPE MAT, a PIPE R may to be entered.

Liner Thickness Entry

LINER T -- Pipe Liner Thickness Entry *ENGLISH (Inches)* *METRIC (Millimeters)*

Enter the pipe liner thickness. Enter this value in inches if ENGLISH was selected as UNITS; in millimeters if METRIC was selected.

Liner Material Entry

[If a LINER Thickness was selected] LINER MAT - Liner Material

TAR EPOXY
RUBBER
MORTAR
POLYPROPYLENE
POLYSTYROL
POLYSTYRENE
POLYESTER
POLYETHYLENE
EBONITE
PTFE or PFA
OTHER

PART 2 - TRANSDUCER POSITIONING

Liner Sound Speed Entry

This list is provided as an example. Additional materials are being added continuously. Select the appropriate material from the list or select OTHER if the liner material is not listed.

LINER SS -- Speed of Sound in the Liner

ENGLISH (Feet per Second)

METRIC (Meters per Second)

Allows adjustments to be made to the speed of sound in the liner. If the UNITS value was set to ENGLISH, the entry is in FPS (feet per second). METRIC entries are made in MPS (meters per second). If a liner was chosen from the LINER MAT list, a nominal value for speed of sound in that media will be automatically loaded. If the actual sound speed rate is known for the pipe liner and that value varies from the automatically loaded value, the value can be revised.

Fluid Type Entry

FL TYPE - Fluid/Media Type

TAP WATER

SEWAGE-RAW

ALCOHOL

SEA WATE

KEROSENE

GASOLINE

FUEL OIL

CRUDE OI

PROPANE

BUTANE

OTHER

This list is provided as an example. Additional liquids are being added continuously. Select the appropriate liquid from the list or select OTHER if the liquid is not listed.

Fluid Sound Speed Entry

FLUID SS -- Speed of Sound in the Fluid

ENGLISH (Feet per Second)

METRIC (Meters per Second)

Allows adjustments to be made to the speed of sound in the liquid. If the UNITS value was set to ENGLISH, the entry is in FPS (feet per second). METRIC entries are made in MPS (meters per second). If a fluid was chosen from the FL TYPE list, a nominal value for speed of sound in that media will be

PART 2 - TRANSDUCER POSITIONING

automatically loaded. If the actual sound speed rate is known for the application fluid and that value varies from the automatically loaded value, the value can be revised.

If OTHER was chosen as FL TYPE, a FLUID SS will need to be entered. A list of alternate fluids and their associated sound speeds are located the Appendix located at the back of this manual.

Fluid Viscosity Entry

FLUID VI -- Absolute Viscosity the Fluid *cps*

Allows adjustments to be made to the absolute viscosity of the liquid. If a fluid was chosen from the FL TYPE list, a nominal value for viscosity in that media will be automatically loaded. If the actual viscosity is known for the application fluid and that value varies from the automatically loaded value, the value can be revised. If OTHER was chosen as FL TYPE, a FLUID VI will need to be entered. A list of alternate fluids and their associated viscosities are located the Appendix located at the back of this manual.

Fluid Specific Gravity Entry

SP GRVTY -- Fluid Specific Gravity Entry *unitless*

Allows adjustments to be made to the specific gravity (density) of the liquid.

If a fluid was chosen from the FL TYPE list, a nominal value for specific gravity in that media will be automatically loaded. If the actual specific gravity is known for the application fluid and that value varies from the automatically loaded value, the value can be revised.

If OTHER was chosen as FL TYPE, a SP GRVTY may need to be entered if mass flows are to be calculated. A list of alternate fluids and their associated specific gravities are located the Appendix located at the back of this manual.

PART 2 - TRANSDUCER POSITIONING

Transducer Spacing Calculation

XDCR SPAC -- Transducer Spacing Calculation

ENGLISH (Inches)

METRIC (Millimeters)

This value represents the one-dimensional linear measurement between the transducers (the upstream/downstream measurement that runs parallel to the pipe). This value is in inches if ENGLISH was selected as UNITS, in millimeters if METRIC was selected. This measurement is taken from the line which is scribed into the side of the transducer block.

IMPORTANT: Pipe sizes under 2 inches [50 mm] require optional transducers and a modified FDT-81 system that can be purchased separately. See Page 2.22 for additional details or consult Omega for information.

PART 2 - TRANSDUCER POSITIONING

3. Transducer Mounting

After selecting an optimal mounting location, Step 1, and successfully determining the proper transducer spacing, Step 2, the transducers can now be mounted onto the pipe.

The transducers need to be properly oriented on the pipe to provide optimum reliability and performance. On horizontal pipes, the transducers should be mounted 180 radial degrees from one another and at least 45 degrees from the top-dead-center and bottom-dead-center of the pipe. See **Figure 2.1**. Figure 2.1 does not apply to vertically oriented pipes.




Figure 2.1 Horizontal pipe transducer mounting

Pipe Preparation

Before the transducers are bonded to the pipe surface, two areas slightly larger than the flat surface of the transducer heads must be cleaned of all rust, scale and moisture. For pipes with rough surfaces, such as ductile iron pipe, it is recommended that the pipe surface be ground flat. Paint and other coatings, if not flaked or bubbled, need not be removed. Plastic pipes typically do not require surface preparation other than soap and water cleaning.

PART 2 - TRANSDUCER POSITIONING

V-Mount and W-mount Transducer Installation

Transducer Mounting - V-mount and W-mount

1. Place a single bead of couplant, approximately 0.50 inch [12mm] thick, on the flat face of the transducer (**Figure 2.2**). Generally, a silicone-based grease is used as an acoustic couplant, but any grease-like substance that is rated not to “flow” at the temperature that the pipe may operate at, will be acceptable.




Figure 2.2 Transducer Couplant Application

2. Place the upstream transducer in position and secure with a mounting strap. The strap should be placed in the arched groove on end of transducer. A screw is provided to help hold the transducer onto the strap. Verify that the transducer is true to the pipe - adjust as necessary. Tighten strap securely.
3. Place the downstream transducer on pipe at the calculated transducer spacing. See **Figure 2.3**. Using firm hand pressure, slowly move the transducer towards and away from the upstream transducer while observing Signal Strength. Clamp the transducer at the position where the highest Signal Strength is observed. A Signal Strength between 3.0 and 95.0 percent is acceptable.




Figure 2.3 Transducer Position

PART 2 - TRANSDUCER POSITIONING

4. If after adjustment of the transducers the Signal Strength does not rise to above 5 percent, then an alternate transducer mounting method should be selected. If the mounting method was W-mode, then reconfigure the FDT-81 for V-mode, reset the FDT-81, move the downstream transducer to the new location and repeat step 3.
5. Certain pipe and liquid characteristics may cause Signal Strength to rise to greater than 95%. The problem with operating an FDT-81 with very high Signal Strength is that the signals may saturate the input amplifiers and cause erratic readings. To decrease the Signal Strength, move one transducer a small distance radially around the pipe, as shown in **Figure 2.4**.




Figure 2.4 High Signal Strength Condition

Z-Mount Transducer Installation

Transducer Mounting in Z-Mount Configuration

Installation on larger pipes requires careful measurements to linear and radial placement of transducers. Failure to properly orient and place transducers on pipe may lead to weak signal strength and/or inaccurate readings. The section below details a method for properly locating transducers on larger pipes. It requires a roll of paper (i.e. freezer or wrapping paper), masking tape and a marking device.

1. Wrap paper around pipe as shown in **Figure 2.5**. Align the paper ends to within 0.25 inches [6mm].

PART 2 - TRANSDUCER POSITIONING




Figure 2.5 Paper Template Alignment

2. Mark the intersection of the two ends of paper to indicate the circumference. Remove the template and spread it out on a flat surface. Fold template in half, bisecting the circumference. See **Figure 2.6**.




Figure 2.6 Bisecting the pipe circumference

3. Crease the paper at the fold line. Mark the crease. Place a mark on the pipe where one of the transducers will be located. See **Figure 2.1** for acceptable radial orientations. Wrap the template back around the pipe, placing the beginning of the paper and corner in the location of the mark. Move to the other side of the pipe and mark the

PART 2 - TRANSDUCER POSITIONING

ends of the crease. Measure from the end of the crease (directly across the pipe from the first transducer location) the dimension derived in Step 2, Transducer Spacing. Mark this location on the pipe.

4. The two marks on the pipe are now properly aligned and measured.

If access to the bottom of the pipe prohibits the wrapping of the paper around the circumference, cut a piece of paper to these dimensions and lay it over the top of the pipe.

Length = Pipe O.D. x 1.57

Width = Spacing determined on 2.12 or 2.14

Mark opposite corners of the paper on the pipe. Apply transducers to these two marks.

5. Place a single bead of couplant, approximately 0.50 inch [12 mm] thick, on the flat face of the transducer. See **Figure 2.2**. Generally, a silicone-based grease is used as an acoustic couplant, but any grease-like substance that is rated not to “flow” at the temperature that the pipe may operate at, will be acceptable.
6. Place the upstream transducer in position and secure with a stainless steel strap. Straps should be placed in the arched groove on the end of the transducer. A screw is provided to help hold the transducer onto the strap. Verify that the transducer is true to the pipe—adjust as necessary. Tighten transducer strap securely. Larger pipes may require more than one strap to reach the circumference of the pipe.
7. Place the downstream transducer on the pipe at the calculated transducer spacing. See **Figure 2.7**. Using firm hand pressure, slowly move the transducer both towards and away from the upstream transducer while observing Signal Strength. Clamp the transducer at the position where the highest Signal Strength is observed. Signal Strength of between 5 and 95 percent is acceptable. On certain pipes, a slight twist to the transducer may cause signal strength to rise to acceptable levels.

PART 2 - TRANSDUCER POSITIONING




Figure 2.7 Z-Mode Transducer Placement

8. Certain pipe and liquid characteristics may cause Signal Strength to rise to greater than 95%. The problem with operating an FDT-81 with very high Signal Strength is that the signals may saturate the input amplifiers and cause erratic readings. To decrease the Signal Strength one transducer can be offset radially, as illustrated in **Figure 2.4**, or a V-Mode mounting method may be chosen.
9. Secure the transducer with a stainless steel strap.

Mounting Track Installation

Transducer Mounting - Mounting Track

1. The transducer mounting track is used for pipes that have outside diameters between 2 and 10 inches [50-250mm]. If the pipe is outside of that range, then select a standard V-mode or W-mode mounting method.
2. Install the mounting rail on the side of the pipe with the stainless steel bands provided. Do not mount on the top or bottom of the pipe. Orientation on vertical pipe is not critical. Ensure that the track is parallel to the pipe and that all four mounting feet are touching the pipe.
3. Slide the two transducer clamps towards the center, 5 inch [125 mm] mark, on the mounting rail.
4. Place a single bead of couplant, approximately 0.25 inch [6 mm] thick, on the flat face of the transducer. See **Figure 2.2**.

PART 2 - TRANSDUCER POSITIONING

5. Place the first transducer in between the mounting rails near the zero point on the mounting rail scale. Slide clamp over the transducer. Adjust the clamp/transducer so the notch in the clamp aligns with zero on the scale. See **Figure 2.8**.




Figure 2.8 Transducer Space Measurement

6. Secure with the thumb screw. Ensure that the screw rests in the counter bore on the top of the transducer. (Excessive pressure is not required. Apply just enough pressure so that the couplant fills the gap between the pipe and transducer.)
7. Place the second transducer in between the mounting rails near the dimension derived in the Transducer Spacing section. Read the dimension on the mounting rail scale. Slide the transducer clamp over the transducer and secure with the thumb screw.

Small Pipe Transducer Installation

Transducer Mounting - Small pipe


Important note for pipe sizes under 2 inches [50 mm]. If the transducer spacing that is calculated is lower than 2.65 inches [67 mm], a set of small pipe transducers are required. Please contact Omega for information regarding the small pipe transducers.

The small pipe transducers offered by Omega are designed for specific pipe outside diameters. Do not attempt to mount a small pipe transducer onto a pipe that is either too large or too small for the transducer - contact Omega to inquire about small pipe transducers that are the correct size.

PART 2 - TRANSDUCER POSITIONING

Small pipe transducer installation consists of the following steps:

1. Apply a thin coating of silicone grease to both halves of the transducer housing where the housing will contact the pipe. See **Figure 2.9**.



**Figure 2.9 Application of Grease
Small Pipe Transducer**

2. On horizontal pipes, mount the transducer in an orientation such that the cable exits at $\pm 45^\circ$ from the side of the pipe. Do not mount with the cable exiting on either the top or bottom of the pipe. On vertical pipes the orientation does not matter.
3. Tighten the wing nuts so that the grease begins to flow out from the edges of the transducer and from the gap between the transducer halves. Do not over tighten.
4. If Signal Strength is less than 5%, remount the transducer at another location on the piping system.
5. If Signal Strength is greater than 95%, contact the factory to obtain a lower power Strategy to load into the FDT-81 flow meter.

PART 3 - STARTUP AND CONFIGURATION

Before Starting the Instrument

Note: The FDT-81 flow meter system requires a full pipe of liquid before a successful startup can be completed.

Do not attempt to make adjustments or change configurations until a full pipe is verified.

Note: If Dow 111 silicone grease was utilized as a couplant, a curing time is not required. However, if Dow 732 or another permanent RTV was used, the adhesive must fully cure before power is applied to the instrument.

Procedure:

Instrument Startup

1. Verify that all wiring is properly connected and routed as described previously in this manual.
2. Verify that the transducers are properly mounted as described in Part 2 of this manual.
3. Press the ON button on the flow meter keypad. The FDT-81 display backlighting will illuminate and the software version number will appear on the display.

The display backlighting illuminates for approximately 20 seconds and automatically extinguishes to preserve battery power. To re illuminate the display, press any key on the keyboard. Adjustments to the backlighting duration can be made in the Display Menu. Refer to page 3.24 for details.

4. Confirm that Signal Strength is greater than 2%. If it is not, verify that proper transducer mounting methods and liquid/pipe characteristics have been entered. The pipe must be full of liquid in order to make this measurement.
5. Once the meter is properly operating (proper signal strength has been achieved), refer to the later portions of this manual section for additional programming features.

PART 3 - KEYPAD CONFIGURATION

General

After an installation of the transducers and connection of appropriate power supplies to the FDT-81, keypad configuration of the instrument can be undertaken. All entries are saved in non-volatile FLASH memory and will be retained in the event of power loss.

Keypad Operation

The FDT-81 can be configured through the keypad interface. The following “Soft Key” menu items will be displayed immediately above the two keys located in the lower corners of the Graphics Display. See **Figure 3.1**.




Figure 3.1

Display Contrast

1. The MENU key is pressed from RUN mode to enter PROGRAM mode. The EXIT key is pressed in PROGRAM mode to exit configuration parameters and menus. If changes to any configuration parameters have been made, the user will be prompted with a SAVE? YES or NO when returning to RUN mode. If no changes have been made, the user will not be prompted to SAVE.
2. The UP/DOWN ARROW keys are used to scroll through menus and configuration parameters. The ARROW keys can also be used to adjust parameter numerical values or to adjust the display contrast level in RUN mode.
3. The Numerical Keypad is used for entering numerical values.
4. The ACCEPT key is used to
 - accept configuration parameter changes.

PART 3 - KEYPAD CONFIGURATION

Graphics Display Configuration

5. The SELECT key is used to

- Configure the engineering units on the graphics display—Press the SELECT key from RUN mode to highlight the engineering unit presently being displayed on the graphics display (pressing the SELECT key multiple times will toggle the highlighted unit from line to line). Use the UP/DOWN ARROW keys to select display units of
 - N - Total (Net Totalizer)
 - + - Total (Positive Totalizer)
 - - - Total (Negative Totalizer)
 - Rate
 - Sound Speed FPS
 - Sound Speed MPS
 - SIGNAL STR.
 - Temp 1
 - Temp 2
 - Temp DIFF

From Menu 8, Display Menu, the number of graphics display lines can be toggled between two and four lines.

- access the configuration parameters in the various menus.
- initiate changes in configuration parameters.

PART 3 - KEYPAD CONFIGURATION

Menu Structure

The eight menus used in the structure of the FDT-81 are as follows:

1. **BSC MENU** -- BASIC operations menu. Contains all of the configuration parameters necessary to program the meter to measure flow.
2. **OUT2 MEN** -- Configures the type and operating parameters of the 4-20mA or other ISO-MOD located internally in the FDT-81 flow meter.
3. **SEN MENU** -- Selects the transducer type (i.e. FDT-81-STD, FDT-81-HTI, etc.).
4. **SEC MENU** -- Resets totalizers, resets the operating system and revises security passwords.
5. **SER MENU** -- SERVICE MENU contains system measurements that are used by service personnel for troubleshooting.
6. **DSP MENU** -- Configures meter display functions.

The following sections define the configuration parameters located in each of the menus.

The BASIC menu contains all of the configuration parameters necessary to make the FDT-81 operational.

1. BSC MENU -- BASIC MENU

UNITS Selection

UNITS

ENGLISH
METRIC

Installs a global measurement standard into the operation of the instrument. The choices are either English or Metric measurements.

- Select ENGLISH if all configurations (pipe sizes, etc.) are to be made in inches. Select METRIC if the meter is to be configured in millimeters.

PART 3 - KEYPAD CONFIGURATION

- The ENGLISH/METRIC selection will also configure the FDT-81 to display sound speeds in pipe materials and liquids as either feet per second or meters per second, respectively.

NOTE: If the UNITS entry has been changed from ENGLISH to METRIC or from METRIC to ENGLISH, the entry must be saved and the instrument reset (power cycled or System Reset entered) in order for the FDT-81 to initiate the change in operating units. Failure to save and reset the instrument will lead to improper transducer spacing calculations and an instrument that may not measure properly.

Transducer Mount

XDCR MNT -- Transducer Mounting Method

V
W
Z

Selects the mounting orientation for the transducers. The selection of an appropriate mounting orientation is based on pipe and liquid characteristics. See PART 2 - Transducer Installation in this manual.

Pipe Diameter

PIPE OD -- Pipe Outside Diameter Entry

ENGLISH (Inches)
METRIC (Millimeters)

Enter the pipe outside diameter in inches if ENGLISH was selected as UNITS; in millimeters if METRIC was selected.

NOTE: Charts listing popular pipe sizes have been included in the Appendix of this manual. Correct entries for pipe P.D. and pipe wall thickness are critical to obtaining accurate flow measurement readings.

PART 3 - KEYPAD CONFIGURATION

Pipe Wall Thickness

PIPE WT -- Pipe Wall Thickness Entry

ENGLISH (Inches)

METRIC (Millimeters)

Enter the pipe wall thickness in inches if ENGLISH was selected as UNITS; in millimeters if METRIC was selected.

Pipe Material

PIPE MAT -- Pipe Material Selection

CARBON S - Carbon Steel

STAINLES - Stainless Steel

CAST IRO - Cast Iron

DUCTILE - Ductile Iron

COPPER - Copper

PVC - Polyvinylchloride

PVDF LOW - Low Density Polyvinylidene Flouride

PVDF HI - High Density Polyvinylidene Flouride

ALUMINUM - Aluminum

FIBERGLA - Fiberglass

OTHER

This list is provided as an example. Additional pipe materials are being added continuously. Select the appropriate pipe material from the list or select OTHER if the material is not listed.

Pipe Sound Speed

PIPE SS -- Speed of Sound in the Pipe Material

ENGLISH (Feet per Second)

METRIC (Meters per Second)

Allows adjustments to be made to the speed of sound in the pipe wall. If the UNITS value was set to ENGLISH, the entry is in FPS (feet per second). METRIC entries are made in MPS (meters per second).

If a pipe material was chosen from the PIPE MAT list, a nominal value for speed of sound in that material will be automatically loaded. If the actual sound speed rate is known for the application piping system and that value varies from the automatically loaded value, the value can be revised.

If OTHER was chosen as PIPE MAT, a PIPE SS will need to be entered.

PART 3 - KEYPAD CONFIGURATION

Pipe Roughness

PIPE R -- Pipe Material Relative Roughness *UNITLESS VALUE*

The FDT-81 provides Reynolds Number compensation in its flow measurement calculation. The ratio of average surface imperfection as it relates to the pipe internal diameter is used in this compensation.

$$\text{PIPE R} = \frac{\text{Linear RMS measurement of the pipe internal wall surface}}{\text{Internal Diameter of the pipe}}$$

If a pipe material was chosen from the PIPE MAT list, a nominal value relative roughness in that material will be automatically loaded. If the actual roughness is known for the application piping system and that value varies from the automatically loaded value, the value can be revised.

If OTHER was chosen as PIPE MAT, a PIPE R may to be entered.

Liner Thickness

LINER T -- Pipe Liner Thickness Entry *ENGLISH (Inches)* *METRIC (Millimeters)*

Enter the pipe liner thickness. Enter this value in inches if ENGLISH was selected as UNITS; in millimeters if METRIC was selected.

Liner Material

[If a LINER Thickness was selected] LINER MAT - Liner Material

TAR EPOXY
RUBBER
MORTAR
POLYPROPYLENE
POLYSTYROL
POLYSTYRENE
POLYESTER
POLYETHYLENE
EBONITE
PTFE or PFA
OTHER

This list is provided as an example. Additional materials are

PART 3 - KEYPAD CONFIGURATION

Liner Sound Speed

being added continuously. Select the appropriate material from the list or select OTHER if the liner material is not listed.

LINER SS -- Speed of Sound in the Liner

ENGLSH (Feet per Second)

METRIC (Meters per Second)

Allows adjustments to be made to the speed of sound in the liner. If the UNITS value was set to ENGLSH, the entry is in FPS (feet per second). METRIC entries are made in MPS (meters per second).

If a liner was chosen from the LINER MAT list, a nominal value for speed of sound in that media will be automatically loaded. If the actual sound speed rate is known for the pipe liner and that value varies from the automatically loaded value, the value can be revised.

Fluid Type

FL TYPE - Fluid/Media Type

TAP WATER

SEA WATER

KEROSENE

GASOLINE

FUEL OIL

CRUDE OIL

PROPANE

BUTANE

OTHER

This list is provided as an example. Additional liquids are being added continuously. Select the appropriate liquid from the list or select OTHER if the liquid is not listed.

Fluid Sound Speed

FLUID SS -- Speed of Sound in the Fluid

ENGLSH (Feet per Second)

METRIC (Meters per Second)

Allows adjustments to be made to the speed of sound in the liquid. If the UNITS value was set to ENGLSH, the entry is in FPS (feet per second). METRIC entries are made in MPS (meters per second).

If a fluid was chosen from the FL TYPE list, a nominal value for speed of sound in that media will be automatically loaded.

PART 3 - KEYPAD CONFIGURATION

Fluid Viscosity

If the actual sound speed rate is known for the application fluid and that value varies from the automatically loaded value, the value can be revised.

If OTHER was chosen as FL TYPE, a FLUID SS will need to be entered. A list of alternate fluids and their associated sound speeds are located the Appendix located at the back of this manual.

FLUID VI -- Absolute Viscosity the Fluid *cps*

Allows adjustments to be made to the absolute viscosity of the liquid. If a fluid was chosen from the FL TYPE list, a nominal value for viscosity in that media will be automatically loaded. If the actual viscosity is known for the application fluid and it varies from the automatically loaded value, the value can be revised.

If OTHER was chosen as FL TYPE, a FLUID VI will need to be entered. A list of alternate fluids and their associated viscosities are located in the Appendix located at the back of this manual.

Fluid Specific Gravity

SP GRVTY -- Fluid Specific Gravity Entry *unitless*

Allows adjustments to be made to the specific gravity (density) of the liquid. If a fluid was chosen from the FL TYPE list, a nominal value for specific gravity in that media will be automatically loaded. If the actual specific gravity is known for the application fluid and that value varies from the automatically loaded value, the value can be revised.

If OTHER was chosen as FL TYPE, a SP GRVTY may need to be entered if mass flows are to be calculated. A list of alternate fluids and their associated specific gravities are located the Appendix located at the back of this manual.

PART 3 - KEYPAD CONFIGURATION

Transducer Spacing

XDCR SPAC -- Transducer Spacing Calculation

ENGLISH (Inches)

METRIC (Millimeters)

This value represents the one-dimensional linear measurement between the transducers (the upstream/downstream measurement that runs parallel to the pipe). This value is in inches if ENGLISH was selected as UNITS; in millimeters if METRIC was selected. This measurement is taken from the line which is scribed into the side of the transducer block.

If the transducers are being mounted using the transducer track assembly, a measuring scale is etched into the track. Place one transducer at 0 inches and the other at the appropriate measurement.

Engineering Units RATE

RATE UNT - Engineering Units for Flow Rate

GALLONS - U.S. Gallons

LITERS - Metric Liter

MGAL - Millions of U.S. Gallons

CUBIC FT - Cubic Feet

CUBIC ME - Cubic Meters

ACRE FT - Acre Feet

OIL BARR - Oil Barrels (42 U.S. Gallons)

LIQ BARR - Liquor Barrels (31.5 U.S. Gallons)

FEET - Linear Feet

METERS - Linear Meters

Select a desired engineering unit for flow rate measurements.

Engineering Units RATE INTERVAL

RATE INT - Time Interval for Flow Rate

MIN - Minutes

HOURL - Hours

DAY - Days

SEC - Seconds

Select a desired engineering unit for flow rate measurements.

PART 3 - KEYPAD CONFIGURATION

Engineering Units TOTALIZER

TOTL UNT - Engineering Units for Flow Totalizer

GALLONS - U.S. Gallons

LITERS - Metric Liter

MGAL - Millions of U.S. Gallons

CUBIC FT - Cubic Feet

CUBIC ME - Cubic Meters

ACRE FT - Acre Feet

OIL BARR - Oil Barrels (42 U.S. Gallons)

LIQ BARR - Liquor Barrels (31.5 U.S. Gallons)

FEET - Linear Feet

METERS - Linear Meters

Select a desired engineering unit for flow accumulator (totalizer) measurements.

Engineering Units TOTAL Exponent

TOTL E - Flow Totalizer Exponent Value

E-1 to E6

Utilized for setting the flow totalizer exponent. This feature is useful for accommodating a very large accumulated flow. The exponent is a $\times 10^n$ multiplier, where "n" can be from -1 ($\times 0.1$) to +6 ($\times 1,000,000$). Table 3.1 should be referenced for valid entries and their influence on the FDT-81 display.

TABLE 3.1—Totalizer Exponent Values

Exponent	Display Multiplier
E-1	$\times 0.1$
E0	$\times 1$ (no multiplier)
E1	$\times 10$
E2	$\times 100$
E3	$\times 1,000$
E4	$\times 10,000$
E5	$\times 100,000$
E6	$\times 1,000,000$

PART 3 - KEYPAD CONFIGURATION

Minimum Flow Rate

MIN RATE - Minimum Flow Rate Settings

Rate Unit/Rate Interval

A minimum volumetric flow rate setting is entered to establish filter software settings. Volumetric entries will be in the Engineering Rate Units and Interval selected on pages 3.10-3.11 of this manual. For unidirectional measurements, set MIN RATE to zero. For bi-directional measurements, set to the highest negative (reverse) flow rate expected in the piping system.

Maximum Flow Rate

MAX RATE - Maximum Flow Rate Settings

Rate Unit/Rate Interval

A maximum volumetric flow rate setting is entered to establish filter software settings. Volumetric entries will be in the Engineering Rate Units and Interval selected on pages 3.10-3.11 of this manual. For unidirectional or bi-directional measurements, set MAX RATE to the highest (positive) flow rate expected in the piping system.

Low Flow Cut-off

FL C-OFF - Low Flow Cut-off

Percent of the range between MIN RATE and MAX RATE

A Low Flow Cut-off entry is provided to allow very low flow rates (that can be present when pumps are off and valves are closed) to be displayed as Zero flow. Typical values that should be entered are between 1.0% and 5.0% of the flow range between MIN RATE and MAX RATE.

System Damping

DAMP PER - System Damping

Relative Percent Entry: 0-100%

Flow Filter Damping establishes a maximum adaptive filter value. Under the stable flow conditions (flow varies less than 10% of reading) this adaptive filter will increase the number of successive flow readings that are averaged together up to this maximum value. If flow changes outside of the **10%** window, the Flow Filter adapts by decreasing and allows the meter to react faster. Increasing this value tends to provide smoother steady-state flow readings and outputs.

PART 3 - KEYPAD CONFIGURATION

2. OUTPUT 2 MENU

Standard 4-20mA

ISO-MOD 4-20mA

FL 4MA

FL 20MA

CAL 4MA

CAL 20MA

4-20 TST

Configured via jumper selections for either a passive or active transmission mode, the 4-20mA Output Module interfaces with virtually all recording and logging systems by transmitting an analog current signal that is proportional to system flow rate. Independent 4mA and 20mA span settings are established in software using the Flow Measuring Range entries. These entries can be set anywhere in the -40 to +40 FPS [-12 to +12 MPS] measuring range of the instrument. Output resolution of the module is 12-bits (4096 discrete points) and the module can drive up to 800 ohms of load with its internal 24V isolated power source.

4-20mA Span

The FL 4MA and FL 20MA entries are used to set the span of the 4-20mA analog output. These entries are volumetric rate units that are equal to the volumetric units configured as Engineering Rate Units and Engineering Units Time Interval entered on page 3.10.

For example, to span the 4-20mA output from -100 GPM to +100 GPM, with 12mA being 0 GPM, set the FL 4MA and FL 20MA inputs as follows:

FL 4MA = -100.0

FL 20MA = 100.0

For example, to span the 4-20mA output from 0 GPM to +100 GPM, with 12mA being 50 GPM, set the FL 4MA and FL 20MA inputs as follows:

FL 4MA = 0.0

FL 20MA = 100.0

PART 3 - KEYPAD CONFIGURATION

4-20mA Calibration

The 4-20mA ISO-MOD is factory calibrated and should not require adjustment unless it is replaced.

The CAL4MA entry allows fine adjustments to be made to the “zero” of the 4-20mA output. To adjust the 4mA output, an ammeter or reliable reference connection to the 4-20mA output must be present.

NOTE: The CAL 4MA and CAL 20MA entries should not be used in an attempt to set the 4-20mA range. Utilize FL 4MA and FL 20MA, detailed above, for this purpose.

Procedure:

1. Disconnect one side of the current loop and connect the ammeter in series (disconnect either wire at the terminals labeled +/- on the **ISO-MOD** 4-20mA module).
2. Using the arrow keys, increase the numerical value to increase the current in the loop to 4mA. Decrease the value to decrease the current in the loop to 4mA. Typical values range between 40-80 counts.

Re connect the 4-20mA output circuitry as required.

Calibration of the 20mA setting is conducted much the same way as the 4mA adjustments.

Procedure:

1. Disconnect one side of the current loop and connect the ammeter in series (disconnect either wire at the terminals labeled +/- on the **ISO-MOD** 4-20mA module).
2. Using the arrow keys, increase the numerical value to increase the current in the loop to 20mA. Decrease the value to decrease the current in the loop to 20mA. Typical values range between 3700-3900 counts.

Re connect the 4-20mA output circuitry as required.

PART 3 - KEYPAD CONFIGURATION

4-20mA Test

4-20 TST - 4-20mA Output Test

4-20

Allows a simulated value to be output on from the 4-20mA output. By incrementing this value, the 4-20mA output will transmit the indicated current value.

Optional Modules

The Series FDT-81 allows other input/output modules to be used in place of the 4-20mA output. Please contact the Omega regarding these options:

Optional Rate Pulse

ISO-MOD RATE PULSE

FL 0H

FL 25KH

The Rate Pulse Output Module is utilized to transmit information to external counters and PID systems via a frequency output that is proportional to system flow rate. Independent Zero and Span settings are established in software using the Flow Measuring Range entries. Output resolution of the module is 12-bits (4096 discrete points) and the maximum output frequency setting is 2,500Hz. The module has two output modes, turbine meter simulation and "open collector". The turbine meter simulation sources a non-ground referenced saw-tooth waveform with a maximum peak amplitude of approximately 500mVpp. The open-collector output utilizes a 0.21-Ohm FET output that is rated to operate at 100 V and 1 A maximum. If the open-collector output type is utilized, an external voltage source and limit resistor must be present.

Rate Pulse Span

The FL 0H and FL 25KH entries are used to set the span of the 0-2.5KHz frequency output. These entries are volumetric rate units that are equal to the volumetric units configured as Engineering Rate Units and Engineering Units Time Interval entered on page 3.11.

PART 3 - KEYPAD CONFIGURATION

In a bi-directional system, to span the 0-2.5kHz output from – 100 GPM to +100 GPM, with 1.25kHz being 0 GPM, set the FL 100H and FL 10KH inputs as follows:

FL 0H = 100.0
FL 25KH = 100.0

To span the 0-2.5 kHz output from 0 GPM to +100 GPM, with 1.25 kHz being 50 GPM, set the FL 0H and FL 25KH inputs as follows:

FL 0H = 0
FL 25KH = 100.0

Optional Dual Relay

ISO-MOD Dual Relay
RELAY 1 AND RELAY 2
NONE
TOTALIZE
TOT MULT
FLOW
ON
OFF
SIG STR
ERRORS

Two independent SPDT (single-pole, double-throw, Form C) relays are contained in this module. The relay operations are user configured via software to act in either a flow rate alarm, signal strength alarm, error alarm or totalizer/batching mode. The relays are rated for 200 VAC max. and a have current rating of 0.5A resistive load [175 VDC @ 0.25A resistive]. It is highly recommended that a secondary relay be utilized whenever the Control Relay ISO-MOD is used to control inductive loads such as solenoids and motors.

Batch/Totalizer Relay

TOTALIZE mode configures the relay to output a 50 mSec pulse (contact changeover) each time the display totalizer increments—divided by the TOT MULT. The TOT MULT value must be a whole, positive, numerical value.

- If the Totalizer Exponent is set to E0 (x1) and the Relay Multiplier is set to 1, then the relay will pulse each time the totalizer increments one count, or each single, whole measurement unit totalized.

PART 3 - KEYPAD CONFIGURATION

- If the Totalizer Exponent is set to E2 (x100) and the Relay Multiplier is set to 1, then the relay will pulse each time the display totalizer increments or once per 100 measurement units totaled.
- If the Totalizer Exponent is set to E0 (x1) and the Relay Multiplier is set to 2, the relay will pulse once for every two counts that the totalizer increments.

Flow Rate Relay

Flow rate relay configuration permits relay changeover at two separate flow rates, allowing operation with an adjustable switch deadband. **Figure 3.2** illustrates how the setting of the two set points influences Rate Alarm operation.

A single-point flow rate alarm would place the ON> setting slightly higher than the OFF< setting -allowing a switch deadband to be established. If a deadband is not established, switch chatter (rapid switching) may result when flow rate is too close to the switch point.




Figure 3.2
Single Point Alarm Operation

Signal Strength Alarm

The SIG STR alarm will provide an indication that the flow meter signals between the transducers have fallen to a point where flow measurements may not be possible. It can also be used to indicate the pipe has emptied. Like the Flow Rate alarm described previously, the Signal Strength alarm requires that two points be entered, establishing an alarm deadband. A valid switch point exists when the ON> is a value lower than OFF<. If a deadband is not established and the signal strength decreases to approximately the value of the switch point, the relay may chatter.

PART 3 - KEYPAD CONFIGURATION

Error Alarm Relay

If a relay is set to ERROR mode, the relay will activate when errors occur in the flow meter that has caused the meter to stop measuring reliably. See Appendix for a list of potential error codes.

Optional RS232C Module

ISO-MOD RS-232C
RS232 MO — MODE
HOST
UIF
RS232 BA — BAUD RATE
1200
2400
9600
19200

The RS232 Module can be interfaced with serial communication ports of PCs, PLCs and SCADA systems. The module runs a proprietary digital protocol, detailed in the Appendix, that is used to monitor flow rate information in piping systems.

Optional RS-485 Module

ISO-MOD RS-485
RS485 MO — MODE
SLAVE
MASTER
RS485 BA — BAUD RATE
1200
2400
9600
19200
ADDRESS — Device Address
1-127

The RS485 Module allows up to 126 FDT-81 systems to be daisy-chained on a single three-wire cable network. Communications are via a proprietary digital protocol, detailed in the Appendix. All meters are assigned a unique one byte serial number that allows all of the meters on the cable network to be accessed independently. Baud rates up to 19.2K and cable lengths to 5,000 feet [1,500 meters] are supported without the need for repeaters.

PART 3 - KEYPAD CONFIGURATION

RS485 MO

Select SLAVE for all of the FDT-81 meters.

RS485 BA

Select a Baud rate that is compatible with the operating system.

ADDRESS

Each FDT-81 connected on the communications bus must have a unique address number assigned. Address 127 is a universal address that will result in all FDT-81 instruments on the network responding simultaneously—regardless of address—resulting in CRC errors. Only select address location 127 if one meter is on the network.

3. SEN MENU -- SENSOR MENU

The SEN MENU is utilized to select the type of transducer that will be interfaced with the FDT-81 meter. Select the appropriate transducer from the list and save the configuration. If the transducer selection is modified, a system reset is required.

4. SEC MENU -- SECURITY MENU

SEC MENU allows users to make password revisions, reset flow totalizer and reset transmitter microprocessor.

Totalizer RESET

TOT RES

NO
YES

Select YES to reset flow totalizer/accumulator to Zero.

System RESET

SYS RSET

NO
YES

Select YES to initiate a microprocessor reset. All configurations and totalizer values will be maintained.

PART 3 - KEYPAD CONFIGURATION

Change Password

CH PSWD? -- Change the Security Password 0-9999

By changing the Security Password from 0 to another value (between 1-9999), configuration parameters will not be accessible without first entering that value when prompted. If the value is left at 0, no security is invoked and unauthorized changes could be made.

5. SER MENU -- SERVICE MENU

The SERVICE Menu makes available two different system measurements that are used for trouble-shooting and fine tuning of the instrument. Actual liquid sound speed and system signal strength readings can be accessed through this menu.

The SERVICE Menu also has features that allow adjustment of Signal Strength Cutoff, Error-Mode outputs, Zero Flow Rate Set and entry of a universal correction factor.

Liquid Sound Speed

SSPD MPS - Sound Speed in the Liquid Metric SSPD FPS - Sound Speed in the Liquid U.S.

The FDT-81 performs an actual speed of sound calculation for the liquid it measures. This calculation will vary with temperature, pressure and fluid composition. The value indicated should be within 2% of the value entered/indicated in the BASIC menu item FLUID SS. The value cannot be modified. If the actual measured value is significantly different than the BASIC MENU's FLUID SS value, it typically indicates a problem with the instrument setup. Any entry such as PIPE OD or wall thickness may be in error, the pipe may not be round, or the transducer spacing is not correct. **Table 3.3 on page 3.21** lists sound speed values for water at varying temperatures. If the FDT-81 is measuring sound speed within 2% of the table values, then the installation and setup of the instrument is correct and accurate readings may be assured.

PART 3 - KEYPAD CONFIGURATION

Table 3.3
Sound Speed in
Liquid water vs.
Temperature

Deg. C	Deg. F	Vs (m/s)	Vs (f/s)
0	32	1402	4600
10	50	1447	4747
20	68	1482	4862
30	86	1509	4951
40	104	1529	5016
50	122	1543	5062
60	140	1551	5089
70	158	1555	5102
80	176	1554	5098
90	194	1550	5085
100	212	1543	5062
110	230	1532	5026
120	248	1519	4984
130	266	1503	4931
140	284	1485	4872
150	302	1466	4810
160	320	1440	4724
170	338	1412	4633
180	356	1390	4560
190	374	1360	4462
200	392	1333	4373
220	428	1268	4160
240	464	1192	3911
260	500	1110	3642

Signal Strength

SIG STR - Signal Strength

The measurement of Signal Strength assists service personnel in troubleshooting the FDT-81 system. In general, expect the signal strength readings to be greater than 4% on a full pipe with the transducers properly mounted. Signal strength readings that are less than 4% may indicate a need to chose an alternative mounting method for the transducers, or that an improper pipe size has been entered.

Signal Strength readings in excess of 95% may indicate that a mounting method with a longer path length may be required. For example, if transducers mounted on a 3 inch PVC pipe in V-mode causes the measured Signal Strength value to exceed 95%, change the mounting method to W-mode for greater stability in readings.

Signal Strength Cutoff

Signal Strength Cutoff SIG C-OFF is used to drive the flow meter and its outputs to the SUB FLOW (Substitute Flow—described below) state if conditions occur that cause low signal strength. A signal strength indication of between 0.5 and 0.8 is inadequate for measuring flow reliably, so

PART 3 - KEYPAD CONFIGURATION

Substitute Flow Entry

minimum settings for SIG C-OFF are in the range of 1.0 to 2.0. A good practice is to set the SIG C-OFF at approximately 60-70% of actual measured signal strength (described above).

If the measured signal strength is lower than the SIG C-OFF setting, an **ERROR 0010** will be displayed on the FDT-81 display until the measured signal strength becomes greater than the cutoff value.

Substitute Flow or SUB FLOW is a value that the analog outputs and the flow rate display will indicate when an error condition in the flow meter occurs. The typical setting for this entry is a value that will make the instrument display zero flow during an error condition.

Table 3.4 below lists some typical settings to achieve “Zero” with respect to MIN and MAX FLOW settings.

MIN RATE SETTING	MAX RATE SETTING	SUB FLOW SETTING	DISPLAY READING DURING ERRORS
0.0	1,000.0	0.0	0.000
-500.0	500.00	50.0	0.000
-100.0	200.0	33.3	0.000
0.0	1,000.0	-5.0	-50.00

TABLE 3.4—Substitute Flow Entry

PART 3 - KEYPAD CONFIGURATION

Setting/Calibrating Zero Flow

Because every flow meter installation is slightly different and sound waves can travel in slightly different ways through these various installations, a provision is made in this entry to establish “Zero” flow—SET ZERO.

To zero the meter:

1. The pipe must be full of liquid.
2. Flow must be absolute zero—securely close any valves and allow time for any settling to occur.
3. Press ENTER, use the arrow keys to make the display read YES.
4. Press ENTER.
5. The procedure is complete.

Factory Default Zero Calibration

If the flow in a piping system cannot be shut off, allowing the SET ZERO procedure described above to be performed, then the factory default zero should be utilized. To utilize the D-FLT 0 function, simply press ENTER, then press an ARROW key to display YES on the display and then press ENTER. This function can also be utilized to correct an inadvertently entered or erroneous SET ZERO entry.

Correction Factor

This function can be used to make the FDT-81 system agree with a different or reference flow meter, by applying a correction factor/multiplier to the readings and outputs. A factory calibrated system should be set to 1.000. The range of settings for this entry is 0.500 to 1.500. The following examples describe two uses for the COR FTR entry.

- The FDT-81 meter is indicating a flow rate that is 4% higher than another flow meter located in the same pipe line. To make the FDT-81 indicate the same flow rate as the other meter, enter a COR FTR of 0.960, to lower the readings by 4%.
- An out-of-round pipe, carrying water, causes the FDT-81 to indicate a measured sound speed that is 7.4% lower than the **TABLE 3.3** value. This pipe condition will cause the flow meter to indicate flow rates that are 7.4% lower than actual flow. To correct the flow readings, enter 1.074.

PART 3 - KEYPAD CONFIGURATION

6. DSP MENU -- DISPLAY MENU

Graphics Display Mode

Allows the selection of a two line or four line display format on the graphics display module.

In 2 Line mode, the display will display flow measurements with larger characters on the top half of the window and smaller standard sized characters on the lower half of the window. In 4 Line mode, the display will display flow measurements with standard sized characters on four lines in the window.

Display Units

DISPLAY UNITS SELECTION

The (soft)SELECT key is used to configure the engineering units on the graphics display—Press the (soft)SELECT key from RUN mode to highlight the engineering unit presently being displayed on the graphics display (pressing the SELECT key multiple times will toggle the highlighted unit from line to line). Use the UP/DOWN ARROW keys to select display units of

- RATE
- TOTALizer
- VELOCITY
- SIGNAL STRENGTH

Back Light Timeout

The LED backlighting on the FDT-81 is used to assist the operator in viewing the display in poorly lit areas—the backlighting, when activated, doubles the power consumption of the flow meter. If left on continuously, the charge in the battery will be depleted much more rapidly than if the backlighting is only activated for short periods of time. If the instrument is being operated while powered from an external power source, the back light may be left on permanently.

Adjust the Back Light Timeout to approximate the amount of seconds that the backlighting should remain active. The time out can be set anywhere between 10 and 30,000 seconds. If continuous backlighting is desired, set the Back Light Timeout to 0 seconds.

APPENDIX

FDT Error Codes

Code Number	Description	Correction
Warnings		
0001	Serial number not present	Hardware serial number has become inoperative – system performance will not be influenced.
0010	Signal Strength is below Signal Strength Cutoff entry	Low signal strength is typically caused by one of the following: <ul style="list-style-type: none"> • Empty pipe • Improper programming/incorrect values • Improper transducer spacing • Non-homogeneous pipe wall
0011	Measured Speed of Sound the in the liquid is greater than 10% different than the value entered during meter setup	Verify that the correct liquid was selected in the BASIC menu. Verify that pipe size parameters are correct.
0020	Heat Flow Units of measure have been selected and an RTD module has not been installed	Verify that the RTD Module has been installed in one of the I/O meter slots. Verify that OUTPUT1 or OUTPUT 2 has been configured for RTD measurements.
Class C Errors		
1001	System tables have changed	Initiate a meter RESET by cycling power or by selecting SYSTEM RESET in the SEC MENU.
1002	System configuration has changed	Initiate a meter RESET by cycling power or by selecting SYSTEM RESET in the SEC MENU.
Class B Errors		
3001	Invalid hardware configuration	Upload corrected file
3002	Invalid system configuration	Upload corrected file
3003	Invalid strategy file	Upload corrected file
3004	Invalid calibration data	Recalibrate the system
3005	Invalid speed of sound calibration data	Upload new data
3006	Bad system tables	Upload new table data
3007	Data Logger is off or not present	If logger is not present, configure I/O port for no logger.
3010	One or more channels are not responding (Multi-channel meters only)	Display indicates which secondary units are not communicating with Master meter. Verify wiring, configuration and address of secondary instrument.
3011	All channels are not responding (Multi-channel meters only)	Verify wiring, configuration and address of secondary instruments.
Class A Errors		
4001	Flash memory full	Return unit to factory for evaluation

Fluid Properties

Fluid	Specific Gravity 20 degrees C	Sound Speed m/s	ft/s	delta-v/degree C m/s/degree C	Kinematic Viscosity Centistokes	Absolute Viscosity Centipoise
Acetate, Butyl		1270	4163.9			
Acetate, Ethyl	0.901	1085	3559.7	4.4	0.489	0.441
Acetate, Methyl	0.934	1211	3973.1		0.407	0.380
Acetate, Propyl		1280	4196.7			
Acetone	0.79	1174	3851.7	4.5	0.399	0.316
Alcohol	0.79	1207	3960.0	4.0	1.396	1.101
Alcohol, Butyl	0.83	1270	4163.9	3.3	3.239	2.688
Alcohol, Ethyl	0.83	1180	3868.9	4	1.396	1.159
Alcohol, Methyl	0.791	1120	3672.1	2.92	0.695	0.550
Alcohol, Propyl		1170	3836.1			
Alcohol, Propyl	0.78	1222	4009.2		2.549	1.988
Ammonia	0.77	1729	5672.6	6.7	0.292	0.225
Aniline	1.02	1639	5377.3	4.0	3.630	3.710
Benzene	0.88	1306	4284.8	4.7	0.711	0.625
Benzol, Ethyl	0.867	1338	4389.8		0.797	0.691
Bromine	2.93	889	2916.7	3.0	0.323	0.946
n-Butane	0.60	1085	3559.7	5.8		
Butyrate, Ethyl		1170	3836.1			
Carbon dioxide	1.10	839	2752.6	7.7	0.137	0.151
Carbon tetrachloride	1.60	926	3038.1	2.5	0.607	0.968
Chloro-benezene	1.11	1273	4176.5	3.6	0.722	0.799
Chloroform	1.49	979	3211.9	3.4	0.550	0.819
Diethyl ether	0.71	985	3231.6	4.9	0.311	0.222
Diethyl Ketone		1310	4295.1			
Diethylene glycol	1.12	1586	5203.4	2.4		
Ethanol	0.79	1207	3960.0	4.0	1.390	1.097
Ethyl alcohol	0.79	1207	3960.0	4.0	1.396	1.101
Ether	0.71	985	3231.6	4.9	0.311	0.222
Ethyl ether	0.71	985	3231.6	4.9	0.311	0.222
Ethylene glycol	1.11	1658	5439.6	2.1	17.208	19.153
Freon R12		774.2	2540			
Gasoline	0.7	1250	4098.4			
Glycerin	1.26	1904	6246.7	2.2	757.100	953.946
Glycol	1.11	1658	5439.6	2.1		
Isobutanol	0.81	1212	3976.4			
Iso-Butane		1219.8	4002			
Isopentane	0.62	980	3215.2	4.8	0.340	0.211
Isopropanol	0.79	1170	3838.6		2.718	2.134
Isopropyl alcohol	0.79	1170	3838.6		2.718	2.134
Kerosene	0.81	1324	4343.8	3.6		
Linalool		1400	4590.2			
Linseed Oil	.925-.939	1770	5803.3			
Methanol	0.79	1076	3530.2	2.92	0.695	0.550
Methyl alcohol	0.79	1076	3530.2	2.92	0.695	0.550
Methylene chloride	1.33	1070	3510.5	3.94	0.310	0.411
Methylethyl Ketone		1210	3967.2			
Motor Oil (SAE 20/30)	.88-.935	1487	4875.4			
Octane	0.70	1172	3845.1	4.14	0.730	0.513
Oil, Castor	0.97	1477	4845.8	3.6	0.670	0.649
Oil, Diesel	0.80	1250	4101			
Oil (Lubricating X200)		1530	5019.9			
Oil (Olive)	0.91	1431	4694.9	2.75	100.000	91.200

Oil (Peanut)	0.94	1458	4783.5			
Paraffin Oil		1420	4655.7			
Pentane	0.626	1020	3346.5		0.363	0.227
Petroleum	0.876	1290	4229.5			
1-Propanol	0.78	1222	4009.2			
Refrigerant 11	1.49	828.3	2717.5	3.56		
Refrigerant 12	1.52	774.1	2539.7	4.24		
Refrigerant 14	1.75	875.24	2871.5	6.61		
Refrigerant 21	1.43	891	2923.2	3.97		
Refrigerant 22	1.49	893.9	2932.7	4.79		
Refrigerant 113	1.56	783.7	2571.2	3.44		
Refrigerant 114	1.46	665.3	2182.7	3.73		
Refrigerant 115		656.4	2153.5	4.42		
Refrigerant C318	1.62	574	1883.2	3.88		
Silicone (30 cp)	0.99	990	3248		30.000	29.790
Toluene	0.87	1328	4357	4.27	0.644	0.558
Transformer Oil		1390	4557.4			
Trichlorethylene		1050	3442.6			
1,1,1-Trichloro-ethane	1.33	985	3231.6		0.902	1.200
Turpentine	0.88	1255	4117.5		1.400	1.232
Water, distilled	0.996	1498	4914.7	-2.4	1.000	0.996
Water, heavy	1	1400	4593			
Water, sea	1.025	1531	5023	-2.4	1.000	1.025
Wood Alcohol	0.791	1076	3530.2	2.92	0.695	0.550
m-Xylene	0.868	1343	4406.2		0.749	0.650
o-Xylene	0.897	1331.5	4368.4	4.1	0.903	0.810
p-Xylene		1334	4376.8		0.662	

Digital Communications Protocol for FDT Flow Meters

Host protocol

A digital communications protocol is utilized. Each message is guarded with the standard CRC-16 error detection (C source code is included)

The host protocol is a master-slave type protocol with the flow meter being the slave. The messages have the following format:

<addr><command><data>...<data><crc-16>

A unit may be assigned an address that responds to (valid addresses are 1-7E). All devices respond to address 7F (ie. this address may not be used for multidrop) and all devices listen to address 0 but do not respond (this is the "broadcast" address).

The following special commands are defined:

Command	Description
65	Special "short" commands
66	Special "long" commands

Command 65 allows up to 255 data items to be transferred while command 66 allows up to 65535 items (The actual maximum size is limited by the memory allocated for the communication buffers and for TOF it is 2048 bytes). There is special encoding for the data for commands 65 and 66 as follows:

Command 65:

<size><code><data₁>...<data_{N-1}> N = <size>

Command 66:

<size_h><size_l><code><data₁>...<data_{N-1}> N = <size_h>*256 + <size_l>

The target device will respond the same for both 65 and 66 commands. The host program needs to make sure that the proper opcode will be used based on the data size requested.

In case of an error, the target will reject the message by replying with an error code. The target will not reply to an ill-formed command (ie. incomplete or CRC-16 error). The error reply is:

<addr><opcode><errorcode><crc-16>

where:

<opcode> is the requested opcode with the Most Significant bit turned on.

The following error codes are defined:

Error Code	Description
1	Bad Command (Invalid command)
2	Bad Command Data
71h	Command not allowed.
72h	Buffer overflow (data exceeded internal allocated memory)
73h	Command not implemented in this version

Special codes

The following special 65 and 66 codes are supported.

Code	Description
00	Echo (for comm debugging)
0A	Read run time data (signal strength, flow rate and totalizers)
0B	Reset Totalizers

Code 00 – Echo

Command: <addr>65<size>00<data₁>...<data_n><crc-16>

Reply: <addr>65<size>00<data₁>...<data_n><crc-16>

Code 0A – Read Flow data

Command: <addr>65010A<crc-16>

Reply: <addr>65210A<data₁>...<data_n><crc-16>

The data section of the reply contains the byte stream representation of the flow data as follows (all numbers use the Intel format – ie. Least significant byte first):

Byte	Type	Description
0-1	2 byte integer	Signal Strength (0-1000)
2-9	8 byte floating point	Current flow rate in the units programmed
10-17	8 byte floating point	Net Totalizer in the units programmed
18-25	8 byte floating point	Positive Totalizer
26-33	8 byte floating point	Negative Totalizer

Code 0A Extension 1 - Read Extra Flow data

Command: <addr>65020A01<crc-16>

Reply: <addr>65220A01<data₁>...<data_n><crc-16>

The data section of the reply contains the byte stream representation of the flow data as follows (all numbers use the Intel format – ie. Least significant byte first):

Byte	Type	Description
0-1	2 byte integer	Signal Strength (0-1000)
2-9	8 byte floating point	Current flow rate in the units programmed
10-17	8 byte floating point	Net Totalizer in the units programmed
18-25	8 byte floating point	Positive Totalizer
26-33	8 byte floating point	Negative Totalizer
34-41	8 byte floating point	Temp 1 in deg C
42-49	8 byte floating point	Temp 2 in deg C

Code 0B – Reset Totalizers

Command: <addr>65010B<crc-16>

Reply: <addr>65010B<crc-16>

C Source Code

Flow Data Definition

```
struct FLOWDATA
{
    short      sSignalStrength;
    double     dCurFlowRate;
    double     dNetTotalizer;
    double     dPositiveTotalizer;
    double     dNegativeTotalizer;
};

struct FLOWDATA_EX
{
    short      sSignalStrength;
    double     dCurFlowRate;
    double     dNetTotalizer;
    double     dPositiveTotalizer;
    double     dNegativeTotalizer;
    double     dTemp1;
    double     dTemp2;
};
```

CRC-16 Calculations

```
unsigned short crc_table[256] = {
    0x0000, 0xC0C1, 0xC181, 0x0140, 0xC301, 0x03C0, 0x0280, 0xC241,
    0xC601, 0x06C0, 0x0780, 0xC741, 0x0500, 0xC5C1, 0xC481, 0x0440,
    0xCC01, 0x0CC0, 0x0D80, 0xCD41, 0x0F00, 0xCFC1, 0xCE81, 0x0E40,
    0x0A00, 0xCAC1, 0xCB81, 0x0B40, 0xC901, 0x09C0, 0x0880, 0xC841,
    0xD801, 0x18C0, 0x1980, 0xD941, 0x1B00, 0xDBC1, 0xDA81, 0x1A40,
    0x1E00, 0xDEC1, 0xDF81, 0x1F40, 0xDD01, 0x1DC0, 0x1C80, 0xDC41,
    0x1400, 0xD4C1, 0xD581, 0x1540, 0xD701, 0x17C0, 0x1680, 0xD641,
    0xD201, 0x12C0, 0x1380, 0xD341, 0x1100, 0xD1C1, 0xD081, 0x1040,
    0xF001, 0x30C0, 0x3180, 0xF141, 0x3300, 0xF3C1, 0xF281, 0x3240,
    0x3600, 0xF6C1, 0xF781, 0x3740, 0xF501, 0x35C0, 0x3480, 0xF441,
    0x3C00, 0xFCC1, 0xFD81, 0x3D40, 0xFF01, 0x3FC0, 0x3E80, 0xFE41,
    0xFA01, 0x3AC0, 0x3B80, 0xFB41, 0x3900, 0xF9C1, 0xF881, 0x3840,
    0x2800, 0xE8C1, 0xE981, 0x2940, 0xEB01, 0x2BC0, 0x2A80, 0xEA41,
    0xEE01, 0x2EC0, 0x2F80, 0xEF41, 0x2D00, 0xEDC1, 0xEC81, 0x2C40,
    0xE401, 0x24C0, 0x2580, 0xE541, 0x2700, 0xE7C1, 0xE681, 0x2640,
    0x2200, 0xE2C1, 0xE381, 0x2340, 0xE101, 0x21C0, 0x2080, 0xE041,
    0xA001, 0x60C0, 0x6180, 0xA141, 0x6300, 0xA3C1, 0xA281, 0x6240,
    0x6600, 0xA6C1, 0xA781, 0x6740, 0xA501, 0xA5C1, 0xA481, 0x6441,
    0x6C00, 0xACC1, 0xAD81, 0x6D40, 0xAF01, 0x6FC0, 0x6E80, 0xAE41,
    0xAA01, 0x6AC0, 0x6B80, 0xAB41, 0x6900, 0xA9C1, 0xA881, 0x6840,
    0x7800, 0xB8C1, 0xB981, 0x7940, 0xBB01, 0x7BC0, 0x7A80, 0xBA41,
    0xBE01, 0x7EC0, 0x7F80, 0xBF41, 0x7D00, 0xBDC1, 0xBC81, 0x7C40,
    0xB401, 0x74C0, 0x7580, 0xB541, 0x7700, 0xB7C1, 0xB681, 0x7640,
    0x7200, 0xB2C1, 0xB381, 0x7340, 0xB101, 0x71C0, 0x7080, 0xB041,
    0x5000, 0x90C1, 0x9181, 0x5140, 0x9301, 0x53C0, 0x5280, 0x9241,
    0x9601, 0x56C0, 0x5780, 0x9741, 0x5500, 0x95C1, 0x9481, 0x5440,
    0x9C01, 0x5CC0, 0x5D80, 0x9D41, 0x5F00, 0x9FC1, 0x9E81, 0x5E40,
    0x5A00, 0x9AC1, 0x9B81, 0x5B40, 0x9901, 0x99C0, 0x9880, 0x9841,
    0x8801, 0x48C0, 0x4980, 0x8941, 0x4B00, 0x8BC1, 0x8A81, 0x4A40,
    0x4E00, 0x8EC1, 0x8F81, 0x4F40, 0x8D01, 0x4DC0, 0x4C80, 0x8C41,
```

```
    0x4400, 0x84C1, 0x8581, 0x4540, 0x8701, 0x47C0, 0x4680, 0x8641,  
    0x8201, 0x42C0, 0x4380, 0x8341, 0x4100, 0x81C1, 0x8081, 0x4040,  
};
```

```
unsigned short    calculate_crc(const unsigned char *pv, int size)  
{  
    unsigned short crc = 0xFFFF;  
  
    for ( ;size-- ; pv++)  
    {  
        crc = (crc >> 8) ^ crc_table[(crc ^ *pv) & 0xFF];  
    }  
  
    return crc;  
}
```

Standard Classes

CLASS A				CLASS B			CLASS C			CLASS D			CLASS E			CLASS F			CLASS G			CLASS H													
Size (Inches)	O.D. Inch	I.D. Inch	Wall	O.D. Inch	I.D. Inch	Wall	O.D. Inch	I.D. Inch	Wall	O.D. Inch	I.D. Inch	Wall	O.D. Inch	I.D. Inch	Wall	O.D. Inch	I.D. Inch	Wall	O.D. Inch	I.D. Inch	Wall	O.D. Inch	I.D. Inch	Wall											
3	3.80	3.02	0.39	3.96	3.12	0.42	3.96	3.06	0.45	3.96	3.00	0.48																							
4	4.80	3.96	0.42	5.00	4.10	0.45	5.00	4.04	0.48	5.00	3.96	0.52																							
6	6.90	6.02	0.44	7.10	6.14	0.48	7.10	6.08	0.51	7.10	6.00	0.55												7.22	6.06	0.58	7.22	6.00	0.61	7.38	6.08	0.65	7.38	6.00	0.69
8	9.05	8.13	0.46	9.05	8.03	0.51	9.30	8.18	0.56	9.30	8.10	0.60												9.42	8.10	0.66	9.42	8.10	0.66	9.60	8.10	0.75	9.60	8.00	0.8
10	11.10	10.10	0.50	11.10	9.96	0.57	11.40	10.16	0.62	11.40	10.04	0.68	11.60	10.12	0.74	11.60	10.00	0.80	11.84	10.12	0.86	11.84	10.00	0.92											
12	13.20	12.12	0.54	13.20	11.96	0.62	13.50	12.14	0.68	13.50	12.00	0.75	13.78	12.14	0.82	13.78	12.00	0.89	14.08	12.14	0.97	14.08	12.00	1.04											
14	15.30	14.16	0.57	15.30	13.98	0.66	15.65	14.17	0.74	15.65	14.01	0.82	15.98	14.18	0.90	15.98	14.00	0.99	16.32	14.18	1.07	16.32	14.00	1.16											
16	17.40	16.20	0.60	17.40	16.00	0.70	17.80	16.20	0.80	17.80	16.02	0.89	18.16	16.20	0.98	18.16	16.00	1.08	18.54	16.18	1.18	18.54	16.00	1.27											
18	19.50	18.22	0.64	19.50	18.00	0.75	19.92	18.18	0.87	19.92	18.00	0.96	20.34	18.20	1.07	20.34	18.00	1.17	20.78	18.22	1.28	20.78	18.00	1.39											
20	21.60	20.26	0.67	21.60	20.00	0.80	22.06	20.22	0.92	22.06	20.00	1.03	22.54	20.24	1.15	22.54	20.00	1.27	23.02	20.24	1.39	23.02	20.00	1.51											
24	25.80	24.28	0.76	25.80	24.02	0.89	26.32	24.22	1.05	26.32	24.00	1.16	26.90	24.28	1.31	26.90	24.00	1.45	27.76	24.26	1.75	27.76	24.00	1.88											
30	31.74	29.98	0.88	32.00	29.94	1.03	32.40	30.00	1.20	32.74	30.00	1.37	33.10	30.00	1.55	33.46	30.00	1.73																	
36	37.96	35.98	0.99	38.30	36.00	1.15	38.70	35.98	1.36	39.16	36.00	1.58	39.60	36.00	1.80	40.04	36.00	2.02																	
42	44.20	42.00	1.10	44.50	41.94	1.28	45.10	42.02	1.54	45.58	42.02	1.78																							
48	50.50	47.98	1.26	50.80	47.96	1.42	51.40	47.98	1.71	51.98	48.00	1.99																							
54	56.66	53.96	1.35	57.10	54.00	1.55	57.80	54.00	1.90	58.40	53.94	2.23																							
60	62.80	60.02	1.39	63.40	60.06	1.67	64.20	60.20	2.00	64.82	60.06	2.38																							
72	75.34	72.10	1.62	76.00	72.10	1.95	76.88	72.10	2.39																										
84	87.54	84.10	1.72	88.54	84.10	2.22																													

Ductile Iron Pipe

Standard Classes

Pipe Size (inches)	Outside Diameter (inches)	Class 50		Class 51		Class 52		Class 53		Class 54		Class 55		Class 56		Cement Lining Std./Double Thickness
		ID	Wall	ID	Wall	ID	Wall	ID	Wall	ID	Wall	ID	Wall	ID	Wall	
3	3.96			3.46	0.25	3.40	0.28	3.34	0.31	3.28	0.34	3.22	0.37	3.14	0.41	.123/.250
4	4.80			4.28	0.26	4.22	0.29	4.16	0.32	4.10	0.35	4.04	0.38	3.93	0.44	
6	6.90	6.40	0.25	6.34	0.28	6.28	0.31	6.22	0.34	6.16	0.37	6.10	0.40	6.04	0.43	
8	9.05	8.51	0.27	8.45	0.30	8.39	0.33	8.33	0.36	8.27	0.39	8.21	0.42	8.15	0.45	
10	11.10	10.32	0.39	10.46	0.32	10.40	0.35	10.34	0.38	10.28	0.41	10.22	0.44	10.16	0.47	
12	13.20	12.58	0.31	12.52	0.34	12.46	0.37	12.40	0.40	12.34	0.43	12.28	0.46	12.22	0.49	
14	15.30	14.64	0.33	14.58	0.36	14.52	0.39	14.46	0.42	14.40	0.45	14.34	0.48	14.28	0.51	.1875/.375
16	17.40	16.72	0.34	16.66	0.37	16.60	0.40	16.54	0.43	16.48	0.46	16.42	0.49	16.36	0.52	
18	19.50	18.80	0.35	18.74	0.38	18.68	0.41	18.62	0.44	18.56	0.47	18.50	0.50	18.44	0.53	
20	21.60	20.88	0.36	20.82	0.39	20.76	0.42	20.70	0.45	20.64	0.48	20.58	0.51	20.52	0.54	
24	25.80	25.04	0.38	24.98	0.41	24.92	0.44	24.86	0.47	24.80	0.50	24.74	0.53	24.68	0.56	
30	32.00	31.22	0.39	31.14	0.43	31.06	0.47	30.98	0.51	30.90	0.55	30.82	0.59	30.74	0.63	.250/.500
36	38.30	37.44	0.43	37.34	0.48	37.06	0.62	37.14	0.58	37.40	0.45	36.94	0.68	36.84	0.73	
42	44.50	43.56	0.47	43.44	0.53	43.32	0.59	43.20	0.65	43.08	0.71	42.96	0.77	42.84	0.83	
48	50.80	49.78	0.51	49.64	0.58	49.50	0.65	49.36	0.72	49.22	0.79	49.08	0.86	48.94	0.93	
54	57.10	55.96	0.57	55.80	0.65	55.64	0.73	55.48	0.81	55.32	0.89	55.16	0.97	55.00	1.05	

Steel, Stainless Steel, P.V.C.

Standard Schedules

Nominal Pipe Size Inches	OUTSIDE DIAMETER	SCH. 5		SCH. 10 (LTWALL)		SCH. 20		SCH. 30		STD.		SCH. 40		SCH. 60		X STG.		SCH. 80		SCH. 100		SCH. 120		SCH. 140		SCH. 180	
		ID	Wall	ID	Wall	ID	Wall	ID	Wall	ID	Wall	ID	Wall	ID	Wall	ID	Wall	ID	Wall	ID	Wall	ID	Wall	ID	Wall	ID	Wall
1	1.315	1.185	0.065	1.097	0.109					1.049		1.049	0.133			0.957	0.179	0.957	0.179							0.815	0.250
1.25	1.660	1.530	0.065	1.442	0.109					1.380		1.380	0.140			1.278	0.191	1.278	0.191							1.160	0.250
1.5	1.900	1.770	0.065	1.682	0.109					1.610		1.610	0.145			1.500	0.200	1.500	0.200							1.338	0.281
2	2.375	2.245	0.065	2.157	0.109					2.067		2.067	0.154			1.939	0.218	1.939	0.218							1.687	0.344
2.5	2.875	2.709	0.083	2.635	0.120					2.469		2.469	0.203			2.323	0.276	2.323	0.276							2.125	0.375
3	3.500	3.334	0.083	3.260	0.120					3.068		3.068	0.216			2.900	0.300	2.900	0.300							2.624	0.438
3.5	4.000	3.834	0.083	3.760	0.120					3.548		3.548	0.226			3.364	0.318	3.364	0.318								
4	4.500	4.334	0.083	4.260	0.120					4.026	0.237	4.026	0.237			3.826	0.337	3.826	0.337			3.624	0.438	3.624	0.438	3.438	0.531
5	5.563	5.345	0.109	5.295	0.134					5.047	0.258	5.047	0.258			4.813	0.375	4.813	0.375			4.563	0.500	4.563	0.500	4.313	0.625
6	6.625	6.407	0.109	6.357	0.134					6.065	0.280	6.065	0.280			5.761	0.432	5.761	0.432			5.501	0.562	5.501	0.562	5.187	0.719
8	8.625	8.407	0.109	8.329	0.148	8.125	0.250	8.071	0.277	7.981	0.322	7.981	0.322	7.813	0.406	7.625	0.500	7.625	0.500	7.437	0.594	7.187	0.719	7.187	0.719	6.183	1.221
10	10.750	10.482	0.134	10.42	0.165	10.25	0.250	10.13	0.310	10.02	0.365	10.020	0.365	9.750	0.500	9.750	0.500	9.562	0.594	9.312	0.719	9.062	0.844	9.062	0.844	8.500	1.125
12	12.750	12.420	0.165	12.39	0.180	12.25	0.250	12.09	0.330	12.00	0.375	11.938	0.406	11.626	0.562	11.750	0.500	11.370	0.690	11.060	0.845	10.750	1.000	10.750	1.000	10.120	1.315
14	14.000			13.50	0.250	13.37	0.315	13.25	0.375	13.25	0.375	13.124	0.438	12.814	0.593	13.000	0.500	12.500	0.750	12.310	0.845	11.810	1.095	11.810	1.095	11.180	1.410
16	16.000			15.50	0.250	15.37	0.315	15.25	0.375	15.25	0.375	15.000	0.500	14.688	0.656	15.000	0.500	14.310	0.845	13.930	1.035	13.560	1.220	13.560	1.220	12.810	1.595
18	18.000			17.50	0.250	17.37	0.315	17.12	0.440	17.25	0.375	16.876	0.562	16.564	0.718	17.000	0.500	16.120	0.940	15.680	1.160	15.250	1.375	15.250	1.375	14.430	1.785
20	20.000			19.50	0.250	19.25	0.375	19.25	0.375	19.25	0.375	18.814	0.593	18.376	0.812	19.000	0.500	17.930	1.035	17.430	1.285	17.000	1.500	17.000	1.500	16.060	1.970
24	24.000			23.50	0.250	23.25	0.375	23.25	0.375	23.25	0.375	22.626	0.687	22.126	0.937	23.000	0.500	21.560	1.220	20.930	1.535	20.930	1.535	20.930	1.535	19.310	2.345
30	30.000			29.37	0.315	29.00	0.500	29.00	0.500	29.25	0.375	29.250	0.375			29.000	0.500										
36	36.000			35.37	0.315	35.00	0.500	35.00	0.500	35.25	0.375	35.250	0.375			35.000	0.500										
42	42.000									41.25	0.375	41.250	0.375			41.000	0.500										
48	48.000									47.25	0.375	47.250	0.375			47.000	0.500										

FPS TO GPM CROSS - REFERENCE (Schedule 40)

Nominal Pipe (Inches)	I.D. INCH	1	1.5	2	2.5	3	3.5	4	4.5	5	5.5	6	6.5	7	7.5	8	8.5	9
1	1.05	2.6989	4.0484	5.3978	6.7473	8.097	9.4462	10.796	12.145	13.490	14.844	16.190	17.540	18.890	20.240	21.590	22.941	24.290
1.25	1.38	4.6620	6.9929	9.3239	11.655	13.99	16.317	18.648	20.979	23.310	25.641	27.970	30.300	32.630	34.960	37.300	39.627	41.958
1.5	1.61	6.3454	9.5182	12.691	15.864	19.04	22.209	25.382	28.555	31.730	34.900	38.070	41.250	44.420	47.590	50.760	53.936	57.109
2	2.07	10.489	15.734	20.979	26.224	31.47	36.713	41.958	47.202	52.450	57.692	62.940	68.180	73.430	78.670	83.920	89.160	94.405
2.5	2.47	14.935	22.402	29.870	37.337	44.80	52.272	59.740	67.207	74.670	82.142	89.610	97.080	104.50	112.00	119.50	126.95	134.41
3	3.07	23.072	34.608	46.144	57.680	69.22	80.752	92.288	103.82	115.40	126.90	138.40	150.00	161.50	173.00	184.60	196.11	207.65
3.5	3.55	30.851	46.276	61.702	77.127	92.55	107.98	123.40	138.83	154.30	169.68	185.10	200.50	216.00	231.40	246.80	262.23	277.66
4	4.03	39.758	59.636	79.515	99.394	119.3	139.15	159.03	178.91	198.80	218.67	238.50	258.40	278.30	298.20	318.10	337.94	357.82
5	5.05	62.430	93.645	124.86	156.07	187.3	218.50	249.72	280.93	312.10	343.36	374.60	405.80	437.00	468.20	499.40	530.65	561.87
6	6.06	89.899	134.85	179.80	224.75	269.7	314.65	359.60	404.55	449.50	494.45	539.40	584.30	629.30	674.20	719.20	764.14	809.09
8	7.98	155.89	233.83	311.78	389.72	467.7	545.61	623.56	701.50	779.40	857.39	935.30	1013.0	1091.0	1169.0	1247.0	1325.1	1403.0
10	10.02	245.78	368.67	491.56	614.45	737.3	860.23	983.12	1106.0	1229.0	1351.8	1475.0	1598.0	1720.0	1843.0	1966.0	2089.1	2212.0
12	11.94	348.99	523.49	697.99	872.49	1047.0	1221.5	1396.0	1570.5	1745.0	1919.5	2094.0	2268.0	2443.0	2617.0	2792.0	2966.5	3141.0
14	13.13	422.03	633.04	844.05	1055.1	1266.0	1477.1	1688.1	1899.1	2110.0	2321.1	2532.0	2743.0	2954.0	3165.0	3376.0	3587.2	3798.2
16	15.00	550.80	826.20	1101.6	1377.0	1652.0	1927.8	2203.2	2478.6	2754.0	3029.4	3305.0	3580.0	3856.0	4131.0	4406.0	4681.8	4957.2

FPS TO GPM: $GPM = (PIPE\ ID)^2 \times VELOCITY\ IN\ FPS \times 2.45$

GPM TO FPS: $FPS = \frac{GPM}{(ID)^2 \times 2.45}$

FPS X .3048 = MPS

GPM X .0007 = GPD

GPM X 3.7878 = LPM

FPS TO GPM CROSS - REFERENCE (Schedule 40)

Nominal Pipe (Inches)	I.D. INCH	1	1.5	2	2.5	3	3.5	4	4.5	5	5.5	6	6.5	7	7.5	8	8.5	9
18	16.88	697.52	1046.3	1395.0	1743.8	2093.0	2441.3	2790.1	3138.8	3488.0	3836.3	4185.0	4534.0	4883.0	5231.0	5580.0	5928.9	6277.7
20	18.81	866.14	1299.0	1732.0	2165.3	2598.4	3031.5	3464.6	3897.6	4330.7	4763.8	5196.8	5629.9	6063.0	6496.0	6929.1	7362.2	7795.3
24	22.63	1253.7	1880.0	2507.0	3134.1	3761.0	4387.8	5014.6	5641.5	6268.3	6895.1	7522.0	8148.8	8775.6	9402.4	10029	10656	11283
26	25.25	1560.7	2341.0	3121.0	3901.9	4682.2	5462.6	6243.0	7023.4	7803.7	8584.1	9364.5	10145	10925	11706	12486	13266	14047
28	27.25	1817.8	2727.0	3636.0	4544.5	5453.4	6362.3	7271.2	8180.0	9088.9	9997.8	10907	11816	12725	13633	14542	15451	16360
30	29.25	2094.4	3142.0	4189.0	5236.0	6283.2	7330.4	8377.6	9424.9	10472	11519	12566	13614	14661	15708	16755	17803	18850
32	31.25	2390.6	3586.0	4781.0	5976.5	7171.9	8367.2	9562.5	10758	11953	13148	14344	15539	16734	17930	19125	20320	21516
34	33.25	2706.4	4060.0	5413.0	6766.0	8119.2	9472.4	10826	12179	13532	14885	16238	17592	18945	20298	21651	23004	24358
36	35.25	3041.8	4563.0	6084.0	7604.5	9125.4	10646	12167	13688	15209	16730	18251	19772	21292	22813	24334	25855	27376
42	41.25	4165.4	6248.0	8331.0	10414	12496	14579	16662	18744	20827	22910	24992	27075	29158	31241	33323	35406	37489
48	47.99	5637.8	8457.0	11276	14095	16913	19732	22551	25370	28189	31008	33827	36646	39465	42284	45103	47922	50740
54	53.98	7133.1	10700	14266	17833	21399	24966	28532	32099	35665	39232	42798	46365	49931	53498	57065	60631	64198
60	60.09	8839.2	13259	17678	22098	26518	30937	35357	39777	44196	48616	53035	57455	61875	66294	70714	75134	79553
72	72.10	12726	19089	25451	31814	38177	44540	50903	57266	63628	69991	76354	82717	89080	95443	101805	108168	114531
84	84.10	17314	25971	34628	43285	51943	60600	69257	77914	86571	95228	103885	112542	121199	129856	138514	147171	155828

FPS TO GPM: $GPM = (PIPE\ ID)^2 \times VELOCITY\ IN\ FPS \times 2.45$

GPM TO FPS: $FPS = \frac{GPM}{(ID)^2 \times 2.45}$

FPS X .3048 = MPS

GPM X .0007 = GPD

GPM X 3.7878 = LPM

Addendum — Heat Flow

FDT Heat Flow

General

The FDT flow meter with the optional heat flow module installed is designed to measure the rate and quantity of heat delivered to a given building, area or heat exchanger. The instrument measures the volumetric flow rate of the heat exchanger liquid (water, water/glycol mixture, brine, etc.), the temperature at the inlet pipe and the temperature at the outlet pipe. Heat delivery is calculated by the following equation:

$$\text{Rate of heat delivery} = Q \cdot (T_{in} - T_{out}) \cdot c$$

Where

Q	=	volumetric flow rate
T _{in}	=	temperature at the inlet
T _{out}	=	temperature at the outlet
c	=	specific heat of the liquid

The RTD module installed in the FDT measures the differential temperature of two 1000-ohm three-wire platinum RTDs. The three-wire configuration allows the temperature sensors to be located several hundred feet away from the FDT meter without influencing system accuracy or stability. The FDT transit time flow meter can also tolerate large distances between the flow measurement transducers and the electronic instrument.

The RTDs included with the FDT heat delivered flow meter have been factory calibrated and are marked with an identification as to which terminal, #1 or #2, the RTD has been calibrated. The RTDs are 1000-ohm platinum and are designed to be mounted on the exterior surface of the pipe. The RTDs are rated for a temperature range of -50 to +130 C.

Installation

1. Follow the instructions outlined in the standard FDT manual for proper installation of the flow measurement transducers. After installation, verify that the Signal Strength is greater than 4-5% and, if possible, perform a Zero flow calibration on the pipe. Please note that all readings require a full pipe of liquid.
2. Select areas on the inlet and outlet pipes where the RTDs will be mounted. Remove or peel back the insulation all the way around the pipe in the installation area. Clean an area slightly larger than the RTD down to bare metal on the pipe.

3. Place a small amount of heat sink compound on the pipe in the RTD installation location. See Figure 1. Press the RTD firmly into the compound. Fasten the RTD to the pipe with the included heater tape.
4. Route the RTD wires to an electrical junction box in close proximity to the installation location. Secure the RTD wires such that they will not be pulled on or abraded inadvertently. Replace the insulation on the pipe.
5. Route a cable from the electrical junction box back to the FDT flow meter. Connect the RTDs as illustrated in Figure 2. Note that the SNS1 and DRV1 wires originate from the same location on the RTD.




Figure 1

Transmitter Programming

1. The RTDs included with the FDT heat delivered flow meter have been factory calibrated and are marked with an identification as to which terminal, #1 or #2, the RTD has been calibrated. If recalibration of the RTDs is required or RTDs other than those supplied with the FDT are being utilized, the UltraLink software utility will be required. UltraLink can also be used to configure all operating parameters of the heat flow instrument.
2. To properly measure heat delivery, the specific heat capacity of the liquid must be entered. When a liquid is chosen from the FL TYPE list, a default specific heat will be loaded. This default value is displayed as SP HEAT in the BASIC MENU. If the actual specific heat of the liquid is known or if it differs from the default value, press the ENTER key and modify the value. Press the enter key to save the value. See the values listed in Tables 1 and 2 for specific values. Enter a value that is the mean of both pipes.




Figure 2

3. The RATE UNIT can be displayed as three different values; BTUs, CALs or Watts. Select the proper unit from the RATE UNIT list. Select the appropriate RATE INTERVAL from the list (seconds, minutes, hours, days). Be aware that the instrument can only display values as large as 99,999,999.
4. Select an appropriate TOTALIZER UNIT from the list; BTU, CAL, Watt.
5. In the SER MENU three values can be displayed that may aid in troubleshooting the heatflow instrument. In this menu, the temperature being read by RTD1 is indicated as TEMP1 (all values are degrees Celsius) , RTD2 as TEMP2 and the absolute difference as TEMPDIFF.

Table 1—Heat Capacity of Water

In the following table the unit is $\text{J g}^{-1} \text{ }^{\circ}\text{C}^{-1}$.

$^{\circ}\text{C}$	0	1	2	3	4	5	6	7	8	9
0	4.2174	4.2138	4.2104	4.2074	4.2045	4.2019	4.1996	4.1974	4.1954	4.1936
10	4.1919	4.1904	4.1890	4.1877	4.1866	4.1855	4.1846	4.1837	4.1829	4.1822
20	4.1816	4.1810	4.1805	4.1801	4.1797	4.1793	4.1790	4.1787	4.1785	4.1783
30	4.1782	4.1781	4.1780	4.1780	4.1779	4.1779	4.1780	4.1780	4.1781	4.1782
40	4.1783	4.1784	4.1786	4.1788	4.1789	4.1792	4.1794	4.1796	4.1799	4.1801
50	4.1804	4.1807	4.1811	4.1814	4.1817	4.1821	4.1825	4.1829	4.1833	4.1837
60	4.1841	4.1846	4.1850	4.1855	4.1860	4.1865	4.1871	4.1876	4.1882	4.1887
70	4.1893	4.1899	4.1905	4.1912	4.1918	4.1925	4.1932	4.1939	4.1946	4.1954
80	4.1961	4.1969	4.1977	4.1985	4.1994	4.2002	4.2011	4.2020	4.2029	4.2039
90	4.2048	4.2058	4.2068	4.2078	4.2089	4.2100	4.2111	4.2122	4.2133	4.2145

Table 2—Heat Capacity of Liquids

Liquids	
Alcohol, amyl	18
„ ethyl	0
„ „	40
„ methyl	12
Aniline	15
Benzene	10
„	40
Brine	20
Brine†	0
„	15
Ether, ethyl	18
Glycerine	18-50
Oil, castor	20
Oil, linseed	20
„ olive	7
„ paraffin	20-60
„ rape	20
„ sperm	20
Sea-water	17
Toluene	18
Turpentine	18

WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **13 months** from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal **one (1) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components in which wear is not warranted, include but are not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by the company will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

RETURN REQUESTS/INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of the product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 2008 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.

Where Do I Find Everything I Need for Process Measurement and Control? **OMEGA...Of Course!**

Shop online at omega.comSM

TEMPERATURE

- ☑ Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- ☑ Wire: Thermocouple, RTD & Thermistor
- ☑ Calibrators & Ice Point References
- ☑ Recorders, Controllers & Process Monitors
- ☑ Infrared Pyrometers

PRESSURE, STRAIN AND FORCE

- ☑ Transducers & Strain Gages
- ☑ Load Cells & Pressure Gages
- ☑ Displacement Transducers
- ☑ Instrumentation & Accessories

FLOW/LEVEL

- ☑ Rotameters, Gas Mass Flowmeters & Flow Computers
- ☑ Air Velocity Indicators
- ☑ Turbine/Paddlewheel Systems
- ☑ Totalizers & Batch Controllers

pH/CONDUCTIVITY

- ☑ pH Electrodes, Testers & Accessories
- ☑ Benchtop/Laboratory Meters
- ☑ Controllers, Calibrators, Simulators & Pumps
- ☑ Industrial pH & Conductivity Equipment

DATA ACQUISITION

- ☑ Data Acquisition & Engineering Software
- ☑ Communications-Based Acquisition Systems
- ☑ Plug-in Cards for Apple, IBM & Compatibles
- ☑ Datalogging Systems
- ☑ Recorders, Printers & Plotters

HEATERS

- ☑ Heating Cable
- ☑ Cartridge & Strip Heaters
- ☑ Immersion & Band Heaters
- ☑ Flexible Heaters
- ☑ Laboratory Heaters

ENVIRONMENTAL MONITORING AND CONTROL

- ☑ Metering & Control Instrumentation
- ☑ Refractometers
- ☑ Pumps & Tubing
- ☑ Air, Soil & Water Monitors
- ☑ Industrial Water & Wastewater Treatment
- ☑ pH, Conductivity & Dissolved Oxygen Instruments