



# OM-CP-PRTEMP1000IS-A2

## Intrinsically Safe Pressure and Temperature Data Logger

INSTRUCTION  
SHEET

MQS5101/0920

Shop online at [omega.com](http://omega.com)<sup>SM</sup> e-mail: [info@omega.com](mailto:info@omega.com)  
For latest product manuals: [www.omegamanual.info](http://www.omegamanual.info)



## Product Notes

### Getting Started

To access the COM Port for the interface cable, unscrew the key-ring end cap. Ensure the end cap is screwed on tightly before deploying the data logger.

### Intrinsic Safety Approval

The OM-CP-PRTEMP1000IS-A2 has been certified as Intrinsically Safe (IS) certification in accordance with the latest issue of FM3600 and FM3610.

### Certified Intrinsically Safe for:

- Class 1 Division 1 Group ABCD
- Class 1 Division 2 Group ABCD
- Temperature Class: T4A

### Operational Warnings

- When used in hazardous locations, the OM-CP-PRTEMP1000IS-A2 is to be installed prior to the location becoming hazardous and removed only after the area is no longer hazardous.
- The maximum allowed ambient temperature for the OM-CP-PRTEMP1000IS-A2 (under any circumstances) is 80 °C. The minimum rated operating temperature is -40 °C.
- The OM-CP-PRTEMP1000IS-A2 is approved for use only with the OM-CP-BAT102 battery. Replacement with any other battery will void the safety rating.
- Batteries are user replaceable, but are to be removed or replaced only in locations known to be non-hazardous.
- Tampering or replacement of non-factory components may adversely affect the safe use of the product, and is prohibited. Except for replacement of the battery, the user may not service the OM-CP-PRTEMP1000IS-A2. Omega or an authorized representative must perform all other service to the product.

### Pressure Sensor

To use the pressure sensor for gauge measurements, screw the ¼ inch male NPT fitting into the pipe to be measured with a ⅝ inch wrench.

### O-Rings

O-ring maintenance is a key factor when properly caring for the OM-CP-PRTEMP1000IS-A2. The O-rings ensure a tight seal and prevent liquid from entering the inside of the device.

## Installation Guide

### Installing the software

Insert the Omega Software Flash Drive in an open USB port. If the autorun does not appear, locate the drive on the computer and double click on **Autorun.exe**. Follow the instructions provided in the Installation Wizard.

### Installing the Interface cable

- OM-CP-IFC200 (required, sold separately)  
Insert the device into a USB port. The drivers will install automatically.

## Device Operation

### Connecting and Starting the data logger

1. Once the software is installed and running, plug the interface cable into the data logger.
2. Connect the USB end of the interface cable into an open USB port on the computer.
3. The device will appear in the **Connected Devices** list, highlight the desired data logger.
4. For most applications, select **“Custom Start”** from the menu bar and choose the desired start method, reading rate and other parameters appropriate for the data logging application and click **“Start”**. (**“Quick Start”** applies the most recent custom start options, **“Batch Start”** is used for managing multiple loggers at once, **“Real Time Start”** stores the dataset as it records while connected to the logger.)
5. The status of the device will change to **“Running”**, **“Waiting to Start”** or **“Waiting to Manual Start”**, depending upon your start method.
6. Disconnect the data logger from the interface cable and place it in the environment to measure.

*Note: The device will stop recording data when the end of memory is reached or the device is stopped. At this point the device cannot be restarted until it has been re-armed by the computer.*

### Downloading data from a data logger

1. Highlight the data logger in the Connected Devices list. Click **“Stop”** on the menu bar.
2. Once the data logger is stopped, with the logger highlighted, click **“Download”**.
3. Downloading will offload and save all the recorded data to the PC.

## Product Maintenance

### Battery Replacement

**Materials:**  $\frac{9}{16}$  inch (15mm) wrench, small needle nose pliers and a replacement Battery (OM-CP-BAT102)

1. Move the device to a non-hazardous location before replacing battery.
2. Observe Operational Warnings when removing and replacing the battery.
3. Carefully use a  $\frac{9}{16}$  inch (15mm) wrench to remove the NPT end of the data logger
4. Once the NPT end is completely unscrewed, gently slide the circuit board assembly out of the enclosure. Care must be taken to prevent breaking or sharply bending cable between the sensor and circuit board. Note: If white Teflon washer comes out with the electronics, it must be reinstalled after battery replacement.
5. The battery is the purple cylinder on the circuit board. Note the orientation of the battery on the board. Gently pull the old battery out of the circuit board battery sockets.
6. Install the new battery, observing the polarity, one lead at a time, pressing firmly with your index finger to make the lead secure in its terminal. Small pliers may be used to fully seat the leads into the sockets. Note: The battery should lay flat against the circuit board, and the positive lead should be closest to the communications jack.
7. Install white Teflon washer (if removed during disassembly), at the end of the electronics (around communications jack).
8. Insert the electronics back into the tube. Make sure the cable is not twisted, sharply bent or kinked. From the connection to the circuit board, it should run up towards the battery, then down to the sensor.
9. Carefully screw the NPT end cap back onto the enclosure, making sure the electronics rotate with the end cap.

### Recalibration

Recalibration is recommended annually for any Omega data logger; a reminder is automatically displayed in the software when the device is due.

## OM-CP-PRTEMP1000IS-A2 General Specifications

Temperature Sensor	Internal semiconductor
Temperature Range	-40 °C to +80 °C (-40 °F to +176 °F)
Temperature Resolution	0.1 °C (0.18 °F)
Calibrated Accuracy	±0.5 °C (±0.9 °F)
Pressure Range	*See table for details
Pressure Resolution	
Pressure Accuracy	
Memory	16,383/channel
Reading Rate	1 reading every 2 seconds up to 1 reading every 12 hours
Data Format	Date and time stamped °C, °F, K, °R ; PSIA(G), inches, feet, mmHg, bar, Torr, kPa
Required Interface Package	OM-CP-IFC200 (required, sold separately)
Baud Rate	2,400
Typical Battery Life	1 year typical
Operating Environment	-40 °C to +80 °C (-40 °F to +176 °F), 0 %RH to 100 %RH
Material	303 Stainless Steel
Dimensions	6.4 in x 1.25 in dia. (163 mm x 32 mm dia.)
Weight	12 oz (340 g)
Approvals	CE; Certified Intrinsically Safe in accordance with the latest issue of FM3600 and FM3610. <ul style="list-style-type: none"> <li>• Class 1, Division 1 Group ABCD</li> <li>• Class 1, Division 2, Group ABCD</li> <li>• Temperature Class: T4A</li> </ul>

### \*OM-CP-PRTEMP1000IS-A2 Range, Accuracy and Resolution

Range	0-30 PSIA/G	0-100 PSIA/G	0-300 PSIA/G	0-500 PSIA/G	0-1000 PSIA	0-5000 PSIA
Accuracy	2 % FSR, 0.25 % @ 25 °C typical					
Resolution	0.002 PSIA/G	0.005 PSIA/G	0.02 PSIA/G	0.05 PSIA/G	0.05 PSIA	0.2 PSIA

### Battery Warning

**WARNING: FIRE, EXPLOSION, AND SEVERE BURN HAZARD. DO NOT SHORT CIRCUIT, CHARGE, FORCE OVER DISCHARGE, CRUSH, PENETRATE OR INCINERATE. BATTERY MAY LEAK OR EXPLODE IF HEATED ABOVE 150°C (302°F).**

*Specifications subject to change.  
See Omega's terms and conditions at [www.omega.com](http://www.omega.com)*

**WARNING – POTENTIAL ELECTROSTATIC CHARGING HAZARD. CONTROL OF ENVIRONMENTAL HUMIDITY TO MINIMIZE THE GENERATION OF STATIC ELECTRICITY OR TOUCH WITH AN INSULATING OBJECT BEFORE USE**



omega.com info@omega.com

### Servicing North America:

#### U.S.A. Headquarters:

Omega Engineering, Inc.  
Toll-Free: 1-800-826-6342 (USA & Canada only)  
Customer Service: 1-800-622-2378 (USA & Canada only)  
Engineering Service: 1-800-872-9436 (USA & Canada only)  
Tel: (203) 359-1660 Fax: (203) 359-7700  
e-mail: info@omega.com

### For Other Locations Visit [omega.com/worldwide](http://omega.com/worldwide)

The information contained in this document is believed to be correct, but OMEGA accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

### WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **13 months** from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal **one (1) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product. If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components in which wear is not warranted, include but are not limited to contact points, fuses, and triacs.

**OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by the company will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.**

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

### RETURN REQUESTS / INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of the product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering. OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 2016 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.