# **PUMP ACCESSORIES**

Anti-Siphon Injection Valve

Designed to prevent the liquid being pumped from siphoning through the pumphead during both the On and Off cycles, and to keep the liquid in the system from flowing backward through lines and fittings.

Ordering Example: FPURV1, anti-siphon injection valve.

Model No.	Tube Size OD	O-Ring
FPURV1	1/4"	EP
FPURV2	1/4"	AFLAS
FPURV3	3/8"	EP
FPURV4	3/8"	AFLAS



In-Line Check Valve

In-line check valves are installed on the discharge side of the line and prevent the liquid being pumped from flowing backward. Constructed of durable polypropy-lene, with AFLAS® FKM O-rings.

		Tube Size OD	O-Ring	
	FPUCV1	3/8"	AFLAS	

### Pressure Relief Valve

In the event of excessive line pressure, this adjustable valve automatically opens, protecting your pump from damage from excessive pressure. An added feature is the priming valve, which eliminates problems caused by line pressure.

Model No.	Tube Size OD	O-Ring
FPRV1	1/4"	EPDM
FPRV2	1/4"	FKM
FPRV3	3/8"	EPDM
FPRV4	3/8"	FKM



## **Feed Indicator**

Verify solution feeding at a glance, no matter how cloudy or discolored the tubing becomes. The rhythmic rising and falling of the float indicates the positive flow, while the appearance of air bubbles indicates solution may be depleted. The indicator is an excellent troubleshooting and diagnostic tool. Available individually or in packages of 12.

Individual,	12-Packs	Tube Size	
Model No.	Model No.	OD	Float
FPUSG1	FPUSGK1	3/8"	Glass
FPUSG2	FPUSGK2	1/4"	Glass
FPUSG3	FPUSGK3	3/8"	316SS
FPUSG4	_	1/4"	316SS

#### **Foot Valve Strainers**

Foot valve strainer bodies are constructed of molded polypropylene with polypropylene screens. The screens act as filters (strainers) to keep particles from entering the suction line and fouling the pumphead. They can be used either as a foot valve or as a bulkhead fitting. Strainers have a barbed fitting so one size will fit all tube sizes.

Bulkhead Model No.	Tube Size OD	O-Ring	Barbed Model No.
FPUSV-E	1/4"	EP	FPUBV-E
FPUSV-V	1/4"	AFLAS	FPUBV-V
FPUSV5*	5/8"		FPUBV5

Fits FPUDT3000 Series pumps.

