

# Shop online at

Omega.com· \_\_\_\_\_CEOMEGA·\_\_\_\_\_ www.omega.com

e-mail: info@omega.com

STAMFORD, CT MARCHESTER, UK
-----------------------------



HHT41 Portable Stroboscope



omega.com

It is the policy of OMEGA to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification. The information contained in this document is believed to be correct, but OMEGA Engineering, Inc. accepts no liability for any errors it contains, and reserves the right to alter specifications without notice. WARNING: These products are not designed for use in, and should not be used for, patient-connected applications.

# TABLE OF CONTENTS


1.0	SPECIFICATIONS1			
2.0		RVIEW		
	2.1	Display Panel	. 3	
3.0	PREPARATION FOR USE			
	3.1	Power	. 3	
	3.2	Input / Output Connections	. 3	
4.0	OPERATION			
	4.1	Internal Mode - Standard Strobe Operation	. 4	
	4.2	External Mode - External Input Required	. 5	
	4.3	Tach Mode - External Input Required	. 5	
5.0	USING THE STROBOSCOPE TO MEASURE RPM6			
6.0	LAMP REPLACEMENT			
7.0	BATTERY PACK			
	7.1	Low Battery Indication	. 8	
	7.2	Charging the Battery Pack	. 9	
	7.3	Battery Disposal	. 9	



- 1. Read and follow all instructions in this manual carefully, and retain this manual for future reference.
- 2. Do not use this instrument in any manner inconsistent with these operating instructions or under any conditions that exceed the environmental specifications stated.
- 3. Use of this product may induce an epileptic seizure in persons prone to this type of attack.
- 4. Objects viewed with this product may appear to be stationary when in fact they are moving at high speeds. Always keep a safe distance from moving machinery and do no touch the target.
- 5. There are lethal voltages present inside this product. Refer to the section on Lamp Replacement before attempting to open this product.
- 6. Do not allow liquids or metallic objects to enter the ventilation holes on the stroboscope as this may cause permanent damage and void the warranty.
- 7. This product contains a sealed lead acid battery which must be disposed of in accordance with Federal, State and Local Regulations. Do not incinerate. Batteries should be shipped to a reclamation facility for recovery of the metal and plastic components as the proper method of waste management. Refer to section 7.3 of this manual, and contact your distributor for appropriate product return procedures.
- 8. This instrument is not user serviceable. For technical assistance, contact the sales organization from which you purchased the product.

# **1.0 SPECIFICATIONS**

Internal Mode: Flash Range		100 - 12,500 FPM (Flashes per Minute)	
Flash Rate Accura	•	The greater of $\pm 0.5$ FPM or $\pm 0.01\%$ of reading	
Flash Rate Resolu	· •	0.1 FPM	
Display Update F	Rate	Continuous	
External Mode:			
Flash Range and I	Display	5.0 to 12,500 FPM - External flash rates to 0 are acceptable	
FPM Accuracy		The greater of $\pm 0.1$ FPM or $\pm 0.01\%$ of reading	
Display Update F	Rate	1 second typical	
Trigger to Flash D	Delay	< 5 µsec	
External Input		0 to 5 volt TTL Compatible (12V pk max)	
-		20 µsec min pulse width, Positive edge triggered	
Tachometer Mod	اه٠		
Tachometer Meas		5 to 250,000 RPM	
Tachometer Accur		The greater of $\pm 0.1$ FPM or $\pm 0.01\%$ of reading	
Display Update R	•	1 second typical	
External Input	Cute	0 to 5 volt TTL Compatible (12V pk max)	
External input		5 µsec min pulse width, Positive edge triggered	
	~ ~		
Time Base	Stable Crysta		
		numeric backlit LCD display with 0.3 inch [7.62 mm] high digits	
Indicators	Low Battery, On Target Indicator, Locked On, External Mode, Tachometer		
A	Mode, $\div 2 \times 2$		
Adjustment	•	nt Pressure Sensitive Tuner Button with decade select for flash rate	
Memory		multiply by 2 and divide by 2	
MemorySaves eight programmable flash rates and last flash rate at power downOutput Pulse350 μsec positive pulse, 5 Vdc typical			
Power		Vdc Rechargeable Battery Pack with Integral Electronics Charge	
10000		echargers (PR115, PR230 or PR Universal Recharger: 9 Vdc @	
	300mA)		
		a, 7 watts equivalent power, Output = 1100 LUX	
0		oseconds typical	
		l at 1800 FPM with fully charged batteries	
Weight	~ .	kg] including Battery Pack	
-	-		
		9.34 [237.34mm]	






1

## 2.0 OVERVIEW

The **HHT41** is a sophisticated stroboscope with many features, yet remains simple to operate. It is a pocket-size, lightweight, industrial strength, single-handed operation instrument that fits in the palm of your hand. A four Quadrant Pressure Sensitive Tuner Button adjusts the flash rate, and provides multiply or divide by 2 functions. A large, bright, backlit, 6-digit alphanumeric LCD display shows the flash rate and mode of operation. The Strobe can store and recall eight programmable flash rate settings and the last used setting in non-volatile memory, so that the unit "remembers" all the flash rates when the power is turned off. The pulse output phone jack connector will accept an external input up to the maximum FPM. The Tachometer mode will measure rotational speed up to 250,000 RPM with an optional Self-Powered Sensor.

The Strobe has a removable, rechargeable Battery Pack which provides up to 1 hour of continuous use depending on the flash rate. This Battery Pack clips in and out with no tools required. An optional second Battery Pack allows for longer operation in the field. A ¼-20 UNC thread bushing on the underside of the Strobe allows for tripod mounting. The Strobe can be locked "ON" for hands free operation.



Multiple features of HHT41 are patent pending.

2

### 2.1 Display Panel




Figure 3 Display Panel

The display panel consists of a backlit, liquid crystal display with six alphanumeric digits which indicate modes, flash rates, etc. (see Figure 3).

Other icons or messages in the display indicate the following:

Ċ	Displayed when the battery is getting low. There is protection circuitry in the
	unit that will prevent the battery from being over discharged or prevent the unit
	from being operated with a low battery.
۲	On Target Indicator for Tachometer Mode and Remote Sensor in External Mode
<b>0</b>	Shown on the display when the Strobe is locked on.
EXT	Shown on the display when the Strobe is in the External Mode.
TACH	Shown on the display when the Strobe is in the Tachometer Mode.
÷2 ×2	When this icon is shown on the display, rocking the tuning button to the left
	will divide the current flash rate by two and rocking the tuning button to the
	right will multiply the current flash rate by two.

# 3.0 PREPARATION FOR USE


HHT41 may be hand held or mounted on a tripod or other user supplied bracket using the ¼-20 UNC bushing in the base of the unit.


#### 3.1 Power

**HHT41** has a removable lead acid Battery Pack that clips in and out of the main strobe housing. The Battery Pack should be charged before use (see section 7.0). **HHT41** will operate continuously in excess of 55 minutes at 1800 flashes per minute from fully charged batteries. The Strobe has a protection feature that prevents the Strobe from operating if the battery voltage is low. This condition is indicated by no flash and the Low Battery icon ( ) will be displayed (see section 7.1). At this time the Battery Pack must be recharged or a fully charged Battery Pack can be plugged in as a substitute. The actual operating time of the stroboscope depends on the flash rate and duty cycle of operation. Slower flash rates increase the operating time.

#### 3.2 Input / Output Connections

**HHT41** has an input / output jack on the side of the stroboscope. This jack accepts a 1/8 inch (3.5 mm) stereo phone plug and can be used for external triggering or synchronization of the stroboscope or for providing a pulse output, synchronous with the flash. The jack's outer





With no external input the Strobe provides a TTL compatible pulse output

Figure 4 Input/Output Connector Detail

from the Strobe's internal oscillator. If an external input is applied, the output pulse mimics the input pulse.

# 4.0 OPERATION

To turn on the stroboscope, press and release the On/Off ( $\bigcirc$ ) button. To lock the power on, press and hold the On/Off ( $\bigcirc$ ) button until the Locked icon ( $\bigcirc$ ) is displayed (about 2 seconds) and then release the button. Press and release the On/Off ( $\bigcirc$ ) button again to turn the Strobe off.

When the Strobe is powered up, it will begin flashing immediately at the last internal flash rate displayed. The last digit changed will flash for 5 seconds allowing the digit to be changed again. Rock the tuning button up or down to change the flashing digit. Rock the tuning button left or right to select a different digit to change.

The flash rate is displayed on the LCD display in flashes per minute, which typically is the same as RPM.

The **HHT41** has three primary operating modes (Internal, External and Tach) and three functions ( $\div 2$  ×2, Recall and Store) that are adjusted by the MODE button. By default, the Strobe powers up in the Internal Mode. Pressing the MODE button will change the mode/function in the following order:  $\div 2$  ×2, Recall, Store, External, Tach, Internal. The  $\div 2$  ×2, Recall and Store functions are only applicable to the Internal Mode.

In the **Internal Mode**, the tuner button adjusts the flash rate from the minimum to the maximum number of Flashes Per Minute (FPM or RPM). In the **External Mode**, an external signal from another strobe or a remote self-powered sensor is used to trigger the flash and the tuner button has no effect. In the **Tach Mode** the unit will not flash, but will display the input from an external (self-powered) sensor as RPM up to 250,000 RPM.

#### 4.1 Internal Mode - Standard Strobe Operation

In the **Internal Mode** the stroboscope generates it's own frequency variable speed signals and functions like a typical stroboscope. This is the default start up mode.

The rubber tuning button functions as a multi dimensional joystick. The tuning button is sensitive in four linear xy quadrants, and also senses pressure in the z-plane. Place your thumb on the button and use a rocking motion (forward, back, or side-to-side) to control it (see Figure 5). The harder you apply pressure, the faster the rate of increase. It is possible to adjust the Strobe in 0.1 FPM increments with very slight finger pressure.




Figure 5 Tuning button

4

To change the flash rate:

- 1. Press the tuning button. The last digit changed will begin blinking.
- 2. Rock the tuning button to the left or right to select which digit to change. The digit blinking is the one to be changed.
- 3. Rock the tuning button up or down to increase or decrease the value of the blinking digit. The digit will stop blinking after 5 blinks and the Strobe will continue to flash at the new flash rate.

To multiply or divide the current flash rate by 2:

- 1. Press the MODE button once. The +2 ×2 icon will be displayed.
- Rock the tuning button to the left for ÷2 or right for ×2. (Rocking the tuning button up or down while in the ÷2 ×2 Mode will have no effect.)
- 3. Repeat steps 1 and 2 each time you want to multiply or divide the flash rate.
  - **NOTE:** If a multiply or divide operation will exceed the limits of the unit, upper limit or lower limit, the display will indicate **OVER** or **UNDER** and no change will be made to the flash rate.

To select a flash rate from a Preset (memory) location:

- 1. Press the MODE button once. The ÷2 ×2 icon will be displayed.
- Press the MODE button again (without pressing the rubber tuning button in between). "RECALL" will be displayed.
- 3. Rock the tuning button up or down to select a preset flash rate. The display will show "R MEMX", where X=the present location (1-8), and then display the flash rate saved in that location and begin flashing at the specified flash rate with each press of the button.
- 4. Press the MODE button to return to the Internal Mode using the selected flash rate.

To store the current flash rate in a Preset (memory) location:

- 1. Press the MODE button once. The +2 ×2 icon will be displayed.
- 2. Press the MODE button a second time (without pressing the rubber tuning button in between). "RECALL" will be displayed.
- Press the MODE button again (without pressing the rubber tuning button in between). "STORE" will be displayed.
- 4. Rock the tuning button up or down to select the location in which to store the current flash rate. The display will show "S MEMX", where X=the present location (1-8), and then display the flash rate saved in that location.
- Once you have selected a preset location to overwrite, press the MODE button to save the current flash rate in that location. "SAVING" will be displayed and then you will return to the Internal Mode.

### 4.2 External Mode - External Input Required

Press the MODE button (without pressing the tuning button in between) until the **EXT** icon is displayed. An external input is required (TTL compatible source from a self-powered sensor).

In the External Mode there are no flash rate adjustments the user can make. The flash rate is triggered by the input signal. This mode is used to synchronize the flash to an external event (for example, from an optical sensor) to stop or freeze motion for timing studies or balancing machines. The flash will be triggered on the rising edge of the external input pulse.

The maximum input is 12,500 FPM, above which the Strobe will no longer flash.

#### 4.3 Tach Mode – External Input Required


Press the MODE button (without pressing the tuning button in between) until the **TACH** icon is displayed. In the **Tachometer Mode** the unit will read the signal from the external input (self-powered sensor) and display the reading on the LCD display, without flashing the lamp. The Strobe can read up to 250,000 RPM in this mode.

# 5.0 USING THE STROBOSCOPE TO MEASURE RPM

The primary use for a stroboscope is to stop motion for diagnostic inspection purposes. However, the stroboscope can also be used to measure speed. In order to do this, several factors need to be considered. First, the object being measured should be visible for all 360° of rotation (e.g. the end of a shaft). Second, the object should have some unique part on it, like a bolt, key way or imperfection to use as a reference point. If the object being viewed is perfectly symmetrical, then the user needs to mark the object with a piece of tape or paint in a single location, while the object is stationary, to be used as a reference point.

If the speed of rotation is within the range of the stroboscope, start at the highest flash rate and adjust the flash rate down. At some point you will stop the motion with only a single image of the object in view. Note that at a flash rate twice the actual speed of the image you will see two images. As you approach the correct speed you may see three, four or more images at harmonics of the actual speed. The first SINGLE image you see is the true speed. To confirm the true speed, note the reading and adjust the stroboscope to exactly half this reading, or just press the left of the joystick button for the  $\div 2$  function. You should again see a single image (which may be phase shifted with respect to the first image seen).

For example, when viewing a shaft with a single key way, you will see one stationary image of the key way at the actual speed and at 1/2, 1/3, 1/4, etc, of the actual speed. You will see 2 images of the key way at 2 times the actual speed, 3 key way images at 3 times, etc. (see Figure 6). The Flash Per Minute (FPM) equals the shaft's Revolutions Per Minute (RPM) at the highest flash rate that gives only one stationary image of the key way.



#### Figure 6 Object Rotating at 3000 RPM

If the speed is outside the full scale range of the stroboscope (12,500 FPM), it can be measured using the method of harmonics and multipoint calculation. Start at the highest flash rate and adjust the flash rate down. Be aware that you will encounter multiple images. Note the flash rate of the first SINGLE image you encounter, and call this speed "A". Continue decreasing the flash rate until you encounter a second SINGLE image, and note this speed as "B". Continue decreasing the speed until you reach a third SINGLE image at speed "C".

For a two point calculation the actual speed is given by: RPM = AB/(A-B)

For a three point calculation:  $RPM = 2XY(X+Y)/(X-Y)^2$  where X = (A-B) and Y = (B-C)

If a Self-Powered Sensor is used to sense one pulse per revolution (External mode), the readout will display directly in RPM (FPM) without any adjustment required.

In instances when you can shut down the device and install a piece of reflective tape, then an optical tachometer is easier to use for RPM measurement. You can use the **HHT41** with an external sensor as an optical tachometer. Stroboscopes need only be used as a tachometer when you can't shut down the device. The human eye is not easily tricked into seeing a stopped image by a stroboscope when the flash rate is slower than 300 FPM. Therefore, a stroboscope image is difficult to use below 300 FPM for inspection or to measure RPM.



## 6.0 LAMP REPLACEMENT

# WARNING: Before attempting to remove the lamp, make sure the stroboscope is turned off and remove the Battery Pack (see section 7.0). Allow the lamp to cool, waiting at least 1 minute.

The stroboscope is designed to discharge the internal high voltages within 30 seconds. However, caution should be exercised when replacing the lamp.

To change the lamp it is necessary only to remove the front lens, which is held in place by the rubber bumper. Pry the rubber bumper off the end of the unit. The reflector is held in place by the front lens and will come loose, but is not necessary to remove the reflector. Hold the lamp with a cloth between your forefinger and thumb and rock it back and forth gently while pulling out. Do not attempt to rotate the lamp. The lamp is socketed and will come out easily when pulled.

## WARNING: Do NOT touch the new lamp with bare fingers.

The lamps are polarized and must be put into the socket matching polarity. Using a lint free cloth to hold the lamp, match up the red dot on the plug with the red dot on the socket and gently rock the lamp back and forth while pushing it into place (see Figure 7). Make sure the lamp is in straight and centered in the reflector hole.





Figure 7 Lamp Replacement

Reinstall the reflector and then position the front lens in place matching up the notches on the lens with the two small tabs on the housing to prevent lens rotation (see Figure 7). Stretch the rubber bumper over the top and bottom case halves to seal in the reflector and front lens.

# 7.0 BATTERY PACK

The Battery Pack can be removed by pressing the two latches on either side of the unit while gently pulling the Battery Pack outwards (see Figure 8). To install the Battery Pack, slide it into the Strobe until you hear the side latches engage and lock. Match the top and bottom colors when inserting the Battery Pack into the Strobe. The Battery Pack is keyed so that it can not be inserted into the Strobe upside down.

CAUTION: The terminals on the Battery Pack are recessed. DO NOT SHORT THESE CONNECTIONS. There is a non-serviceable internal resettable fuse for protection.



#### Figure 8 Battery Pack Removal / Installation

#### 7.1 Low Battery Indication

When the batteries are low, the Low Battery icon  $(\frown)$  is displayed. The Strobe may still be used for a short time. When the battery charge is further depleted, the Strobe will stop flashing, the Low Battery icon (  $\frown$  ) will be displayed, and then the Strobe will completely shut off. When the Low Battery icon (  $\frown$  ) is displayed, the Battery Pack needs to be recharged (see section 7.2).

NOTE: If the batteries are discharged you will not be able to run the unit. The unit may not start at all, or the Low Battery icon ( () may be displayed and then the Strobe will shut off. Recharge the Battery Pack or replace it with a fully charged unit.



#### 7.2 Charging the Battery Pack

The Battery Pack may be recharged at any time. You do not need to wait until the low battery condition is indicated. The Battery Pack does not need to be in the Strobe for charging.

To charge the Battery Pack:

- 1. Make sure the Strobe is off or remove the Battery Pack from the Strobe.
- 2. Plug the recharger cable into the battery recharger socket on the Battery Pack (see Figure 2 for location).
- 3. Plug the recharger into an AC mains wall outlet.
- NOTE: When using the HHT41-URC recharger, make sure the correct adapter plug is inserted into the recharger before plugging the recharger into the wall outlet.
- CAUTION: Use of rechargers other than the one supplied (HHT41-115RC, HHT41-230RC or HHT41-URC) may damage the stroboscope and void the warranty.

The battery module contains circuitry to control the charge. The **red** LED comes on to indicate that the battery is being charged. Once the charge is completed, the LED turns **amber** and the recharger will trickle charge the battery. The Battery Pack may be used at this point.

**NOTE:** The total charge time is typically 6 to 8 hours. The Battery Pack may be left on trickle charge indefinitely.

#### 7.3 Battery Disposal

Prior to disposing of the Battery Pack, the user must remove the sealed lead acid battery. To do this, remove the four screws on the under side of the Battery Pack and separate the case halves, exposing the battery. Remove the cables from the battery and place tape over the battery terminals to prevent them from shorting. The battery should be sent to a recycling center or returned to the factory. The rest of the parts may now be disposed of.



WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **13 months** from date of purchase. OMEGA's Warranty adds an additional one (1) month grace period to the normal **one** (1) year product warranty to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components which wear are not warranted, including but not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by it will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESS OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract. warranty. negligence. indemnification. strict liability or otherwise, shall OMEGA is pleased to offer suggestions on the use of its various products. However, based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

# RETURN REQUESTS/INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR WARRANTY RETURNS, please have the following information available BEFORE contacting OMEGA:

- 1. Purchase Order number under which the product was PURCHASED,
- 2. Model and serial number of the product under warranty, and
- 3. Repair instructions and/or specific problems relative to the product.

FOR NON-WARRANTY REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

- 1. Purchase Order number to cover the COST of the repair,
- 2. Model and serial number of the product, and
- 3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 203 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.

# Where Do I Find Everything I Need for Process Measurement and Control? OMEGA...Of Course!

# Shop online at www.omega.com

# **TEMPERATURE**

- Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- Wire: Thermocouple, RTD & Thermistor
- Calibrators & Ice Point References
- Recorders, Controllers & Process Monitors
- Infrared Pyrometers

# **PRESSURE, STRAIN AND FORCE**

- 🖬 Transducers & Strain Gages
- Load Cells & Pressure Gages
- Displacement Transducers
- Instrumentation & Accessories

#### FLOW/LEVEL

- & Rotameters, Gas Mass Flowmeters & Flow Computers
- Air Velocity Indicators
- Turbine/Paddlewheel Systems
- 🗹 Totalizers & Batch Controllers

# pH/CONDUCTIVITY

- pH Electrodes, Testers & Accessories
- Benchtop/Laboratory Meters
- Controllers, Calibrators, Simulators & Pumps
- Industrial pH & Conductivity Equipment

## DATA ACQUISITION

- Data Acquisition & Engineering Software
- Communications-Based Acquisition Systems
- Plug-in Cards for Apple, IBM & Compatibles
- Datalogging Systems
- Recorders, Printers & Plotters

#### HEATERS

- Heating Cable
- Cartridge & Strip Heaters
- Immersion & Band Heaters
- Flexible Heaters
- Laboratory Heaters

#### ENVIRONMENTAL MONITORING AND CONTROL

- Metering & Control Instrumentation
- Refractometers
- Pumps & Tubing
- Air, Soil & Water Monitors
- Industrial Water & Wastewater Treatment
- PH, Conductivity & Dissolved Oxygen Instruments

M3855/0103